


















Dell UltraSharp 52 Thunderbolt Hub Monitor
U5226KW/U5226KW WOST
Schnellstartanleitung





































Dell Display and Peripheral Manager:
[Dell.com/support/ddpm](https://dell.com/support/ddpm)



KVM



[Dell.com/support/U5226KW](https://dell.com/support/U5226KW)