



EN User manual دليل المستخدم AR  
FR Mode d'emploi راهنمای کاربر FA

**PHILIPS**



Specifications are subject to change without notice  
© 2015 Koninklijke Philips N.V.  
All rights reserved.

3140 035 31234

## English

### 1 Important

Read this user manual carefully before you use the appliance, and save the user manual for future reference.

#### Danger

- Do not immerse the motor unit in water nor rinse it under the tap.

#### Warning

- Never use your fingers or an object to push ingredients into the feeding tube while the appliance is running. Only use the pusher.
- Before you connect the appliance to the power, make sure that the voltage indicated on the bottom of the appliance corresponds to the local power voltage.
- Never connect this appliance to a timer switch, to avoid a hazardous situation.
- Do not use the appliance if the power cord, the plug, protecting cover, rotating sieve or any other parts are damaged or has visible cracks.
- If the power cord is damaged, you must have it replaced by Philips, a service center authorized by Philips, or similarly qualified persons to avoid a hazard.
- This appliance shall not be used by children. Keep the appliance and its cord out of reach of children.
- This appliance can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- For their safety, do not allow children to play with the appliance.
- Never let the appliance run unattended.
- If food sticks to the wall of the blender jar or bowl, switch off the appliance and unplug it. Then use a spatula to remove the food from the wall.
- Be careful when you are emptying the bowl, handle or clean the discs, the blade units and the juicer sieve. The cutting edges are very sharp.
- Do not touch the blades, especially when the appliance is plugged in. The blades are very sharp.
- If the blades get stuck, unplug the appliance before you remove the ingredients that block the blades.
- Be careful if hot liquid is poured into the food processor or blender as it can be ejected out of the appliance due to a sudden steaming.
- This appliance is intended for household use only.


**Caution**

- Never switch off the appliance by turning the blender jar, the bowl, or their lids. Always switch off the appliance by turning the speed selector to 0 or OFF.
- Unplug the appliance immediately after use.
- Always wait until the moving parts stop running, then switch off and unplug the appliance before opening the lid and reaching into any of the parts that move in use.


### 1

		( MAX)	(kg MAX)	()
		5 x 1 sec	750 g	P
		5 x 1 sec	1 kg	P/2
		30 sec	100 g	P
		60 sec	1 kg	2
		45 sec	500 g	2
		30 sec	400 g	2
		60-180 sec	750 g	1-2
		2 min	1 kg	1
		60-180 sec	600 ml	1
		60-300 sec	750 ml	1
		60-180 sec	8 pcs	1
		30 sec	1 kg	1
		30 sec	1 kg	1
		30 sec	750 g	1
		30 sec	3 pcs	1
		30 sec	1 kg	1
		30 sec	200 g	1
		30 sec	3 pcs	1
		30 sec	1 kg	1
		2 min	1 kg	1
		20 sec	500 g	1


### 2




### 3




### 4




### 5




### 6



### 7




### 8




### 9

✓	✓	✗				✓	✓	✓	✓
✓	✓	✓	✓	✓	✓	✓	✓	✓	✗


### 10



### 11



### 12



- Always switch off and unplug the appliance if it is left unattended, and before assembling, disassembling, cleaning and changing accessories, or approaching parts that move in use.

- Thoroughly clean the parts that come into contact with food before you use the appliance for the first time. Refer to the instructions and table for cleaning given in this manual.

- Never use any accessories or parts from other manufacturers that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

- Do not exceed the maximum level indication on the bowl or the jar. Follow the quantities, processing time and speed as indicated in the user manual.

- Let hot ingredients cool down (< 80°C) before processing them.

- Always let the appliance cool down to room temperature after each batch that you process.

- Certain ingredients such as carrots may cause discolorations on the surface of the parts. This does not have a negative effect on the parts. The discolorations usually disappear after some time.

#### Noise level: Lc = 85 dB [A]

#### Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

#### Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

For their safety, do not allow children to play with the appliance.

Never let the appliance run unattended.

If food sticks to the wall of the blender jar or bowl, switch off the appliance and unplug it. Then use a spatula to remove the food from the wall.

Be careful when you are emptying the bowl, handle or clean the discs, the blade units and the juicer sieve. The cutting edges are very sharp.

Do not touch the blades, especially when the appliance is plugged in. The blades are very sharp.

If the blades get stuck, unplug the appliance before you remove the ingredients that block the blades.

Be careful if hot liquid is poured into the food processor or blender as it can be ejected out of the appliance due to a sudden steaming.

This appliance is intended for household use only.

**Caution**

• Never use your fingers or an object (for example, a spatula) to push ingredients into the feeding tube while the appliance is running. Only use the pusher.

#### Note

• Do not let the appliance run too long when you chop (hard) cheese or chocolate. Otherwise these ingredients become too hot, start to melt, and turn lumpy.

• Pre-cut large pieces of food into pieces of approx. 3 x 3 x 3 cm.

#### Chopper knife

Before you start, make sure you assemble according to Fig. 2.

You can use the chopper knife to chop, mix, blend, or puree ingredients. You can also use it to mix and blend cake batters.

#### Warning

• Do not use the chopper knife to chop hard ingredients, like coffee beans, turmeric, nutmeg, and ice cubes, as this may cause the blade to get blunt.

#### Note

• Do not let the appliance run too long when you chop (hard) cheese or chocolate. Otherwise these ingredients become too hot, start to melt, and turn lumpy.

• Pre-cut large pieces of food into pieces of approx. 3 x 3 x 3 cm.

#### Citrus press

Before you start, make sure you assemble according to Fig. 6.

You can use the citrus press to squeeze citrus fruits.

- Turn the bowl clockwise to fix it on the motor unit, and then put the tool holder in the bowl.

→ When the bowl is fixed correctly, you hear a click.

- Put the chopper knife on the tool holder.

→ When the lid is assembled correctly, you hear a click and the lid is fixed to the bowl handle.

- Put the ingredients in the bowl.

→ When the lid is assembled correctly, you hear a click and the lid is fixed to the bowl handle.

- Turn the lid clockwise to fix it.

→ When the lid is assembled correctly, you hear a click and the lid is fixed to the bowl handle.

- Put the pusher into the feeding tube.

→ Connect the power plug to the power supply.

- Check the preparation time, the maximum amount and the speed setting required for the ingredients in Table 1. Turn the knob to the desired speed setting.

8 After use, turn the knob to 0, and then unplug the appliance.

#### Tip

- When you chop onions, turn the knob to P a few times to prevent the onions from becoming too finely chopped.

- When the food sticks to the blade or inside the bowl, you can do the following steps: 1. Switch off the appliance, and then unplug it. 2. Remove the lid from the bowl. 3. Remove the ingredients from the blade or from the side of the bowl with a spatula.

#### Serrated blade

Before you start, make sure you assemble according to Fig. 3.

You can use the serrated blade to crush frozen fruit.

#### Note

- Always put the blade unit in the bowl before you start.

- It is recommended to cut the fruit into 2x2x2cm cube size before having it frozen.

- For making fruit desserts, it is recommended to use speed 2 for smooth result, and speed 1 for chunky result.

- Turn the bowl clockwise to fix it on the motor unit, and then put the tool holder in the bowl.

→ When the bowl is fixed correctly, you hear a click.

- Put the serrated ice blade on the tool holder.

→ When the lid is assembled correctly, you hear a click and the lid is fixed to the bowl handle.

- Put the lid on the bowl, and then turn the lid clockwise to fix it.

→ When the lid is assembled correctly, you hear a click and the lid is fixed to the bowl handle.

- Put the pusher into the feeding tube.

→ Connect the power plug to the power supply.

- Turn the knob to 1 or 2.

8 After use, turn the speed selector to 0, and then unplug the appliance.

#### Tip

- If using High Gluten Flour, for

