



# User's Guide

---

---

NPD4736-00 EN

---

## **Copyright and Trademarks**

# **Copyright and Trademarks**

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information herein. The information contained herein is designed only for use with this Epson product. Epson is not responsible for any use of this information as applied to other products.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation and its affiliates shall not be liable for any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

Seiko Epson Corporation shall not be held liable for any damage resulting from electromagnetic interference that occurs from the use of any interface cables other than those designated as Epson Approved Products by Seiko Epson Corporation.

EPSON® is a registered trademark, and EPSON EXCEED YOUR VISION or EXCEED YOUR VISION is a trademark of Seiko Epson Corporation.

Intel® is a registered trademark of Intel Corporation.

PowerPC® is a registered trademark of International Business Machines Corporation.

Epson Scan software is based in part on the work of the Independent JPEG Group.

libtiff

Copyright © 1988-1997 Sam Leffler  
Copyright © 1991-1997 Silicon Graphics, Inc.

Permission to use, copy, modify, distribute, and sell this software and its documentation for any purpose is hereby granted without fee, provided that (i) the above copyright notices and this permission notice appear in all copies of the software and related documentation, and (ii) the names of Sam Leffler and Silicon Graphics may not be used in any advertising or publicity relating to the software without the specific, prior written permission of Sam Leffler and Silicon Graphics.

THE SOFTWARE IS PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR OTHERWISE, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

## Copyright and Trademarks

IN NO EVENT SHALL SAM LEFFLER OR SILICON GRAPHICS BE LIABLE FOR ANY SPECIAL, INCIDENTAL, INDIRECT OR CONSEQUENTIAL DAMAGES OF ANY KIND, OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER OR NOT ADVISED OF THE POSSIBILITY OF DAMAGE, AND ON ANY THEORY OF LIABILITY, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

Microsoft®, Windows®, and Windows Vista® are registered trademarks of Microsoft Corporation.

Apple®, Macintosh®, Mac OS®, and OS X® are registered trademarks of Apple Inc.

ABBYY® and ABBYY FineReader® names and logos are registered trademarks of ABBYY Software House.

Adobe, Adobe Reader, Acrobat, and Photoshop are trademarks of Adobe systems Incorporated, which may be registered in certain jurisdictions.

*General Notice: Other product names used herein are for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.*

Copyright © 2012 Seiko Epson Corporation. All rights reserved.

## Contents

### Copyright and Trademarks

Copyright and Trademarks. . . . . 2

### Introduction

Where to Find Information. . . . . 7

Caution, Important and Note. . . . . 7

Operating System Versions. . . . . 7

### Important Instructions

Safety Instructions. . . . . 9

Product Advisories and Warnings. . . . . 9

    Setting up/using the product. . . . . 9

    Using the product with a wireless connection  
    . . . . . 11

    Using the LCD screen. . . . . 11

    Handling ink. . . . . 11

Restrictions on Copying. . . . . 11

### Getting to Know Your Product

Product Parts. . . . . 13

Guide to the Control Panel. . . . . 15

    Buttons and LCD. . . . . 15

    Lights. . . . . 16

### Paper and Media Handling

Introduction to Using, Loading, and Storing  
Media. . . . . 17

    Storing paper. . . . . 17

Selecting Paper. . . . . 17

    Paper type settings on the LCD screen. . . . . 18

    Paper type settings from the printer driver. . . . . 18

Loading Paper and Envelopes. . . . . 19

Placing Originals. . . . . 21

    Automatic Document Feeder (ADF). . . . . 21

    Scanner glass. . . . . 23

### Copying

Copying Documents. . . . . 25

    Basic copying. . . . . 25

Copy Mode Menu List. . . . . 25

### Printing

Printer Driver and Status Monitor. . . . . 26

    Accessing the printer driver for Windows. . . . . 26

    Accessing the printer driver for Mac OS X. . . . . 27

Basic Operations. . . . . 28

    Basic printing. . . . . 28

    Canceling printing. . . . . 31

Other Options. . . . . 32

    Product presets (For Windows Only). . . . . 32

    2-sided printing (for Windows only). . . . . 33

    Fit to page printing. . . . . 34

    Pages per sheet printing. . . . . 35

Sharing the Product for Printing. . . . . 36

    Setup for Windows. . . . . 36

    Setup for Mac OS X. . . . . 38

### Scanning

Let's Try Scanning. . . . . 39

    Starting a Scan. . . . . 39

    Image Adjustment Features. . . . . 41

Basic Scanning from the Control Panel. . . . . 43

    Scan mode menu list. . . . . 44

Basic Scanning from Your Computer. . . . . 44

    Scanning in Home Mode. . . . . 44

    Scanning in Office Mode. . . . . 46

    Scanning in Professional Mode. . . . . 48

    Previewing and Adjusting the Scan Area. . . . . 50

Various Types of Scanning. . . . . 52

    Scanning a Magazine. . . . . 52

    Scanning Multiple Documents to a PDF File  
    . . . . . 53

    Scanning a Photo. . . . . 56

Software Information. . . . . 57

    Starting Epson Scan Driver. . . . . 57

    Starting Other Scanning Software. . . . . 58

### Menu List of Control Panel

Copy Mode. . . . . 59

Scan Mode. . . . . 60

### Refilling Ink

Ink Bottle Safety Instructions, Precautions, and  
Specifications. . . . . 61

## Contents

Safety instructions. . . . .	61
Precautions on refilling ink. . . . .	61
Ink bottle specifications. . . . .	62
Checking the Ink Level. . . . .	62
Refilling the Ink Tank. . . . .	62

## **Maintaining Your Product and Software**

Checking the Print Head Nozzles. . . . .	65
Using the Nozzle Check utility for Windows . . . . .	65
Using the Nozzle Check utility for Mac OS X . . . . .	65
Using the control panel. . . . .	66
Cleaning the Print Head. . . . .	67
Using the Head Cleaning utility for Windows . . . . .	67
Using the Head Cleaning utility for Mac OS X . . . . .	67
Using the control panel. . . . .	68
Aligning the Print Head. . . . .	68
Using the Print Head Alignment utility for Windows. . . . .	68
Using the Print Head Alignment utility for Mac OS X. . . . .	69
Using the control panel. . . . .	69
Replacing Ink inside the Ink Tube. . . . .	70
Using the Power Ink Flushing utility for Windows. . . . .	70
Using the Power Ink Flushing utility for Mac OS X. . . . .	71
Using the control panel. . . . .	71
Saving Power. . . . .	72
For Windows. . . . .	72
For Mac OS X. . . . .	72
Using the control panel. . . . .	72
Checking the Number of Sheets of Paper Fed. . . . .	73
Cleaning the Product. . . . .	73
Cleaning the exterior of the product. . . . .	73
Cleaning the interior of the product. . . . .	74
Transporting the Product. . . . .	75
Checking and Installing Your Software. . . . .	77
Checking the software installed on your computer. . . . .	77
Installing the software. . . . .	77
Uninstalling Your Software. . . . .	77
For Windows. . . . .	78
For Mac OS X. . . . .	79

## **Error Indicators**

Error Messages on the Control Panel. . . . .	80
--	----

## **Troubleshooting for Printing/Copying**

Diagnosing the Problem. . . . .	81
Checking product status. . . . .	81
Paper Jams. . . . .	83
Removing jammed paper from inside the product. . . . .	84
Removing jammed paper from the Automatic Document Feeder (ADF). . . . .	85
Preventing paper jams. . . . .	86
Reprinting after a paper jam (for Windows only). . . . .	87
Print Quality Help. . . . .	87
Horizontal banding. . . . .	88
Vertical banding or misalignment. . . . .	88
Printout is blurry, smeared, or scuffed or ink supply is poor. . . . .	89
Miscellaneous Printout Problems. . . . .	90
Incorrect or garbled characters. . . . .	90
Incorrect margins. . . . .	90
Printout has a slight slant. . . . .	90
Size or position of copied image is incorrect. . . . .	91
Inverted image. . . . .	91
Blank pages print. . . . .	91
Printed side is smeared or scuffed. . . . .	91
Printing is too slow. . . . .	92
Paper Does Not Feed Correctly. . . . .	92
Paper does not feed. . . . .	92
Multiple pages feed. . . . .	92
Paper is improperly loaded. . . . .	93
Paper is not ejected fully or is wrinkled. . . . .	93
The Product Does Not Print. . . . .	93
All lights are off. . . . .	93
Only the power light is on. . . . .	93
Increasing the Print Speed (For Windows Only) . . . . .	94
Other Problem. . . . .	95
Printing plain papers quietly. . . . .	95

## **Troubleshooting for Scanning**

Problems Indicated by Messages on the LCD Screen or Status Light. . . . .	96
Problems When Starting a Scan. . . . .	96
Using the Automatic Document Feeder (ADF) . . . . .	96
Using the button. . . . .	97

**Contents**

Using scanning software other than Epson Scan driver. . . . .	98
Problems When Feeding Paper. . . . .	98
The paper gets dirty. . . . .	98
Multiple sheets of paper are fed. . . . .	98
The paper jams in the Automatic Document Feeder (ADF). . . . .	98
Problems With Scanning Time. . . . .	99
Problems With Scanned Images. . . . .	99
Scan quality is unsatisfactory. . . . .	99
The scanning area or direction is unsatisfactory. . . . .	100
Problems Remain After Trying All Solutions. . . .	101

**Product Information**

Ink Bottles. . . . .	102
System Requirements. . . . .	102
For Windows. . . . .	102
For Mac OS X. . . . .	102
Technical Specifications. . . . .	103
Printer specifications. . . . .	103
Scanner specifications. . . . .	104
Automatic Document Feeder (ADF) specifications. . . . .	105
Network interface specification. . . . .	105
Mechanical. . . . .	105
Electrical. . . . .	106
Environmental. . . . .	107
Standards and approvals. . . . .	107
Interface. . . . .	107

**Where To Get Help**

Technical Support Web Site. . . . .	108
Contacting Epson Support. . . . .	108
Before Contacting Epson. . . . .	108
Help for Users in Europe. . . . .	109
Help for Users in Thailand. . . . .	109
Help for Users in Vietnam. . . . .	109
Help for Users in Indonesia. . . . .	109
Help for Users in Hong Kong. . . . .	111
Help for Users in Malaysia. . . . .	111
Help for Users in India. . . . .	112
Help for Users in the Philippines. . . . .	113

**Index**

---

## Introduction

# Where to Find Information

The latest version of the following manuals are available on the Epson support website.

<http://www.epson.eu/Support> (Europe)

<http://support.epson.net/> (other than Europe)

**Start Here (paper):**

Provides you with information on setting up the product and installing the software.

**User's Guide (PDF):**

Provides you with detailed operating, safety, and troubleshooting instructions. See this guide when using this product with a computer.

To view the PDF manual, you need Adobe Acrobat Reader 5.0 or later, or Adobe Reader.

**Network Guide (HTML):**

Provides network administrators with information on both the printer driver and network settings.

## Caution, Important and Note

Caution, Important, and Note in this manual are indicated as below and have the following meaning.



**Caution**

*must be followed carefully to avoid bodily injury.*



**Important**

*must be observed to avoid damage to your equipment.*

**Note**

*contain useful tips and restrictions on product operation.*

## Operating System Versions

In this manual, the following abbreviations are used.

Windows 7 refers to Windows 7 Home Basic, Windows 7 Home Premium, Windows 7 Professional, and Windows 7 Ultimate.

Windows Vista refers to Windows Vista Home Basic Edition, Windows Vista Home Premium Edition, Windows Vista Business Edition, Windows Vista Enterprise Edition, and Windows Vista Ultimate Edition.

## Introduction

- ❑ Windows XP refers to Windows XP Home Edition, Windows XP Professional x64 Edition, and Windows XP Professional.
- ❑ Mac OS X refers to Mac OS X 10.5.8 or later.



## Important Instructions

---

### ***Important Instructions***

## **Safety Instructions**

Read and follow these instructions to ensure safe use of this product. Make sure you keep this guide for future reference. Also, be sure to follow all warnings and instructions marked on the product.

- Use only the power cord supplied with the product and do not use the cord with any other equipment. Use of other cords with this product or the use of the supplied power cord with other equipment may result in fire or electric shock.
- Be sure your AC power cord meets the relevant local safety standard.
- Never disassemble, modify, or attempt to repair the power cord, plug, printer unit, scanner unit, or options by yourself, except as specifically explained in the product's guides.
- Unplug the product and refer servicing to qualified service personnel under the following conditions:  
The power cord or plug is damaged; liquid has entered the product; the product has been dropped or the casing damaged; the product does not operate normally or exhibits a distinct change in performance. Do not adjust controls that are not covered by the operating instructions.
- Place the product near a wall outlet where the plug can be easily unplugged.
- Do not place or store the product outdoors, near excessive dirt or dust, water, heat sources, or in locations subject to shocks, vibrations, high temperature or humidity.
- Take care not to spill liquid on the product and not to handle the product with wet hands.
- Keep this product at least 22 cm away from cardiac pacemakers. Radio waves from this product may adversely affect the operation of cardiac pacemakers.
- If the LCD screen is damaged, contact your dealer. If the liquid crystal solution gets on your hands, wash them thoroughly with soap and water. If the liquid crystal solution gets into your eyes, flush them immediately with water. If discomfort or vision problems remain after a thorough flushing, see a doctor immediately.

**Note:**

*The following provides safety instructions for ink.*

➔ ["Refilling Ink" on page 61](#)

## **Product Advisories and Warnings**

Read and follow these instructions to avoid damaging the product or your property. Make sure you keep this guide for future reference.

---

### **Setting up/using the product**

- Do not block or cover the vents and openings in the product.

## Important Instructions

- ❑ Use only the type of power source indicated on the product's label.
- ❑ Avoid using outlets on the same circuit as photocopiers or air control systems that regularly switch on and off.
- ❑ Avoid electrical outlets controlled by wall switches or automatic timers.
- ❑ Keep the entire computer system away from potential sources of electromagnetic interference, such as loudspeakers or the base units of cordless telephones.
- ❑ The power-supply cords should be placed to avoid abrasions, cuts, fraying, crimping, and kinking. Do not place objects on top of the power-supply cords and do not allow the power-supply cords to be stepped on or run over. Be particularly careful to keep all the power-supply cords straight at the ends and the points where they enter and leave the transformer.
- ❑ If you use an extension cord with the product, make sure that the total ampere rating of the devices plugged into the extension cord does not exceed the cord's ampere rating. Also, make sure that the total ampere rating of all devices plugged into the wall outlet does not exceed the wall outlet's ampere rating.
- ❑ If you plan to use the product in Germany, the building installation must be protected by a 10 or 16 amp circuit breaker to provide adequate short-circuit protection and over-current protection for the product.
- ❑ When connecting the product to a computer or other device with a cable, ensure the correct orientation of the connectors. Each connector has only one correct orientation. Inserting a connector in the wrong orientation may damage both devices connected by the cable.
- ❑ Place the product on a flat, stable surface that extends beyond the base of the product in all directions. If you place the product by the wall, leave more than 10 cm between the back of the product and the wall. The product will not operate properly if it is tilted at an angle.
- ❑ When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.
- ❑ Allow spaces behind the product for the cables, and space above the product so that you can fully raise the document cover.
- ❑ Leave enough space in front of the product for the paper to be fully ejected.
- ❑ Avoid places subject to rapid changes in temperature and humidity. Also, keep the product away from direct sunlight, strong light, or heat sources.
- ❑ Do not insert objects through the slots in the product.
- ❑ Do not put your hand inside the product during printing.
- ❑ Do not touch the white flat cable and the ink tube inside the product.
- ❑ Do not use aerosol products that contain flammable gases inside or around the product. Doing so may cause fire.
- ❑ Do not move the print head by hand; otherwise, you may damage the product.
- ❑ Always turn the product off using the ⏻ button. Do not unplug the product or turn off the power at the outlet until the LCD screen has turned off completely.
- ❑ Before transporting the product, make sure that the print head is in the home (far right) position.

## Important Instructions

- ❑ Be careful not to trap your fingers when closing the scanner unit.
- ❑ If the ink level is below the lower limit on the ink tank, refill the ink soon. Continued use of the product when the ink level is below the lower limit on the tank could damage the product.
- ❑ If you are not going to use the product for a long period, be sure to unplug the power cord from the electrical outlet.
- ❑ Do not press too hard on the scanner glass when placing the originals.
- ❑ During the life of your product it may be necessary to replace the waste ink pad when it has become full. Whether and how often this is required will vary according to the number of pages you print, the type of material that you print and the number of cleaning cycles that the product performs. Epson Status Monitor, your LCD, or lights on the control panel will advise you when this part needs replacing. The need for replacement of the pad does not mean that your product has ceased to operate in accordance with its specifications. The replacement of this part is a routine product servicing activity within the product's specification and is not a problem which requires repair. The Epson warranty does not therefore cover the cost of this replacement. If your product needs the pad replacing this can be performed for you by any authorised Epson service provider. It is not a user-serviceable part.

---

## Using the product with a wireless connection

**Note:**

*The availability of this feature varies by product.*

- ❑ Do not use this product inside medical facilities or near medical equipment. Radio waves from this product may adversely affect the operation of electrical medical equipment.
- ❑ Do not use this product near automatically controlled devices such as automatic doors or fire alarms. Radio waves from this product may adversely affect these devices, and could lead to accidents due to malfunction.

---

## Using the LCD screen

- ❑ The LCD screen may contain a few small bright or dark spots, and because of its features it may have an uneven brightness. These are normal and do not indicate that it is damaged in any way.
- ❑ Only use a dry, soft cloth to clean the LCD screen. Do not use liquid or chemical cleansers.
- ❑ The exterior cover of the LCD screen could break if it receives a heavy impact. Contact your dealer if the panel surface chips or cracks, and do not touch or attempt to remove the broken pieces.

---

## Handling ink

➔ [“Refilling Ink” on page 61](#)

## Restrictions on Copying

Observe the following restrictions in order to ensure the responsible and legal use of the product.

## Important Instructions

### Copying of the following items is prohibited by law:

- Bank bills, coins, government-issued marketable securities, government bond securities, and municipal securities
- Unused postage stamps, pre-stamped postcards, and other official postal items bearing valid postage
- Government-issued revenue stamps, and securities issued according to legal procedure

### Exercise caution when copying the following items:

- Private marketable securities (stock certificates, negotiable notes, checks, etc.), monthly passes, concession tickets, etc.
- Passports, driver's licenses, warrants of fitness, road passes, food stamps, tickets, etc.

**Note:**


*Copying these items may also be prohibited by law.*

### Responsible use of copyrighted materials:


- Products can be misused by improperly copying copyrighted materials. Unless acting on the advice of a knowledgeable attorney, be responsible and respectful by obtaining the permission of the copyright holder before copying published material.

# Getting to Know Your Product

## Product Parts




a.	ADF cover
b.	Automatic Document Feeder (ADF)
c.	Edge guide
d.	ADF input tray (place your originals here to be copied)
e.	ADF output tray (your originals are ejected here as they are copied)




a.	Edge guide
b.	Rear paper feed
c.	Paper support extension
d.	Paper support
e.	Feeder guard
f.	Output tray
g.	Stopper


Getting to Know Your Product



a.	Document cover
b.	Scanner glass
c.	Control panel



a.	Scanner Unit
b.	Print head (under this section)
c.	Transportation lock
d.	Ink reservoir tank (Ink tank)
e.	Ink tube



a.	AC inlet
----	----------

## Getting to Know Your Product


b.	LAN port*
c.	USB connector

\* The availability of this part varies by product.

## Guide to the Control Panel

**Note:**

Although the control panel design and menu and option names and other items in the LCD display may slightly differ from the actual product, the method of operation is the same.



## Buttons and LCD



	Buttons	Function
a		Turns the product on and off
b		Enters copy mode.
c		Enters scan mode.
d		Provided with Wi-Fi-capable models only. Displays the <b>Wi-Fi Setup</b> menus that allow you to set up the product wirelessly. For instructions on using the menus, see the Network Guide.*
e	-	LCD screen (monochrome 2-line display)
f		Press  ,  ,  ,  to select menus. Press <b>OK</b> to confirm the setting you have selected and go to next screen.
g		Stops the ongoing operation or initializes the current settings. If this button is pressed to cancel copying or scanning while the ADF is in use, all originals in the ADF will be fed out.
h		Displays detailed settings for each mode.
i		Cancels/returns to the previous menu.
j		Start copying.

\* The availability of this part varies by product.

**Getting to Know Your Product**

---

**Lights**

Lights	Function
	On when the product is on. Flashes when the product is receiving data, printing/copying/scanning, or cleaning the print head.
	Stays on while the product is connected to a Wi-Fi network. Flashes while the Wi-Fi network settings are being made. This light turns off in sleep mode*.
<b>ADF</b>	On when originals are detected in the ADF.

\* The availability of this part varies by product.



---

# Paper and Media Handling

---


## Introduction to Using, Loading, and Storing Media

You can achieve good results with most types of plain paper. However, Epson provides special types of paper that is formulated for the ink used in Epson ink jet products, and we recommend using this paper to ensure high-quality results.

When loading special paper distributed by Epson, read the instruction sheets packed with the paper first and keep the following points in mind.

**Note:**

- ❑ *Load the paper into the rear paper feed printable side up. The printable side is usually whiter. See the instruction sheets packed with the paper for more information. Some types of paper have cut corners to help identify the correct loading direction.*
- ❑ *If the paper is curled, flatten it or curl it slightly in the opposite direction before loading. Printing on curled paper may cause ink to smear on your prints. Do not use the paper that is folded, wavy or torn.*



---

## Storing paper

Return unused paper to the original package as soon as you finish printing. Keep unused paper and prints away from high temperature, humidity, and direct sunlight.

## Selecting Paper

Refer to the table below for the loading capacities of paper and other media.

## Paper and Media Handling

Media Type	Size	Loading capacity (sheets)
Plain paper*1	Letter*2	up to 11mm
	A4*2	up to 11mm
	B5*2	up to 11mm
	A5*2	up to 11mm
	A6*2	up to 11mm
	Legal	1
	User Defined	1
Envelope	#10	10
	DL	10
	C6	10
Epson Bright White Ink Jet Paper	A4*2	80
Epson Photo Quality Ink Jet Paper	A4	80
Epson Matte Paper - Heavyweight	A4	1

\*1 Paper with a weight of 64 g/m<sup>2</sup> (17 lb) to 90 g/m<sup>2</sup> (24 lb).

\*2 The loading capacity for manual 2-sided printing is 30 sheets.

**Note:**

*The availability of paper varies by location.*

## Paper type settings on the LCD screen

The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

For this paper	LCD paper type
Plain paper	Plain Paper
Epson Bright White Ink Jet Paper	
Epson Matte Paper – Heavyweight	Matte

## Paper type settings from the printer driver

The product automatically adjusts itself for the type of paper you select in your print settings. That is why the paper type setting is so important. It tells your product what kind of paper you are using and adjusts the ink coverage accordingly. The table below lists the settings you should choose for your paper.

## Paper and Media Handling

For this paper	Printer driver paper type
Plain paper	plain papers
Epson Bright White Ink Jet Paper	
Epson Matte Paper – Heavyweight	Epson Matte
Epson Photo Quality Ink Jet Paper	
Envelopes	Envelope

**Note:**


The availability of special media varies by location. For the latest information on media available in your area, contact Epson support.

➔ [“Technical Support Web Site” on page 108](#)


## Loading Paper and Envelopes

Follow these steps to load paper:

- 1 Flip the feeder guard forward.



- 2 Slide out the paper support and the output tray and then raise the stopper.




**Note:**

Leave enough space in front of the product for the paper to be fully ejected.

## Paper and Media Handling


**3** Slide the edge guide to the left.

**4** Load paper with the printable side up, against the right side of the rear paper feed.




**Note:**

- Fan and align the edges of the paper before loading.
- The printable side is often whiter than the other side.
- Always load paper into the rear paper feed short edge first, even when you are printing landscape -oriented pictures.
- You can use the following sizes of paper with binding holes: A4, A5, A6, Legal, Letter. Load only 1 sheet of paper at a time.
- When loading envelopes, load the short edge first with the flap facing down.




- Do not use envelopes that are curled, folded, or glued or that have plastic windows.
- Flatten the envelope and the flaps before loading.



- Flatten the leading edge of the envelope before loading.
- Avoid using envelopes that are too thin, as they may curl during printing.

## Paper and Media Handling

- 5** Slide the edge guide against the left edge of the paper, but not too tightly.




**Note:**

For plain paper, do not load paper above the ▽ arrow mark inside the edge guide.

For Epson special media, make sure the number of sheets is less than the limit specified for the media.

➔ [“Selecting Paper” on page 17](#)

- 6** Flip the feeder guard back.



## Placing Originals

### Automatic Document Feeder (ADF)

You can load your original documents in the Automatic Document Feeder (ADF) to copy or scan multiple pages quickly. You can use the following originals in the ADF.

Size	A4/Letter/Legal
Type	Plain paper
Weight	64 g/m <sup>2</sup> to 95 g/m <sup>2</sup>
Capacity	Total thickness of 3 mm, up to about 30 sheets (Letter, A4) 10 sheets (Legal)

## Paper and Media Handling




**Important:**

To prevent paper jams, avoid the following documents. For these types, use the scanner glass.


- ❑ Documents held together with paper clips, staples, etc.
- ❑ Documents that have tape or paper stuck to them.
- ❑ Photos, OHPs, or thermal transfer paper.
- ❑ Paper that is torn, wrinkled, or has holes.

**1** Make sure that there are no originals on the scanner glass. The ADF may not detect documents in the feeder if there are originals on the scanner glass.


**2** Tap the originals on a flat surface to even the edges.



**3** Slide the edge guide on the Automatic Document Feeder.




**4** Insert the originals face-up and short edge first into the Automatic Document Feeder.



## Paper and Media Handling

- 5 Slide the edge guide until it is flush with the originals.



- 6 Check that the ADF light in the control panel is on.


**Note:**

- The ADF light may stay off if there is any other original on the scanner glass. If you press  $\diamond$  in this case, the original on the scanner glass will be copied or scanned instead of the originals in the ADF.
- The ADF light will not turn on when the product is in sleep mode. Press any button other than  $\text{⏻}$  to recover from sleep mode. It may take some time for the light to turn on after recovery from sleep mode.
- Be careful not to let any foreign object get inside the hole on the left front corner of the scanner glass. Doing so may prevent the ADF from operating.
- When you use the copy function with the Automatic Document Feeder (ADF), the print settings are fixed at Reduce/Enlarge - **Actual Size**, Paper Type - **Plain Paper**, and Paper Size - **A4/Legal**. The print is cropped if you copy an original larger than A4/Legal.

---


## Scanner glass

- 1 Open the document cover and place your original face-down on the scanner glass.



## Paper and Media Handling

- 2** Slide the original to the corner.



**Note:**

See the following sections if any problems occur with the scanning area or the scanning direction when using EPSON Scan.

- ➔ [“The edges of your original are not scanned” on page 100](#)
- ➔ [“Multiple documents are scanned into a single file” on page 101](#)

- 3** Close the cover gently.



---

# Copying









---

## Copying Documents

---

### Basic copying

Follow the steps below to copy documents.

- 1 Load paper.  
➔ [“Loading Paper and Envelopes” on page 19](#)
- 2 Place your original(s) in the Automatic Document Feeder or on the scanner glass.  
➔ [“Placing Originals” on page 21](#)
- 3 Press  to enter the copy mode.
- 4 Press  or  to set the number of copies.
- 5 Press  to display the copy setting menus.
- 6 Select the appropriate copy settings such as layout, paper size, paper type, and quality. Use  or  to select a setting item and then press **OK**. When finished, press  again to return to the copy mode top screen.
- 7 Press  to start copying.

## Copy Mode Menu List

Refer to the section below for the Copy mode menu list.

➔ [“Copy Mode” on page 59](#)

---

# Printing

---

## Printer Driver and Status Monitor

The printer driver lets you choose from a wide variety of settings to get the best printing results. The status monitor and the printer utilities help you check the product and keep it in top operating condition.

**Note for Windows users:**

- ❑ Your printer driver automatically finds and installs the latest version of the printer driver from Epson's Web site. Click the **Software Update** button in your printer driver's **Maintenance** window, and then follow the on-screen instructions. If the button does not appear in the **Maintenance** window, point at **All Programs** or **Programs** in the Windows Start menu, and check in the **EPSON** folder.
- ❑ If you want to change the language of the driver, select the language you want to use from the **Language** setting in your printer driver's **Maintenance** window. Depending on the location, this function may not be available.

---

## Accessing the printer driver for Windows

You can access the printer driver from most Windows applications, the Windows Start menu, or the taskbar.

To make settings that apply only to the application you are using, access the printer driver from that application.

To make settings that apply to all of your Windows applications, access the printer driver from the Start menu or the taskbar.

Refer to the following sections to access the printer driver.

**Note:**

Screen shots of the printer driver windows in this User's Guide are from Windows 7.

### From Windows applications

- 1 Click **Print** or **Print Setup** on the File menu.
- 2 In the window that appears, click **Printer**, **Setup**, **Options**, **Preferences**, or **Properties**. (Depending on your application, you may need to click one or a combination of these buttons.)

### From the Start menu

- ❑ **Windows 7:**  
Click the start button, select **Devices and Printers**. Then right-click the product and select **Printing preferences**.
- ❑ **Windows Vista:**  
Click the start button, select **Control Panel**, and then select **Printer** from the **Hardware and Sound** category. Then select the product and then click **Select printing preferences**.

## Printing

### ❑ Windows XP:

Click **Start, Control Panel, (Printers and Other Hardware,)** then **Printers and Faxes**. Select the product, then click **Printing Preferences** on the File menu.


## From the shortcut icon on the taskbar

Right-click the product icon on the taskbar, then select **Printer Settings**.

To add a shortcut icon to the Windows taskbar, first access the printer driver from the Start menu as described above. Next, click the **Maintenance** tab, and then the **Monitoring Preferences** button. In the Monitoring Preferences window, select the **Shortcut Icon** check box.

## Getting information through online help

In the printer driver window, try one of the following procedures.

- ❑ Right-click the item, then click **Help**.
- ❑ Click the  button at the top right of the window, then click the item (for Windows XP only).

---

## Accessing the printer driver for Mac OS X

The table below describes how to access the printer driver dialog.

Dialog Box	How to Access It
Page Setup	Click <b>Page Setup</b> on the File menu of your application. <i>Note:</i> <i>Depending on your application, the Page Setup menu may not appear in the File menu.</i>
Print	Click <b>Print</b> on the File menu of your application.
Epson Printer Utility 4	For Mac OS X 10.7, click <b>System Preferences</b> on the Apple menu and then click <b>Print &amp; Scan</b> . Select your product from the Printers list box, click <b>Options &amp; Supplies, Utility</b> , and then click <b>Open Printer Utility</b> . For Mac OS X 10.6, click <b>System Preferences</b> on the Apple menu and then click <b>Print &amp; Fax</b> . Select your product from the Printers list box, click <b>Options &amp; Supplies, Utility</b> , and then click <b>Open Printer Utility</b> . For Mac OS X 10.5, click <b>System Preferences</b> on the Apple menu and then click <b>Print &amp; Fax</b> . Select your product from the Printers list box, click <b>Open Print Queue</b> and then click <b>Utility</b> button.

## Getting information through online help

Click the  **Help** button in the Print dialog box.

## Basic Operations


### Basic printing

**Note:**

- ❑ The screen shots in this section may vary depending on the model.
- ❑ Before you print, load paper properly.
  - ➔ [“Loading Paper and Envelopes” on page 19](#)
- ❑ Refer to the section below for the printable area.
  - ➔ [“Printable area” on page 104](#)
- ❑ After completing the settings, print one test copy and examine the results before printing an entire job.

### Basic product settings for Windows

- 1 Open the file you want to print.
- 2 Access the printer settings.
  - ➔ [“Accessing the printer driver for Windows” on page 26](#)



- 3 Click the **Main** tab.
- 4 Select the appropriate Document Size setting. You can also define a custom paper size. For details, see the online help.

## Printing

- 5 Select **Portrait** (tall) or **Landscape** (wide) to change the orientation of your print.

**Note:**  
Select **Landscape** when printing on envelopes.

- 6 Select the appropriate Paper Type setting.  
➔ [“Paper type settings from the printer driver”](#) on page 18

**Note:**  
Print quality is automatically adjusted for the selected Paper Type.

- 7 Click **OK** to close the printer settings window.

**Note:**  
To make changes to advanced settings, refer to the relevant section.

- 8 Print your file.


## Basic product settings for Mac OS X

**Note:**  
Screen shots of the printer driver windows in this section are from Mac OS X 10.7.

- 1 Open the file you want to print.

## Printing

- 2 Access the Print dialog box.  
 ➔ “Accessing the printer driver for Mac OS X” on page 27



**Note:**

If the simplified dialog box is displayed, click the **Show Details** button (for Mac OS X 10.7) or the ▼ button (for Mac OS X 10.6 or 10.5) to extend this dialog box.

- 3 Select the product you are using as the Printer setting.

**Note:**

Depending on your application, you may not be able to select some of the items in this dialog box. If so, click **Page Setup** on the File menu of your application, and then make suitable settings.

- 4 Select the appropriate Paper Size setting.


- 5 Select the appropriate Orientation setting.

**Note:**

Select landscape orientation when printing envelopes.

## Printing

- 6** Select **Print Settings** from the pop-up menu.




- 7** Select the appropriate Media Type setting.  
 ➔ [“Paper type settings from the printer driver” on page 18](#)

- 8** Click **Print** to start printing.

## Canceling printing

If you need to cancel printing, follow the instructions in the appropriate section below.

### Using the product button

Press  to cancel a print job in progress.

### For Windows

**Note:**

You cannot cancel a print job that has been completely sent to the product. In this case, cancel the print job by using the product.

- 1** Access the EPSON Status Monitor 3.  
 ➔ [“For Windows” on page 81](#)


## Printing

- 2 Click the **Print Queue** button. The Windows Spooler appears.
- 3 Right-click on the job you want to cancel and then select **Cancel**.

### For Mac OS X

Follow the steps below to cancel a print job.

- 1 Click your product icon in the Dock.
- 2 In the Document Name list, select the document which is printing.
- 3 Click the **Delete** button to cancel the print job.



## Other Options

### Product presets (For Windows Only)

Printer driver presets make printing a snap. You can also create presets of your own.

### Product settings for Windows

- 1 Access the printer settings.  
➔ [“Accessing the printer driver for Windows” on page 26](#)
- 2 Select a Printing Presets in the Main tab. Product settings are automatically set to the values displayed in the pop-up window.



## 2-sided printing (for Windows only)

Use the printer driver to print on both sides of the paper.



Two types of 2-sided printing are available: standard and folded booklet.

2-sided printing is only available for the following papers and sizes.

Paper	Size
Plain paper	Legal, Letter, A4, B5, A5, A6
Epson Bright White Ink Jet Paper	A4

**Note:**

- This feature is not available for Mac OS X.
- This feature may not be available at some settings.
- This feature may not be available when the product is accessed over a network or is used as a shared printer.
- The loading capacity differs during 2-sided printing.
  - ➔ [“Selecting Paper” on page 17](#)
- Only use papers that are suitable for 2-sided printing. Otherwise, the printout quality may deteriorate.
- Depending on the paper and the amount of ink used to print text and images, ink may bleed through to the other side of the paper.
- The surface of the paper may be smeared during 2-sided printing.
- This feature is available only when EPSON Status Monitor 3 is enabled. To enable the status monitor, access the printer driver and click the **Maintenance** tab followed by the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.

## Product settings for Windows

- 1 Access the printer settings.
  - ➔ [“Accessing the printer driver for Windows” on page 26](#)
- 2 Select **2-Sided Printing** check box.

## Printing

- 3 Click **Settings**, and make the appropriate settings.

**Note:**

If you want to print a folded booklet, select **Booklet**.

- 4 Check the other settings and print.


**Note:**

- The actual binding margin may be different from the specified settings depending on your application. Experiment with a few sheets to examine actual results before printing the entire job.
- Make sure that the ink is completely dry before reloading the paper.

---

## Fit to page printing

Lets you automatically enlarge or reduce the size of your document to fit the paper size selected in the printer driver.



**Note:**

This feature may not be available at some settings.

## Product settings for Windows

- 1 Access the printer settings.  
➔ [“Accessing the printer driver for Windows” on page 26](#)
- 2 Select **Reduce/Enlarge Document** and **Fit to Page** in the More Options tab, and then select the size of the paper you are using from Output Paper.
- 3 Check the other settings and print.

## Product settings for Mac OS X

- 1 Access the Print dialog box.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)


## Printing

- 2 Choose **Scale to fit paper size** for Destination Paper Size in the Paper Handling pane and select the desired paper size from the pop-up menu.
- 3 Check the other settings and print.

---

## Pages per sheet printing

Lets you use the printer driver to print two or four pages on a single sheet of paper.



**Note:**

*This feature may not be available at some settings.*

### Product settings for Windows

- 1 Access the printer settings.  
➔ [“Accessing the printer driver for Windows” on page 26](#)
- 2 Select **2-Up** or **4-Up** as Multi-Page in the Main tab.
- 3 Click **Page Order**, and make the appropriate settings.
- 4 Check the other settings and print.

### Product settings for Mac OS X

- 1 Access the Print dialog box.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- 2 Select the desired number of Pages per Sheet and the Layout Direction (page order) in the Layout pane.
- 3 Check the other settings and print.

# Sharing the Product for Printing

---

## Setup for Windows

These instructions tell you how to set up your product so other users on the network can share it.

First you will set up the product as a shared printer on the computer directly connected to it. Then you will add the product to each network computer that will access it.

**Note:**

- These instructions are for small networks only. To share the product on a large network, consult your network administrator.*
- The screen shots in the following section are from Windows 7.*

## Setting up the product as a shared printer

**Note:**

- To set up the product as a shared printer in Windows 7 or Vista, you will need an account with administrator privileges and the password if you log on as a standard user.*
- To set up the product as a shared printer in Windows XP, you must log on to a Computer Administrator account.*

Follow the steps below on the computer that is connected directly to the product:

**1****Windows 7:**

Click the start button, select **Devices and Printers**.

**Windows Vista:**

Click the start button, select **Control Panel**, and then select **Printer** from the **Hardware and Sound** category.

**Windows XP:**

Click **Start** and select **Control Panel**, and then select **Printers and Faxes**, from the **Printers and Other Hardware** category.

**2****Windows 7:**

Right-click the icon for your product, click **Printer properties**, and then click **Sharing**. Then click the **Change Sharing Options** button.

**Windows Vista:**

Right-click the icon for your product, and then click **Sharing**. Click the **Change sharing options** button and then click **Continue**.

**Windows XP:**

Right-click the icon for your product, then click **Sharing**.


**3**

Select **Share this printer**, then type a Share name.

**Note:**

*Do not use spaces or hyphens in the share name.*

## Printing



If you want to automatically download printer drivers for computers that are running different versions of Windows, click **Additional Drivers** and select the environment and the operating systems of the other computers. Click **OK**, then insert the product software disk.

- 4 Click **OK** or **Close** (if you installed additional drivers).

### Adding the product to the other network computers

Follow these steps to add the product to each network computer that will access it.

**Note:**

*Your product must be set up as a shared printer on the computer to which it is connected before you can access it from another computer.*

➔ *"Setting up the product as a shared printer" on page 36.*

- 1 **Windows 7:**  
Click the start button, select **Devices and Printers**.

**Windows Vista:**

Click the start button, select **Control Panel**, and then select **Printer** from the **Hardware and Sound** category.

**Windows XP:**

Click **Start** and select **Control Panel**, and then select **Printers and Faxes**, from the **Printers and Other Hardware** category.

## Printing

- 2** **Windows 7 and Vista:**  
Click the **Add a printer** button.


**Windows XP:**

Click the **Add a printer** button. The Add Printer Wizard appears. Click the **Next** button.

- 3** **Windows 7 and Vista:**  
Click **Add a network, wireless or Bluetooth printer**, and then click **Next**.

**Windows XP:**

Select **A network printer, or a printer attached to another computer**, then click **Next**.



- 4** Follow the on-screen instructions to select the product you want to use.

**Note:**

Depending on the operating system and the configuration of the computer to which the product is connected, the Add Printer Wizard may prompt you to install the printer driver from the product software disk. Click the **Have Disk** button and follow the on-screen instructions.

---

## Setup for Mac OS X

To set up your product on a Mac OS X network, use the Printer Sharing setting. See your Macintosh documentation for details.

---

# Scanning

---


## Let's Try Scanning

---

### Starting a Scan


Let's scan a document to get used to the process.

- 1 Place your original(s) on the scanner glass.  
➔ [“Placing Originals” on page 21](#)
- 2 Start Epson Scan.
  - Windows:  
Double-click the **Epson Scan** icon on the desktop.
  - Mac OS X:  
Select **Applications > Epson Software > EPSON Scan**.
- 3 Select **Home Mode**.




### Scanning


**4** Select **Text/Line Art** as the **Document Type** setting.



**5** Click **Preview**.




**6** Click **Scan**.





## Scanning

**7** Click **OK**.




Your scanned image is saved.

---







## Image Adjustment Features

Epson Scan offers a variety of settings for improving color, sharpness, contrast, and other aspects affecting image quality.






See the Help for more details on Epson Scan.

<p>Histogram</p>	<p>Provides a graphical interface for adjusting highlight, shadow, and gamma levels individually.</p> 
------------------	--

### Scanning

<p>Tone Correction</p>	<p>Provides a graphical interface for adjusting tone levels individually.</p> 
<p>Image Adjustment</p>	<p>Adjusts brightness and contrast and the balance of red, green, and blue colors in the overall image.</p> 
<p>Color Palette</p>	<p>Provides a graphical interface for adjusting mid-tone levels, such as skin tones, without affecting the highlight and shadow areas of the image.</p> 
<p>Unsharp Mask</p>	<p>Sharpens the edges of image areas for an overall clearer image.</p> 
<p>Descreening</p>	<p>Removes rippled patterns (known as moiré) that can appear in subtly shaded image areas such as skin tones.</p> 
<p>Color Restoration</p>	<p>Restores the colors in faded photos automatically.</p> 

### Scanning


<p>Backlight Correction</p>	<p>Removes shadows from photos that have too much background light.</p> 
<p>Dust Removal</p>	<p>Removes dust marks from your originals automatically.</p> 
<p>Text Enhancement</p>	<p>Enhances text recognition when scanning text documents.</p> 
<p>Auto Area Segmentation</p>	<p>Makes Black&amp;White images clearer and text recognition more accurate by separating the text from the graphics.</p> 
<p>Color Enhance</p>	<p>Enhance a certain color. You can select from red, blue, or green.</p> 

## Basic Scanning from the Control Panel

You can scan documents and send the scanned image from the product to a connected computer. Make sure you have installed software for the product on your computer and connected to the computer.

- 1 Place your original(s) in the Automatic Document Feeder or on the scanner glass.  
 ➔ [“Placing Originals” on page 21](#)

## Scanning

- 2 Press  to enter the scan mode.
- 3 Select a scan menu item. Use ▲ or ▼ to select a menu, and press OK.  
➔ [“Scan Mode” on page 60](#)
- 4 Select your computer.

**Note:**

- If the product is connected to a network, you can select the computer to which you want to save the scanned image.*
- You can change the computer name displayed on the control panel using Epson Event Manager.*

- 5 Press OK to start scanning.

Your scanned image is saved.

---

## Scan mode menu list

Refer to the section below for the Scan mode menu list.

➔ [“Scan Mode” on page 60](#)

## Basic Scanning from Your Computer

---

### Scanning in Home Mode

Home Mode lets you customize some scanning settings and check the changes you have made in a preview image. This mode is useful for basic scanning of photos and graphics.


**Note:**

- In Home Mode, you can only scan from the scanner glass.*
- See the Help for more details on Epson Scan.*

- 1 Place your original(s).  
➔ [“Scanner glass” on page 23](#)
- 2 Start Epson Scan.  
➔ [“Starting Epson Scan Driver” on page 57](#)

## Scanning

- 3 Select **Home Mode** from the Mode list.



- 4 Select the Document Type setting.
- 5 Select the Image Type setting.
- 6 Click **Preview**.  
 ➔ [“Previewing and Adjusting the Scan Area” on page 50](#)
- 7 Adjust the exposure, brightness, and other image quality settings.
- 8 Click **Scan**.

## Scanning

- 9** In the File Save Settings window, select the Type setting and then click **OK**.

**Note:**

If the **Show this dialog box before next scan** check box is cleared, Epson Scan starts scanning immediately without displaying the File Save Settings window.

Your scanned image is saved.

---

## Scanning in Office Mode

Office Mode lets you quickly scan text documents without previewing your image.

**Note:**

See the *Help* for more details on Epson Scan.

- 1** Place your original(s).  
➔ [“Placing Originals” on page 21](#)


**Note for the Automatic Document Feeder (ADF):**

- If you are using preview function, load only the first page.
- Do not load paper above the line just under the ▼ arrow mark on the ADF.

- 2** Start Epson Scan.  
➔ [“Starting Epson Scan Driver” on page 57](#)

## Scanning

- 3 Select **Office Mode** from the Mode list.



- 4 Select the Image Type setting.
- 5 Select the Document Source setting.
- 6 Select the size of your original as the Size setting.
- 7 Select an appropriate resolution for your original(s) as the Resolution setting.
- 8 Click **Scan**.

## Scanning

- 9 In the File Save Settings window, select the Type setting and then click **OK**.

**Note:**

If the **Show this dialog box before next scan** check box is cleared, Epson Scan starts scanning immediately without displaying the File Save Settings window.

Your scanned image is saved.

---

## Scanning in Professional Mode

Professional Mode gives you total control of your scanning settings and lets you check the changes you have made in a preview image. This mode is recommended for advanced users.

**Note:**

See the *Help* for more details on Epson Scan.

- 1 Place your original(s).  
➔ [“Placing Originals” on page 21](#)

**Note for the Automatic Document Feeder(ADF):**


If you are using preview function, load only the first page.

- 2 Start Epson Scan.  
➔ [“Starting Epson Scan Driver” on page 57](#)



## Scanning

- 3 Select **Professional Mode** from the Mode list.



- 4 Select the type of original(s) you are scanning as the Document Type setting.

- 5 Select the Document Source setting.

- 6 If you select **Reflective** as the Document Type setting, select **Photo** or **Document** as the Auto Exposure Type setting.

## Scanning

- 7 Select the Image Type setting.
- 8 Select an appropriate resolution for your original(s) as the Resolution setting.
- 9 Click **Preview** to preview your image(s). The Preview window opens and displays your image(s).  
➔ [“Previewing and Adjusting the Scan Area” on page 50](#)

**Note for the Automatic Document Feeder (ADF):**

- The ADF loads your first document page, and then Epson Scan prescans it and displays it in the Preview window. The ADF then ejects your first page.  
Place your first document page on top of the rest of the pages, and then load the entire document into the ADF.
- Do not load paper above the line just under the ▼ arrow mark on the ADF.

- 10 Select the size of the scanned image(s) as the Target Size setting if necessary. You can scan your images at their original size, or you can reduce or enlarge their size by selecting Target Size.
- 11 Adjust the image quality if necessary.  
➔ [“Image Adjustment Features” on page 41](#)

**Note:**

You can save the settings you make as a group of custom settings with a **Name**, and later apply these custom settings when scanning. Your custom settings are also available in Epson Event Manager.  
See the Help for more details on Epson Event Manager.

- 12 Click **Scan**.
- 13 In the File Save Settings window, select the Type setting and then click **OK**.

**Note:**

If the **Show this dialog box before next scan** check box is cleared, Epson Scan starts scanning immediately without displaying the File Save Settings window.

Your scanned image is saved.

---

## Previewing and Adjusting the Scan Area

### Selecting a preview mode

Once you have selected your basic settings and resolution, you can preview your image and select or adjust the image area in a Preview window. There are two types of preview.

- Normal preview displays your previewed image(s) in their entirety. You can select the scan area and make any image quality adjustments manually.
- Thumbnail preview displays your previewed image(s) as thumbnail(s). Epson Scan automatically locates the edges of your scan area, applies automatic exposure settings to the image(s), and rotates the image(s) if necessary.

## Scanning

### Note:

- ❑ Some of the settings that you change after previewing an image are reset if you change the preview mode.
- ❑ Depending on your document type and the Epson Scan mode you are using, you may not be able to change the preview type.
- ❑ If you preview image(s) without the Preview dialog displayed, image(s) are displayed in the default preview mode. If you preview with the Preview dialog displayed, image(s) are displayed in the preview mode that was displayed just before previewing.
- ❑ To resize the Preview window, click and drag the corner of the Preview window.
- ❑ See the Help for more details on Epson Scan.


## Creating a marquee

A marquee is a moving dotted line that appears on the edges of your preview image to indicate the scan area.

Do one of the following to draw a marquee.



- ❑ To draw the marquee manually, position the pointer in the area where you want to place the corner of your marquee and click. Drag the cross-hairs over the image to the opposite corner of the desired scan area.






- ❑ To draw the marquee automatically, click the  auto locate icon. You can only use this icon when you are viewing a normal preview and you only have one document on the scanner glass.
- ❑ To draw the marquee at a specified size, type in a new width and height in the Document Size setting.
- ❑ For best results and image exposure, make sure all sides of the marquee are located inside the preview image. Do not include any areas around the preview image in the marquee.

## Adjusting a marquee

You can move the marquee and adjust its size. If you are viewing a normal preview, you can create multiple marquees (up to 50) on each image to scan different image areas as separate scan files.

	To move the marquee, position your cursor inside the marquee. The pointer becomes a hand. Click and drag the marquee to the desired location.
	To resize the marquee, position your cursor over the edge or corner of the marquee. The pointer becomes a straight or angled double-arrow. Click and drag the edge or corner to the desired size.

## Scanning

	To create additional marquees of the same size, click this icon.
	To delete a marquee, click inside the marquee and click this icon.
	To activate all marquees, click this icon.

**Note:**


- To restrict the movement of the marquee to vertical or horizontal only, hold down the **Shift** key as you move the marquee.
- To restrict the size of the marquee to the current proportions, hold down the **Shift** key as you resize the marquee.
- If you draw multiple marquees, make sure you click **All** in the Preview window before you scan. Otherwise, only the area inside the last marquee you drew will be scanned.

## Various Types of Scanning

### Scanning a Magazine

First of all, place your magazine and start Epson Scan.


➔ “Starting a Scan” on page 39



- 1** Select **Home Mode** from the Mode list.

## Scanning

- 2 Select **Magazine** as the Document Type setting.
- 3 Click **Preview**.
- 4 Adjust the exposure, brightness, and other image quality settings.  
See the Help for more details on Epson Scan.
- 5 Click **Scan**.



- 6 Select **PDF** as the Type setting, and then click **OK**.  
Your scanned image is saved.

---


## Scanning Multiple Documents to a PDF File

First of all, place your document and start Epson Scan.

➔ [“Starting a Scan” on page 39](#)

**Note for the Automatic Document Feeder(ADF):**  
If you are using preview function, load only the first page.


## Scanning



- 1 Select **Professional Mode** from the Mode list.
- 2 Select the Document Source setting.
- 3 Click **Preview**.

**Note for the Automatic Document Feeder (ADF):**

The document page ejected by the ADF has not been scanned yet. Reload the entire document into the ADF.




Do not load paper above the line just under the ▼ arrow mark on the ADF.

## Scanning

**4** Adjust the exposure, brightness, and other image quality settings.

See the Help for more details on Epson Scan.


**5** Click **Scan**.



**6** Select **PDF** as the Type setting, and then click **OK**.

**Note:**  
 If the **Show Add Page dialog after scanning** check box is cleared, Epson Scan automatically saves your document without displaying the Add Page Confirmation window.

**7** Epson Scan starts scanning your document.




**8** If you want to scan more pages, click **Add page**.  
 Load the document and scan again, repeating as necessary for each page.

If you have finished scanning, go to step 9.

## Scanning

### 9 Click **Edit page** or **Save File**.


<p>Edit page</p>	<p>Select this button if you want to delete or reorder any of the pages. Then use the icons on the bottom of the Editing Page window to select, rotate, reorder, and delete pages. See the Help for more details on Epson Scan.</p>  <p>Click OK when you are finished editing your pages.</p>
<p>Save File</p>	<p>Select this button when you are finished.</p>

The pages are saved in one PDF file.

## Scanning a Photo

First of all, place your photo on the scanner glass and start Epson Scan.


➔ [“Starting a Scan” on page 39](#)





## Scanning

- 1 Select **Home Mode** from the Mode list.
- 2 Select **Photograph** as the Document Type setting.
- 3 Click **Preview**.
- 4 Adjust the exposure, brightness, and other image quality settings.  
See the Help for more details on Epson Scan.
- 5 Click **Scan**.



- 6 Select **JPEG** as the Type setting, and then click **OK**.

Your scanned image is saved.

## Software Information

---

### Starting Epson Scan Driver

This software lets you control all aspects of scanning. You can use this as a standalone scanning program or use it with another TWAIN-compliant scanning program.

## How to start

- ❑ Windows:  
Double-click the **EPSON Scan** icon on the desktop.  
Or, select the start button icon or **Start > All Programs** or **Programs > EPSON > EPSON Scan > EPSON Scan**.
- ❑ Mac OS X:  
Select **Applications > Epson Software > EPSON Scan**.

## How to access the help

Click the **Help** button on the Epson Scan driver.

---

## Starting Other Scanning Software

*Note:*  
Some scanning software may not be included in some countries.


## Epson Event Manager

This lets you assign any of the product buttons to open a scanning program. You can also save frequently used scanning settings, which can really speed up your scanning projects.

### How to start

- ❑ Windows:  
Select the start button or **Start > All Programs** or **Programs > Epson Software > Event Manager**.
- ❑ Mac OS X:  
Select **Applications > Epson Software**, and then double-click the **Launch Event Manager** icon.

### How to access the help

- ❑ Windows:  
Click the  icon in the upper right corner of the screen.
- ❑ Mac OS X:  
Click **menu > Help > Epson Event Manager Help**.


# Menu List of Control Panel


You can use this product as a printer, copier, and scanner. When using one of these functions, except the printer function, select your desired function by pressing the corresponding Mode button on the control panel. Each mode's main screen appears as you select the mode.

## Copy Mode

**Note:**

*Depending on the model, some functions may not be available.*

Press  to see the menu.

Setting Item	Setting item and description.	
Layout	With Border, ID Card Copy	
Reduce/Enlarge	Actual Size, Auto Fit Page, Custom	
Paper Size	A4, Legal	
Paper Type	Plain Paper, Matte	
Quality	Draft, Standard Quality, Best	
Copy Density	-4 to +4	
Restore Default Settings	Reset Network Settings	Initializes Network settings to the factory default settings.
	Reset Wi-Fi Settings	Initializes Wi-Fi settings to the factory default settings.
	Reset All except Network Settings	Initializes all settings except for Network settings to the factory default settings.
	Reset All except Wi-Fi Settings	Initializes all settings except for Wi-Fi settings to the factory default settings.
	Reset All Settings	Initializes all settings to the factory default settings.
Wi-Fi Settings (Wi-Fi capable models only)	Wi-Fi Setup	See the online Network Guide. You can access the Wi-Fi Setup menus directly by pressing the  button.
	Check Wi-Fi Connection	You can check the network connection status, and print the report. If there is any problem with the connection, the report helps you find the solution.
	Confirm Wi-Fi Settings	You can see the current network settings.
	Print Wi-Fi Status Sheet	You can print a network status sheet.

## Menu List of Control Panel


Setting Item	Setting item and description.	
Network Settings (Ethernet capable models only)	Check Network Connection	You can check the network connection status, and print the report. If there is any problem with the connection, the report helps you find the solution.
	Confirm Network Settings	You can see the current network settings.
	Print Network Status Sheet	You can print a network status sheet.
Maintenance	Nozzle Check	Prints a nozzle check pattern to check the condition of the print head.
	Head Cleaning	Cleans the print head to improve the condition of the print head.
	Head Alignment	Adjusts the alignment of the print head.
	LCD Contrast	+1 to +16
	Scroll Speed	Fast, Standard, Slow
	Power Off Timer	Off, 30minutes, 1h, 2h, 4h, 8h, 12h
	Sleep Timer	3minutes, 5minutes, 10minutes
	Language	-

## Scan Mode

**Note:**

Depending on the model, some functions may not be available.

Menu	Setting and Options
Scan to PC	➔ <a href="#">"Basic Scanning from the Control Panel" on page 43</a>
Scan to PC (PDF)	
Scan to PC (Email)	
Scan to PC (WSD)	This feature is only available for English versions of Windows 7/Vista.

Press  to see the menu.

Menu	Description
Restore Default Settings	➔ <a href="#">"Copy Mode" on page 59.</a>
Wi-Fi Settings	
Network Settings	
Maintenance	

---

# Refilling Ink

---

## Ink Bottle Safety Instructions, Precautions, and Specifications

---

### Safety instructions

Observe the following when handling the ink:

- Keep ink bottles and the ink tank unit out of the reach of children. Do not allow children to drink from or handle the ink bottles and ink bottle cap.
- Do not tilt or shake an ink bottle after removing its seal; this can cause leakage.
- Be careful not to touch any ink when you handle the ink tank, ink tank cap, and opened ink bottles or ink bottle caps.  
If ink gets on your skin, wash the area thoroughly with soap and water.  
If ink gets into your eyes, flush them immediately with water. If discomfort or vision problems continue after a thorough flushing, see a doctor immediately.  
If ink gets into your mouth, spit it out immediately and see a doctor right away.

---

### Precautions on refilling ink

Read all of the instructions in this section before refilling ink.

- Use ink bottles with the correct part number for this product.  
➔ [“Ink Bottles” on page 102](#)
- Epson recommends the use of genuine Epson ink bottles. Epson cannot guarantee the quality or reliability of non-genuine ink. The use of non-genuine ink may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic product behavior.
- Other products not manufactured by Epson may cause damage that is not covered by Epson's warranties, and under certain circumstances, may cause erratic product behavior.
- This product requires careful handling of ink. Ink may splatter when the ink tank is filled or refilled with ink. If ink gets on your clothes or belongings, it may not come off.
- To maintain optimum print head performance, some ink is consumed not only during printing but also during maintenance operation such as print head cleaning.
- Do not open the ink bottle package until you are ready to fill the ink tank. The ink bottle is vacuum packed to maintain its reliability. If you leave an ink bottle unpacked for a long time before using it, normal printing may not be possible.
- If the ink level is below the lower limit on the ink tank, refill the ink soon. Continued use of the product when the ink level is below the lower limit on the tank could damage the product.

## Refilling Ink

- ❑ After bringing an ink bottle inside from a cold storage site, allow it to warm up at room temperature for at least three hours before using it.
- ❑ Store ink bottles in a cool, dark place.
- ❑ Store the ink bottles in the same environment as the product. When storing or transporting the ink bottle after opening the sealed bottle, avoid temperature changes, impacts, shaking or tilting the bottle; otherwise ink may leak even if you tighten the cap on the bottle. Be sure to keep the ink bottle upright when tightening the cap, and take measures to prevent ink from leaking when you transport the bottle.

---

## Ink bottle specifications

- ❑ Epson recommends using the ink bottle before the date printed on the package.
- ❑ Some ink is consumed in the initial charging. In order to produce high quality printouts, the print head in your product will be fully charged with ink.
- ❑ Quoted yields may vary depending on the images that you are printing, the paper type that you are using, the frequency of your prints and environmental conditions such as temperature.
- ❑ Although the ink bottles may contain recycled materials, this does not affect product function or performance.

## Checking the Ink Level

To confirm the actual ink remaining, visually check the ink level in the product's ink tank.




### **Important:**

*If the ink level is below the lower limit on the ink tank, fill it to the upper line on the ink tank. Continued use of the product when the ink level is below the lower limit on the tank could damage the product.*

## Refilling the Ink Tank

Ink can be refilled at any time.

- 1** Open the ink tank unit cover, and then remove the cap of the ink tank. After removing the cap, place it as shown in the illustration below.




## Refilling Ink

**Note:**

*Be careful not to spill any ink.*


2

Snap off the top of the cap, remove the cap of the ink bottle, remove the seal from the bottle, and then install the cap.



**Important:**

*Install the ink bottle cap tightly; otherwise ink may leak.*




**Note:**

*Do not dispose of the top of the cap. If any ink remains in the ink bottle after refilling the tank, use the top of the cap to seal the ink bottle cap.*

3


Refill the ink tank up to the upper line on the ink tank.




## Refilling Ink

**Note:**


If any ink remains in the ink bottle after filling the ink tank up to the upper line, install the cap securely and store the ink bottle upright for later use.



- 4** Install the cap onto the ink tank securely.



- 5** Close the ink tank unit cover.





---

# Maintaining Your Product and Software

---

## Checking the Print Head Nozzles

If you find that the printout is unexpectedly faint or that dots are missing, you may be able to identify the problem by checking the print head nozzles.

You can check the print head nozzles from your computer by using the Nozzle Check utility or from the product by using the buttons.

---

## Using the Nozzle Check utility for Windows

Follow the steps below to use the Nozzle Check utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the rear paper feed.
- 3 Right-click the product icon on the taskbar, then select **Nozzle Check**.  
If the product icon does not appear, refer to the following section to add the icon.  
➔ [“From the shortcut icon on the taskbar” on page 27](#)
- 4 Follow the on-screen instructions.

---

## Using the Nozzle Check utility for Mac OS X


Follow the steps below to use the Nozzle Check utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the rear paper feed.
- 3 Access the Epson Printer Utility 4.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- 4 Click the **Nozzle Check** icon.
- 5 Follow the on-screen instructions.

---


## Using the control panel

Follow the steps below to check the print head nozzles using the product control panel.


- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the rear paper feed.
- 3 Press  to display the menus.
- 4 Select **Maintenance**.
- 5 Select **Nozzle Check** and follow the instructions in the LCD screen to print a nozzle check pattern.

Below are two sample nozzle check patterns.

Compare the quality of the printed check page with the sample shown below. If there are no print quality problems, such as gaps or missing segments in the test lines, the print head is fine.



If any segment of the printed lines is missing, as shown below, this could mean a clogged ink nozzle or a misaligned print head.



- ➔ [“Cleaning the Print Head” on page 67](#)
- ➔ [“Aligning the Print Head” on page 68](#)

## Cleaning the Print Head

If you find that the printout is unexpectedly faint or that dots are missing, you may be able to solve these problems by cleaning the print head, which ensures that the nozzles are delivering ink properly.

You can clean the print head from your computer using the Head Cleaning utility in the printer driver or from the product by using the buttons.

**Important:**

*Do not open the scanner unit or turn off the product during head cleaning. If the head cleaning is incomplete, you may not be able to print.*

**Note:**

- Because print head cleaning uses some ink, clean the print head only if quality declines; for example, if the printout is blurry or scuffed.*
- Use the Nozzle Check utility first to confirm that the print head needs to be cleaned. This saves ink.*
- When ink is low you may not be able to clean the print head. Refill the ink tank first.*
- If print quality has not improved after repeating this procedure about three times, use the Power Ink Flushing utility.  
➔ [“Replacing Ink inside the Ink Tube” on page 70](#)*
- To maintain print quality, we recommend printing a few pages on a regular basis.*

---

## Using the Head Cleaning utility for Windows

Follow the steps below to clean the print head using the Head Cleaning utility.

- 1** Make sure that the transportation lock is set to the unlocked (Printing) position.
- 2** Make sure that no warnings or errors are indicated in the control panel.
- 3** Right-click the product icon on the taskbar, then select **Head Cleaning**.  
If the product icon does not appear, refer to the following section to add the icon.  
➔ [“From the shortcut icon on the taskbar” on page 27](#)
- 4** Follow the on-screen instructions.

---

## Using the Head Cleaning utility for Mac OS X

Follow the steps below to clean the print head using the Head Cleaning utility.

- 1** Make sure that the transportation lock is set to the unlocked (Printing) position.


## Maintaining Your Product and Software

- 2 Make sure that no warnings or errors are indicated in the control panel.
- 3 Access the Epson Printer Utility 4.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- 4 Click the **Head Cleaning** icon.
- 5 Follow the on-screen instructions.

---

## Using the control panel

Follow the steps below to clean the print head using the product control panel.


- 1 Make sure that the transportation lock is set to the unlocked (Printing) position.
- 2 Make sure that no warnings or errors are indicated in the control panel.
- 3 Press  to display the menus.
- 4 Select **Maintenance**.
- 5 Select **Head Cleaning**.
- 6 Follow the instructions on the LCD screen to continue.

## Aligning the Print Head

If you notice a misalignment of vertical lines or horizontal banding, you may be able to solve this problem by using the Print Head Alignment utility in your printer driver or by using the product buttons.

Refer to the appropriate section below.

**Note:**

*Do not press  to cancel printing while printing a test pattern with the Print Head Alignment utility.*

---

## Using the Print Head Alignment utility for Windows

Follow the steps below to align the print head using the Print Head Alignment utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.

## Maintaining Your Product and Software

- 2 Make sure A4-size paper is loaded in the rear paper feed.
- 3 Right-click the product icon on the taskbar, then select **Print Head Alignment**.  
If the product icon does not appear, refer to the following section to add the icon.  
➔ [“From the shortcut icon on the taskbar” on page 27](#)
- 4 Follow the on-screen instructions to align the print head.

---

## Using the Print Head Alignment utility for Mac OS X

Follow the steps below to align the print head using the Print Head Alignment utility.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure A4-size paper is loaded in the rear paper feed.
- 3 Access the Epson Printer Utility 4.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- 4 Click the **Print Head Alignment** icon.
- 5 Follow the on-screen instructions to align the print head.

---


## Using the control panel

Follow the steps below to align the print head using the product control panel.

- 1 Make sure that no warnings or errors are indicated in the control panel.
- 2 Make sure that A4-size paper is loaded in the rear paper feed.
- 3 Press  $\equiv$  to display the menus.
- 4 Select **Maintenance**.
- 5 Select **Head Alignment** and follow the instructions in the LCD screen to print the patterns.

## Maintaining Your Product and Software

- 6** Find the most solid pattern in each of #1 to #4 groups.



- 7** Enter the pattern number for the most solid pattern in #1 group.

- 8** Repeat step 7 for the other groups (#2 to #4).

- 9** Finish aligning the print head.

## Replacing Ink inside the Ink Tube

If print quality has not improved even after running Head Cleaning several times, you may need to replace the ink inside the ink tube to solve the problem.

The Power Ink Flushing utility allows you to replace all of the ink inside the ink tube.

**!** **Important:**

*This function consumes a lot of ink. Before using this function, make sure there is enough ink in the product's ink tank. If there is not enough ink, refill the ink tank.*

**Note:**

- This function consumes a lot of ink. We only recommend using this function after running Head Cleaning several times.*
- This function effects the service life of the ink pads. Ink pads reach their capacity earlier by running this function. Contact Epson Support to request replacement before the end of their service life. When the ink pads are at the end of their service life, the product stops and Epson support is required to continue printing.*
- After using the Power Ink Flushing utility, run the nozzle check again and repeat head cleaning if necessary. If print quality has still not improved, turn the product off and wait for at least six hours. If you still cannot solve the problem after trying all of the methods above, contact Epson support.*

## Using the Power Ink Flushing utility for Windows

Follow the steps below to use the Power Ink Flushing utility.

- 1** Make sure that the transportation lock is set to the unlocked (Printing) position.

- 2** Make sure that no warnings or errors are indicated in the control panel.

## Maintaining Your Product and Software

- 3 Access the printer driver.  
➔ “Accessing the printer driver for Windows” on page 29
- 4 Click the **Maintenance** tab, then click the **Power Ink Flushing** button.
- 5 Follow the on-screen instructions.

---

## Using the Power Ink Flushing utility for Mac OS X




Follow the steps below to use the Power Ink Flushing utility.

- 1 Make sure that the transportation lock is set to the unlocked (Printing) position.
- 2 Make sure that no warnings or errors are indicated in the control panel.
- 3 Access the Epson Printer Utility 4.  
➔ “Accessing the printer driver for Mac OS X” on page 30
- 4 Click the **Power Ink Flushing** icon.
- 5 Follow the on-screen instructions.

---

## Using the control panel

Follow the steps below to use the Power Ink Flushing function.

- 1 Make sure that the transportation lock is set to the unlocked (Printing) position.
- 2 Make sure that no warnings or errors are indicated in the control panel.
- 3 Turn off the product.
- 4 While holding down  and , press  to turn on the product.
- 5 When the product turns on, release both the buttons.
- 6 Follow the instructions in the LCD screen.

## Saving Power

The LCD screen turns black or turns off automatically if no operations are performed for a set period.

You can adjust the time before power management is applied. Any increase will affect the product's energy efficiency. Please consider the environment before making any change.

Follow the steps below to adjust the time.

---

### For Windows

- 1 Access the printer settings.  
➔ [“Accessing the printer driver for Windows” on page 26](#)
- 2 Click the **Maintenance** tab, and then click the **Printer and Option Information** button.
- 3 Select **Off**, **30 minutes**, **1 hour**, **2 hours**, **4 hours**, **8 hours**, or **12 hours** as the Power Off Timer setting. Then click the **Send** button.
- 4 Select **3 minutes**, **5 minutes**, or **10 minutes** as the Sleep Timer setting. Then click the **Send** button.
- 5 Click the **OK** button.


---

### For Mac OS X

- 1 Access the Epson Printer Utility 4.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- 2 Click the **Printer Settings** button. The Printer Settings screen appears.
- 3 Select **Off**, **30 minutes**, **1 hour**, **2 hours**, **4 hours**, **8 hours**, or **12 hours** as the Power Off Timer setting.
- 4 Select **3 minutes**, **5 minutes**, or **10 minutes** as the Sleep Timer setting.
- 5 Click the **Apply** button.

---

### Using the control panel

- 1 Press  to display the menus.
- 2 Select **Maintenance**.



## Maintaining Your Product and Software

- 3 Select **Power Off Timer**.
- 4 Select **Off, 30minutes, 1h, 2h, 4h, 8h, or 12h**.
- 5 Select **Sleep Timer**.
- 6 Select **3minutes, 5minutes, or 10minutes**.

## Checking the Number of Sheets of Paper Fed

You can check the number of sheets of paper fed from the printer driver.

Click the **Printer and Option Information** button on your printer driver's Maintenance window (for Windows) or on the Epson Printer Utility 4 (for Mac OS X).

## Cleaning the Product

---


### Cleaning the exterior of the product

To keep your product operating at its best, clean it thoroughly several times a year by using the following instructions.

**!** **Important:**  
*Never use alcohol or thinner to clean the product. These chemicals can damage the product.*


**Note:**  
*Close the paper support and the output tray when you are not using the product to protect the product from dust.*

- Use a soft, dry, clean cloth to clean the LCD screen. Do not use liquid or chemical cleaners.
- Use a soft, dry, clean cloth to clean the surface of the scanner glass.  
If straight lines appear in the printout or the scanned data, clean the left side of the scanner glass carefully.



## Maintaining Your Product and Software

- ❑ If the glass surface is stained with grease or some other hard-to-remove material, use a small amount of glass cleaner and a soft cloth to remove it. Wipe off all remaining liquid.
- ❑ Open the ADF cover and use a soft, dry, clean cloth to clean the roller and the interior of the ADF.



- ❑ Do not press the surface of the scanner glass with any force.
- ❑ Be careful not to scratch or damage the surface of the scanner glass, and do not use a hard or abrasive brush to clean it. A damaged glass surface can decrease the scan quality.

---

## Cleaning the interior of the product

To keep your print results at their best, clean the roller inside by using the following procedure.



**Caution:**

*Be careful not to touch the parts inside the product.*



**Important:**

- ❑ *Be careful to keep water away from the electronic components.*
- ❑ *Do not spray the inside of the product with lubricants.*
- ❑ *Unsuitable oils can damage the mechanism. Contact your dealer or a qualified service person if lubrication is needed.*


**1**

Make sure that no warnings or errors are indicated in the control panel.


**2**

Load several sheets of A4-size plain paper in the rear paper feed.

**3**

Press  to enter the copy mode.

**4**

Press  to make a copy without placing a document on the scanner glass.

**5**

Repeat step 4 until the paper is not smeared with ink.


## Transporting the Product

If you move the product some distance, you need to prepare it for transportation in its original box or one of a similar size.

**!** **Important:**

- ❑ *When storing or transporting the product, avoid tilting it, placing it vertically, or turning it upside down; otherwise ink may leak.*
- ❑ *When storing or transporting the ink bottle after opening the sealed bottle, avoid temperature changes, impacts, shaking or tilting the bottle; otherwise ink may leak even if you tighten the cap on the bottle. Be sure to keep the ink bottle upright when tightening the cap, and take measures to prevent ink from leaking when you transport the bottle.*

- 1** Remove all paper from the rear paper feed and make sure the product is off.
- 2** Close the paper support and the output tray.
- 3** Open the scanner unit and make sure the print head is in the home position on the right.




**Note:**

*If the print head is not in the home position on the right, turn on the product and wait until the print head locks in the far right position. Then turn off the product.*

- 4** Unplug the power cord from the outlet, then disconnect all cables from the product.

## Maintaining Your Product and Software


- 5 Secure the print head to the case with tape as shown, then close the scanner unit.




**Note:**

*Do not place tape on the white flat cable inside the product.*

- 6 Set the transportation lock to the locked (Transporting) position.



- 7 Make sure to install the cap onto the ink tank securely.



- 8 Repack the product in the box, using the protective materials that came with it.



**Important:**

- Keep the product level during transport. Otherwise, ink may leak.
- After you move it, remove the tape securing the print head, then set the transportation lock to the unlocked (Printing) position. If you notice a decline in print quality, run a cleaning cycle or align the print head.
- Do not put opened ink bottles in the box with product.

# Checking and Installing Your Software

---

## Checking the software installed on your computer

To use the functions described in this User's Guide, you need to install the following software.

- Epson Driver and Utilities
- Epson Event Manager

Follow the steps below to check that the software is installed on your computer.

### For Windows

- 1** **Windows 7 and Vista:** Click the start button and select **Control Panel**.  
**Windows XP:** Click **Start** and select **Control Panel**.
- 2** **Windows 7 and Vista:** Click **Uninstall a program** from the Programs category.  
**Windows XP:** Double-click the **Add or Remove Programs** icon.
- 3** Check the list of currently installed programs.

### For Mac OS X

- 1** Double-click **Macintosh HD**.
- 2** Double-click the **Epson Software** folder in the Applications folder and check the contents.

**Note:**

- The Applications folder contains software provided by third parties.*
- To check that the printer driver is installed, click **System Preferences** on the Apple menu and then click **Print & Scan** (for Mac OS X 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5). Then locate your product in the Printers list box.*

---

## Installing the software

Insert the product software disk that came with your product and select the software you want to install on the Software Select screen.

## Uninstalling Your Software

You may need to uninstall and then reinstall your software to solve certain problems or if you upgrade your operating system.

## Maintaining Your Product and Software

See the following section for information on determining what applications are installed.

➔ [“Checking the software installed on your computer” on page 77](#)

---

### For Windows

**Note:**

- For Windows 7 and Vista, you need an administrator account and password if you log on as a standard user.
- For Windows XP, you must log on to a Computer Administrator account.

**1** Turn off the product.

**2** Disconnect the product's interface cable from your computer.

**3** Do one of the following.

**Windows 7 and Vista:** Click the start button and select **Control Panel**.

**Windows XP:** Click **Start** and select **Control Panel**.

**4** Do one of the following.

**Windows 7 and Vista:** Click **Uninstall a program** from the Programs category.

**Windows XP:** Double-click the **Add or Remove Programs** icon.

**5** Select the software you want to uninstall such as your product's driver and the application from the list displayed.

**6** Do one of the following.

**Windows 7:** Click **Uninstall/Change** or **Uninstall**.

**Windows Vista:** Click **Uninstall/Change** or **Uninstall**, and then click **Continue** in the User Account Control window.

**Windows XP:** Click **Change/Remove** or **Remove**.

**Note:**

*If you chose to uninstall your product's printer driver in step 5, select the icon for your product and then click **OK**.*

**7** When the confirmation window appears, click **Yes** or **Next**.

**8** Follow the on-screen instructions.

In some cases, a message may appear to prompt you to restart your computer. If so, make sure **I want to restart my computer now** is selected and click **Finish**.

---

## For Mac OS X

**Note:**

- To uninstall your software you need to download the Uninstaller.  
Access the site at:  
<http://www.epson.com>  
Next, select the support section of your local Epson Web site.
- To uninstall applications, you must log on to a Computer Administrator account.  
You cannot uninstall programs if you log on as a limited account user.
- Depending on the application, the Installer may be separated from the Uninstaller.

- 1** Quit all running applications.
- 2** Double-click the **Uninstaller** icon in your Mac OS X hard drive.
- 3** Select the check boxes for the software you want to uninstall, such as the printer driver and the application, from the list displayed.
- 4** Click **Uninstall**.
- 5** Follow the on-screen instructions.

If you cannot find the software you want to uninstall in the Uninstaller window, double-click the **Applications** folder in your Mac OS X hard drive, select the application you want to uninstall, and then drag it to the **Trash** icon.

**Note:**

If you uninstall the printer driver and the name of your product remains in the *Print & Scan* (for Mac OS X 10.7) or *Print & Fax* (for Mac OS X 10.6 or 10.5) window, select the name of your product and click the - **remove** button.

# Error Indicators

## Error Messages on the Control Panel

This section describes the meaning of messages displayed on the LCD screen.

Error Messages	Solutions
Paper jam Press OK. If the error does not clear, remove the paper by hand.	Remove the jammed paper. ➔ <a href="#">"Paper Jams" on page 83</a>
Paper jam in the ADF. Remove the jammed paper.	
Communication error. Make sure the cable is connected, then try again.	Make sure the computer is connected correctly. If the error messages still appears, make sure that scanning software is installed on your computer and that the software settings are correct.
Printer error Paper jam. Open the scanner unit and remove the paper, then turn off the printer. See your documentation.	Turn the product off and then back on. Make sure that no paper is still in the product. If the error message still appears, contact Epson support.
ADF Error. Remove any objects or documents inside ADF. Turn power off. See documentation.	
Printer error See your documentation.	
Scanner error See your documentation.	Turn the product off and then back on. If the error message still appears, contact Epson support.
A printer's ink pad is nearing the end of its service life. Please contact Epson Support.	Press <b>OK</b> to resume printing. The message will be displayed until the ink pad is replaced.  Contact Epson support to replace ink pads before the end of their service life. When the ink pads are saturated, the product stops and Epson support is required to continue printing.
A printer's ink pad is at the end of its service life. Please contact Epson Support.	Contact Epson support to replace the ink pad.
Recovery Mode	The firmware update has failed. You will need to re-attempt the firmware update. Ready a USB cable and visit your local Epson website for further instructions.



---

# Troubleshooting for Printing/Copying

---

## Diagnosing the Problem

Troubleshooting product problems is best handled in two steps: first diagnose the problem, then apply likely solutions until the problem is fixed.

The information that you need to diagnose and solve most common problems is provided by online problem solving, the control panel, or the status monitor. Refer to the appropriate section below.

If you have a specific problem relating to print quality, a printing problem not related to print quality, or a paper feeding problem, or if the product does not print at all, refer to the appropriate section.

To solve a problem, you may need to cancel printing.

➔ [“Canceling printing” on page 31](#)

---

## Checking product status

If a problem occurs while printing, an error message will appear in the status monitor window.

If an error message appears indicating the product's ink pads are nearing the end of their service life, contact Epson support to replace them. The message will be displayed at regular intervals until the ink pads are replaced. When the product's ink pads are saturated, the product stops and Epson support is required to continue printing.


## For Windows

There are two ways to access EPSON Status Monitor 3:

- Double-click the product shortcut icon on your Windows taskbar. To add a shortcut icon to the taskbar, see the following section:
  - ➔ [“From the shortcut icon on the taskbar” on page 27](#)
- Open the printer driver, click the **Maintenance** tab, then click the **EPSON Status Monitor 3** button.

## Troubleshooting for Printing/Copying

When you access EPSON Status Monitor 3, the following window appears:



**Note:**

If EPSON Status Monitor 3 does not appear, access the printer driver and click the **Maintenance** tab and then the **Extended Settings** button. In the Extended Settings window, check the **Enable EPSON Status Monitor 3** check box.

EPSON Status Monitor 3 provides the following information:

- Technical Support:**  
Click **Technical Support** to access the Epson technical support website.
- Print Queue:**  
You can view Windows Spooler by clicking **Print Queue**.

### For Mac OS X


Follow these steps to access EPSON Status Monitor.

- 1** Access the Epson Printer Utility 4.  
➔ [“Accessing the printer driver for Mac OS X” on page 27](#)

## Troubleshooting for Printing/Copying

2

Click the **EPSON Status Monitor** icon. The EPSON Status Monitor appears.



## Paper Jams

**Caution:**

*Never touch the buttons on the control panel while your hand is inside the product.*

**Important:**


*Be careful not to pull the cables or ink tube, or touch other components inside the product unnecessarily. Otherwise, ink may leak or the product may be damaged.*

**Note:**

- Cancel the print job if prompted by a message from the LCD screen or the printer driver.*
- After you have removed the jammed paper, press the button indicated in the LCD screen.*

## Removing jammed paper from inside the product


- 1 Open the scanner unit.



**!** **Important:**  
Do not lift up the scanner unit when the document cover is open.



- 2 Remove all of the paper inside, including any torn pieces.




- 3 Close the scanner unit slowly.

---

## Removing jammed paper from the Automatic Document Feeder (ADF)


1 Remove the stack of paper from the ADF input tray.

2 Open the ADF cover.




**!** **Important:**  
*Make sure you open the ADF cover before removing jammed paper. If you do not open the cover, the product may be damaged.*

3 Carefully remove the jammed paper.




4 Open the Automatic Document Feeder (ADF).




## Troubleshooting for Printing/Copying

- 5 Remove all of the paper inside, including any torn pieces.




- 6 Close the Automatic Document Feeder (ADF).

- 7 Raise the ADF input tray.



- 8 Carefully remove the jammed paper.



- 9 Return the ADF input tray to its original position, and close the ADF cover.

---

## Preventing paper jams

If your paper jams frequently, check the following.

- The paper is smooth, not curled or wrinkled.

## Troubleshooting for Printing/Copying

- You are using high-quality paper.
- The printable side of the paper is face up in the rear paper feed.
- The paper stack was fanned before loading.
- For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide. For Epson special media, make sure the number of sheets is less than the limit specified for the media.  
➔ [“Selecting Paper” on page 17](#)
- The edge guides are snug against the edges of the paper.
- The product is on a flat, stable surface that extends beyond the base in all directions. The product will not operate properly if it is tilted.

---

## Reprinting after a paper jam (for Windows only)

After you cancel the print job because of a paper jam, you can reprint it without reprinting pages that have already been printed.

- 1** Solve the paper jam.  
➔ [“Paper Jams” on page 83](#)
- 2** Access the printer settings.  
➔ [“Accessing the printer driver for Windows” on page 26](#)
- 3** Select the **Print Preview** check box in the Main window of your printer driver.
- 4** Make the settings that you want to use to print.
- 5** Click **OK** to close the printer settings window, and then print your file. Print Preview window opens.
- 6** Select a page that has already been printed in the page list box on the left side, and then select **Remove Page** from the Print Options menu. Repeat this step for all the pages that have already been printed.
- 7** Click **Print** on the Print Preview window.

## Print Quality Help

If you are having print quality problems, then compare it with the illustrations below. Click the caption under the illustration that best resembles your prints.

## Troubleshooting for Printing/Copying

<p>enthalten alle          i Aufdruck. W          J 5008 "Regel"</p> <p>Good sample</p>	<p>enthalten alle          i Aufdruck. W          J 5008 "Regel"</p> <p>➔ "Horizontal banding" on page 88</p>
<p>enthalten alle          i Aufdruck. W          J 5008 "Regel"</p> <p>➔ "Vertical banding or misalignment" on page 88</p>	<p>enthalten alle          i Aufdruck. W          J 5008 "Regel"</p> <p>➔ "Printout is blurry, smeared, or scuffed or ink supply is poor" on page 89</p>

---

### Horizontal banding

- Make sure the printable side (the whiter side) of the paper is face up in the rear paper feed.
- Run the Head Cleaning utility to clear any clogged ink nozzles.  
➔ "Cleaning the Print Head" on page 67
- Make sure you use ink bottles with the correct part number for this product.  
➔ "Ink Bottles" on page 102
- Try to use genuine Epson ink bottles.
- Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.  
➔ "Selecting Paper" on page 17
- If banding appears at intervals of 2.5 cm, run the Print Head Alignment utility.  
➔ "Aligning the Print Head" on page 68
- If a moire (cross-hatch) pattern appears on your copy, change the **Reduce/Enlarge** setting in the LCD menu or shift the position of your original.
- If there is problem with copy quality, clean the surface of the scanner glass.  
➔ "Cleaning the exterior of the product" on page 73

---

### Vertical banding or misalignment

- Make sure the printable side (the whiter side) of the paper is face up in the rear paper feed.
- Run the Head Cleaning utility to clear any clogged ink nozzles.  
➔ "Cleaning the Print Head" on page 67



## Troubleshooting for Printing/Copying

- ❑ Run the Print Head Alignment utility.  
➔ [“Aligning the Print Head” on page 68](#)
- ❑ For Windows, clear the **High Speed** check box from the More Options window in your printer driver. See the online help for details.  
For Mac OS X, select **Off** from the High Speed Printing. To display the High Speed Printing, click through the following menus: **System Preferences, Print & Scan** (for Mac OS X 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.
- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.  
➔ [“Selecting Paper” on page 17](#)
- ❑ If there is problem with copy quality, clean the surface of the scanner glass.  
➔ [“Cleaning the exterior of the product” on page 73](#)

---

## Printout is blurry, smeared, or scuffed or ink supply is poor

- ❑ Make sure the initial ink charging is complete.
- ❑ Make sure you use ink bottles with the correct part number for this product.  
➔ [“Ink Bottles” on page 102](#)
- ❑ Try to use genuine Epson ink bottles and paper recommended by Epson.
- ❑ Make sure the product is on a flat, stable surface that extends beyond the base in all directions. The product will not operate properly if it is tilted.
- ❑ Check the transportation lock. If the transportation lock is in the locked (Transporting) position, turn it to the unlocked (Printing) position. If print quality does not improve, run the Head Cleaning utility.  
➔ [“Cleaning the Print Head” on page 67](#)
- ❑ Check the ink tank. If the tank is empty, refill the ink immediately and run the Head Cleaning utility.  
➔ [“Cleaning the Print Head” on page 67](#)  
  
Once the tank has been expended, the problem might not be solved by the head cleaning, and you may have to run the Power Ink Flushing utility.  
➔ [“Replacing Ink inside the Ink Tube” on page 70](#)
- ❑ Make sure your paper is not damaged, dirty, or too old.
- ❑ Make sure your paper is dry and the printable side (the whiter side) is face up in the rear paper feed.
- ❑ If the paper is curled toward the printable side, flatten it or curl it slightly in the opposite direction.
- ❑ Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.  
➔ [“Selecting Paper” on page 17](#)
- ❑ Remove each sheet from the output tray as it is printed.
- ❑ Do not touch or allow anything to come into contact with the printed side of paper with a shiny finish. To handle your prints, follow the instructions of the paper.

## Troubleshooting for Printing/Copying

- ❑ Run the Head Cleaning utility to clear any clogged ink nozzles.  
➔ [“Cleaning the Print Head” on page 67](#)
- ❑ Run the Print Head Alignment utility.  
➔ [“Aligning the Print Head” on page 68](#)
- ❑ If the paper is smeared with ink after printing, clean the interior of the product.  
➔ [“Cleaning the interior of the product” on page 74](#)
- ❑ If there is problem with copy quality, clean the surface of the scanner glass.  
➔ [“Cleaning the exterior of the product” on page 73](#)
- ❑ If you have not used the product for a long time, use the Power Ink Flushing utility.  
➔ [“Replacing Ink inside the Ink Tube” on page 70](#)

## Miscellaneous Printout Problems

---

### Incorrect or garbled characters

- ❑ Clear any stalled print jobs.  
➔ [“Canceling printing” on page 31](#)
- ❑ Turn off the product and computer. Make sure the product's interface cable is securely plugged in.
- ❑ Uninstall the printer driver, then reinstall it.  
➔ [“Uninstalling Your Software” on page 77](#)

### Incorrect margins

- ❑ Make sure that the paper is loaded into the rear paper feed correctly.  
➔ [“Loading Paper and Envelopes” on page 19](#)
- ❑ Check the margin settings in your application. Make sure that the margins are within the printable area of the page.  
➔ [“Printable area” on page 104](#)
- ❑ Make sure the printer driver settings are appropriate for the paper size you are using.  
For Windows, check the Main window.  
For Mac OS X, check the Page Setup dialog box or Print dialog box.
- ❑ Uninstall the printer driver, then reinstall it.  
➔ [“Uninstalling Your Software” on page 77](#)

### Printout has a slight slant

---

- ❑ Make sure that the paper is loaded into the rear paper feed correctly.  
➔ [“Loading Paper and Envelopes” on page 19](#)

## Troubleshooting for Printing/Copying

- ❑ If **Draft** is selected in Quality in the Main window in your printer driver (for Windows), or **Draft** is selected in Print Quality in Print Settings (for Mac OS X), select another setting.

---

### Size or position of copied image is incorrect

- ❑ Make sure the paper size, layout, or reduce/enlarge setting selected in the control panel matches the paper used.
- ❑ If the edges of the copy are cropped off, move the original slightly away from the corner.
- ❑ Clean the scanner glass.
  - ➔ [“Cleaning the exterior of the product” on page 73](#)

---

### Inverted image

- ❑ For Windows, clear the **Mirror Image** check box from the More Options window of your printer driver, or turn off the Mirror Image setting in your application.  
For instructions, see the online help for your printer driver or for your application.
- ❑ Uninstall the printer driver, then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)

---

### Blank pages print

- ❑ Make sure the printer driver settings are appropriate for the paper size you are using.  
For Windows, check the Main window.  
For Mac OS X, check the Page Setup dialog box or Print dialog box.
- ❑ For Windows, check the **Skip Blank Page** setting by clicking the **Extended Settings** button on the Maintenance window of the printer driver.  
For Mac OS X, select **On** from the Skip Blank Page. To display the Skip Blank Page, click through the following menus: **System Preferences, Print & Scan** (for Mac OS X 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.
- ❑ Uninstall the printer driver, then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)

---

### Printed side is smeared or scuffed

- ❑ If the paper is curled toward the printable side, flatten it or curl it slightly in the opposite direction.
- ❑ Make several copies without placing a document on the scanner glass.
  - ➔ [“Cleaning the interior of the product” on page 74](#)
- ❑ Uninstall the printer driver, then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)

## Troubleshooting for Printing/Copying

---

### Printing is too slow

- Make sure the paper type selected in the LCD menu or printer driver is appropriate for the type of paper loaded in the product.
  - ➔ [“Selecting Paper” on page 17](#)
- For Windows, choose a lower **Quality** in the printer driver Main window.  
For Mac OS X, choose a lower Print Quality in the Print Settings dialog box from your printer driver's Print dialog box.
  - ➔ [“Accessing the printer driver for Windows” on page 26](#)
  - ➔ [“Accessing the printer driver for Mac OS X” on page 27](#)
- Close any unnecessary applications.
- If you print continuously for an extended period, the printing may be extremely slow. This is to slow down the printing speed and prevent the product mechanism from overheating and being damaged. If this happens, you can continue to print, but we recommend stopping and leaving the product idle for at least 30 minutes with the power on. (The product does not recover with the power off.) After you restart, the product will print at normal speed.
- Uninstall the printer driver, then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)

If you try all of the methods above and cannot solve the problem, see the following:

- ➔ [“Increasing the Print Speed \(For Windows Only\)” on page 94](#)

### Paper Does Not Feed Correctly

---

#### Paper does not feed

Remove the stack of paper and make sure of the following:

- The paper is not curled or creased.
- The paper is not too old. See the instructions that came with the paper for more information.
- For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide.  
For Epson special media, make sure the number of sheets is less than the limit specified for the media.
  - ➔ [“Selecting Paper” on page 17](#)
- Paper is not jammed inside the product. If it is, remove the jammed paper.
  - ➔ [“Paper Jams” on page 83](#)
- You have followed any special loading instructions that came with your paper.

---

#### Multiple pages feed

- For plain paper, do not load paper above the line just under the ▼ arrow mark inside the edge guide.  
For Epson special media, make sure the number of sheets is less than the limit specified for the media.
  - ➔ [“Selecting Paper” on page 17](#)

## Troubleshooting for Printing/Copying

- ❑ Make sure the edge guides are snug against the edges of the paper.
- ❑ Make sure the paper is not curled or folded. If so, flatten it or curl it slightly toward the opposite side before loading.
- ❑ Remove the stack of paper and make sure that the paper is not too thin.  
➔ [“Paper” on page 103](#)
- ❑ Fan the edges of the stack to separate the sheets, then reload the paper.
- ❑ If too many copies of a file are being printed, check the Copies setting in your printer driver as follows, and also check in your application.  
For Windows, check the Copies setting on the Main window.  
Mac OS X, check the Copies setting in the Print dialog.

---

### Paper is improperly loaded

If you have loaded the paper too far into the product, the product cannot feed the paper correctly. Turn the product off and gently remove the paper. Then turn the product on and reload the paper correctly.

---

### Paper is not ejected fully or is wrinkled

- ❑ If the paper does not eject fully, press  $\diamond$  to eject the paper. If the paper is jammed inside the product, remove it by referring to the following section.  
➔ [“Paper Jams” on page 83](#)
- ❑ If the paper is wrinkled when it comes out, it may be damp or too thin. Load a new stack of paper.

**Note:**

*Store any unused paper in its original packaging in a dry area.*

---

## The Product Does Not Print

---

### All lights are off

- ❑ Press the  $\odot$  button to make sure the product is on.
- ❑ Make sure that the power cord is securely plugged in.
- ❑ Make sure that your outlet works and is not controlled by a wall switch or timer.

---

### Only the power light is on


- ❑ Turn off the product and computer. Make sure the product's interface cable is securely plugged in.
- ❑ If you are using the USB interface, make sure your cable meets the USB or Hi-Speed USB standards.

## Troubleshooting for Printing/Copying

- ❑ If you are connecting the product to your computer via a USB hub, connect the product to the first-tier hub from your computer. If the printer driver is still not recognized on your computer, try to directly connect the product to your computer without the USB hub.
- ❑ If you are connecting the product to your computer via a USB hub, make sure the USB hub device is recognized by your computer.
- ❑ If you are trying to print a large image, your computer may not have enough memory. Try reducing the resolution of your image or printing the image at a smaller size. You may need to install more memory in your computer.
- ❑ Users of Windows can clear any stalled print jobs from the Windows Spooler.
  - ➔ [“Canceling printing” on page 31](#)
- ❑ Uninstall the printer driver, then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)


## Increasing the Print Speed (For Windows Only)

Print speed may be increased by selecting certain settings in the Extended Settings window when the printing speed is slow. Click the **Extended Settings** button on your printer driver's Maintenance window.



## Troubleshooting for Printing/Copying

The following dialog box appears.



Select the following check boxes and print speed may be increased.

- High Speed Copies
- Always spool RAW datatype
- Page Rendering Mode
- Print as Bitmap

For more details on each item, see the online help.

## Other Problem

### Printing plain papers quietly

When plain paper is selected for the paper type and Standard (Windows) or Normal (Mac OS X) is selected as for quality in the printer driver, the product prints at high speed. Try choosing Quiet Mode for quieter operation which will reduce the print speed.

For Windows, select the Quiet Mode check box in the Main window of your printer driver.

For Mac OS X, select **On** from the Quiet Mode. To display the Quiet Mode, click through the following menus: **System Preferences, Print & Scan** (for Mac OS X 10.7) or **Print & Fax** (for Mac OS X 10.6 or 10.5), your product (in the Printers list box), **Options & Supplies**, and then **Driver**.

---

# Troubleshooting for Scanning

---

## Problems Indicated by Messages on the LCD Screen or Status Light

- ❑ Make sure the product is connected to your computer properly.
- ❑ Turn off the product and turn it on again. If the problem is not solved, the product may be malfunctioning, or the light source in the scanner unit may need to be replaced. Contact your dealer.
- ❑ Make sure the scanning software is fully installed.  
See the paper manual for instructions on installing the scanning software.

## Problems When Starting a Scan

- ❑ Check the status light and make sure the product is ready to scan.
- ❑ Make sure your cables are securely connected to the product and a working electrical outlet.  
If necessary, test your product's AC adapter by plugging in another electrical device and turning it on.
- ❑ Turn off the product and computer, and then check the interface cable connection between them to make sure it is secure.
- ❑ Make sure you select the correct product if a scanner list appears when starting to scan.

### Windows:

When you start Epson Scan using the EPSON Scan icon, and the Select Scanner list is displayed, make sure you select the model of your product.

### Mac OS X:

When you start Epson Scan from the Applications folder and the Select Scanner list is displayed, make sure you select the model of your product.

- ❑ Connect the product directly to the computer's external USB port or through one USB hub only. The product may not work properly when connected to the computer through more than one USB hub. If the problem persists, try connecting the product directly to the computer.
- ❑ If more than one product is connected to your computer, it may not work. Connect only the product you want to use, and then try scanning again.
- ❑ If the scanning software does not work properly, uninstall the software first and then reinstall it as described in the paper manual.  
➔ ["Uninstalling Your Software" on page 77](#)

---

## Using the Automatic Document Feeder (ADF)

- ❑ Check the ADF light and make sure the ADF is ready to scan.



## Troubleshooting for Scanning

- Make sure there are no originals on the scanner glass.
- If the document cover or ADF cover is open, close it and try scanning again.
- Make sure you have selected either **Office Mode** or **Professional Mode** in Epson Scan.
- Make sure your cables are securely connected to the product and a working electrical outlet.
- If the ADF light is on and your originals are not fed, check that there is no foreign object inside the hole on the left front corner of the scanner glass.

---

## Using the button

**Note:**

*Depending on the product, the scanning function may not be available when using the button.*

- Check if you have assigned a program to the button.
  - ➔ [“Epson Event Manager” on page 58](#)
- Make sure Epson Scan and Epson Event Manager are installed correctly.
- If you have clicked the **Keep Blocking** button in the Windows Security Alert window during or after installation of the Epson Software, unblock Epson Event Manager.
  - ➔ [“How to unblock Epson Event Manager” on page 97](#)
- Mac OS X:  
Make sure you are logged on as the user who installed the scanning software. Other users must first start Epson Scanner Monitor in the Applications folder and then press a button to scan.

## How to unblock Epson Event Manager

- 1** Click **Start** or the start button, and then point to **Control Panel**.
- 2** Do one of the following.
  - Windows 7:  
Select **System and Security**.
  - Windows Vista:  
Select **Security**.
  - Windows XP:  
Select **Security Center**.
- 3** Do one of the following.
  - Windows 7 and Windows Vista:  
Select **Allow a program through Windows Firewall**.
  - Windows XP:  
Select **Windows Firewall**.

## Troubleshooting for Scanning

**4**

Do one of the following.

- Windows 7:  
Confirm that the check box for **EEventManager Application** is selected in the Allowed programs and features list.
- Windows Vista:  
Click the **Exceptions** tab, and then confirm that the check box for **EEventManager Application** is selected in the Program or port list.
- Windows XP:  
Click the **Exceptions** tab, and then confirm that the check box for **EEventManager Application** is selected in the Programs and Services list.

**5**

Click OK.

---

## Using scanning software other than Epson Scan driver

- If you are using any TWAIN-compliant programs, such as Adobe Photoshop Elements, make sure that the correct product is selected as the Scanner or Source setting.
- If you cannot scan using any TWAIN-compliant scanning programs, such as Adobe Photoshop Elements, uninstall the TWAIN-compliant scanning program and then reinstall it.
  - ➔ [“Uninstalling Your Software” on page 77](#)

## Problems When Feeding Paper

---

### The paper gets dirty

You may need to clean the product.

- ➔ [“Cleaning the Product” on page 73](#)

---

### Multiple sheets of paper are fed

- If you load unsupported paper, the product may feed more than one sheet of paper at a time.
  - ➔ [“Automatic Document Feeder \(ADF\) specifications” on page 105](#)
- You may need to clean the product.
  - ➔ [“Cleaning the Product” on page 73](#)

---

### The paper jams in the Automatic Document Feeder (ADF)

Remove the jammed paper inside the ADF.

- ➔ [“Removing jammed paper from the Automatic Document Feeder \(ADF\)” on page 85](#)

## Problems With Scanning Time

- Computers with Hi-Speed external USB ports can scan faster than those with external USB ports. If you are using a Hi-Speed external USB port with your product, make sure it meets the system requirements.
  - ➔ [“System Requirements” on page 102](#)
- Scanning at a high resolution takes a long time.

## Problems With Scanned Images

---

### Scan quality is unsatisfactory

Scan quality can be improved by changing the current settings or adjusting the scanned image.

- ➔ [“Image Adjustment Features” on page 41](#)

### An image on the back of your original appears in your scanned image

If your original is printed on thin paper, images on the back may be visible to the product and appear in your scanned image. Try scanning the original with a piece of black paper placed on the back of it. Also make sure the Document Type and Image Type settings are correct for your original.

### Characters are distorted or blurred

- In Office Mode or Home Mode, select the **Text Enhancement** check box.
- Adjust the Threshold setting.

Home Mode:

Select **Black&White** as the Image Type setting, click the **Brightness** button, and then try adjusting the Threshold setting.

Office Mode:

Select **Black&White** as the Image Type setting, and then try adjusting the Threshold setting.

Professional Mode:

Select **Black & White** as the Image Type setting and click the + (Windows) or ► (Mac OS X) button next to **Image Type**. Make the appropriate Image Option setting and then try adjusting the Threshold setting.

- Increase the resolution setting.


### Characters are not recognized correctly when converted into editable text (OCR)

Place the document so that it is straight on the scanner glass. If the document is skewed, it may not be recognized correctly.

## Troubleshooting for Scanning

### Ripple patterns appear in your scanned image

A ripple or cross-hatch pattern (known as moiré) may appear in a scanned image of a printed document.



- Rotate your original document.
- Rotate the scanned image using the application software after scanning.
- Select the **Descreening** check box.
- In Professional Mode, change a resolution setting and scan again.

### Uneven color, smears, dots, or straight lines appear in your image

You may need to clean the interior of the product.


➔ [“Cleaning the Product” on page 73](#)

---

## The scanning area or direction is unsatisfactory

### The edges of your original are not scanned


- If you are scanning using thumbnail preview in Home Mode or Professional Mode, move the document or photo 6 mm (0.2 inch) away from the horizontal and vertical edges of the scanner glass to avoid cropping.
- If you are scanning using the button or using normal preview in Office Mode, Home Mode, or Professional Mode, move the document or photo about 3 mm (0.12 inch) away from the horizontal and vertical edges of the scanner glass to avoid cropping.



## Troubleshooting for Scanning

### Multiple documents are scanned into a single file

Position documents at least 20 mm (0.8 inch) apart from each other on the scanner glass.



### Cannot scan the area you want

Depending on the documents, you may not be able to scan the area you want. Use normal preview in Office Mode, Home Mode, or Professional Mode and create marquees on the area you want to scan.

### Cannot scan in the direction you want

Click **Configuration**, select the **Preview** tab, and then clear the **Auto Photo Orientation** check box. Then, place your documents correctly.

## Problems Remain After Trying All Solutions

If you have tried all the solutions and have not solved the problem, initialize the Epson Scan settings.

Click **Configuration**, select the **Other** tab, and then click **Reset All**.

---

# Product Information

---

## Ink Bottles

You can use the following ink bottles with this product:

Ink bottles	Part numbers
Black	T7741



**Important:**

*Genuine Epson ink, other than those specified here, could cause damage that is not covered by Epson's warranties.*

<b>Color</b>	Black
<b>Ink bottle life</b>	For best results, use up ink within six months after removing a seal from ink bottle.
<b>Temperature</b>	Storage: -20 to 40 °C (-4 to 104 °F) 1 month at 40 °C (104 °F) Freezing: * -15 °C (5.0 °F)

\* Ink thaws and is usable after approximately 3 hours at 25 °C (77 °F).

## System Requirements

---

### For Windows

System	PC Interface
Windows 7 (32-bit, 64-bit), Vista (32-bit, 64-bit), XP SP1 or higher(32-bit), or XP Professional x64 Edition	Hi-Speed USB

---

### For Mac OS X

System	PC Interface
Mac OS X 10.5.8 or later	Hi-Speed USB

**Note:**

*The UNIX File System (UFS) for Mac OS X is not supported.*

# Technical Specifications

**Note:**

Specifications are subject to change without notice.

## Printer specifications

<b>Paper path</b>	Rear paper feed, top entry
<b>Capacity</b>	11 mm (0.4in.)

## Paper

**Note:**

- Since the quality of any particular brand or type of paper may be changed by the manufacturer at any time, Epson cannot attest to the quality of any non-Epson brand or type of paper. Always test samples of paper stock before purchasing large quantities or printing large jobs.
- Poor quality paper may reduce print quality and cause paper jams or other problems. If you encounter problems, switch to a higher grade of paper.

*Single sheets:*

<b>Size</b>	A4 210 × 297 mm 10 × 15 cm (4 × 6 in.) 13 × 18 cm (5 × 7 in.) A6 105 × 148 mm A5 148 × 210 mm B5 182 × 257 mm 9 × 13 cm (3.5 × 5 in.) 13 × 20 cm (5 × 8 in.) 20 × 25 cm (8 × 10 in.) 16:9 wide size (102 × 181 mm) 100 × 148 mm Letter 8 1/2 × 11 in. Legal 8 1/2 × 14 in.
<b>Paper types</b>	Plain paper or special paper distributed by Epson
<b>Thickness (for plain paper)</b>	0.08 to 0.11 mm (0.003 to 0.004 in.)
<b>Weight (for plain paper)</b>	64 g/m <sup>2</sup> (17 lb) to 90 g/m <sup>2</sup> (24 lb)


*Envelopes:*

**Product Information**

<b>Size</b>	Envelope #10 4 1/8 × 9 1/2 in. Envelope DL 110 × 220 mm Envelope C6 114 × 162 mm
<b>Paper types</b>	Plain paper
<b>Weight</b>	75 g/m <sup>2</sup> (20 lb) to 90 g/m <sup>2</sup> (24 lb)

**Printable area**

Highlighted portions show printable area.



Media type	Minimum margin	
	Single sheets	Envelopes
A	3.0 mm (0.12 in.)	3.0 mm (0.12 in.)
B	3.0 mm (0.12 in.)	5.0 mm (0.20 in.)
C	3.0 mm (0.12 in.)	21.0 mm (0.83 in.)

**Note:**  
Depending on the type of paper, print quality may decline in the top and bottom areas of the print, or the area may be smeared.

**Scanner specifications**

Scanner type	Flatbed color
Photoelectric device	CIS
Effective pixels	10200 × 14040 pixels at 1200 dpi Scanning area may be restricted if resolution setting is large.



## Product Information

Document size	216 × 297 mm (8.5 × 11.7 inches) A4 or US letter size
Scanning resolution	1200 dpi (main scan) 2400 dpi (sub scan)
Output resolution	50 to 4800, 7200, and 9600 dpi (50 to 4800 dpi in 1 dpi increments)
Image data	16 bits per pixel per color internal 8 bits per pixel per color external (maximum)
Light source	LED

## Automatic Document Feeder (ADF) specifications

Paper input	Face-up loading
Paper output	Face-down ejection
Paper size	A4, Letter, Legal
Paper types	Plain paper
Paper weight	64 to 95 g/m <sup>2</sup>
Paper capacity	Total thickness of 3 mm, up to about 30 sheets (Letter, A4) 10 sheets (Legal)

## Network interface specification

Wi-Fi* <sup>1</sup>	Standard:	IEEE 802.11b/g/n* <sup>2</sup>
	Security:	WEP (64/128bit) WPA-PSK (TKIP/AES) * <sup>3</sup>
	Frequency Band:	2.4 GHz
	Communication Mode:	Infrastructure, Ad hoc
Ethernet* <sup>1</sup>	Standard:	IEEE802.3i/u, IEEE802.3az* <sup>4</sup>
	Communication Mode:	Ethernet 100BASE-TX/10BASE-T

\*1 The availability of this feature varies by product.

\*2 Complies with either IEEE 802.11b/g/n or IEEE 802.11b/g depending on location of purchase.

\*3 Complies with WPA2 with support for WPA/WPA2 Personal.

\*4 The connected device should comply with IEEE802.3az.

## Mechanical

	<b>M200</b>	<b>M205</b>
--	-------------	-------------

## Product Information

<b>Dimensions</b>	Storage	
	Width: 435 mm (17.1 inches) Depth: 377 mm (14.8 inches) Height: 226 mm (8.9 inches)	
<b>Weight</b>	Printing* <sup>1</sup>	
	Width: 435 mm (17.1 inches) Depth: 540 mm (21.3 inches) Height: 291 mm (11.5 inches)	
	Approx. 6.0 kg (13.2 lb) * <sup>2</sup>	Approx. 6.0 kg (13.2 lb) * <sup>2</sup>

\*1 With the output tray extension extended.

\*2 Without the ink and the power cord.

---

## Electrical

### M200

		100-240 V Model
<b>Input voltage range</b>		90 to 264 V
<b>Rated frequency range</b>		50 to 60 Hz
<b>Input frequency range</b>		49.5 to 60.5 Hz
<b>Rated current</b>		0.5 to 0.3 A
<b>Power consumption</b>	<b>Standalone copying</b>	Approx. 10 W (ISO/IEC24712)
	<b>Ready mode</b>	Approx. 4.0 W
	<b>Sleep mode</b>	Approx. 1.8 W
	<b>Power off</b>	Approx. 0.3 W

### M205

		100-240 V Model
<b>Input voltage range</b>		90 to 264 V
<b>Rated frequency range</b>		50 to 60 Hz
<b>Input frequency range</b>		49.5 to 60.5 Hz
<b>Rated current</b>		0.5 to 0.3 A
<b>Power consumption</b>	<b>Standalone copying</b>	Approx. 10 W (ISO/IEC24712)
	<b>Ready mode</b>	Approx. 4.5 W
	<b>Sleep mode</b>	Approx. 2.2 W
	<b>Power off</b>	Approx. 0.3 W

## Product Information

**Note:**  
Check the label on the back of the product for its voltage.

---

## Environmental

<b>Temperature</b>	Operation: 10 to 35 °C (50 to 95 °F)  Storage: -20 to 40 °C (-4 to 104 °F)  1 month at 40 °C (104 °F)
<b>Humidity</b>	Operation:* 20 to 80% RH  Storage:* 5 to 85% RH

\* Without condensation

---

## Standards and approvals

European model:

For M200

<b>Low voltage directive 2006/95/EC</b>	EN60950-1
<b>EMC directive 2004/108/EC</b>	EN55022 Class B EN61000-3-2 EN61000-3-3 EN55024

---

## Interface

Hi-Speed USB (Device Class for computers)

---

# Where To Get Help

---

## Technical Support Web Site

Epson's Technical Support Web Site provides help with problems that cannot be solved using the troubleshooting information in your product documentation. If you have a Web browser and can connect to the Internet, access the site at:

<http://support.epson.net/>  
<http://www.epson.eu/Support> (Europe)

If you need the latest drivers, FAQs, manuals, or other downloadables, access the site at:

<http://www.epson.com>  
<http://www.epson.eu/Support> (Europe)

Then, select the support section of your local Epson Web site.

## Contacting Epson Support

---

### Before Contacting Epson

If your Epson product is not operating properly and you cannot solve the problem using the troubleshooting information in your product documentation, contact Epson support services for assistance. If Epson support for your area is not listed below, contact the dealer where you purchased your product.

Epson support will be able to help you much more quickly if you give them the following information:

- Product serial number  
(The serial number label is usually on the back of the product.)
- Product model
- Product software version  
(Click **About**, **Version Info**, or similar button in the product software.)
- Brand and model of your computer
- Your computer operating system name and version
- Names and versions of the software applications you normally use with your product
- Number of sheets of paper fed
  - ➔ [“Checking the Number of Sheets of Paper Fed” on page 73](#)

## Where To Get Help

**Note:**

*Depending on the product, the dial list data for fax and/or network settings may be stored in the product's memory. Due to breakdown or repair of a product, data and/or settings may be lost. Epson shall not be responsible for the loss of any data, for backing up or recovering data and/or settings even during a warranty period. We recommend that you make your own backup data or take notes.*

---

### Help for Users in Europe

Check your **Pan-European Warranty Document** for information on how to contact Epson support.

---

### Help for Users in Thailand

Contacts for information, support, and services are:

#### **World Wide Web (<http://www.epson.co.th>)**

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and e-mail are available.

#### **Epson Hotline (Phone: (66)2685-9899)**

Our Hotline team can help you with the following over the phone:

- Sales enquiries and product information
- Product usage questions or problems
- Enquiries on repair service and warranty

---

### Help for Users in Vietnam

Contacts for information, support, and services are:

Epson Hotline (Phone): 84-8-823-9239

Service Center: 80 Truong Dinh Street, District 1, Hochiminh City  
Vietnam

---

### Help for Users in Indonesia

Contacts for information, support, and services are:

#### **World Wide Web (<http://www.epson.co.id>)**

- Information on product specifications, drivers for download
- Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

**Where To Get Help****Epson Hotline**

Sales enquiries and product information

Technical support

Phone (62) 21-572 4350

Fax (62) 21-572 4357

**Epson Service Center**

Jakarta Mangga Dua Mall 3rd floor No 3A/B  
Jl. Arteri Mangga Dua,  
Jakarta

Phone/Fax: (62) 21-62301104

Bandung Lippo Center 8th floor  
Jl. Gatot Subroto No.2  
Bandung

Phone/Fax: (62) 22-7303766

Surabaya Hitech Mall Lt IIB No. 12  
Jl. Kusuma Bangsa 116 – 118  
Surabaya

Phone: (62) 31-5355035

Fax: (62)31-5477837

Yogyakarta Hotel Natour Garuda  
Jl. Malioboro No. 60  
Yogyakarta

Phone: (62) 274-565478

Medan Wisma HSBC 4th floor  
Jl. Diponegoro No. 11  
Medan

Phone/Fax: (62) 61-4516173

Makassar MTC Karebosi Lt. III Kav. P7-8  
Jl. Ahmad Yani No.49  
Makassar

Phone: (62)411-350147/411-350148

---

## Help for Users in Hong Kong

To obtain technical support as well as other after-sales services, users are welcome to contact Epson Hong Kong Limited.

### Internet Home Page

Epson Hong Kong has established a local home page in both Chinese and English on the Internet to provide users with the following information:

- Product information
- Answers to Frequently Asked Questions (FAQs)
- Latest versions of Epson product drivers

Users can access our World Wide Web home page at:

<http://www.epson.com.hk>

### Technical Support Hotline

You can also contact our technical staff at the following telephone and fax numbers:

Phone: (852) 2827-8911

Fax: (852) 2827-4383

---

## Help for Users in Malaysia

Contacts for information, support, and services are:

### World Wide Web (<http://www.epson.com.my>)

- Information on product specifications, drivers for download
- Frequently Asked Questions (FAQ), Sales Enquiries, questions through e-mail

### Epson Trading (M) Sdn. Bhd.

Head Office.

Phone: 603-56288288

Fax: 603-56288388/399

## Where To Get Help

### ***Epson Helpdesk***

- Sales enquiries and product information (Infoline)

Phone: 603-56288222

- Enquiries on repair services & warranty, product usage and technical support (Techline)

Phone: 603-56288333

---

## **Help for Users in India**

Contacts for information, support, and services are:

**World Wide Web (<http://www.epson.co.in>)**

Information on product specifications, drivers for download, and products enquiry are available.



**Where To Get Help****Epson India Head Office - Bangalore**

Phone: 080-30515000

Fax: 30515005

**Epson India Regional Offices:**

Location	Telephone number	Fax number
Mumbai	022-28261515 /16/17	022-28257287
Delhi	011-30615000	011-30615005
Chennai	044-30277500	044-30277575
Kolkata	033-22831589 / 90	033-22831591
Hyderabad	040-66331738/ 39	040-66328633
Cochin	0484-2357950	0484-2357950
Coimbatore	0422-2380002	NA
Pune	020-30286000 /30286001/30286002	020-30286000
Ahmedabad	079-26407176 / 77	079-26407347

**Helpline**

For Service, Product info or to order a cartridge - 18004250011 (9AM - 9PM) - This is a Toll-free number.

For Service (CDMA & Mobile Users) - 3900 1600 (9AM - 6PM) Prefix local STD code

---

**Help for Users in the Philippines**

To obtain technical support as well as other after sales services, users are welcome to contact the Epson Philippines Corporation at the telephone and fax numbers and e-mail address below:

Trunk Line: (63-2) 706 2609

Fax: (63-2) 706 2665

Helpdesk Direct Line: (63-2) 706 2625

E-mail: [epchelpdesk@epc.epson.com.ph](mailto:epchelpdesk@epc.epson.com.ph)

**World Wide Web** (<http://www.epson.com.ph>)

Information on product specifications, drivers for download, Frequently Asked Questions (FAQ), and E-mail Enquiries are available.

**Toll-Free No. 1800-1069-EPSON(37766)**

## Where To Get Help

Our Hotline team can help you with the following over the phone:

- Sales enquiries and product information
- Product usage questions or problems
- Enquiries on repair service and warranty

**Index****2**

2-Sided.....	53
2-sided printing.....	33

**A**

Aligning print head.....	68
Automatic Document Feeder (ADF).....	21
paper jams in.....	85, 98
problems.....	98

**B**

Banding.....	88
Blank pages.....	91
Blurry prints.....	89

**C**

Canceling printing.....	31
Mac OS X.....	32
Windows.....	31
Cleaning	
print head.....	67
product.....	73
Contacting Epson.....	108
Copying	
basic.....	25
Copyright.....	2

**D**

Documents	
printing.....	28
Driver.....	57
accessing for Mac OS X.....	27
accessing for Windows.....	26
uninstalling.....	77

**E**

Enlarging pages.....	34
Envelopes	
loading.....	19
printable area.....	104
Epson	
paper.....	17
Epson Event Manager.....	58
Error messages.....	80
Errors	
copy.....	91
print.....	81
scan.....	96

**F**

Fit to page printing.....	34
---------------------------	----

**H**

Head cleaning	
control panel.....	68
Mac OS X.....	67
Windows.....	67
Help	
Epson.....	108
Epson Event Manager.....	58
Epson Scan.....	57
Home Mode.....	44
Horizontal banding.....	88

**I**

Image Adjustment.....	41
Incorrect characters.....	90
Initialize.....	101
Ink	
precaution.....	61
Ink bottles	
part numbers.....	102
Interface cables.....	107

**L**

Lights	
status lights.....	96
Loading	
paper.....	17, 19

**M**

Mac OS X	
accessing printer settings.....	27
checking product status.....	82
Managing print jobs	
Windows.....	81
Margins	
problems.....	90
Marquee.....	51
Mirror image.....	91
Misalignment.....	88
Multiple pages per sheet.....	35

**N**

Nozzle check.....	65
control panel.....	66
Mac OS X.....	65

## Index

Windows.....	65	accessing for Mac OS X.....	27
		accessing for Windows.....	26
<b>O</b>		Power Off Timer.....	72
Office Mode.....	46	Sleep Timer.....	72
		Professional Mode.....	48
<b>P</b>		<b>R</b>	
Pages per sheet printing.....	35	Reducing page size.....	34
Paper		Refilling the ink tank.....	62
Epson special paper.....	17	Resizing pages.....	34
feeding problems.....	92	Restrictions on copying.....	11
jams.....	83	<b>S</b>	
loading.....	19	Safety information.....	9
loading capacity.....	17	Saving energy.....	72
printable area.....	104	Scan quality problems.....	99
specifications.....	103	Scanner glass.....	23
wrinkling.....	93	Scanning software	
Paper jam.....	83, 98	bundle software.....	58
PDF.....	53	Service.....	108
Previewing.....	50	Sharing printer	
Print head		Mac OS X.....	38
aligning.....	68	Windows.....	36
checking.....	65	Smeared prints.....	89, 91
cleaning.....	67	Software	
Print quality		uninstalling.....	77
improving.....	87	Specifications	
Print speed		automatic document feeder.....	105
increasing.....	92, 94	ink bottles.....	102
Printable area specifications.....	104	mechanical.....	105
Printing		paper.....	103
2-sided.....	33	printer.....	103
canceling.....	31	scanner.....	104
fit to page.....	34	standards and approvals.....	107
multiple pages per sheet.....	35	Speed	
preset.....	32	increasing.....	92, 94
shortcut.....	32	Status lights.....	96
text.....	28	Status Monitor	
Problems		Mac OS X.....	82
banding.....	88	System requirements.....	102
blank pages.....	91	<b>T</b>	
blurry prints.....	89	Technical support.....	108
contacting Epson.....	108	Text	
diagnosing.....	81	printing documents.....	28
incorrect characters.....	90	Trademarks.....	2
margins.....	90	Transporting product.....	75
mirror image.....	91	<b>U</b>	
paper feeding.....	92	USB	
paper jams.....	83	connector.....	107
print.....	81	<b>W</b>	
print speed.....	92	Windows	
product does not print.....	93		
scan.....	96		
smeared prints.....	89, 91		
solving.....	108		
Product			
checking status.....	81		
cleaning.....	73		
parts.....	13		
transporting.....	75		
Product settings			

**Index**

accessing printer settings.....	26
checking product status.....	81
managing print jobs.....	81