Microwave Oven

User manual

MS32J5133A*



MS32J5133AT_TC_DE68-04345J-00_EN.indd 1 2015-09-14 III 4:08:08

Contents

Using this user manual	3
The following symbols are used in this user manual:	3
Safety instructions	3
Important safety instructions	3
Installation	8
What's included	8
Installation site	9
Turntable	9
Maintenance	10
Cleaning	10
Replacement (repair)	10
Care against an extended period of disuse	10
Before you start	11
Current time	11
Power saving	11
Child Lock	11
Sound On/Off	11
Kitchen timer	11
About microwave energy	12
Cookware for microwave	12

Operations	13
Feature panel	13
Simple steps to start	14
Manual mode	14
Common settings	15
Auto mode	16
Convenience	20
Deodorisation	22
Cooking smart	23
Microwave cooking guide	23
Reheating guide	24
Defrosting guide	25
Quick & Easy	26
Troubleshooting	27
Checkpoints	27
information code	30
Technical specifications	30

2 English -

Using this user manual

You have just purchased a SAMSUNG microwave oven. Your Owner's Instructions contains valuable information on cooking with your microwave oven:

- Safety precautions
- Suitable accessories and cookware
- Useful cooking tips
- Cooking tips

The following symbols are used in this User Manual:

WARNING

Hazards or unsafe practices that may result in severe personal injury or death.

⚠ CAUTION

Hazards or unsafe practices that may result in **minor personal injury or property damage**.

NOTE

Useful tips, recommendations, or information that helps users manipulate the product.

Safety instructions

IMPORTANT SAFETY INSTRUCTIONS

READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

MAKE SURE THAT THESE SAFETY PRECAUTIONS ARE OBEYED AT ALL TIMES.

BEFORE USING THE OVEN, CONFIRM THAT THE FOLLOWING INSTRUCTIONS ARE FOLLOWED.

Microwave function only

WARNING: If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person.

WARNING: It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy.

WARNING: Liquids and other foods must not be heated in sealed containers since they are liable to explode.

This appliance is intended to be used in household only and it is not intended to be used such as:

- staff kitchen areas in shops, offices and other working environments;
- farm houses;
- by clients in hotels, motels and other residential environments;
- bed and breakfast type environments.

Safety instructions

WARNING: Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.

WARNING: This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children unless they are aged from 8 years and above and supervised.

Only use utensils that are suitable for use in microwave ovens. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition.

The microwave oven is intended for heating food and beverages. Drying of food or clothing and heating of warming pads, slippers, sponges, damp cloth and similar may lead to risk of injury, ignition or fire.

If smoke is emitted (observed), switch off or unplug the appliance and keep the door closed in order to stifle any flames.

WARNING: Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container.

WARNING: The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burns.

Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended.

The oven should be cleaned regularly and any food deposits removed.

Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation.

The appliance is not intended for installing in road vehicles, caravans and similar vehicles etc.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

The appliance should not be cleaned with a water jet.

This oven should be positioned proper direction and height permitting easy access to cavity and control area.

Before using the your oven first time, oven should be operated with the water during 10 minute and then used.

If the oven generates a strange noise, a burning smell, or smoke is emitted, unplug the power plug immediately and contact your nearest service center.

The microwave oven has to be positioned so that plug is accessible.

The microwave oven is intended to be used on the counter top (freestanding) use only, the microwave oven shall not be placed in a cabinet.

Oven function only - Optional

WARNING: When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.

During use the appliance becomes hot. Care should be taken to avoid touching heating elements inside the oven.

WARNING: Accessible parts may become hot during use. Young children should be kept away.

A steam cleaner is not to be used.

WARNING: Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.

Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass.

WARNING: The appliance and its accessible parts become hot during use.

Care should be taken to avoid touching heating elements.

Children less than 8 years of age shall be kept away unless continuously supervised.

Safety instructions

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

The temperature of accessible surfaces may be high when the appliance is operating.

The door or the outer surface may get hot when the appliance is operating.

Keep the appliance and its cord out of reach of children less than 8 years.

Appliances are not intended to be operated by means of an external timer or separate remote-control system.

General safety

WARNING

Only qualified staff should be allowed to modify or repair the appliance. Do not heat liquids and other food in sealed containers for microwave function. For your safety, do not use high-pressure water cleaners or steam jet cleaners. Do not install this appliance; near heater, inflammable material; in a humid, oily or dusty location, in a location exposed to direct sunlight and water or where gas may leak; on un level ground.

This appliance must be properly grounded in accordance with local and national codes.

Remove all foreign substances such as dust or water from the power plug terminals and contact points using a dry cloth on a regular basis.

Do not pull or excessively bend or place heavy objecton the power cord.

In the event of a gas leak (such as propane gas, LP gas, etc.), ventilate immediately without touching the power plug.

Do not touch the power plug with wet hands.

Do not turn the appliance off by unplugging the power plug while an operation is in progress.

Do not insert fingers or foreign substances, If any foreign substance such as water has entered the appliance, unplug the power plug and contact your nearest service centre.

Do not apply excessive pressure or impact to the appliance.

Do not place the oven over a fragile object such as a sink or glass object.

Do not use benzene, thinner, alcohol, steam cleaner or high pressure cleaner to clean the appliance.

Ensure that the power voltage, frequency and current are the same as those of the product specifications.

Plug the power plug into the wall socket firmly. Do not use a multiple plug adapter, an extension cord or an electric transformer.

Do not hook the power cord on a metal object, insert the power cord between the objects or behind the oven.

Do not use a damaged power plug, damaged power cord or loose wall socket. When the power plug or power cord is damaged, contact your nearest service centre.

Do not pour or directly spray water onto the oven.

Do not place objects on the oven, inside or on the door of the oven.

Do not spray volatile material such as insecticide onto the surface of the oven.

Do not store flammable materials in the oven. Take special care when heating dishes or drinks that contain alcohol as alcohol vapours may contact a hot part of the oven.

Keep children away from the door when opening or closing it as they may bump themselves on the door or catch their fingers in the door.

WARNING: Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container; To prevent this situation ALWAYS allow a standing time of at least 20 seconds after the oven has been switched off so that the temperature can equalize. Stir during heating, if necessary, and ALWAYS stir after heating.

In the event of scalding, follow these FIRST AID instructions:

- Immerse the scalded area in cold water for at least 10 minutes.
- · Cover with a clean, dry dressing.
- Do not apply any creams, oils or lotions.

Do not put the tray or rack in water shortly after cooking because it may cause breakage or damage of the tray or rack.

Do not operate the microwave oven for deep fat frying because the oil temperature cannot be controlled. This could result in a sudden boil over of the hot liquid.

↑ CAUTION

Only use utensils that are suitable for use in microwave ovens; DO NOT use any metallic containers, Dinnerware with gold or silver trimmings, Skewers, forks, etc.

Remove wire twist ties from paper or plastic bags.

Reason: Electric arcing or sparking may occur and may damage the oven.

Do not use your microwave oven to dry papers or clothes.

Use shorter times for smaller amounts of food to prevent overheating and burning food.

Do not immerse the power cable or power plug in water and keep the power cable away from heat.

Eggs in their shell and whole hard-boiled eggs should not be heated in microwave ovens since they may explode, even after microwave heating has ended; Also do not heat airtight or vacuum-sealed bottles, jars, containers, nuts inshells, tomatoes etc.

Do not cover the ventilation slots with cloth or paper. They may catch fire as hot air escapes from the oven. The oven may also overheat and switch itself off automatically, and will remain off until it cools sufficiently.

Always use oven mitts when removing a dish from the oven to avoid unintentional burns.

Stir liquids halfway during heating or after heating ends and allow the liquid stand at least 20 seconds after heating to prevent eruptive boiling.

Stand at arms length from the oven when opening the door to avoid getting scalded by escaping hot air or steam.

Do not operate the microwave oven when it is empty. The microwave oven will automatically shut down for 30 minutes for safety purposes. We recommend placing a glass of water inside the oven at all times to absorb microwave energy in case the microwave oven is started accidentally.

Install the oven in compliance with the clearances stated in this manual. (See installing your microwave oven.)

Take care when connecting other electrical appliances to sockets near the oven.

Precautions to avoid possible exposure to excessive microwave energy. (Microwave function only)

Failure to observe the following safety precautions may result in harmful exposure to microwave energy.

- **A.** Under no circumstances should any attempt be made to operate the oven with the door open or to tamper with the safety interlocks (door latches) or to insert anything into the safety interlock holes.
- **B.** Do NOT place any object between the oven door and front face or allow food or cleaner residues to accumulate on sealing surfaces. Ensure that the door and door sealing surfaces are kept clean by wiping after use first with a damp cloth and then with a soft dry cloth.
- **C.** Do NOT operate the oven if it is damaged until it has been repaired by a qualified microwave service technician trained by the manufacturer. It is particularly important that the oven door closes properly and that there is no damage to the:
 - 1) door (bent)
 - 2) door hinges (broken or loose)
 - **3)** door seals and sealing surfaces
- **D.** The oven should not be adjusted or repaired by anyone other than a properly qualified microwave service technician trained by the manufacturer.

Safety instructions

Samsung will charge a repair fee for replacing an accessory or repairing a cosmetic defect if the damage to the unit and/or damage to or loss of the accessory was caused by the customer. Items this stipulation covers include:

- **A.** A dented, scratched, or broken door, handle, out-panel, or control panel.
- **B.** A broken or missing tray, guide roller, coupler, or wire rack.
 - Use this appliance only for its intended purpose as described in this
 instruction manual. Warnings and Important Safety Instructions in this
 manual do not cover all possible conditions and situations that may occur.
 It is your responsibility to use common sense, caution, and care when
 installing, maintaining, and operating your appliance.
 - Because these following operating instructions cover various models, the characteristics of your microwave oven may differ slightly from those described in this manual and not all warning signs may be applicable. If you have any questions or concerns, contact your nearest service centre or find help and information online at www.samsung.com.
 - This microwave oven is supposed for heating food. It is intended for domestic home-use only. Do not heat any type of textiles or cushions filled with grains, which could cause burns and fire. The manufacturer cannot be held liable for damage caused by improper or incorrect use of the appliance.
 - Failure to maintain the oven in a clean condition could lead to deterioration
 of the surface that could adversely affect the life of the appliance and
 possible result in a hazardous situation.

Please recycle or dispose of the packaging material for this product in an environmentally responsible manner. Please contact your local authorities in regard to the environmentally safe disposal of this product.


Product and its cord in compliance with SASO/IEC tropical temp.rise requirements, and, cross section is the only discrepancy, and it won't affect safety, meanwhile, it is not practical to change the power cord, e.g. too small chamber.

Installation

What's included

Make sure all parts and accessories are included in the product package. If you have a problem with the oven or accessories, contact a local Samsung customer centre or the retailer.

Oven at a glance



01 Door

02 Vent


03 Oven light

- **04** Display
- **05** Coupler
- **06** Open (door)

07 Feature panel

Accessories

The oven comes with different accessories that help you prepare different types of food.




Roller ring	Put in the centre of the base. It supports the turntable.
Turntable	Put on the roller ring with the centre fitting the coupler. It serves as a cooking base.

NOTE

• Do not operate the oven without the turntable on the roller ring.


Installation site



- **01** 85 cm from the floor
- **02** 10 cm from the rear wall
- **03** 10 cm from the side
- **04** 20 cm from above

- Select a flat, level surface approx. 85 cm above the floor. The surface must support the weight of the oven.
- Secure room for ventilation, at least 10 cm from the rear wall and both sides, and 20 cm from above.
- Do not install the oven in hot or damp surroundings, such as next to other microwave ovens or radiators.
- Conform to the power supply specifications of this oven. Use only approved extension cables if you need to use.
- Wipe the interior and the door seal with a damp cloth before using your oven for the first time.

Turntable



Remove all packing materials inside the oven.Install the roller ring and turntable. Check that the turntable rotates freely.

Maintenance

Cleaning


Clean the oven regularly to prevent impurities from building up on or inside the oven. Also pay special attention to the door, door sealing, and turntable and roller ring (applicable models only).

If the door won't open or close smoothly, first check if the door seals have built up impurities. Use a soft cloth in soapy water to clean both the inner and outer sides of the oven. Rinse and dry well.

To remove stubborn impurities with bad smells from inside the oven

- With an empty oven, put a cup of diluted lemon juice on the centre of the turntable.
- **2.** Heat the oven for 10 minutes at max power.
- **3.** When the cycle is complete, wait until the oven cools down. Then, open the door and clean the cooking chamber.

To clean inside swing-heater models



To clean the upper area of the cooking chamber, lower the top heating element by 45° (A) as shown. This will help clean the upper area. When done, reposition the top heating element.

⚠ CAUTION

- Keep the door and door sealing clean and ensure the door opens and closes smoothly. Otherwise, the oven's lifecycle may be shortened.
- Take caution not to spill water into the oven vents.
- Do not use any abrasive or chemical substances for cleaning.
- After each use of the oven, use a mild detergent to clean the cooking chamber after waiting for the oven to cool down.

Replacement (repair)

▲ WARNING

This oven has no user-removable parts inside. Do not try to replace or repair the oven yourself.

- If you encounter a problem with hinges, sealing, and/or the door, contact a
 qualified technician or a local Samsung service centre for technical assistance.
- If you want to replace the light bulb, contact a local Samsung service centre.
 Do not replace it yourself.
- If you encounter a problem with the outer housing of the oven, first unplug
 the power cord from the power source, and then contact a local Samsung
 service centre.

Care against an extended period of disuse

If you don't use the oven for an extended period of time, unplug the power cord and move the oven to a dry, dust-free location. Dust and moisture that builds up inside the oven may affect the performance of the oven.


10 English -

Before you start

There is some basic information that you should know before going directly to a cooking recipe. Before or during any cooking mode, you can set/change the clock or the kitchen timer to your needs.

Current time

It is important to set the correct clock time to ensure correct automatic operations. The time can be displayed in either the 24- hour (default) or 12-hour notation. You must set the clock.



To display the time in the 12-hour / 24-hour notation.


- **1.** Press the **Clock** button and the **0** button at the same time for 1 second.
- **2.** Time setting that you want to change (12Hr or 24Hr) will be displayed.
- **3.** If you want to change the notation again, press the **Number** buttons. For example, press 1 for 12Hr or press 2 for 24 Hr notation.
- **4.** Press the **START** button to confirm your setting.

To set the current time,

- Press Clock.
- 2. Use the number buttons to enter the current time. For example, press 5, 0, and 0 in sequence for 5:00 o'clock.
- Press START to confirm your settings. Then, the colon (:) indicator blinks several times.

Power saving

To reduce power consumption when not using the oven, use the power saving function of the oven.



- To activate power saving, press **Eco** to turn off the display.
- To deactivate power saving, open the door or press **Eco** again. The display turns back on with the current time.

Auto power saving

- After 25 minutes of user inactivity, the oven automatically enters power saving mode. Any previous function will be cancelled, and the current time will be displayed.
- After 5 minutes of the door being open, the oven lamp will turn off.

Child Lock



To prevent accidents, Child Lock disables all controls except for the Eco button.
Hold down **STOP/CANCEL** for 3 seconds to

activate, or hold down for 3 seconds to deactivate the lock on the feature panel.


Sound On/Off



You can mute or unmute the beep or melody of the oven.

- To mute the sound, press Sound to show "OFF" on the display. Then, press START.
- To unmute the sound, press **Sound** again to show "ON" on the display. Then, press **START**.

Kitchen timer




- 1. Press Kitchen Timer.
- **2.** Use the **Number** buttons to set the time for your cooking.
- 3. Press START.

Before you start

About microwave energy

Microwaves are high-frequency electromagnetic waves. The oven uses the prebuilt magnetron to generate microwaves which are used to cook or reheat food without deforming or discolouring the food.



- The microwaves generated by the magnetron are distributed uniformly through the whirling distribution system. This is why the food is cooked evenly.
- The microwaves are absorbed down to the food up to a depth of approx.
 2.5 cm. Then, the microwaves are dissipated inside the food as cooking continues.
- **3.** The cooking time is affected by the following conditions of the food.
 - Quantity and density
 - Moisture content
 - Initial temperature (especially, when frozen)

■ NOTE

The cooked food keeps heat in its core after cooking is complete. This is why you must respect the standing time specified in this manual, which ensures cooking evenly down to the core.

Cookware for microwave

Cookware used for Microwave Mode must allow microwaves to pass through and penetrate food. Metals such as stainless steel, aluminum and copper reflect microwaves. Therefore, do not use cookware made of metallic materials. Cookware marked microwave - safe is always safe for use. For additional information on appropriate cookware refer to the following guide and place a glass of water or some food on the turntable.

Requirements:

- Flat bottom and straight sides
- · Tight-fitting lid
- Well-balanced pan with handles that weigh less than the main pan

Material		Material Microwave-safe	
Aluminium foil		Δ	Use for a small serving size to protect against overcooking. Arcing can occur if the foil is near the oven wall or if using an excessive amount of foil.
Crusty plate	e	0	Do not use for preheating for more than 8 minutes.
Bone china	Bone china or earthenware		Porcelain, pottery, glazed earthenware and bone china are usually microwave-safe, unless decorated with a metal trim.
	Disposable polyester cardboard dishes		Some frozen foods are packaged in these dishes.
	Polystyrene cups or containers		Overheating may cause these to melt.
Fast-food packaging	Paper bags or newspaper	×	These may catch fire.
	Recycled paper or metal trims	×	These may cause arcing

		Microwave-safe	Description
	Oven-to-table ware	O	Microwave-safe unless decorated with metal trims.
Glassware	Fine glassware	0	Delicate glassware may break or crack by rapid heating.
	Glass jars	0	Appropriate for warming only. Remove the lid before cooking.
	Dishes	×	
Metal	Freezer bag with twist-ties	×	These may cause arcing or fire.
Paper	Plates, cups, napkins, and kitchen paper	0	Use to cook for a short time. These absorb excess moisture.
	Recycled paper	×	Causes arcing.
	Containers	0	Use thermoplastic containers only. Some plastics may warp or discolour at high temperatures.
Plastic	Cling film	0	Use to maintain moisture after cooking.
	Freezer bags	Δ	Use boilable or ovenproof bags only.
Wax or grease-proof paper		0	Use to maintain moisture and prevent spattering.

O: Microwave safe


 Δ : Use caution

X: Microwave unsafe

Operations

Feature panel

The front panel comes in a wide range of materials and colours. For improved quality, the actual appearance of the oven is subject to change without notice.




- Healthy cooking
- Beverage
- Auto reheat
- Pizza reheat
- Soften/Melt
- Power defrost
- Keep warm
- Deodorisation
- Number Pad
- MWO power level
- Kitchen timer
- Clock
- Eco
- Sound
- STOP/CANCEL **16** +30s
- START

Operations

Simple steps to start

To cook food




- Put the food in a microwave-safe container and then in the centre of the turntable.
- **2.** Use the **Number** buttons to set the cooking time.
- 3. Press START.

♠ NOTE

When cooking is complete, the oven beeps 4 times. Use oven gloves to take out the food.

To defrost frozen food



- **1.** Put the frozen food in a microwavesafe container and then in the centre of the turntable.
- 2. Press Power Defrost.
- **3.** Use the **Number** buttons to set the serving size.
- 4. Press START.

♠ NOTE

For more information, see the Power Defrost section.


Manual mode

Microwave

This is the basic function of this microwave oven. The power level is set to High by default.



1. Put food in a microwave-safe container and then on the turntable.




- 2. Use the **Number** buttons to set the cooking time (max: 99 min 99 sec). For example, press 1 and 0 for the minutes, and 0 and 0 for the seconds (10:00).
- To change the default power level, press Power Level and select a different level. See the Power level section for details.
- 4. Press START.
- **5.** When cooking is complete with a beep 4 times, use oven gloves to take out the food.

14 English -

Common settings

Cooking time

Follow these steps to set or change the cooking time. By default, the power level is set to High.



Use the **Number** buttons to set the cooking time (max: 99 min 99 sec). The time area consists of the minute and second elements. To set a cooking time of 25 minutes, for example, press 2 and 5 for the minutes, then 0 and 0 for the seconds

♠ NOTE

- To change the cooking time during operation, press STOP/CANCEL twice, and repeat the steps above.
- To stop cooking, simply open the door, or press STOP/CANCEL. To resume operation, close the door and press Start.
- To cancel cooking, press STOP/CANCEL twice.

Time increment

You might want to add extra time to the current cooking time while cooking is in process. Time can be added by 30 seconds.




- 1. Before or during cooking, press +30s as many times as needed. For example, to add 2 minutes to the current cooking time, press the button 4 times.
- **2.** Press **START**. The oven continues to operate for the changed time.



This button is not enabled with Auto mode.

Power level

You can change the heating intensity according to the cooking recipe or to your preference.



- 1. Press Power Level.
- Use the **Number** buttons to select a specific power level. Available levels range from No power (0) to High (10). See the table below.

0	PL:0	No power (0 %)	
1	PL:1	Warm (10 %)	
2	PL:2	Defrost (20 %)	
3	PL:3	Low (30 %)	
4	PL:4	Medium low (40 %)	
5	PL:5	Medium (50 %)	
6	PL:6 Simmer (60 %)		
7	PL:7	Medium high (70 %)	
8	PL:8	Reheat (80 %)	
9	PL:9	Sauté (90 %)	
10	PL:Hi	High (100 %)	

♠ NOTE

To check the current power level while cooking is in process, press **Power Level**.

Operations


Auto mode

Healthy Cook

For healthier alternatives, the oven offers a total of 16 Healthy Cook programmes in 2 different categories. Take advantage of this feature to save you time or shorten your learning curve. The cooking time and temperature will be adjusted according to the selected recipe.



1. Put food in a microwave-safe container and then in the centre of the turntable.



04 O

- Select a category by pressing either Vegetables/Grains or Poultry/Seafood.
- Use the selected button again or the Number buttons to select a specific programme.
- **4.** Press **START**.
- **5.** When cooking is complete with a beep 4 times, use oven gloves to take out the food.

Healthy Cook guide

The following table presents auto programmes for cooking, and baking. The table contains food quantities, weight ranges, and appropriate recommendations. Cooking modes and times have been pre-programmed for your convenience.

1. Vegetable & Grains

Code	Food	Serving Size (g)	Instructions
1	Broccoli	250	Rinse and clean fresh broccoli and prepare florets. Put them evenly into a glass bowl with lid. Add 30 ml (2 tbsp) water. Put bowl in the centre of turntable. Cook covered. Stir after cooking. Stand for 1-2 minutes.
2	Carrots	250	Rinse and clean carrots and prepare even slices. Put them evenly into a glass bowl with lid. Add 30 ml (2 tbsp) water. Put bowl in the centre of turntable. Cook covered. Stir after cooking. Stand for 1-2 minutes.
3	Green Beans	250	Rinse and clean green beans. Put them evenly into a glass bowl with lid. Add 30 ml (2 tbsp) water. Put bowl in the centre of turntable. Cook covered. Stir after cooking Stand for 1-2 minutes.
4	Spinach	150	Rinse and clean spinach. Put into a glass bowl with lid. Do not add water. Put bowl in the centre of turntable. Cook covered. Stir after cooking. Stand for 1-2 minutes.
5	Corn on the Cob	500	Rinse and clean corn on the cobs and put into an oval glass dish. Cover with microwave cling film and pierce film. Stand for 1-2 minutes.

Code	Food	Serving Size (g)	Instructions
6	Peeled Potatoes	250	Wash and peel the potatoes and cut into a similar size. Put them into a glass bowl with lid. Add 45-60 ml (3-4 tbsp) water. Put bowl in the centre of turntable. Cook covered. Stand for 2-3 minutes.
7	Brown Rice	250	Use a large glass ovenware dish with lid. Add double quantity of cold water (500 ml). Cook covered. Stir before standing time and add salt and herbs. Stand for 5-10 minutes.
8	Wholemeal Macaroni	250	Use a large glass ovenware dish with lid. Add 1 L hot boiling water, a pinch of salt and stir well. Cook covered. Stir before standing time and drain thoroughly afterwards. Stand for 1 minutes.
9	Quinoa	250	Use a large glass ovenware dish with lid. Add double quantity of cold water (500 ml). Cook covered. Stir before standing time and add salt and herbs. Stand for 1-3 minutes.
10	Bulgur	250	Use a large glass ovenware dish with lid. Add double quantity of cold water (500 ml). Cook covered. Stir before standing time and add salt and herbs. Stand for 2-5 minutes.


2. Poultry & Seafood

Code	Food	Serving Size (g)	Instructions
1	Chicken Breasts	300	Rinse pieces and put on a ceramic plate. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 2 minutes.
2	Turkey Breasts	300	Rinse pieces and put on a ceramic plate. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 2 minutes.
3	Fresh Fish Fillets	300	Rinse fish fillets and put on a ceramic plate, add 1 tbsp lemon juice. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 1-2 minutes.
4	Fresh Salmon Fillets	300	Rinse fish fillets and put on a ceramic plate, add 1 tbsp lemon juice. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 1-2 minutes.
5	Fresh Prawns	250	Rinse prawns fillets and put on a ceramic plate, add 1 tbsp lemon juice. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 1-2 minutes.
6	Fresh Trout	400	Put 1-2 fresh whole fish into an ovenproof dish. Add a pinch salt, 1 tbsp lemon juice and herbs. Cover with microwave cling film. Pierce the film. Put dish on turntable. Stand for 2 minutes.

Operations

Beverage


This is useful to make hot drink such as tea, coffee.



- **1.** Put food in the centre of the turntable.
- **2.** Press **Beverage**.
- **3.** Use the **Beverage** button again or the **Number** buttons to select a specific programme.
- 4. Press START.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

Auto Reheat

Use Auto Reheat to warm up food leftovers or precooked food. The operating time and power level will be set according to the selected programme.



- **1.** Put food in the centre of the turntable and close the door.
- 2. Press Auto Reheat.
- **3.** Use the Auto Reheat button again or the **Number** buttons to select a specific programme.
- 4. Press START.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

Beverage guide

Code	Food	Serving Size	Instructions
1	Beverage	1 serving (250 g)	Use a measuring cup or mug and
2	Beverage	2 servings (500 g)	do not cover. Place the beverage in
3	Beverage	3 servings (750 g)	the oven. After heating, stir well.
4	Beverage	4 servings (1 kg)	

Auto Reheat guide


MS32J5133AT_TC_DE68-04345J-00_EN.indd 19

The following table presents auto programmes for reheating food. The table contains food quantities, weight ranges, and appropriate recommendations.

Code	Food	Serving Size (g)	Instructions
1	Plate of Food	1 serving	Use only precooked, refrigerated foods. Cover the plate with vented plastic wrap or waxed paper tucked under the plate. Contents: 90-110 g meat, poultry or fish (up to 170 g with bone) ½ cup starch (potatoes, pasta, rice, etc.) ½ cup vegetables (about 90-110 g)
2	Casserole	1 serving 200-230 g	Cover the plate with a lid or
3	Casserole	2 servings 400-450 g	vented plastic wrap. Stir the food once before serving.
4	Casserole	3 servings 600-690 g	2 Contents: Casserole,
5	Casserole	4 servings 800-920 g	refrigerated foods.
6	Pasta	1 serving 200-230 g	
7	Pasta	2 servings 400-450 g	
8	Pasta	3 servings 600-690 g	
9	Pasta	4 servings 800-920 g	

Pizza Reheat

Use Pizza Reheat to warm up food leftovers or precooked food. The operating time and power level will be set according to the selected programme.



- **1.** Put food in the centre of the turntable and close the door.
- 2. Press Pizza Reheat.
- **3.** Use the Auto Reheat button again or the **Number** buttons to select a specific programme.
- 4. Press START.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

Pizza Reheat guide

The following table presents auto programmes for reheating food.

Code	Food	Serving Size (g)	Instructions
1	Pizza Reheat	1 Slice	Place pizza slices on a microwave-
2	Pizza Reheat	2 Slices	safe plate with the wide ends of
3	Pizza Reheat	3 Slices	the slices towards the outside edge of the plate. Do not let the slices
4	Pizza Reheat	4 Slices	overlap. Do not cover.


2015-09-14 🗓 4:08:19

Operations

Convenience

Soften/Melt

This is useful to soften or melt soft food or confection such as butter, chocolate, and sugar.



- **1.** Put food in the centre of the turntable.
- 2. Press Soften/Melt.
- **3.** Use the Soften/Melt button again or the **Number** buttons to select a specific programme.
- **4.** Press **START**.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

Soften & Melt guide


The following table presents auto programmes for softening or melting specific kinds of food. The table contains food quantities, weight ranges, and appropriate recommendations.

Code	Food	Serving Size (g)	Instructions
1	Melt Butter	50	Cut butter into 3 or 4 pieces and Put them on small glass
2	Melt Butter	100	bowl. Melt uncovered. Stir after cooking. Stand for 1-2 minutes.
3	Melt Dark Chocolate	50	Grate dark chocolate and put in small glass bowl. Melt uncovered.
4	Melt Dark Chocolate	100	Stir after melting. Stand for 1-2 minutes.
5	Melt Sugar	25	Put sugar on small glass bowl. Add 10 ml water for 25 g and add 20 ml water for 50 g. Melt uncovered. Take out carefully, use
6	Melt Sugar	50	oven gloves! Use spoon or fork and pour caramel decorations on baking paper. Let stand for 10 minutes until dry and remove from paper.
7	Soften Butter	50	Cut butter into 3 or 4 pieces and Put them in small glass bowl.
8	Soften Butter	100	Soften uncovered. Stand for 1-2 minutes.

20 English -

Power Defrost

This is useful to defrost frozen meat, poultry, fish or bread/cake. The operating time and power level will be adjusted according to the selected programme.



- **1.** Put food in the centre of the turntable and close the door.
- **2.** Press **Power Defrost** to select category.
- **3.** Use the **Number** buttons to select a weight.
- 4. Press START.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

■ NOTE

- The oven beeps in the middle of the cycle to remind you to turn the food over. Turn the food over, and press Start again to continue. When the cycle is complete, the oven beeps 4 times.
- You can defrost food manually. To do this, use a cooking mode with just 20 % of the default power level of the cooking mode. For more information, see the Power level section.

Power Defrost guide

The following table presents auto programmes for defrosting food. The table contains food quantities, weight ranges, and appropriate recommendations.

Code	Food	Serving Size (kg)	Instructions	
1	Meat	0.1-1.5	Shield the edges with aluminium foil. Turn the meat over, when the oven beeps. This programme is suitable for beef,lamb, pork, steaks, chops, minced meat. Stand for 10-30 minutes.	
2	Poultry	0.1-1.5	meat. Stand for 10-30 minutes. This program is suitable for whole chicken as well as for chicken pieces. Before defrosting, if a lot of ice crystals are present on poultry surface, it should be rinsed under cold water until all the ice crystals are removed. The poultry should then be left to stand for 5 to 10 min. at room temperature. Shield the leg and wing tips with aluminum foil. Place chicken pieces skin-side down, and whole chicken breast-side down on the middle of a flat microwave-safe plate. Turn the poultry over when the oven beeps.	
3	Fish	0.1-1.5	Shield the tail of a whole fish with aluminium foil. Turn the fish over, when the oven beeps. This programme is suitable for whole fishes as well as for fish fillets. Stand for 10-30 minutes.	
4	Bread/ Cake	0.1-1.0	Put bread on a piece of kitchen paper and turn over, as soon as the oven beeps. Place cake on a ceramic plate and if possible, turn over, as soon as the oven beeps. (Oven keeps operating and is stopped, when you open the door.) This programme is suitable for all kinds of bread, sliced or whole, as well as for bread rolls and baguettes. Arrange bread rolls in a circle. This programme is suitable for all kinds of yeast cake, biscuit, cheese cake and puff pastry. It is not suitable for short/crust pastry, fruit and cream cakes as well as for cake with chocolate topping. Stand for 5-30 minutes.	


English 21

MS32J5133AT_TC_DE68-04345J-00_EN.indd 21 2015-09-14 III 4:08:20

Operations

Keep Warm

If you want to keep cooked foods warm until serving, use this function. The operating time and power level will be adjusted according to the selected programme.



- **1.** Put food in the centre of the turntable and close the door.
- **2.** Press **Keep Warm**. The default time is 99 minutes.
- **3.** Use the **Number** buttons to set the warming time.
- **4.** Press **START**.
- **5.** When the cycle is complete with a beep 4 times, use oven gloves to take out the food.

⚠ CAUTION

- Do not use this function to reheat cold foods. Use this only for keeping food warm that has just been cooked.
- Do not keep food for more than 1 hour.
 The food surface may be dried.
- Do not put food covered with lids or plastic wrap in the oven.

Deodorisation



Deodorisation helps remove bad smells from inside the oven after cooking. The default time is 5 minutes.

- To activate, press **Deodorisation** and then **START** on the feature panel.
- To change the time, press **+30s** to increase by 30 seconds (max: 15 min).

Cooking smart

We provide these cooking guides to help you make the most out of this oven. Experience our cooking know-how to add convenience and richness to your life.

Microwave cooking guide

- Cover the food throughout the entire cooking. The vaporised moisture from the food circles through inside and helps cook evenly.
- When cooking is complete, let stand for the specified time. This allows the food to even out inside.
- Use only microwave-safe cookware.

Frozen vegetables

- Use a suitable glass Pyrex container with a lid.
- Stir twice during cooking and once after cooking, and then add seasoning to your preference.

Food	Serving Size (g)	Power	Time (min.)	
Spinach	150	60 %	5-6	
	Add 15 ml (1 tbsp)	cold water. Stand fo	r 2-3 minutes.	
Broccoli	300	60 %	8-9	
	Add 30 ml (2 tbsp)	cold water. Stand fo	r 2-3 minutes.	
Peas	300	60 %	7-8	
	Add 15 ml (1 tbsp) cold water. Stand for 2-3 minutes.			
Green Beans	300	60 %	7½-8½	
	Add 30 ml (2 tbsp) cold water. Stand for 2-3 minutes.			
Mixed Vegetables	300	60 %	7-8	
(Carrots/Peas/Corn)	Add 15 ml (1 tbsp) cold water. Stand for 2-3 minutes.			
Mixed Vegetables	300	60 %	7½-8½	
(Chinese style)	Add 15 ml (1 tbsp) cold water. Stand for 2-3 minutes.			

Fresh vegetables

- Use a suitable glass Pyrex container with a lid.
- Cut ingredients into as small pieces as possible to reduce the cooking time.
- Add 30-45 ml of cold water to every 250 g unless otherwise specified.
- Stir once during cooking and once after cooking, and then add seasoning to your preference.

Food	Serving Size (g)	Power	Time (min.)	
Broccoli	250	90 %	4½-5	
	500		7-8	
	Prepare even sized	florets. Arrange the	stems to the	
	centre. Stand for 3	minutes.		
Brussels Sprouts	250	90 %	6-6½	
	Add 60-75 ml (4-5	tbsp) water. Stand fo	or 3 minutes.	
Carrots	250	90 %	4½-5	
	Cut carrots into eve	en sized slices. Stand	for 3 minutes.	
Cauliflower	250	90 %	5-5½	
	500		7½-8½	
	Prepare even sized	florets. Cut big flore	ets into halves.	
	Arrange stems to the	ne centre. Stand for 3	3 minutes.	
Courgettes	250	90 %	4-41/2	
		slices. Add 30 ml (2	1.7	
	knob of butter. Coo	k until just tender. S	tand for 3 minutes.	
Eggplants	250	90 %	3½-4	
	Cut eggplants into small slices and sprinkle with 1 tbsp			
	lemon juice. Stand	for 3 minutes.		
Leeks	250	90 %	4-41/2	
	Cut leeks into thick	slices. Stand for 3 m	ninutes.	
Mushrooms	125	90 %	1½-2	
	250		2½-3	
	Prepare small whole or sliced mushrooms. Do not add			
	'	with lemon juice. Sp		
	pepper. Drain befor	re serving. Stand for	3 minutes.	

English 23

MS32J5133AT_TC_DE68-04345J-00_EN.indd 23 2015-09-14 🗉 4:08:21

Cooking smart

Food	Serving Size (g)	Power	Time (min.)	
Onions	250	90 %	5-5½	
	Cut onions into slices or halves. Add only 15 ml (1 tbsp) water. Stand for 3 minutes.			
Pepper	250	90 %	4½-5	
	Cut pepper into sm	all slices. Stand for 3	3 minutes.	
Potatoes	250	90 %	4-5	
	500		7-8	
	Weigh the peeled potatoes and cut them into similar			
	sized halves or quarters. Stand for 3 minutes.			
Turnip Cabbage	250	90 %	5½-6	
	Cut turnip cabbage	into small cubes. Sta	and for 3 minutes.	

Rice and pasta

Rice

• Use a large-sized glass Pyrex container with a lid. Note that rice doubles in volume during cooking.

Pasta

- Use a large-sized glass Pyrex container. Cook uncovered.
- Add boiling water and a little salt, and stir well. Stir several times during and after cooking.
- Cover with a lid while letting stand, and then drain well.

Food	Serving Size	Power	Time (min.)	
White Rice	250 g	90 %	15-16	
(Parboiled)	375 g		17½-18½	
	Add 500 ml cold water.(250 g), Add 750 ml cold water. (375 g) Stand for 5 minutes.			
Brown Rice	250 g 90 % 20-21			
(Parboiled)	375 g 22-23			
	Add 500 ml cold water.(250 g), Add 750 ml cold water.			
	(375 g) Stand for 5	minutes.		

Food	Serving Size	Power	Time (min.)	
Mixed Rice	250 g	90 %	16-17	
(Rice + Wild Rice)	Add 500 ml cold water. Stand for 5 minutes.			
Mixed Corn	250 g	90 %	17-18	
(Rice + Grain)	Add 400 ml cold water. Stand for 5 minutes.			
Pasta	250 g	90 %	10-11	
	Add 1000 ml hot water. Stand for 5 minutes.			

Reheating guide

General

This reheating guide is based on the condition that the room temperature is between 18 °C and 20 °C for liquid, and between 5 °C and 7 °C for chilled food. Follow the operating time, power level, and standing time specified in this table.

Food	Serving Size (g)	Power	Time (min.)		
Drinks	150 ml (1 cup)	90 %	1-1½		
(Coffee, Tea	300 ml (2 cups)		2-21/2		
and Water)	450 ml (3 cups)		3-3½		
	600 ml (4 cups)		31/2-4		
	Pour into cups and re	eheat uncovered: 1 cu	p in the centre,		
	2 cups opposite of ea	ach other, 3 cups in a	circle. Keep in		
	microwave oven dur	ing standing time and	stir well. Stand for		
	1-2 minutes.				
Soup (Chilled) 250 g		90 %	21/2-3		
	350 g		3-3½		
	450 g		31/2-4		
	550 g 4½-5				
	Pour into a deep ceramic plate or deep ceramic bowl. Cover with plastic lid. Stir well after reheating. Stir again before serving. Stand for 2-3 minutes.				
	Jet virig. Staria for 2	J HIHOCCS.			

24 English -

Food	Serving Size (g)	Power	Time (min.)	
Stew (Chilled)	350	60 %	4½-5½	
	· ·	eramic plate. Cover wi reheating and again bo 3 minutes.	· ·	
Pasta with	350	60 %	31/2-41/2	
Sauce (Chilled)	Put pasta (e.g. spaghetti or egg noodles) on a flat ceramic plate. Cover with microwave cling film. Stir before serving. Stand for 3 minutes.			
Filled Pasta	350	60 %	4-5	
with Sauce (Chilled)	Put filled pasta (e.g. ravioli, tortellini) in a deep ceramic plate. Cover with plastic lid. Stir occasionally during reheating and again before standing and serving. Stand for 3 minutes.			
Plated Meal	350	60 %	4½-5	
(Chilled)	450		5½-6½	
	Plate a meal of 2-3 chilled components on a ceramic dish. Cover with microwave cling-film. Stand for 3 minutes.			
Cheese Fondue	400	60 %	6-7	
Ready-to- Serve (Chilled)	glass pyrex bowl wit	ve cheese fondue in a h lid. Stir occasionally efore serving. Stand f	during and after	

Special care for baby food

To prevent accidents such as burns, special care must be taken for baby food before serving. Make sure to strictly follow this reheating guide for baby food.

Baby food

- Use a deep ceramic plate and cover it with a plastic lid.
- Recommended serving temperature is 30-40 °C.

Baby milk

- Use a sterilised glass bottle and reheat it uncovered.
- Remove the teat before reheating. Otherwise, the milk in the bottle boils over.

Food	Serving Size	Power	Time (sec.)	
Baby Food	190 g	60 %	30	
(Vegetables + Meat)	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Before serving, stir well and check the temperature carefully. Stand for 2-3 minutes.			
Baby Porridge	190 g	60 %	20	
(Grain + Milk + Fruit)	Empty into ceramic deep plate. Cook covered. Stir after cooking time. Before serving, stir well and check the temperature carefully. Stand for 2-3 minutes.			
		30-40 60-70		
	Stir or shake well and pour into a sterilised glass bottle. Place into the centre of turn-table. Cook uncovered. Shake well and stand for at least 3 minutes. Before serving, shake well and check the temperature carefully.			

Defrosting guide

This defrosting guide is based on the condition that frozen food is between -18 $^{\circ}$ C and -20 $^{\circ}$ C in internal temperatures. The standing time varies depending on the food type (meat or vegetables) and serving size (thinner or thicker pieces of food).

- Put frozen food in a microwave-safe container uncovered.
- Turn it over halfway through defrosting time and drain well when complete.

Food		Serving Size	Power	Time (min.)
Meat	Minced Meat	250 g 500 g	20 %	6-7 8-13
	Pork Steaks	250 g		7-8
			d thinner edges wit time! Stand for 15-	

Cooking smart

	Food	Serving Size	Power	Time (min.)	
Poultry	Chicken Pieces	500 g (2 pcs)	20 %	14-15	
	Whole Chicken	1200 g		32-34	
	breast-side-dow	, n on a flat ceramic with aluminium fo	side down, whole of plate. Shield the toil. Turn over after	hinner parts like	
Fish	Fish Fillets	200 g	20 %	6-7	
	Whole Fish	400 g		11-13	
	Put frozen fish in the middle of a flat ceramic plate. Arrange the thinner parts under the thicker parts. Shield narrow ends of fillets and tail of whole fish with aluminium foil. Turn over after half of defrosting time! Stand for 10-25 minutes.				
Fruits	Berries	300 g	20 %	6-7	
	Spread fruit on for 5-10 minute		dish (with a large o	diameter). Stand	
Bread	Bread Rolls (Each ca. 50 g)	2 pcs 4 pcs	20 %	1-1½ 2½-3	
	Toast/ Sandwich	250 g		4-41/2	
	German Bread (Wheat + Rye Flour)	500 g		7 - 9	
			orizontally on kitcler half of defrosting		

Quick & Easy

Melting crystallized honey

Put 20 g crystallized honey into a small deep glass dish. Heat for 20-30 seconds using 30 %, until honey is melted.

Melting gelatine

Lay dry gelatine sheets (10 g) for 5 minutes into cold water. Put drained gelatine into a small glass pyrex bowl. Heat for 1 minute using 30 %. Stir after melting.

Cooking glaze/icing (for cake and gateaux)

Mix instant glaze (approximately 14 g) with 40 g sugar and 250 ml cold water. Cook uncovered in a glass pyrex bowl for 3½ to 4½ minutes using 90 %, until glaze/icing is transparent. Stir twice during cooking.

Cooking jam

Put 600 g fruits (for example mixed berries) in a suitable sized glass pyrex bowl with lid. Add 300 g preserving sugar and stir well.

Cook covered for 10-12 minutes using 90 %.

Stir several times during cooking. Empty directly into small jam glasses with twist-off lids. Stand on lid for 5 minutes.

Cooking pudding/ custard

Mix pudding powder with sugar and milk (500 ml) by following the manufacturers instructions and stir well. Use a suitable sized glass pyrex bowl with lid. Cook covered for 6% to 7% minutes using 90 %.

Stir several times well during cooking.

Browning almond slices

Spread 30 g sliced almonds evenly on a medium sized ceramic plate. Stir several times during browning for 3½ to 4½ minutes using 60 %. Let it stand for 2-3 minutes in the oven. Use oven gloves while taking out!

English 27

Troubleshooting

You may encounter a problem using the oven. In that case, first check the table below and try the suggestions. If a problem persists, or if any information code keeps appearing on the display, contact a local Samsung service centre.

Checkpoints

If you encounter a problem with the oven, first check the table below and try the suggestions.

Problem	Cause	Action
General		
The buttons cannot be pressed properly.	Foreign matter may be caught between the buttons.	Remove the foreign matter and try again.
	For touch models: Moisture is on the exterior.	Wipe the moisture from the exterior.
	Child lock is activated.	Deactivate Child lock.
The time is not	Power is not supplied.	Make sure power is supplied.
displayed.	The Eco (power-saving) function is set.	Turn off the Eco function.
The oven does not	Power is not supplied.	Make sure power is supplied.
work.	The door is open.	Close the door and try again.
	The door open safety mechanisms are covered in foreign matter.	Remove the foreign matter and try again.
The oven stops while in operation.	The user has opened the door to turn food over.	After turning over the food, press the Start button again to start operation.

Problem	Cause	Action
The power turns off during operation.	The oven has been cooking for an extended period of time.	After cooking for an extended period of time, let the oven cool.
	The cooling fan is not working.	Listen for the sound of the cooling fan.
	Trying to operate the oven without food inside.	Put food in the oven.
	There is not sufficient ventilation space for the oven.	There are intake/exhaust outlets on the front and rear of the oven for ventilation. Keep the gaps specified in the product installation guide.
	Several power plugs are being used in the same socket.	Designate only one socket to be used for the oven.
There is no power to the oven.	Power is not supplied.	Make sure power is supplied.
There is a popping sound during operation, and the oven doesn't work.	Cooking sealed food or using a container with a lid may causes popping sounds.	Do not use sealed containers as they may burst during cooking due to expansion of the contents.
The oven exterior is too hot during operation.	There is not sufficient ventilation space for the oven.	There are intake/exhaust outlets on the front and rear of the oven for ventilation. Keep the gaps specified in the product installation guide.
	Objects are on top of the oven.	Remove all objects on the top of the oven.

MS32J5133AT_TC_DE68-04345J-00_EN.indd 27 2015-09-14 🗓 4:08:21

Troubleshooting

Problem	Cause	Action
The door cannot be opened properly.	Food residue is stuck between the door and oven interior.	Clean the oven and then open the door.
The oven does not heat.	The oven may not work, too much food is being cooked, or improper cookware is being used.	Put one cup of water in a microwave-safe container and run the microwave for 1-2 minutes to check whether the water is heated. Reduce the amount of food and start the function again. Use a cooking container with a flat bottom.
Heating is weak or slow.	The oven may not work, too much food is being cooked, or improper cookware is being used.	Put one cup of water in a microwave-safe container and run the microwave for 1-2 minutes to check whether the water is heated. Reduce the amount of food and start the function again. Use a cooking container with a flat bottom.
The warm function does not work.	The oven may not work, too much food is being cooked, or improper cookware is being used.	Put one cup of water in a microwave-safe container and run the microwave for 1-2 minutes to check whether the water is heated. Reduce the amount of food and start the function again. Use a cooking container with a flat bottom.

Problem	Cause	Action
The thaw function does not work.	The oven may not work, too much food is being cooked, or improper cookware is being used.	Put one cup of water in a microwave-safe container and run the microwave for 1-2 minutes to check whether the water is heated. Reduce the amount of food and start the function again. Use a cooking container with a flat bottom.
The interior light is dim or does not turn on.	The door has been left open for a long time.	The interior light may automatically turn off when the Eco function operates. Close and reopen the door or press the "Cancel" button.
	The interior light is covered by foreign matter.	Clean the inside of the oven and check again.
A beeping sound occurs during cooking.	If the Auto Cook function is being used, this beeping sound means it's time to turn over the food during thawing.	After turning over the food, press the Start button again to restart operation.
The oven is not level.	The oven is installed on an uneven surface.	Make sure the oven is installed on flat, stable surface.
There are sparks during cooking.	Metal containers are used during the oven/thawing functions.	Do not use metal containers.

English 29

Problem	Cause	Action
When power is connected, the oven immediately starts to work.	The door is not properly closed.	Close the door and check again.
There is electricity coming from the oven.	The power or power socket is not properly grounded.	Make sure the power and power socket are properly grounded.
There is water dripping.	There may be water or steam in some cases depending on the food. This is not an oven malfunction.	Let the oven cool and then wipe with a dry dish towel.
Steam leaks from the door.	There may be water or steam in some cases depending on the food. This is not an oven malfunction.	Let the oven cool and then wipe with a dry dish towel.
There is water left in the oven.	There may be water or steam in some cases depending on the food. This is not an oven malfunction.	Let the oven cool and then wipe with a dry dish towel.
The brightness inside the oven varies.	Brightness changes depending on power output changes according to function.	Power output changes during cooking are not malfunctions. This is not an oven malfunction.
Cooking is finished, but the cooling fan is still running.	To ventilate the oven, the cooling fan continues to run for about 5 minutes after cooking is complete.	This is not an oven malfunction.

Problem	Cause	Action
Pressing the +30sec button operates the oven.	This happens when the oven was not operating.	The microwave oven is designed to operate by pressing the +30 sec button when it was not operating.
Turntable		
While turning, the turntable comes out of place or stops turning.	There is no roller ring, or the roller ring is not properly in place.	Install the roller ring and then try again.
The turn table drags while turning.	The roller ring is not properly in place, there is too much food, or the container is too large and touches the inside of the microwave.	Adjust the amount of food and do not use containers that are too large.
The turn table rattles while turning and is noisy.	Food residue is stuck to the bottom of the oven.	Remove any food residue stuck to the bottom of the oven.



If the above guidelines do not enable you to solve the problem, then contact your local SAMSUNG customer service centre.

Please have the following information read;

- The model and serial numbers, normally printed on the rear of the oven
- Your warranty details
- A clear description of the problem

Then contact your local dealer or SAMSUNG aftersales service.

MS32J5133AT_TC_DE68-04345J-00_EN.indd 29

Troubleshooting

information code

Code	Description	Action
C-d0	Control buttons are pressed over 10 seconds.	Clean the keys and check if there is water on the surface around key. If it occurs again, turn off the microwave oven over 30 seconds and try setting again. If it appears again, call your local SAMSUNG Customer Care Centre.



If the suggested solution does not solve the problem, contact your local SAMSUNG Customer Care Centre.

Technical specifications

SAMSUNG strives to improve its products at all times. Both the design specifications and these user instructions are thus subject to change without notice.

	Model	MS32J5133A*
Power Source		220 V ~ 60 Hz
Power Consum	ption	1500 W
Output Power		100 W / 1000 W (IEC - 705)
Operating Fred	quency	2450 MHz
Magnetron		OM75P (31)
Cooling Metho	d	Cooling fan motor
Dimensions	Main unit	517 x 297 x 384 mm
(W x H x D)	Cooking chamber	357 x 255 x 357 mm
Volume		1.1 cu.ft
Weight	Net	14.5 kg

Memo

MS32J5133AT_TC_DE68-04345J-00_EN.indd 31 2015-09-14 🗉 4:08:22



Please be advised that the Samsung warranty does NOT cover service calls to explain product operation, correct improper installation, or perform normal cleaning or maintenance.

QUESTIONS OR COMMENTS?

COUNTRY	COUNTRY CALL 0		
AUSTRALIA	1300 362 603	www.samsung.com/au/support	
NEW ZEALAND	0800 726 786	www.samsung.com/nz/support	
CHINA	400-810-5858	www.samsung.com/cn/support	
HONG KONG	3698 4698	www.samsung.com/hk/support (Chinese)	
Hond Rond	3030 4030	www.samsung.com/hk_en/support (English	
INDIA	1800 3000 8282 - Toll Free		
INDIA	1800 266 8282 - Toll Free	www.samsung.com/in/support	
BANGLADESH	0961-2300300	www.samsong.com/m/sopport	
BANGLADESIT	0800-0300300 (Toll free)		
INDONESIA	021-56997777	www.samsung.com/id/support	
INDONESIA	08001128888	www.samsong.com/id/sopport	
JAPAN	0120-363-905	www.samsung.com/jp/support	
1441 AVG1A	1800-88-9999	WILLIAM COMPLINE COM / MY / CLIPPORT	
MALAYSIA	603-77137477 (Overseas contact)	www.samsung.com/my/support	
	1-800-10-726-7864 [PLDT Toll Free]		
PHILIPPINES	1-800-8-726-7864 [Globe Landline and Mobile]	www.samsung.com/ph/support	
	02- 422-2111 [Standard Landline]		
SINGAPORE	1800-SAMSUNG(726-7864)	www.samsung.com/sg/support	
THAILAND	0-2689-3232,	www.samsung.com/th/support	
INAILANU	1800-29-3232		
TAIWAN	0800-329999	www.samsung.com/tw/support	
VIETNAM	1800 588 889	www.samsung.com/vn/support	
MACAU	0800 333		
MYANMAR	+95-1-2399-888	www.camcung.com/cupport	
SRI LANKA	0117540540	www.samsung.com/support	
	0115900000		

DE68-04345J-00

MS32J5133AT_TC_DE68-04345J-00_EN.indd 32