

**THANK YOU FOR BUYING AN INDESIT PRODUCT**  
In order to receive a more complete assistance, please register your product on [www.indesit.com/register](http://www.indesit.com/register)



**Before using the appliance carefully read the Safety Instruction.**


PRODUCT DESCRIPTION

FIRST TIME USE

Wait at least two hours, after the installation, before connecting the appliance to the power supply.  
Connect the appliance to the power supply and turn the thermostat knob to switch on the appliance.

After turning the appliance on, you must wait for 4-6 hours for the correct storage temperature to be reached for a normally filled appliance. Position the antibacterial anti-odour filter in the fan as demonstrated in the filter packaging (if available).


CONTROL PANEL



- 1. Temperature alarm indicator
- 2. Fast freezing function
- 3. Temperature settings (stand by button)

TEMPERATURE ALARM INDICATOR

When the product is plugged in to the mains, during the first 10 minutes of working, any temperature sensor failure will be displayed on the control panel.



The appliance will work anyway preserving the food stored, but it is necessary to contact after-sales service and provide alarm code.

Note: The Temperature alarm may activate if the door is left open for a prolonged period of time or following the introduction of fresh food in the freezer compartment; this temporary rise in temperature does not affect the storage of already frozen food in any way.

FAST FREEZING FUNCTION

The use of this function is recommended to increase the cooling speed when placing a very high quantity of food in the freezer compartment. To activate this function press the Temperature button on the control panel repeatedly until 3 LED's flash and then remain lit.








The function is automatically deactivated after 48 h.

TEMPERATURE SETTING

Press the Temperature button on the control panel to adjust the temperature from the warmest through the lower to the coldest level. Pressing the Temperature button, the temperature setting will change cyclically.

At first plug-in of appliance temperature setpoint is present at medium position (factory setting).

Following table shows temperature setpoints:


	high temp.
	med-high temp.
	medium temp.
	med-low temp.
	low temp.
	
	

Note: Displayed set points correspond to the average temperature throughout the whole freezer.

STAND-BY BUTTON

To put the product in Stand-by, press and hold for 3 seconds the Stand-by button. All the indicators turn off. To reactivate the appliance press once (briefly) or for 3 seconds this button.

# HOW TO STORE FOOD AND BEVERAGE



## Legend



**FREEZING ZONE**  
All food items

# TROUBLESHOOTING

What to do if...	Possible reasons	Solutions
The appliance doesn't work.	There may be an appliance power supply problem.	Make sure: <ul style="list-style-type: none"><li>• there is not a power failure;</li><li>• the plug is properly inserted in the power socket and the double-pole switch (if present) is in the correct position (on);</li><li>• the household electrical system protection devices function;</li><li>• the power cable is not broken.</li></ul>
The inside light does not work.	It may be necessary to replace the light bulb.	Disconnect the appliance from the power supply and contact the Technical Assistance Service if you need a replacement.
The internal temperature of the compartments is not cold enough.	The reasons could vary (see "Solution") column.	Check that: <ul style="list-style-type: none"><li>• the doors are closed properly;</li><li>• the appliance is not installed near a heat source;</li><li>• the temperature is appropriately set;</li><li>• the circulation of air through the ventilation grilles on the base of the appliance is not obstructed.</li></ul>
There is water on the bottom of the refrigerator compartment.	The defrost water drain is blocked.	Clean the defrosting water drain (see section "Cleaning and Maintenance").
Excessive amount of frost in the freezer compartment.	The door to the freezer compartment is not closed properly.	<ul style="list-style-type: none"><li>• Check that there is nothing preventing the door from closing properly.</li><li>• Defrost the freezer compartment.</li><li>• Make sure the appliance has been correctly installed.</li></ul>
The front edge of the appliance that the door gaskets seal against is hot.	This is not a problem. It prevents condensation from forming.	A solution is not needed.
The temperature of the refrigerator compartment is too cold.	<ul style="list-style-type: none"><li>• The set temperature is too cold.</li><li>• A large amount of fresh food may have been placed in the freezer compartment.</li></ul>	<ul style="list-style-type: none"><li>• Try to set a less cold temperature.</li><li>• If fresh food has been put in the freezer compartment, wait until the freezing has been completed.</li><li>• Turn off the fan (if present) described in the paragraph "FAN".</li></ul>



You can download the **Safety Instructions, User Manual, Product Fiche and Energy data** by:

- Visiting our website **docs.indesit.eu**
- Using QR Code
- Alternatively, **contact our After-sales Service** (See phone number in the warranty booklet). When contacting our After-sales Service, please state the codes provided on your product's identification plate.

