

# Dell Precision 7920 Rack

## Owner's Manual



## Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

**Copyright © 2017 Dell Inc. or its subsidiaries. All rights reserved.** Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

# Contents

<b>1 Working on your computer</b>	<b>6</b>
Safety instructions	6
Before working inside your computer	6
After working inside your computer	7
<b>2 Chassis View</b>	<b>8</b>
Front chassis view	8
Back chassis view	9
Inside the system	9
LCD panel	10
Viewing Home screen	11
Setup menu	12
View menu	12
<b>3 Product Overview</b>	<b>13</b>
System information label	13
Precision 7920 Rack – Front system information label	13
Precision 7920 Rack – Service information	14
<b>4 Removing and installing components</b>	<b>15</b>
Product Positioning	15
Recommended tools	16
Need to know	16
Common error messages	16
Startup-Shutdown sequence	18
Diagnostics and indicators	19
Chassis LEDs	19
Status LED indicators	19
Hard drive indicator codes	20
NIC indicator codes	21
Power supply unit indicator codes	21
iDRAC Direct LED indicator codes	22
iDRAC Quick Sync 2 indicator codes	23
Enhanced Preboot System Assessment	24
Jumpers and connectors	26
System board jumpers and connectors	27
System board jumper settings	28
Disabling forgotten password	29
Disassembly and reassembly	30
Front Bezel	30
System cover	31
Optical drive	32
Air shroud	33



Cooling fan assembly.....	34
Cooling fans.....	34
Intrusion switch.....	35
Hard drive.....	36
Memory modules.....	44
Processors and heat sinks.....	46
Expansion card.....	50
vFlash card – optional.....	57
Network daughter card.....	58
Hard drive backplane.....	59
Front USB module.....	60
Internal USB memory key (optional).....	61
Power supply unit.....	61
System board.....	63
Trusted Platform Module.....	65
Control panel .....	66
Updating BIOS .....	68
Restoring the Service Tag using Easy Restore .....	68
Manually update the Service Tag .....	69
Installation.....	69
Rack Rails.....	69
Initialization.....	79
Basic configuration.....	80
Accessing system information by using QRL.....	81
Quick Resource Locator for 7920R.....	81

**5 Technology and components..... 82**

iDRAC9.....	82
iDRAC 9 - New features.....	82
Dell Lifecycle Controller.....	83
iDRAC9 with Lifecycle Controller.....	83
Benefits of using iDRAC with Lifecycle Controller.....	83
Key features.....	84
Starting Lifecycle Controller.....	84
Processors.....	84
Processor features.....	85
Supported Processors.....	85
Chipset.....	87
System memory.....	88
General memory module installation guidelines.....	89
Memory.....	89
LCD panel.....	91
Viewing Home screen.....	91
Setup menu.....	92
View menu.....	92
Expansion cards and expansion card risers.....	92
Expansion card installation guidelines.....	93



Storage.....	94
Supported Drives.....	94
Power supply units.....	95
Hot spare feature.....	95
Trusted platform module .....	96
<b>6 BIOS and UEFI.....</b>	<b>97</b>
Options to manage the pre-operating system applications.....	97
System Setup.....	97
Viewing System Setup.....	97
System Setup Main Menu.....	98
System BIOS screen.....	98
System information screen details.....	99
Memory settings screen details.....	99
Processor settings screen details.....	100
SATA settings screen details.....	101
Boot settings screen details.....	103
Network settings screen details.....	104
Integrated devices screen details.....	104
Serial Communication screen details.....	107
System profile settings screen details.....	107
System security settings screen details.....	108
Miscellaneous settings screen details.....	110
Technical specifications.....	110
System dimensions.....	110
Chassis weight.....	111
Processor specifications.....	111
PSU specifications.....	111
System battery specifications.....	112
Expansion bus specifications.....	112
Memory specifications.....	112
Ports and connectors specifications.....	113
Video specifications.....	114
Environmental specifications.....	114
<b>7 Troubleshooting your system.....</b>	<b>117</b>
Safety first — for you and your system.....	117
Using system diagnostics.....	117
Dell Embedded System Diagnostics.....	117



# Working on your computer

## Safety instructions

### Prerequisite

Use the following safety guidelines to protect your computer from potential damage and to ensure your personal safety. Unless otherwise noted, each procedure included in this document assumes that the following conditions exist:

- You have read the safety information that shipped with your computer.
- A component can be replaced or, if purchased separately, installed by performing the removal procedure in reverse order.

### About this task

- ⚠ WARNING:** Disconnect all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting to the power source.
- ⚠ WARNING:** Before working inside your computer, read the safety information that shipped with your computer. For additional safety best practices information, see the Regulatory Compliance Homepage at [www.Dell.com/regulatory\\_compliance](http://www.Dell.com/regulatory_compliance)
- ⚠ CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.
- ⚠ CAUTION:** To avoid electrostatic discharge, ground yourself by using a wrist grounding strap or by periodically touching an unpainted metal surface at the same time as touching a connector on the back of the computer.
- ⚠ CAUTION:** Handle components and cards with care. Do not touch the components or contacts on a card. Hold a card by its edges or by its metal mounting bracket. Hold a component such as a processor by its edges, not by its pins.
- ⚠ CAUTION:** When you disconnect a cable, pull on its connector or on its pull-tab, not on the cable itself. Some cables have connectors with locking tabs; if you are disconnecting this type of cable, press in on the locking tabs before you disconnect the cable. As you pull connectors apart, keep them evenly aligned to avoid bending any connector pins. Also, before you connect a cable, ensure that both connectors are correctly oriented and aligned.
- ℹ NOTE:** The color of your computer and certain components may appear differently than shown in this document.
- ⚠ CAUTION:** System will shut down if side covers are removed while the system is running. The system will not power on if the side cover is removed.
- ⚠ CAUTION:** System will shut down if side covers are removed while the system is running. The system will not power on if the side cover is removed.
- ⚠ CAUTION:** System will shut down if side covers are removed while the system is running. The system will not power on if the side cover is removed.

## Before working inside your computer

### About this task

To avoid damaging your computer, perform the following steps before you begin working inside the computer.

### Steps

- 1 Ensure that you follow the **Safety instructions**.
- 2 Turn off the system, including any attached peripherals.
- 3 Disconnect the system from the electrical outlet and disconnect the peripherals.
- 4 If applicable, remove the system from the rack.

- 5 Remove the system cover.

## After working inside your computer

### About this task

After you complete any replacement procedure, ensure that you connect any external devices, cards, and cables before turning on your computer.


### Steps

- 1 Replace the cover.
- 2 If applicable, install the system into the rack.
- 3 Reconnect the peripherals and connect the system to the electrical outlet.
- 4 Turn on the system, including any attached peripherals.




## Chassis View

### Front chassis view



- |    |                                       |    |                                  |
|----|---------------------------------------|----|----------------------------------|
| 1  | System Status Indicator               | 2  | System health and system ID      |
| 3  | iDRAC Quick Sync 2 wireless indicator | 4  | Hard drive (x8)                  |
| 5  | USB 3.0 connector                     | 6  | Optical-drive (optional)         |
| 7  | USB 2.0 connector                     | 8  | Power button/Power light         |
| 9  | VGA connector                         | 10 | USB management port/iDRAC Direct |
| 11 | USB 2.0 connector                     |    |                                  |


# Back chassis view



- |    |                                 |    |                                     |
|----|---------------------------------|----|-------------------------------------|
| 1  | PCIe expansion card slots       | 2  | PCIe expansion card slots           |
| 3  | PCIe expansion card slots       | 4  | PCIe expansion card slots           |
| 5  | Power supply (x2)               | 6  | Network connectors (x4)             |
| 7  | USB 3.0 connectors (x2)         | 8  | VGA connector                       |
| 9  | Serial connector                | 10 | iDRAC9 Enterprise Network connector |
| 11 | System identification connector | 12 | System identification button        |

## Inside the system

**NOTE:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that are shipped with your product.



**Figure 1. Inside chassis view**

- 1 hard drive backplane
- 2 cooling fan (6) in the cooling fan assembly
- 3 DIMM sockets
- 4 CPU DIMM blank
- 5 CPU 2
- 6 expansion card riser 3A
- 7 expansion card riser 2A
- 8 VFlash connector
- 9 system board
- 10 expansion card riser 1C
- 11 CPU 1

## LCD panel

The LCD panel provides system information, status, and error messages to indicate if the system is functioning correctly or requires attention. The LCD panel can be used to configure or view the system's iDRAC IP address. For more information about error messages, see the *Dell Event and Error Messages Reference Guide* at [Dell.com/openmanagemanuals](https://Dell.com/openmanagemanuals) > **OpenManage software**.

The LCD panel is available only on the optional LCD bezel. The optional LCD bezel is hot pluggable.

The statuses and conditions of the LCD panel are outlined here:

- The LCD backlight is white during normal operating conditions.
- When the system needs attention, the LCD backlight turns amber, and displays an error code followed by descriptive text.

**NOTE:** If the system is connected to a power source and an error is detected, the LCD turns amber regardless of whether the system is turned on or off.

- When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.
- If the LCD panel stops responding, remove the bezel and reinstall it. If the problem persists, see the Getting help section.
- The LCD backlight remains off if LCD messaging is turned off using the iDRAC utility, the LCD panel, or other tools.



Figure 2. LCD panel features

Table 1. LCD panel features

Item	Button or display	Description
1	Left	Moves the cursor back in one-step increments.
2	Select	Selects the menu item highlighted by the cursor.
3	Right	Moves the cursor forward in one-step increments. During message scrolling: <ul style="list-style-type: none"> <li>• Press and hold the right button to increase scrolling speed.</li> <li>• Release the button to stop.</li> </ul>
4	LCD display	Displays system information, status, and error messages or iDRAC IP address.

**NOTE:** The display stops scrolling when the button is released. After 45 seconds of inactivity, the display starts scrolling.

## Viewing Home screen

The **Home** screen displays user-configurable information about the system. This screen is displayed during normal system operation when there are no status messages or errors. When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.

- 1 To view the **Home** screen, press one of the three navigation buttons (Select, Left, or Right).
- 2 To navigate to the **Home** screen from another menu, complete the following steps:
  - a Press and hold the navigation button till the up arrow  is displayed.
  - b Navigate to the **Home** icon  using the up arrow .
  - c Select the **Home** icon.
  - d On the **Home** screen, press the **Select** button to enter the main menu.

# Setup menu

**NOTE:** When you select an option in the Setup menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC	Select <b>DHCP</b> or <b>Static IP</b> to configure the network mode. If <b>Static IP</b> is selected, the available fields are <b>IP</b> , <b>Subnet (Sub)</b> , and <b>Gateway (Gtw)</b> . Select <b>Setup DNS</b> to enable DNS and to view domain addresses. Two separate DNS entries are available.
Set error	Select <b>SEL</b> to view LCD error messages in a format that matches the IPMI description in the SEL. This enables you to match an LCD message with an SEL entry.  Select <b>Simple</b> to view LCD error messages in a simplified user-friendly description. For more information about error messages, see the <i>Dell Event and Error Messages Reference Guide</i> at <a href="https://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a> > <b>OpenManage software</b> .
Set home	Select the default information to be displayed on the <b>Home</b> screen. See View menu section for the options and option items that can be set as the default on the <b>Home</b> screen.

# View menu

**NOTE:** When you select an option in the View menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC IP	Displays the <b>IPv4</b> or <b>IPv6</b> addresses for iDRAC9. Addresses include <b>DNS (Primary and Secondary)</b> , <b>Gateway</b> , <b>IP</b> , and <b>Subnet</b> (IPv6 does not have Subnet).
MAC	Displays the MAC addresses for <b>iDRAC</b> , <b>iSCSI</b> , or <b>Network</b> devices.
Name	Displays the name of the <b>Host</b> , <b>Model</b> , or <b>User String</b> for the system.
Number	Displays the <b>Asset tag</b> or the <b>Service tag</b> for the system.
Power	Displays the power output of the system in BTU/hr or Watts. The display format can be configured in the <b>Set home</b> submenu of the <b>Setup</b> menu.
Temperature	Displays the temperature of the system in Celsius or Fahrenheit. The display format can be configured in the <b>Set home</b> submenu of the <b>Setup</b> menu.



# Product Overview

The following pages contain information about Dell Precision 7920 Rack product overview.

## System information label

### Precision 7920 Rack – Front system information label




Figure 3. LED Behavior, Express Service Tag, Configuration and Layout

# Precision 7920 Rack – Service information

### Service Information

**System Touchpoints**

- Components with orange touchpoints can be serviced while the system is running (not sleep).
- Components with blue touchpoints require a full system shutdown before servicing (cold swap).

### Mechanical Overview

**Top View**

**Front of system**

### Electrical Overview

**System Board Connections**

- NIC
- IO\_Riser 2
- TPM
- Coin Cell Battery
- IO\_Riser 1
- SATA\_B
- IO\_Riser 1/Mini/PCIe Option
- SATA\_A
- SATA\_Optical Drive
- CPU1 (Optical Channels 3/4/5)
- CPU2
- CPU1 DIMMs Channels 1/2/3
- CPU2 DIMMs Channels 3/4/5
- CPU3
- Backplane 0 Signal
- Backplane 1 Signal
- Backplane 2 Signal
- IO\_Riser 3
- PSU1
- Backplane 0 Power/Rear 3 PCIe 2280W Power
- Backplane 1 Power
- PSU2
- Backplane 2 Power
- Fan 5
- Jumpers
- Fan 4
- Internal USB
- ESDMM + of/ash
- Fan 3
- Backplane 1 Signal
- Backplane 1 Power
- Fan 1
- Left Control Panel
- CPU2 (Optical Channels 3/4/5)
- CPU3
- Backplane 0 Signal
- Backplane 1 Signal
- Backplane 2 Signal
- IO\_Riser 3
- PSU1
- Backplane 0 Power/Rear 3 PCIe 2280W Power
- Backplane 1 Power
- PSU2
- Backplane 2 Power
- Fan 5
- Jumpers
- Fan 4
- Internal USB
- ESDMM + of/ash
- Fan 3

**Rear View Configurations**

### Memory Information

**Caution:** Memory (DIMMs) and CPUs may be hot during servicing.

**Memory Population Configuration**

Configuration	Sequence
Memory-Optimized	1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12
Advanced ECC or Mirroring	(1,2) (3,4) (5,6) (7,8) (9,10) (11,12)

Memory sparing details are documented in the Owner's Manual.

**System Touchpoints**

**Memory Sparing**

**Hot Swap**

**Caution:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that came with the product.

Figure 4. System touchpoint, electrical overview, jumper settings and memory information



# Removing and installing components

This section provides detailed information on how to remove or install the components from your computer.

## Product Positioning

The Precision 7920 Rack is a general-purpose platform with highly expandable memory (up to 1536 GB), massive storage capacity and impressive I/O capability to match. The Precision 7920 Rack adds extraordinary storage capacity options, making it well-suited for data intensive applications that require greater storage, while not sacrificing I/O performance.

- **Performance**
  - Two Intel Xeon Skylake Processor Scalable Family processors
  - Twenty four DIMM Slot supporting up total up to 1.5TB of memory
  - Support total up to eight hard drives.
- **Availability**
  - Redundant power supply units (PSUs)
  - Hot-plug and hot-swappable PSUs, hard disk drives, and fans
  - PERC9/PERC10/Chipset SATA.
  - Internal vFLASH card
  - iDRAC9 Express or Enterprise with Dell Lifecycle Controller
  - Optional iDRAC Quick Sync II
- **Expandability, I/O Storage**
  - Only 8x 3.5" SAS,SATA(front) hard drives
  - Up to eight optional NVMe Express Flash PCIe SSDs with two PCIe Zoom4 cards.
  - System Network Architecture (SNA): 4x 1GbE or 2x 10GbE + 2x 1GbE
  - Choice of RAID options for even higher performance



# Recommended tools

Table 2. Recommended tools and optional tools

## Recommended tools



- Key to the system keylock
- #1 and #2 Phillips screwdriver
- T30 and T8 Torx screwdrivers
- Wrist-grounding strap connected to the ground
- ESD Mat

## Optional tools



- Needle-nose pliers to disconnect cables and connectors in hard-to-reach locations
- Small flat-head screwdriver to disconnect small cables from boards

# Need to know

Before you begin servicing the system, you must read the following information:

- Critical callouts
- Common error codes
- Version control for BIOS/ Firmware/ Software
- Startup/Shutdown sequence

# Common error messages

The Event Message Reference contains the error and event information generated by firmware and other agents that monitor system components. These events might be logged, presented to the user on one of the system management consoles, or both logged and displayed.

Each event consists of the following fields:

**Table 3. Common error messages****Event Message Fields**

Item	Description
Message ID	<p>The unique alphanumeric identifier for the event. This identifier can be up to eight characters long and consist of two parts:</p> <ul style="list-style-type: none"> <li>• Message ID Prefix — Up to four alphabetic characters.</li> <li>• Message ID Sequence — Up to four numeric digits.</li> </ul>
Message	<p>The message text that is displayed to the user or logged as a result of the event. If the message has variable content in it, the variable substitution is reflected by text in <i>italics</i>. The substitution variables are described in the Arguments field of the event.</p>
Arguments	<p>Describes the values for any substitution variables appearing in the event message text. If there is no variable content in the message, this field is omitted from the event description.</p>
Detailed Description	<p>Additional information describing the event.</p>
Recommended Response Action	<p>The recommended action to remedy the event described. The response action can vary based on the specific platform.</p>
Category	<p>Dell Lifecycle Controller log filter used to select a subset of messages from different domains or agents.</p>
Subcategory	<p>Additional filter to further subset the event.</p>
Trap/EventID	<p>The identification number used as the Trap ID for SNMP alert traps and as the Event ID when the message is logged in operating system logs.</p>
Severity	<p>The classification of the event based on its impact to the platform or system. The severity can be:</p> <ul style="list-style-type: none"> <li>• Severity 1 Critical — Indicates a catastrophic production problem that might severely impact production systems or components, or systems are down or not functioning.</li> <li>• Severity 2 Warning — Indicates a high-impact problem where a system or component is disrupted but can remain productive and perform business-level operations.</li> <li>• Severity 3 Information — Indicates a medium-to-low impact problem that involves a partial or noncritical loss of functionality; operations are impaired but can continue to function.</li> </ul>
LCD Message	<p>The event message text that is displayed on the system's LCD.</p>
Initial Default	<p>Event messages result in event actions such as logging, SNMP or email alerts. Generally, the event actions are configurable using the Dell iDRAC event action filtering feature. This item describes the initial default and possible event actions for the message.</p>
Event Action Filter	<p>Describes additional configurable actions that are available for the event action for this message. This information is presented in a table, and each entry has a value of <code>TRUE</code> or <code>FALSE</code> to indicate its applicability.</p> <ul style="list-style-type: none"> <li>• Filter Visibility — Event visible to iDRAC event filtering.</li> <li>• IPMI Alert — Event can generate an IMPI alert.</li> <li>• SNMP Alert — Event can generate an SNMP trap.</li> <li>• Email Alert — Event can generate an email alert.</li> </ul>



## Event Message Fields

Item	Description
	<ul style="list-style-type: none"><li>• LC Log — Event can generate a Dell Lifecycle Controller log entry.</li><li>• LCD — Event is displayed on the system's LCD.</li><li>• Power Off — Event can cause the system to power off.</li><li>• Power Cycle — Event can cause the system to perform a power cycle.</li><li>• Reset — Event can cause the system to perform a reset.</li></ul>

For more information on the list of error and event messages, see the [Dell Event Messages Reference Guide](#)

## Startup-Shutdown sequence

**NOTE:** Precision 7920 Rack BIOS is pure UEFI with a legacy compatibility layer. This layer is called the Compatibility Support Module.

## New POST display

The following are the POST display enhancements:

- The look of the boot process has been revamped for Precision 7920 Rack.
- The Dell high-resolution splash screen displays instantly after power-on.
- Both a progress bar and descriptive text appear on-screen.
- Hotkey behavior remains unchanged (<F2> still takes you to System Setup).
- There is a uniform look and feel through the boot process (one exception — the system will drop to text mode briefly to run legacy option ROMs when booting in legacy mode).
- POST error messages are now compliant with Error Exception Message Initiative (EEMI).

**NOTE:** All POST error and warning messages will be logged in the LC log.

- UEFI option ROMs display error/warning messages on the screen via the Driver Health Protocol (DHP). The auto-repair logic is also included in Boot Device Selection (BDS) just before booting. Show the repair GUI and load the controller formset if EfiDriverHealthStatusConfigurationRequired status is returned.

## Enhanced boot support

The following lists the boot support enhancements:

- Enhanced method to change the boot list based on Fully Qualified Descriptors (FQDDs). This allows for systems management consoles and the factory to specify a boot list for devices that are not currently present, for example, disabled NDC or other boot mode.
- New ability to toggle between LC and BIOS.
- The Boot Manager (<F11>) and BIOS Setup (<F2>) will only contain the boot option enumeration of the current Boot mode.
- Completely revised boot flow.

# Diagnostics and indicators

The following pages contain the information about diagnostics and indicators for Precision 7920 Rack.

## Chassis LEDs

The following pages contain the information about the chassis LEDs.

### Status LED indicators

**NOTE:** The diagnostic indicators are not present if the system is equipped with an LCD display.

**NOTE:** The status LED indicators are always off and only turns on to a solid amber if any error occurs.

Table 4. Status LED indicators and descriptions


Icon	Description	Condition	Corrective action
	Health indicator	The indicator turns solid blue if the is in good health.  The indicator blinks amber: <ul style="list-style-type: none"><li>When the is turned on.</li><li>When the is in standby.</li><li>If any error condition exists. For example, a failed fan, PSU, or a hard drive.</li></ul>	None required.  Check the System Event Log or system messages for the specific issue. For more information about error messages, see the <i>Dell Event and Error Messages Reference Guide</i> at <a href="http://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a> > <b>OpenManage software</b> .  The POST process is interrupted without any video output due to invalid memory configurations. See the Getting help section.
	Drive indicator	The indicator turns solid amber if there is a drive error.	<ul style="list-style-type: none"><li>Check the System Event Log to determine if the drive has an error.</li><li>Run the appropriate Online Diagnostics test. Restart the system and run embedded diagnostics (ePSA).</li><li>If the drives are configured in a RAID array, restart the system, and enter the host adapter configuration utility program.</li></ul>
	Temperature indicator	The indicator turns solid amber if the system experiences a thermal error (for example, the ambient temperature is out of range or there is a fan failure).	Ensure that none of the following conditions exist: <ul style="list-style-type: none"><li>A cooling fan has been removed or has failed.</li><li>System cover, air shroud, memory module blank, or back filler bracket is removed.</li><li>Ambient temperature is too high.</li><li>External airflow is obstructed.</li></ul> If the problem persists, see the Getting help section.
	Electrical indicator	The indicator turns solid amber if the system experiences an electrical error (for example, voltage out of range, or a failed power supply unit (PSU) or voltage regulator).	Check the System Event Log or system messages for the specific issue. If it is due to a problem with the PSU, check the LED on the PSU. Reseat the PSU. If the problem persists, see the Getting help section.
	Memory indicator	The indicator turns solid amber if a memory error occurs.	Check the System Event Log or system messages for the location of the failed memory. Reseat the memory



Icon	Description	Condition	Corrective action
	PCIe indicator	The indicator turns solid amber if a PCIe card experiences an error.	<p>Restart the system. Update any required drivers for the PCIe card. Reinstall the card. If the problem persists, see the Getting help section.</p> <p><b>NOTE:</b> For more information about the supported PCIe cards, see the Expansion card installation guidelines section.</p>

## Hard drive indicator codes

Each hard drive carrier has an activity LED indicator and a status LED indicator. The indicators provide information about the current status of the hard drive. The activity LED indicator indicates whether the hard drive is currently in use or not. The status LED indicator indicates the power condition of the drive.



**Figure 5. Hard drive indicators**

- 1 hard drive activity LED indicator
- 2 hard drive status LED indicator
- 3 hard drive

**NOTE:** If the hard drive is in the Advanced Host Controller Interface (AHCI) mode, the status LED indicator does not turn on.

**NOTE:** Drive status indicator behavior is managed by Storage Spaces Direct. Not all drive status indicators may be used.

**Table 5. Hard drive indicator codes**

Hard drive status indicator code	Condition
Flashes green twice per second	Identifying drive or preparing for removal.
Off	Drive ready for removal.

**NOTE:** The drive status indicator remains off until all drives are initialized after the system is turned on. Drives are not ready for removal during this time.

Hard drive status indicator code	Condition
Flashes green, amber, and then turns off	Predicted drive failure.
Flashes amber four times per second	Drive failed.
Flashes green slowly	Drive rebuilding.
Solid green	Drive online.
Flashes green for three seconds, amber for three seconds, and then turns off after six seconds	Rebuild stopped.

## NIC indicator codes

Each NIC on the back of the system has indicators that provide information about the activity and link status. The activity LED indicator indicates if data is flowing through the NIC, and the link LED indicator indicates the speed of the connected network.




Figure 6. NIC indicator codes


- 1 link LED indicator
- 2 activity LED indicator

Table 6. NIC indicator codes

Status	Condition
Link and activity indicators are off	The NIC is not connected to the network.
Link indicator is green and activity indicator is blinking green	The NIC is connected to a valid network at its maximum port speed and data is being sent or received.
Link indicator is amber and activity indicator is blinking green	The NIC is connected to a valid network at less than its maximum port speed and data is being sent or received.
Link indicator is green and activity indicator is off	The NIC is connected to a valid network at its maximum port speed and data is not being sent or received.
Link indicator is amber and activity indicator is off	The NIC is connected to a valid network at less than its maximum port speed and data is not being sent or received.
Link indicator is blinking green and activity is off	NIC identify is enabled through the NIC configuration utility.

## Power supply unit indicator codes

AC power supply units (PSUs) have an illuminated translucent handle that serves as an indicator. The indicator shows whether power is present or a power fault has occurred.



**Figure 7. AC PSU status indicator**

1 AC PSU status indicator/handle

**Table 7. AC PSU status indicator codes**

Power indicator codes	Condition
Green	A valid power source is connected to the PSU and the PSU is operational.
Blinking amber	Indicates a problem with the PSU.
Not illuminated	Power is not connected to the PSU.
Blinking green	When the firmware of the PSU is being updated, the PSU handle blinks green. <ul style="list-style-type: none"> <li>⚠ <b>CAUTION:</b> Do not disconnect the power cord or unplug the PSU when updating firmware. If firmware update is interrupted, the PSUs do not function.</li> </ul>
Blinking green and turns off	When hot-plugging a PSU, the PSU handle blinks green five times at a rate of 4 Hz and turns off. This indicates a PSU mismatch with respect to efficiency, feature set, health status, or supported voltage. <ul style="list-style-type: none"> <li>⚠ <b>CAUTION:</b> If two PSUs are installed, both the PSUs must have the same type of label. For example, Extended Power Performance (EPP) label. Mixing PSUs from previous generations of Precision Workstation is not supported, even if the PSUs have the same power rating. This results in a PSU mismatch condition or failure to turn the system on.</li> <li>⚠ <b>CAUTION:</b> When correcting a PSU mismatch, replace only the PSU with the blinking indicator. Swapping the PSU to make a matched pair can result in an error condition and unexpected system shutdown. To change from a high output configuration to a low output configuration or vice versa, you must turn off the system.</li> <li>⚠ <b>CAUTION:</b> AC PSUs support both 240 V and 120 V input voltages with the exception of Titanium PSUs, which support only 240 V. When two identical PSUs receive different input voltages, they can output different wattages, and trigger a mismatch.</li> <li>⚠ <b>CAUTION:</b> If two PSUs are used, they must be of the same type and have the same maximum output power.</li> <li>ℹ <b>NOTE:</b> Ensure that both the PSUs are of the same capacity.</li> <li>ℹ <b>NOTE:</b> Mixing PSUs (even the PSUs that have the same power rating) from previous generations of Precision Workstation is not supported. This results in a PSU mismatch condition or failure to turn the system on.</li> </ul>

## iDRAC Direct LED indicator codes

The iDRAC Direct LED indicator lights up to indicate that the port is connected and is being used as a part of the iDRAC subsystem.

iDRAC Direct LED indicator is located below the iDRAC Direct port on the right control panel.

You can configure iDRAC Direct by using a USB to micro USB (type AB) cable, which you can connect to your laptop or tablet. The following table describes iDRAC Direct activity when the iDRAC Direct port is active:



**Table 8. iDRAC Direct LED indicator codes**

iDRAC Direct LED indicator code	Condition
Solid green for two seconds	Indicates that the laptop or tablet is connected.
Flashing green (on for two seconds and off for two seconds)	Indicates that the laptop or tablet connected is recognized.
Turns off	Indicates that the laptop or tablet is unplugged.

## iDRAC Quick Sync 2 indicator codes

iDRAC Quick Sync 2 module (optional) is located on the left controlfront panel of your system.



**Figure 8. iDRAC Quick Sync 2 indicator**



**Figure 9. iDRAC Quick Sync 2 indicators**

**Table 9. iDRAC Quick Sync 2 indicators and descriptions**

iDRAC Quick Sync 2 indicator code	Condition	Corrective action
Off (default state)	Indicates that the iDRAC Quick Sync 2 feature is turned off. Press the iDRAC Quick Sync 2 button to turn on the iDRAC Quick Sync 2 feature.	If the LED fails to turn on, reseal the left control panel flex cable and check. If the problem persists, see the Getting help section.
Solid white	Indicates that iDRAC Quick Sync 2 is ready to communicate. Press the iDRAC Quick Sync 2 button to turn off.	If the LED fails to turn off, restart the system. If the problem persists, see the Getting help section.
Blinks white rapidly	Indicates data transfer activity.	If the indicator continues to blink indefinitely, see the Getting help section.
Blinks white slowly	Indicates that firmware update is in progress.	If the indicator continues to blink indefinitely, see the Getting help section.
Blinks white five times rapidly and then turns off	Indicates that the iDRAC Quick Sync 2 feature is disabled.	Check if iDRAC Quick Sync 2 feature is configured to be disabled by iDRAC. If the problem persists, see the Getting help section. For more information, see <i>Integrated Dell Remote Access Controller User's Guide</i> at <a href="http://Dell.com/idracmanuals">Dell.com/idracmanuals</a> or <i>Dell</i>



iDRAC Quick Sync 2 indicator code	Condition	Corrective action
Solid amber	Indicates that the system is in fail-safe mode.	Restart the system. If the problem persists, see the Getting help section.
Blinking amber	Indicates that the iDRAC Quick Sync 2 hardware is not responding properly.	Restart the system. If the problem persists, see the Getting help section.

## Enhanced Preboot System Assessment

If you experience a problem with your system, run the system diagnostics before contacting Dell for technical assistance. The purpose of running system diagnostics is to test your system hardware without requiring more equipment or risking data loss. If you are unable to fix the problem yourself, service and support personnel can use the diagnostics results to help you solve the problem.

### Dell Embedded system diagnostics

**NOTE:** The Dell Embedded System Diagnostics is also known as Enhanced Preboot System Assessment (ePSA) diagnostics.


The embedded system diagnostics provides a set of options for particular device groups or devices allowing you to:

- Run tests automatically or in an interactive mode.
- Repeat tests
- Display or save test results.
- Introduce more test options for extra information about the failed devices, run a thorough test.
- View status messages that inform you if tests are completed successfully.
- View error messages that inform you of problems encountered during testing.



### Running the Embedded system diagnostics from Boot Manager

To run the embedded system diagnostics from Boot Manager:


- 1 As the system boots, press <F11>.



- 2 Using the arrow keys select **System Utilities** → **Launch Diagnostics**.



3 Wait while the Quick Tests automatically run.



4 Once the tests have been completed, you can view the results and additional information on the **Results** tab, the **System Health** tab, the **Configuration** tab, and the **Event Log** tab.

5 Close the **Embedded System Diagnostics** utility.

6 To leave the diagnostics, click **Exit**.


7 Click **OK** when prompted, and the system reboots.

## Running the Embedded System Diagnostics from the Dell Lifecycle Controller


To run the embedded system diagnostics from the Dell Lifecycle Controller:



- 1 As the system boots, press **F10**.



- 2 Select **Hardware Diagnostics** → **Run Hardware Diagnostics**.



## Jumpers and connectors

This topic provides specific information about the jumpers. It also provides some basic information about jumpers and switches and describes the connectors on the various boards in the system. Jumpers on the system board help to disable the system and setup passwords. You must know the connectors on the system board to install components and cables correctly.

# System board jumpers and connectors




Figure 10. System board jumpers and connectors

Table 10. System board jumpers and connectors

Item	Connector	Description
1	J_ODD	Optical drive power connector
2	A7, A1, A8, A2, A9, A3	Memory module sockets
3	J_FAN2U_6	Cooling fan 6 connector
4	J_BP3	Backplane 3 power connector
5	J_FAN2U_5	Cooling fan 5 connector
6	A6, A12, A5, A11, A4, A10	Memory module sockets
7	J_FAN2U_4	Cooling fan 4 connector
8	INTRUSION_DET	Intrusion switch connector



Item	Connector	Description
9	B7, B1, B8, B2, B9, B3	Memory module sockets
10	J_FAN2U_3	Cooling fan 3 connector
11	J_FAN2U_2	Cooling fan 2 connector
12	J_BP_SIG1	Backplane 1 signal connector
13	B6, B12, B5, B11, B4, B10	Memory module sockets
14	J_BP1	Backplane 1 power connector
15	J_FAN2U_1	Cooling fan 1 connector
16	P_LFT_CP	Left control panel connector
17	CPU2	CPU2 processor and heat sink module socket (with dust cover)
18	J_R3_X24	Riser 3 connector
19	J_BP_SIG2	Backplane 2 signal connector
20	J_BP_SIG0	Backplane 0 signal connector
21	J_BP0 (RSR3_225W)	Backplane 0 power connector (Riser 3 PCIe 225 W power)
22	J_BP2 (RSR2_225W)	Backplane 2 power connector (Riser 2 PCIe 225 W power)
23	J_BATT_SIG	NVDIMM-N battery signal connector
24	J_BATT_PWR	NVDIMM-N battery power connector
25	J_USB_INT	Internal USB connector
26	J_IDSDM	IDSMD/vFlash connector
27	J_NDC	NDC connector
28	J_R2_X24_IT9	Riser 2 connector
29	J_R2_3R_X8_IT9	Riser 2 connector
30	BATTERY	Battery connector
31	J_FRONT_VIDEO	Video connector
32	J_R1_SS82_3 and J_R1_SS60_1	Riser 1 connector
33	J_TPM_MODULE	TPM connector
34	J_SATA_B	SATA B connector
35	J_R1_SS82_1	Riser 1 connector (Mini PERC option)
36	J_SATA_A	SATA A connector
37	J_SATA_C	SATA C connector (Optical drive SATA connector)
38	CPU1	CPU1 processor and heat sink module
39	P_RGT_CP	Right control panel connector

## System board jumper settings

For information on resetting the password jumper to disable a password, see the Disabling a forgotten password section.

**Table 11. System board jumper settings**

Jumper	Setting	Description
PWRD_EN	 2 4 6 (default)	The BIOS local access is protected with the software security features.
	 4 6	The BIOS local access security features are unlocked on the next AC power cycle.
NVRAM_CLR	 1 3 5 (default)	The BIOS configuration settings are retained at system boot.
	 1 3	The BIOS configuration settings are cleared at system boot.

## Disabling forgotten password

The software security features of the system include a system password and a setup password. The password jumper enables or disables password features and clears any password(s) currently in use.

### Prerequisite

**⚠ CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that are shipped with your product.

### Steps

- 1 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 2 Remove the system cover.
- 3 Move the jumper on the system board jumper from pins 2 and 4 (default) to pins 4 and 6.
- 4 Install the system cover.

The existing passwords are not disabled (erased) until the system boots with the jumper on pins 4 and 6. However, before you assign a new system and/or setup password, you must move the jumper back to pins 2 and 4.

**ⓘ NOTE:** If you assign a new system and/or setup password with the jumper on pins 4 and 6, the system disables the new password(s) the next time it boots.

- 5 Reconnect the system to its electrical outlet and turn on the system, including any attached peripherals.
- 6 Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
- 7 Remove the system cover.
- 8 Move the jumper on the system board jumper from pins 4 and 6 to pins 2 and 4 (default).
- 9 Install the system cover.
- 10 Reconnect the system to its electrical outlet and turn on the system, including any attached peripherals.
- 11 Assign a new system and/or setup password.


# Disassembly and reassembly

The following sections contain the procedures for removing and replacing system components.

## Front Bezel

### Removing the optional front bezel

- 1 Locate and remove the bezel key.
  - ① **NOTE: The bezel key is attached to the LCD bezel package.**
- 2 Unlock the bezel by using the key.
- 3 Press the release button to release the bezel, and pull the left end of the bezel.
- 4 Unhook the right end, and remove the bezel.



### Installing the optional front bezel

- 1 Locate and remove the bezel key.
  - ① **NOTE: The bezel key is attached to the LCD bezel package.**
- 2 Align and insert the right end of the bezel onto the system .
- 3 Press the release button and fit the left end of the bezel onto the system.
- 4 Lock the bezel by using the key.

# System cover

## Removing system cover

### Prerequisites

- 1 Turn off the system, including any attached peripherals.
- 2 Disconnect the system from the electrical outlet and disconnect the peripherals.

### Steps

- 1 Using a flat head screwdriver, rotate the latch release lock counter clockwise to the unlocked position.
- 2 Lift the latch till the system cover slides back and the tabs on the system cover disengage from the slots on the system.
- 3 Hold the cover on both sides, and lift the cover away from the system.



## Installing system cover

### Prerequisite

- 1 Ensure that all internal cables are routed correctly and connected, and no tools or extra parts are left inside the system.

### Steps

- 1 Align the tabs on the system cover with the slots on the system.
- 2 Push the system cover latch down.
- 3 Using a flat head screwdriver, rotate the latch release lock clockwise to the locked position.

### Next steps

- 1 Reconnect the peripherals and connect the system to the electrical outlet.



- 2 Turn on the system, including any attached peripherals.

## Optical drive


### Removing optical drive

#### Prerequisites

- 1 If installed, remove the front bezel.
- 2 Remove the system cover.

#### Steps

- 1 Disconnect the optical drive cable from the optical drive.
- 2 Press the blue latch and slide the optical drive from the system.



#### Next step

Install the optical drive.

### Installing optical drive

- 1 Slide the optical drive to the system, until the locks into place.
- 2 Connect the optical drive cable on the optical drive.
- 3 Install system cover and front bezel if applicable.

# Air shroud

## Removing air shroud

### Prerequisites


#### ⚠ CAUTION:

Never operate your system with the air shroud removed. The system may get overheated quickly, resulting in shutdown of the system and loss of data.

- 1 If installed, remove the full length PCIe cards.
- 2 If applicable, remove the GPU cards.

### Step

Hold the shroud at both ends and lift it away from the system.



### Next step

Install the shroud.

## Installing air shroud

### Prerequisite

- 1 If applicable, route the cables inside the system along the system wall and secure the cables by using the cable securing bracket.

### Steps

- 1 Align the tabs on the air shroud with the slots on the system.
- 2 Lower the air shroud into the system until it is firmly seated.  
When firmly seated, the memory socket numbers marked on the air shroud align with the respective memory sockets.

### Next steps

- 1 If removed, install the full length PCIe cards.




- 2 If applicable, install the GPU cards.

## Cooling fan assembly

### Removing cooling fan assembly

- 1 Lift the release levers to unlock the cooling fan assembly from the system.
- 2 Hold the release levers and lift the cooling fan assembly away of the system.



### Installing cooling fan assembly

- 1 Align the guide rails on the cooling fan assembly with the standoffs on the system.
- 2 Lower the cooling fan assembly into the system until the cooling fan connectors engage with the connectors on the system board.
- 3 Press the release levers to lock the cooling fan assembly into the system.

## Cooling fans

### Removing cooling fan

#### Prerequisites

**⚠ WARNING:** Opening or removing the system cover when the system is ON may expose you to a risk of electric shock. Exercise utmost care while removing or installing cooling fans.

**ℹ NOTE:** The system will shutdown if the system cover is removed before shutting down the system

**CAUTION:** The cooling fans are hot swappable. To maintain proper cooling while the system is on, replace only one fan at a time.

### Step

Press the release tab and lift the cooling fan out of the cooling fan assembly.



## Installing cooling fan

- 1 Holding the release tab, align the connector at the base of the cooling fan with the connector on the system board.
- 2 Slide the cooling fan into the cooling fan assembly until the release tab locks into place.

## Intrusion switch


### Removing intrusion switch

#### Prerequisite

- 1 Remove the cooling fan assembly.

#### Step

Press the intrusion switch and slide it out of the from the intrusion switch slot.



## Installing intrusion switch

### Steps

- 1 Align the tabs on the intrusion switch with the slots on the cooling fan assembly.
- 2 Pull the intrusion switch up and push it until the switch locks in place.

### Next step

- 1 Install the cooling fan assembly.

## Hard drive

### Removing hard drive blank


#### Prerequisite

- 1 If installed, remove the front bezel.

**⚠ CAUTION: To maintain proper system cooling, all empty hard drive slots must have hard drive blanks installed.**

#### Step

Press the release button and slide the hard drive blank out of the hard drive slot.



## Installing hard drive blank

### Step

Insert the hard drive blank into the hard drive slot and push until the release button clicks into place.

### Next step

- 1 If removed, install the front bezel.

## Removing hard drive

### Prerequisites

- 1 If applicable, remove the front bezel.
- 2 Using the management software, prepare the hard drive for removal. If the hard drive is online, the green activity or fault indicator flashes while the drive is turning off. When the hard drive indicators are off, the hard drive is ready for removal. For more information, see the documentation for the storage controller.

**CAUTION:** To prevent data loss, ensure that your operating system supports hot swappable drive installation. See the documentation supplied with your operating system.

**CAUTION:** Before attempting to remove or install a hard drive while the system is running, see the documentation for the storage controller card to ensure that the host adapter is configured correctly to support hard drive removal and insertion.

**CAUTION:** Mixing hard drives from previous generations of Precision Workstations is not supported.

### Steps

- 1 Press the release button to open the hard drive release handle.
- 2 Holding the handle, slide the hard drive out of the hard drive slot.



### Next step

Install the hard drive.

**NOTE:** If you are not replacing the hard drive immediately, insert a hard drive blank in the empty hard drive slot.

## Installing hard drive

### Prerequisites

**CAUTION:** When installing a hard drive, ensure that the adjacent drives are fully installed. Inserting a hard drive carrier and attempting to lock its handle next to a partially installed carrier can damage the partially installed carrier's shield spring and make it unusable.

**NOTE:** To prevent data loss, ensure that your operating system supports hot-swap drive installation. See the documentation supplied with your operating system.

**NOTE:** When a replacement hot swappable hard drive is installed and the system is powered on, the hard drive automatically begins to rebuild. Make absolutely sure that the replacement hard drive is blank or contains data that you wish to have overwritten. Any data on the replacement hard drive is immediately lost after the hard drive is installed.

### Steps

- 1 Press the release button on the front of the hard drive to open the release handle.
- 2 Insert the hard drive into the hard drive slot until the hard drive connects with the backplane.
- 3 Close the hard drive handle to lock the hard drive in place.



**Figure 11. Installing hard drive**

**Next step**

If applicable, install the front bezel.

## Removing 3.5 inch hard drive from hard drive carrier

**Steps**

- 1 Using Phillips #1 screwdriver, remove the screws from the slide rails on the hard drive carrier.
- 2 Lift the hard drive out of the hard drive carrier.



**Next step**

Install hard drive into the hard drive carrier.



## Installing 3.5 inch hard drive into hard drive carrier

- 1 Insert the hard drive into the hard drive carrier with the connector end of the hard drive toward the back of the carrier.
- 2 Align the screw holes on the hard drive with the screws holes on the hard drive carrier.  
When aligned correctly, the back of the hard drive is flush with the back of the hard drive carrier.
- 3 Using the Phillips #1 screwdriver, tighten the screws to secure the hard drive to the hard drive carrier.



## Removing hard drive

### Prerequisites

- 1 If applicable, remove the front bezel.
- 2 Using the management software, prepare the hard drive for removal. If the hard drive is online, the green activity or fault indicator flashes while the drive is turning off. When the hard drive indicators are off, the hard drive is ready for removal. For more information, see the documentation for the storage controller.


**CAUTION:** To prevent data loss, ensure that your operating system supports hot swappable drive installation. See the documentation supplied with your operating system.

**CAUTION:** Before attempting to remove or install a hard drive while the system is running, see the documentation for the storage controller card to ensure that the host adapter is configured correctly to support hard drive removal and insertion.

**CAUTION:** Mixing hard drives from previous generations of Precision Workstations is not supported.

### Steps

- 1 Press the release button to open the hard drive release handle.
- 2 Holding the handle, slide the hard drive out of the hard drive slot.



#### Next step

Install the hard drive.

**NOTE:** If you are not replacing the hard drive immediately, insert a hard drive blank in the empty hard drive slot.

## Installing 2.5 inch hard drive

### Prerequisites

- CAUTION:** When installing a hard drive, ensure that the adjacent drives are fully installed. Inserting a hard drive carrier and attempting to lock its handle next to a partially installed carrier can damage the partially installed carrier's shield spring and make it unusable.
- NOTE:** To prevent data loss, ensure that your operating system supports hot-swap drive installation. See the documentation supplied with your operating system.
- NOTE:** When a replacement hot swappable hard drive is installed and the system is powered on, the hard drive automatically begins to rebuild. Make absolutely sure that the replacement hard drive is blank or contains data that you wish to have overwritten. Any data on the replacement hard drive is immediately lost after the hard drive is installed.

### Steps

- 1 Press the release button on the front of the hard drive to open the release handle.
- 2 Insert the hard drive into the hard drive slot until the hard drive connects with the backplane.
- 3 Close the hard drive handle to lock the hard drive in place.




Figure 12. Installing hard drive


**Next step**

If applicable, install the front bezel.


## Removing 2.5 inch hard drive from 3.5 inch hard drive carrier

**Steps**

- 1 Using Phillips #1 screwdriver, remove the screws from the slide rails on the 3.5 inch hard drive carrier and lift the hard drive.



- 2 Remove the screws that secure 2.5 inch hard drive to the hard drive assembly and remove the hard drive.




**Next step**

Install hard drive into the hard drive carrier.


## Installing 2.5 inch hard drive into 3.5 inch hard drive carrier

- 1 Insert the 2.5 inch hard drive into the hard drive carrier and tighten the screws.





- 2 Place the 2.5 inch hard drive into the 3.5 inch hard drive carrier.
- 3 Align the screw holes on the hard drive with the screws holes on the hard drive carrier.



## Memory modules

### Removing memory modules

#### Prerequisites


- 1 If applicable, remove the air shroud.

**⚠ WARNING:** Allow the memory modules to cool after you power off the system. Handle the memory modules by the card edges and avoid touching the components or metallic contacts on the memory module.

**⚠ CAUTION:** To ensure proper system cooling, memory module blanks must be installed in any memory socket that is not occupied. Remove memory module blanks only if you intend to install memory modules in those sockets.

### Steps

- 1 Locate the appropriate memory module socket.
- 2 Push the ejectors outward on both ends of the memory module socket, to release the memory module from the socket.



- 3 Lift and remove the memory module from the system.

## Installing memory modules

### Steps

- 1 Locate the appropriate memory module socket.
- 2 Open the ejectors on the memory module socket outward to allow the memory module to be inserted into the socket.
- 3 Align the edge connector of the memory module with the alignment key of the memory module socket, and insert the memory module in the socket.

**⚠ CAUTION:** Do not apply pressure at the center of the memory module; apply pressure at both ends of the memory module evenly.

**ⓘ NOTE:** The memory module socket has an alignment key that enables you to install the memory module in the socket in only one orientation.

- 4 Press the memory module with your thumbs until the socket levers firmly click into place.
- 5 Repeat step 1 through step 4 of this procedure to install the remaining memory modules.

### Next steps

- 1 If applicable, install the air shroud.
- 2 To verify if the memory module has been installed properly, press F2 and navigate to **System Setup Main Menu > System BIOS > Memory Settings**. In the Memory Settings screen, the System Memory Size must reflect the updated capacity of the installed memory.
- 3 If the value is incorrect, one or more of the memory modules may not be installed properly. Ensure that the memory module is firmly seated in the memory module socket.
- 4 Run the system memory test in system diagnostics.



# Processors and heat sinks

## Removing processor and heat sink module

- 1 Using Torx #T30 screwdriver, loosen the screws.  
**NOTE:** Ensure that the screw is completely loosened before moving on to the next screw.
- 2 Pushing both retention clips simultaneously, lift the processor heat sink module out of the system
- 3 Set the module aside with processor side facing up.





Figure 13. Removing heat sink (2U)

## Removing processor from processor heat sink module

- 1 Place the heat sink with the processor side facing up.
- 2 Insert a flat blade screwdriver into the release slot marked with a yellow label. Twist (do not pry) the screwdriver to break the thermal paste seal.
- 3 Push the retaining clips on the processor bracket to unlock the bracket from the heat sink.



- 4 Lift the bracket and the processor away from the heat sink, and place the processor connector side down on the processor tray.
- 5 Flex the outer edges of the bracket to release the processor from the bracket.

① **NOTE:** Ensure that the processor and the bracket are placed in the tray after you remove the heat sink.



## Installing processor into processor heat sink module

### Steps

- 1 Place the processor in the processor tray.

① **NOTE:** Ensure that pin 1 indicator on the CPU tray is aligned with the pin 1 indicator on the processor.

- 2 Flex the outer edges of the bracket around the processor ensuring that the processor is locked into the clips on the bracket.

① **NOTE:** Ensure pin 1 indicator on the bracket is aligned with the pin 1 indicator on the processor before placing the bracket on the processor.






**Figure 14. Installing the processor bracket**

- 3 If you are using an existing heat sink, remove the thermal grease from the heat sink by using a clean lint-free cloth.
- 4 Use the thermal grease syringe included with your processor kit to apply the grease in a spiral quadrilateral design on the top of the processor.


**⚠ CAUTION:** Applying too much thermal grease can result in excess grease coming in contact with and contaminating the processor socket.

**ℹ NOTE:** The thermal grease syringe is intended for single use only. Dispose the syringe after you use it.



**Figure 15. Applying thermal grease on top of the processor**

- 5 Place the heat sink on the processor and push down until the bracket locks onto the heat sink.



**NOTE:**

- Ensure that the two guide pin holes on the bracket match the guide holes on the heat sink.

**Next steps**

- 1 Install the processor and heat sink module.
- 2 Install air shroud.

## Installing processor and heat sink module

- 1 Align the pin 1 indicator of the heat sink to the system board and then place the processor and heat sink module on the processor socket.

**CAUTION:** To avoid damaging the fins on the heat sink, do not press down on the heat sink fins.

**NOTE:** Ensure that the processor and heat sink is held parallel to the system board to prevent damaging the components.

- 2 Push the blue retention clips inward to allow the heat sink to drop into place.
- 3 Using the #Torx T30 screwdriver, tighten one screw at a time.

**NOTE:** Ensure that the screw is tightened completely before moving onto the next screw.




Figure 16. Installing the processor and heat sink module (2U)

## Expansion card

### Removing expansion card from expansion card riser

#### Prerequisite

- 1 If applicable, disconnect the cables from the expansion card.

#### Steps

- 1 Lift the expansion card latch out of the slot.
- 2 Hold the expansion card by its edges, and pull the card until the card edge connector disengages from the expansion card connector on the riser.




Figure 17. Removing expansion card from expansion card riser 1





Figure 18. Removing expansion card from expansion card riser 2



**Figure 19. Removing expansion card from expansion card riser 3**

- 3 If you are removing the card permanently, install a metal filler bracket over the empty expansion slot opening and close the expansion card latch.

**NOTE:** You must install a filler bracket over an empty expansion card slot to maintain Federal Communications Commission (FCC) certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.

- 4 Insert the expansion card latch into the slot to secure the bracket.

## Installing expansion card into expansion card riser

### Prerequisite

- 1 Unpack the expansion card and prepare it for installation.

**NOTE:** For instructions, see the documentation accompanying the card.

### Steps

- 1 Lift the expansion card latch and remove the filler bracket.
- 2 Hold the card by its edges, and align the card edge connector with the expansion card connector on the riser.
- 3 Insert the card edge connector firmly into the expansion card connector until the card is fully seated.
- 4 Close the expansion card latch.

### Next steps

- 1 If applicable, connect the cables to the expansion card.
- 2 Install any device drivers required for the card as described in the documentation for the card.


## Opening and closing the full length PCIe card holder latch

### About this task

**NOTE:** Before installing a full length PCIe card, the PCIe card holder latch must be open.

## Steps

- 1 To open the PCIe card holder latch, press the release tab.
- 2 To close the PCIe card holder latch, rotate the latch until it locks.




## Removing expansion card riser 1



### Prerequisites

- 1 If installed, remove expansion cards from the riser.
- 2 Disconnect any cables connected to the riser card.

### About this task

**NOTE:** If installing a replacement expansion card riser 1 make sure the VROC key is transferred from the old card to the new card.





### Steps

- 1 Pull the expansion card latch out of the slot.
- 2 Hold the expansion card by its edges, and pull the card until the card edge connector disengages from the expansion card connector on the riser.




Figure 20. Removing expansion card riser 1

## Installing expansion card riser 1

### About this task

**NOTE:** If installing a replacement expansion card riser 1 make sure the VROC key is transferred from the old card to the new card.

### Steps

- 1 Align the guide rails on the riser with the standoffs on the side of the system.
- 2 Lower the riser into the system until the riser card connector engages with the connector on the system board.

### Next steps

- 1 If removed, install expansion cards into the riser.
- 2 Connect the cable which disconnected from the expansion card.
- 3 Install any device drivers required for the card as described in the documentation for the card.

## Removing expansion card riser 2

### Prerequisites


- 1 If applicable, remove the air shroud.
  - NOTE:** If applicable, close the PCIe card holder latch on the air shroud to release the full length card.
- 2 If installed, remove expansion cards installed on the riser.
- 3 Disconnect any cables connected to the riser card.

### Steps

- 1 To remove expansion card riser 2A:
  - a Using Phillips #2 screwdriver, loosen the screws that secure the riser to the system.



- b Press the release tab, and holding the riser by its edges, lift the riser from the riser connector on the system board.



**Figure 21. Removing expansion card riser 2A**

- 2 Remove the expansion card riser.

## Installing expansion card riser 2

### Step

To install expansion card riser 2A:

- a Align the screw and tab on the riser with the screw hole and slot on the system.
- b Lower the riser into the system until the riser connector engages with the connector on the system board.
- c Using Phillips #2 screwdriver, tighten the screws to secure the riser to the system.

### Next steps

- 1 If removed, install expansion cards into the riser and connect any cable disconnected.
- 2 If applicable, install the air shroud.

**NOTE:** If applicable, open the PCIe card holder latch on the air shroud to install the full length card.

- 3 Install any device drivers required for the card as described in the documentation for the card.

## Removing expansion card riser 3

### Prerequisites

- 1 If applicable, remove the air shroud.

**NOTE:** If applicable, close the PCIe card holder latch on the air shroud to release the full length card.

- 2 If installed, remove expansion cards installed on the riser.
- 3 Disconnect any cables connected to the riser card.

### Steps

- 1 Using Phillips #2 screwdriver, loosen the screw that secures the riser to the system.
- 2 Press the release tab, and holding the riser by its edges, lift the riser from the riser connector on the system board.




Figure 22. Removing expansion card riser 3

## Installing expansion card riser 3

### Steps

- 1 Align the following:
  - a Tab on the riser with the slot on the system and guide rails on the riser with the standoffs on the side of the system.
  - b Lower the riser into the system until the riser edge connector engages with the connector on the system board.  
The riser card edge engages with the riser guide on the system.
- 2 Using Phillips #2 screwdriver, tighten the screw to secure the riser to the system.

### Next steps

- 1 If removed, install expansion cards into the riser and connect any cable disconnected.
- 2 If applicable, install the air shroud.

**NOTE:** If applicable, open the PCIe card holder latch on the air shroud to install the full length card.

- 3 Install any device drivers required for the card as described in the documentation for the card.

## vFlash card – optional

### Removing vFlash card

#### Prerequisites


- 1 If applicable, remove the full height PCIe card in expansion card riser 2.
- 2 If you are replacing the vFlash card, remove the micro SD cards.



**NOTE:** Temporarily label each micro SD card with its corresponding slot number after removal

### Steps

- 1 Locate the vFlash connector on the system board. To locate vFlash , see the System board jumpers and connectors section.
- 2 Holding the pull tab, lift the vFlash card out of the system.



## Installing vFlash card

### Steps

- 1 Locate the vFlash connector on the system board. To locate vFlash, see the System board jumpers and connectors section.
- 2 Align vFlash card with the connector on the system board.
- 3 Push vFlash card until it is firmly seated on the system board.

### Next step

- 1 If applicable, install the full height PCIe card in expansion card riser 2.

## Network daughter card


## Removing network daughter card

### Prerequisite

- 1 Remove the expansion card riser 2.

### Steps

- 1 Using a Phillips #2 screwdriver, loosen the captive screws that secure the Network Daughter Card (NDC) to the system board.
- 2 Hold the NDC by the edges on either side of the touch points and lift to remove it from the connector on the system board.
- 3 Slide the NDC away from the back of the system until the Ethernet connectors are clear of the slot in the back panel.



## Installing network daughter card

### Steps

- 1 Orient the NDC so that the Ethernet connectors fit through the slot in the back panel.
- 2 Align the captive screws at the back-end of the card with the screw holes on the system board.
- 3 Press the touch points on the card until the card connector is firmly seated on the system board connector.
- 4 Using a Phillips #2 screwdriver, tighten the captive screws to secure the NDC to the system board.

### Next step

- 1 Install the expansion card riser 2.

## Hard drive backplane

### Removing hard drive backplane

#### Prerequisites

**CAUTION:** To prevent damage to the drives and backplane, remove the hard drives from the system before removing the backplane.

**CAUTION:** Note the number of each hard drive and temporarily label them before you remove the hard drive so that you can replace them in the same locations.

- 1 Remove the air shroud.
- 2 Remove the cooling fan assembly.
- 3 Remove the backplane cover.
- 4 Remove all hard drive.
- 5 Disconnect all the cables from the backplane.

#### Step

Press the release tabs and lift the backplane to disengage the backplane from the hooks on the system.






Figure 23. Removing hard drive backplane

## Installing hard drive backplane

### Steps

- 1 Use the hooks on the system as guides to align the hard drive backplane.
- 2 Lower the hard drive backplane until the release tabs snap into place. If applicable, tighten the captive screws on the backplane.

### Next steps

- 1 Connect all the cables to the backplane.
- 2 Install all the hard drives.
- 3 Install the backplane cover.
- 4 Install the cooling fan assembly.
- 5 Install the air shroud.

## Front USB module


### Removing front USB module

#### Prerequisites

- 1 Remove the front bezel.
- 2 Remove the system cover.

#### Steps

- 1 Unroute the cable and remove the screw that secures the USB module on the system.
- 2 Push the cable and disconnect it from the system.
- 3 Remove the front USB module from the system.



## Installing front USB module

### Steps

- 1 Place the front USB module in the slot on the system.
- 2 Connect and slide the USB module cable and tighten the screw.
- 3 Route the cable through the routing channel.

### Next steps

- 1 Install the system cover.
- 2 Install the front bezel.

## Internal USB memory key (optional)

### Replacing optional internal USB memory key

### Steps

- 1 Locate the USB connector or USB key on the system board.
- 2 If installed, remove the USB key.
- 3 Insert the new USB key into the USB connector.

### Next step

- 1 While booting, press <F2> to enter the System Setup and verify that the USB key is detected by the system.


## Power supply unit

### Removing power supply unit blank

Install the power supply unit (PSU) blank only in the second PSU bay.

If you are installing a second PSU, remove the PSU blank in the bay by pulling the blank outward.





**CAUTION:** To ensure proper system cooling, the PSU blank must be installed in the second PSU bay in a non-redundant configuration. Remove the PSU blank only if you are installing a second PSU.

## Installing power supply unit blank

Install the power supply unit (PSU) blank only in the second PSU bay.

Align the PSU blank with the PSU slot and push it into the PSU slot until it clicks into place.

## Removing AC power supply unit

### Prerequisite

**CAUTION:** The needs one power supply unit (PSU) for normal operation. On power-redundant systems, remove and replace only one PSU at a time in a system that is powered on.

- 1 Disconnect the power cable from the power source and from the PSU you intend to remove, and then remove the cable from the strap on the PSU handle.

### Step

Press the release latch and slide the PSU out of the system by using the PSU handle.



## Installing AC power supply unit

### Step

Slide the PSU into the system until the PSU is fully seated and the release latch snaps into place.

### Next step

- 1 Connect the power cable to the PSU, and plug the cable into a power outlet.

**CAUTION:** When connecting the power cable to the PSU, secure the cable to the PSU with the strap.

## System board

### Removing system board

#### Prerequisites

**CAUTION:** If you are using the Trusted Platform Module (TPM) with an encryption key, you may be prompted to create a recovery key during program or System Setup. Be sure to create and safely store this recovery key. If you replace this system board, you must supply the recovery key when you restart your system or program before you can access the encrypted data on your hard drives.

**CAUTION:** Do not attempt to remove the TPM plug-in module from the system board. Once the TPM plug-in module is installed, it is cryptographically bound to that specific system board. Any attempt to remove an installed TPM plug-in module breaks the cryptographic binding, and it cannot be re-installed or installed on another system board.

- 1 Remove the following:
  - a Air shroud
  - b Cooling fan assembly
  - c Optical drive
  - d Power supply unit(s)
  - e All expansion card risers
  - f vFlash card



- g USB 3.0 module
- h Internal USB key (if installed)
- i Processor and heat sink module
- j Processors and memory blank

**CAUTION:** To prevent damage to the processor pins when replacing a faulty system board, ensure that you cover the processor socket with the processor protective cap.

- k Memory modules
- l Network daughter card


### Steps

- 1 Disconnect all cables from the system board.

**CAUTION:** Take care not to damage the system identification button while removing the system board from the chassis.

**CAUTION:** Do not lift the system board by holding a memory module, processor, or other components.

- 2 Holding the system board holder, pull the blue release pin, lift the system board, and then slide it toward the front of the chassis. Sliding the system board toward the front of the chassis disengages the connectors from the back of the chassis slots.
- 3 Lift the system board out of the chassis.



## Installing system board

### Steps

- 1 Unpack the new system board assembly.

**CAUTION:** Do not lift the system board by holding a memory module, processor, or other components

**CAUTION:** Take care not to damage the system identification button while placing the system board into the chassis.

- 2 Holding the system board holder, push the system board toward the back of the system until the release pin clicks into place.

### Next steps

- 1 Install the Trusted Platform Module (TPM).

**NOTE:** The TPM plug-in module is attached to the system board and cannot be removed. A replacement TPM plug-in module will be provided for all system board replacements where a TPM plug-in module was installed.

- 2 Replace the following:
  - a Network daughter card
  - b Internal USB key (if applicable)

- c USB 3.0 module
  - d vFlash card
  - e Optical drive
  - f All expansion card risers
  - g Processor and heat sink module
  - h Processor and memory blank
  - i Memory modules
  - j Cooling fan assembly
  - k Air shroud
  - l Power supply unit(s)
- 3 Reconnect all cables to the system board.

**NOTE:** Ensure that the cables inside the system are routed along the chassis wall and secured using the cable securing bracket.

- 4 The Easy Restore feature restores several configuration settings, most notably the Service Tag, iDRAC Licenses, and OEM ID Modules (if needed for the last two). Refer to the Restoring the Service Tag Using Easy Restore page. When the system board is booted for the first time it will present a screen with settings it can restore.

**NOTE:** If for any reason Easy Restore does not execute, you must enter the service tag manually. Refer to the Update the Service Tag page. Other configuration issues must also be done manually, for instance importing iDRAC License through iDRAC GUI

- 5 Import your new or existing iDRAC Enterprise license. For more information, see Integrated Dell Remote Access Controller User's Guide, at [Dell.com/esmmanuals](http://Dell.com/esmmanuals).
- 6 Ensure that you:
- a Use the Easy Restore feature to restore the Service Tag. For more information, see the Easy restore section.
  - b If the Service Tag is not backed up in the backup flash device, enter the Service Tag manually. For more information, see the Entering the Service Tag section.
  - c Update the BIOS and iDRAC versions.
  - d Re-enable the Trusted Platform Module (TPM). For more information, see the Re-enabling the Trusted Platform Module (TPM) section.

## Trusted Platform Module

Trusted Platform Module (TPM) is a dedicated microprocessor designed to secure hardware by integrating cryptographic keys into devices. Software can use a TPM to authenticate hardware devices. Because each TPM chip has a unique and secret RSA key which is embedded during the manufacture of the TPM, it is capable of performing platform authentication operation.

## Replacing the Trusted Platform Module

### Prerequisites

**CAUTION:** Do not attempt to remove the Trusted Platform Module (TPM) from the system board. Once the TPM is installed, it is cryptographically bound to that specific system board. Any attempt to remove an installed TPM breaks the cryptographic binding, and it cannot be re-installed or installed on another system board.

**NOTE:** This is a Field Replaceable Unit (FRU). Removal and installation procedures should be performed only by Dell certified service technicians.

**NOTE:** There is a TPM slot on the system board of each sled.

### Steps

- 1 Locate the TPM connector on the system board.

**NOTE:** To locate the TPM connector on the system board, see the System board connectors section.

- 2 Align the edge connectors on the TPM with the slot on the TPM connector.
- 3 Insert the TPM into the TPM connector such that the plastic rivet aligns with the slot on the system board.



- 4 Press the plastic rivet until the rivet snaps into place.




Figure 24. Installing the TPM

#### Next step

- 1 Install the system board.

## Initializing TPM for BitLocker users

Initialize the TPM.

For more information, see <http://technet.microsoft.com/en-us/library/cc753140.aspx>.

The **TPM Status** changes to **Enabled, Activated**.

## Initializing the TPM 1.2 for TXT users

- 1 While booting your system, press F2 to enter System Setup.
- 2 On the **System Setup Main Menu** screen, click **System BIOS > System Security Settings**.
- 3 From the **TPM Security** option, select **On with Pre-boot Measurements**.
- 4 From the **TPM Command** option, select **Activate**.
- 5 Save the settings.
- 6 Restart your system.
- 7 Enter **System Setup** again.
- 8 On the **System Setup Main Menu** screen, click **System BIOS > System Security Settings**.
- 9 From the **Intel TXT** option, select **On**.

## Control panel


### Removing left control panel

#### Prerequisites

- 1 Remove air shroud.
- 2 For ease of removal of the left control panel, remove the cooling fan assembly #1 to access the cable latch.

## Steps

- 1 Pull the cable latch and disconnect the control panel cable from the system board.
- 2 Using Phillips #1 screwdriver, remove the screws(6) that secure the control panel and cable tube to the system.
- 3 Holding the control panel and cable tube by its sides, remove the control panel and cable tube away from the system.



## Installing left control panel

### Steps

- 1 Route the control panel cable through the side wall of the system.
- 2 Align the control panel with the control panel slot on the system and attach the control panel to the system.
- 3 Connect the control panel cable to the system board and secure it using cable latch.
- 4 Using Phillips #1 screwdriver, install the screws(6) that secure the control panel and cable tube to the system.

### Next steps

- 1 If applicable, install the cooling fan #1.
- 2 Install air shroud.

## Removing right control panel


### Prerequisites

- 1 Remove air shroud.
- 2 Remove cooling fan assembly.

### Steps

- 1 Disconnect the VGA cable from the system board.
- 2 Pull the cable latch and disconnect the control panel cable from the system board.
- 3 Using Phillips #1 screwdriver, remove the screws(6) that secure the control panel and cable tube to the system.
- 4 Holding the control panel and cable tube by its sides, remove the control panel and cable tube away from the system.





## Installing right control panel

### Steps

- 1 Route the control panel cable and VGA cable through the side wall of the system.
- 2 Align the control panel with the control panel slot on the system and attach the control panel to the system.
- 3 Connect the VGA cable to the system board.
- 4 Connect the control panel cable to the system board and secure it using cable latch.
- 5 Using Phillips #1 screwdriver, install the screws(6) that secure the control panel and cable tube to the system.

### Next steps

- 1 Install cooling fan assembly.
- 2 Install air shroud.

## Updating BIOS

To update the BIOS, perform the following steps:

- 1 Copy the BIOS update file on a USB device.
- 2 Plug in the USB device into any of the USB ports on your system.
- 3 Turn on your system.
- 4 While booting, press **F11** to enter the **Boot Manager**.
- 5 Go to **System Utilities** → **BIOS Update File Explorer**, and select the plugged in USB device.
- 6 From the **BIOS Update File Explorer**, select the **BIOS update file**.  
The **BIOS Update Utility** with the current and new version of BIOS is displayed.
- 7 Select **Continue BIOS Update** to install the BIOS update.

## Restoring the Service Tag using Easy Restore

The easy restore feature allows you to restore your service tag, license, UEFI configuration, and the system configuration data after replacing the system board. All data is backed up in a backup flash device automatically. If BIOS detects a new system board, and the service tag in the backup flash device, BIOS prompts the user to restore the backup information.

## About this task

Below is a list of options available:

- Restore the service tag, license, and diagnostics information, press **Y**.
- Navigate to the Lifecycle Controller based restore options, press **N**.
- Restore data from a previously created **Hardware Server Profile**, press **F10**.

 **NOTE:** When the restore process is complete, BIOS prompts to restore the system configuration data.

- To restore the system configuration data, press **Y**.
- To use the default configuration settings, press **N**.

 **NOTE:** After the restore process is complete, system reboots

## Manually update the Service Tag

After replacing a system board, if Easy Restore fails, follow this process to manually enter the Service Tag, using **System Setup**.

### About this task

If you know the system service tag, use the System Setup menu to enter the service tag.

- 1 Turn on the system.
- 2 To enter the **System Setup**, press **F2**.
- 3 Click **Service Tag Settings**.
- 4 Enter the service tag.

 **NOTE:** You can enter the service tag only when the Service Tag field is empty. Ensure that you enter the correct service tag. Once the service tag is entered, it cannot be updated or changed.

- 5 Click **OK**.

## Installation

Installing the Precision 7920 Rack requires information about the following topics:


- Rack Rails
- System Initialization
- Basic Configuration

## Rack Rails


The rail offerings consist of two types of rails — sliding and static.

The sliding rails allow the system to be fully extended out of the rack for service. They are available with or without the optional cable management arm (CMA).





The static rails support a wider variety of racks than the sliding rails. However, they do not support serviceability in the rack and are thus not compatible with the CMA.



One key factor in selecting the proper rails is identifying the type of rack in which they will be installed. Both the sliding rails and the static rails support tool-less mounting in 19" wide, EIA-310-E-compliant square hole and unthreaded round hole 4-post racks. Both also support toolled mounting in threaded hole 4-post racks, but only the static rails, as the more universal solution, support mounting in 2-post (Telco) racks.

The table below shows the sliding and static rail configurations and supported racks:

**Table 12. Sliding and Static Rails**

Rail identifier	Mounting interface	Rail type	Supported rack types				
			4-Post			2-Post	
			Square	Round	Thread	Flush	Center
B6	Ready Rails II	Sliding	√	√	√	X	X
B4	Ready Rails	Static	√	√	√	√	√

**NOTE:** Screws are not included in either kit due to the fact that threaded racks are offered with a variety of thread designations. Users must therefore provide their own screws when mounting the rails in threaded racks.

**NOTE:** Screw head diameter for the sliding rails must be 10 mm or less.

Other key factors governing proper rail selection include the following:

- Spacing between the front and rear mounting flanges of the rack
- Type and location of any equipment mounted in the back of the rack such as power distribution units (PDUs)
- Overall depth of the rack

The static rails offer a greater adjustability range and a smaller overall mounting footprint than the sliding rails. This is because of their reduced complexity and lack of need for CMA support.

**Table 13. Static Rails Adjustability**

Rail Identifier	Rail Type	Rail Adjustable Range (mm)						Rail Depth (mm)	
		Square		Round		Threaded		without CMA	with CMA
		Min	Max	Min	Max	Min	Max		
B6	Sliding	676	868	662	861	676	883	714	845
B4	Static	608	879	594	872	604	890	622	N/A

Note that the adjustment range of the rails is a function of the type of rack in which they are being mounted. The Min/Max values listed above represent the allowable distance between the front and rear mounting flanges in the rack. Rail depth without the CMA represents the minimum depth of the rail with the outer CMA brackets removed (if applicable) as measured from the front mounting flanges of the rack.

## Cable management arm (CMA)


The optional cable management arm (CMA) organizes and secures the cords and cables exiting the back of the systems. It unfolds to allow the systems to extend out of the rack without having to detach the cables. Some key features of the CMA include:

- Large U-shaped baskets to support dense cable loads
- Open vent pattern for optimal airflow
- Ability to be mounted on either side by simply swinging the spring-loaded brackets from one side to the other
- Utilizes hook-and-loop straps rather than plastic tie wraps to eliminate the risk of cable damage during cycling
- Includes a low-profile fixed tray to both support and retain the CMA in its fully closed position
- Both the CMA and the tray mount without the use of tools via simple and intuitive snap-in designs

The CMA can be mounted to either side of the sliding rails without the use of tools or the need for conversion. However, it is recommended that it be mounted on the side opposite to the power supplies to allow easier access to the power supplies and rear hard drives (if applicable) for service or replacement.



## Rack Installation



ⓘ **NOTE:** The 2U system requires two people for installation due to its heavier weight.

### Installing the system into the rack (option A: Drop-In)


The sliding rails are a "drop-in" design. This means that the system is installed vertically into the rails by inserting the standoffs on the sides of the system into the "J-slots" in the inner rail members with the rails in the fully extended position. As with all 2U systems, a minimum of two people are required in order to properly install the system in the rails.

- 1 Pull the inner rails out of the rack until they lock into place.



**Figure 25. Pull out inner rail**

- 2 Locate the rear rail standoff on each side of the system and lower them into the rear J-slots on the slide assemblies.
- 3 Rotate the system downward until all the rail standoffs are seated in the J-slots.



**Figure 26. Rail standoffs seated in J-slots**

- 4 Push the system inward until the lock levers click into place
- 5 Pull the blue slide release lock tabs forward on both rails and slide the system into the rack until the system is in the rack.




Figure 27. Slide system into the rack

## Installing the system into the rack (option B: Stab-In)

The static rails are a "stab-in" design. This means that the inner (chassis) rail members must first be attached to the sides of the system and then inserted into the outer (cabinet) members installed in the rack.

- 1 Pull the intermediate rails out of the rack until they lock into place.
- 2 Release the inner rail lock by pulling forward on the white tabs and sliding the inner rail out of the intermediate rails.




**Figure 28. Pull out the intermediate rail**

**Table 14. Rail component**


Rail component	
1	Intermediate rail
2	Inner rail

3 Attach the inner rails to the sides of the system by aligning the J-slots on the rail with the standoffs on the system and sliding forward on the system until they lock into place.



**Figure 29. Attach the inner rails to the system**

- 4 With the intermediate rails extended, install the system into the extended rails.



**Figure 30. Install system into the extended rails**

- 5 Pull the blue slide release lock tabs forward on both the rails ,and slide the system into the rack.




Figure 31. Slide system into the rack

## Initialization

After you receive your system, you must set up your system, install the operating system, and set up and configure the system iDRAC IP address for system management.

## Setting up your system

- Unpack the system.
- If applicable, install the system into the rack.
- Connect any peripherals to the system.
- Connect the system to its electrical outlet.
- Turn on the system by pressing the power button.
- Turn on the attached peripherals.

## Methods of setting up and configuring the iDRAC IP address

You can set up the Integrated Dell Remote Access Controller (iDRAC) IP address by using one of the following interfaces:

- 1 iDRAC Settings utility
- 2 Lifecycle Controller



### 3 Dell Deployment Toolkit

You can use the default iDRAC IP address 192.168.0.120 to configure the initial network settings, including setting up DHCP or a static IP for iDRAC.

You can configure iDRAC IP using the following:

- 1 iDRAC Web Interface
- 2 Remote Access Controller Admin (RACADM)
- 3 Remote Services that include Web Services Management -WSMAN

For more information on setting up and configuring iDRAC, see the Integrated Dell Remote Access Control User's Guide at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).

## Information about logging in to iDRAC

You can log in to iDRAC as an iDRAC local user, as a Microsoft Active Directory user, or as a Lightweight Directory Access Protocol (LDAP) user. You can also log in using Single Sign-On or a Smart Card. The default user name is **root**, and default password is random unless customer choose to use **calvin** as password at the point of sales. For more information on logging in to the iDRAC and iDRAC licenses, see Integrated Dell Remote Access Control User's Guide at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).

You can also access iDRAC using RACADM. For more information, see RACADM Command Line Interface Reference Guide and Integrated Dell Remote Access Controller User's Guide is available at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).

## Basic configuration

Once the system has been set up correctly, users may perform further configurations such as operating system installation, remote management, and also drivers/firmware installation.

## Methods of installing the operating system

You can install the supported operating system on the system, if the system has been shipped without an operating system, use the following methods:

- Dell Systems Management Tools and Documentation media-See the operating system documentation at [Dell.com/operatingsystemmanuals](http://Dell.com/operatingsystemmanuals).
- Dell Lifecycle Controller-See the Lifecycle Controller documentation at [Dell.com/esmmanuals](http://Dell.com/esmmanuals).
- Dell OpenManage Deployment Toolkit-See the OpenManage documentation at [Dell.com/openmanagemanuals](http://Dell.com/openmanagemanuals)

For information on the list of operating systems supported on your system, see the operating systems support matrix at [Dell.com/ossupport](http://Dell.com/ossupport).

## Remote management

To perform out-of-band systems management using iDRAC, you must configure iDRAC for remote accessibility, set up the management station and managed system, and configure the supported web browsers. For more information, see the iDRAC User's Guide at [Dell.com/esmmanuals](http://Dell.com/esmmanuals).

You can also remotely monitor and manage the system, using the Dell OpenManage Server Administrator (OMSA) software and OpenManage Essentials (OME) systems management console. For more information, see [Dell.com/openmanagemanuals](http://Dell.com/openmanagemanuals).



## Downloading and installing drivers and firmware

It is recommended that you download and install the latest BIOS, drivers, and systems management firmware on your system.

**NOTE:** Ensure that you clear the web browser cache.

- 1 Go to [Dell.com/support/drivers](http://Dell.com/support/drivers).
- 2 In the **Product Selection** section, enter the service tag of your system in the **Service Tag** or **Express Service Code** field.

**NOTE:** If you do not have the service tag, select **Automatically detect my Service Tag for me to allow the system to automatically detect your service tag, or select Choose from a list of all Dell products to select your product from the Product Selection page.**

- 3 Click **Get drivers and downloads**. The drivers that are applicable to your selection are displayed.
- 4 Repeat steps 1 through 3 to download the HDD zoning configuration utility.
- 5 Search by **Category** and click the **System utilities. HDD Zoning Configuration Utility** is displayed.

## Accessing system information by using QRL

You can use the Quick Resource Locator (QRL) to get immediate access to the information about your system. The QRL is located on the top of the system cover.

### Prerequisites

Ensure that your smartphone or tablet has the QR code scanner installed.

The QRL includes the following information about your system:

- How-to videos
- Reference materials, including the Owner's Manual, LCD diagnostics, and mechanical overview.
- Your system service tag to quickly access your specific hardware configuration and warranty information.
- A direct link to Dell to contact technical assistance and sales teams

### Steps

- 1 Go to **Dell.com/QRL** and navigate to your specific product or
- 2 Use your smartphone or tablet to scan the model-specific Quick Resource (QR) code on your Dell system or in the Quick Resource Locator section.

## Quick Resource Locator for 7920R



# Technology and components

The following sections contain information about the technology and components in the system.

Topics:

- [iDRAC9](#)
- [Dell Lifecycle Controller](#)
- [Processors](#)
- [Chipset](#)
- [System memory](#)
- [LCD panel](#)
- [Expansion cards and expansion card risers](#)
- [Storage](#)
- [Power supply units](#)
- [Trusted platform module](#)

## iDRAC9

The Integrated Dell Remote Access Controller (iDRAC) is designed to make system administrators more productive and improve the overall availability of Dell system. iDRAC alerts administrators to system issues, helps them perform remote system management, and reduces the need for physical access to the system.

iDRAC with Lifecycle Controller technology is part of a larger data center solution that helps keep business critical applications and workloads available always. The technology allows administrators to deploy, monitor, manage, configure, update, troubleshoot and remediate Dell system from any location, and without the use of agents. It accomplishes this regardless of operating system or hypervisor presence or state.

iDRAC9 is available in the following variants:

- **iDRAC9 Basic** - available by default on all 200-500 series of rack or tower systems.
- **iDRAC9 Express** - available by default on all 600 and higher series of rack or tower systems, and all blade systems.
- **iDRAC9 Enterprise** - available on all system models.

For more information, see the Integrated Dell Remote Access Controller User's Guide at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).

## iDRAC 9 - New features

The following list contains the key new features available on iDRAC9:

- Added support for Redfish 2016.R1 and .R2, a RESTful Application Programming Interface (API), which is standardized by the Distributed Management Task Force (DMTF). It provides a scalable and secure systems management interface.
- Enhanced iDRAC RESTful API support for System Configuration Profiles with access via local file streaming and via HTTP/S file transfer.
- Added System Configuration Profile support for firmware repository-based updates and JSON file format.
- Export and import System Configuration Profiles from the iDRAC GUI.

- Quick Sync 2 replaces Quick Sync NFC (Near Field Communication) with BLE (Bluetooth Low Energy) and Wi-Fi for high throughput. Supports iDRAC GUI and Virtual Console access.
- Added support for HTTP/HTTPS file transfers
- Added support for WSman streaming for System Configuration Profiles.
- Added new feature Group Manager. All iDRACs in the same subnet can be grouped together and the systems can be grouped and managed by one master iDRAC of the group.
- Added Security Banner for GUI log in page.
- Multi Vector Cooling for better air flow cooling of 3rd party PCIe cards.
- DHCP is the default iDRAC IP address (static was the default on previous generations).
- Default password is randomly generated and printed on the pull out information tag, unless the legacy “root/calvin” was ordered from the factory.
- iDRAC Direct USB on the front of the system is now a Micro B slot, and is hard wired to iDRAC only for increased security.
- Added new System Lockdown feature to restrict use of Dell tools to make changes to BIOS, iDRAC, firmware, etc.
- iDRAC Service Module (iSM) is pre-installed on the iDRAC and can be surfaced to the OS; nothing to download.
- SupportAssist can be set up through the iDRAC for 1x1 ‘phone home’ service to Dell Support.
- SupportAssist Collector now includes iDRAC core dumps, hardware crash dumps, and ESXi logs.
- SupportAssist viewer - option to export HTML5 formatted report for customer viewing by standard web browsers.
- Full HTML5 web interface for faster page loading and ease of use.
- BIOS configuration in the iDRAC GUI.
- Expanded storage functions via iDRAC, such as Online Capacity Expansion (OCE) and RAID Level Migration (RLM) without the use of agents, via GUI or CLI.
- Improved add/delete of iDRAC Users.
- Streamlined alerts configuration.
- Added Power Control and Next Boot options in HTML5 vConsole.
- Added feature Connection View provide the switch and port for iDRAC, LOM's and Dell supported PCIe cards.
- Internal 16GB vFlash card (optional).
- Bezel with LCD panel (optional).

## Dell Lifecycle Controller

**NOTE:** This is an overview of the Lifecycle Controller. For more information about Dell LifeCycle Controller, see [dell.com/idracmanuals](http://dell.com/idracmanuals).

## iDRAC9 with Lifecycle Controller

Dell Lifecycle Controller provides advanced embedded systems management to perform systems management tasks such as deploy, configure, update, maintain, and diagnose by using a graphical user interface (GUI). It is delivered as part of integrated Dell Remote Access Controller (iDRAC) out-of-band solution and embedded Unified Extensible Firmware Interface (UEFI) applications in the latest Dell systems. iDRAC works with the UEFI firmware to access and manage every aspect of the hardware, including component and subsystem management that is beyond the traditional Baseboard Management Controller (BMC) capabilities.

## Benefits of using iDRAC with Lifecycle Controller

The benefits of using iDRAC with Lifecycle Controller includes:

- Increased availability—Early notification of potential or actual failures that help prevent a system failure or reduce recovery time after failure.
- Improved productivity and lower Total Cost of Ownership (TCO) — Extending the reach of administrators to larger numbers of distant systems can make the IT staff more productive while driving down operational costs such as travel.



- Secure environment—By providing secure access to remote systems, administrators can perform critical management functions while maintaining system and network security.
- Enhanced embedded management through Lifecycle Controller - Lifecycle Controller provides deployment and simplified serviceability through Lifecycle Controller GUI for local deployment and remote services (Redfish, Racadm, and WS-Man) interfaces for remote deployment integrated with Dell OpenManage Essentials and partner consoles.

## Key features

The key features of Lifecycle Controller are:

- Provisioning - Entire pre-operating system configuration from a unified interface.
- Deploying - Simplified OS installation with the embedded drivers on Lifecycle Controller. Unattended installation mode is available for Microsoft Windows and Red Hat Enterprise Linux (RHEL) 7 operating systems.
- Download drivers for OS installation from one of the following sources:
  - [downloads.Dell.com](https://downloads.Dell.com)
  - *Dell Lifecycle Controller OS Driver Packs DVD for Windows and Linux*
- Patching or updating - Operating system diagnostics, and reduced maintenance downtime with direct access to updates from [downloads.Dell.com](https://downloads.Dell.com). It simplifies firmware updates by maintaining a working version for rollback.
- Servicing - Continuous availability of diagnostics without depending on a hard drive. Ability to automatically update firmware, while replacing components such as a storage controller, NIC, and power supply unit. Support for VLAN in network configuration.
- System erase - Deletes the system and storage-related data on selected components of a system. You can delete information pertaining to BIOS, Lifecycle Controller logs, iDRAC settings, and storage components on the system. However, you cannot delete the iDRAC license information.
- Security - Support local key encryption.
- Restoring the system - Back up the system profile, including RAID configuration, and restore the system to a previously known state. Importing a system license, firmware rollback, and restoring system configuration if there is system board replacement.
- Easy Restore - Automatically restore hardware configuration and license information after a system board replacement
- SupportAssist Collection - Gathers all hardware and OS logs and inventory information required for technical support.
- Lifecycle Controller logs for troubleshooting.
- Hardware inventory - Provides information about the current and factory system configuration.

## Starting Lifecycle Controller

To start Lifecycle Controller, restart the system and press **<F10>** during POST to select Lifecycle Controller from the list displayed. When Lifecycle Controller is started for the first time, the Settings wizard is displayed which allows you to configure the language and network settings.

## Processors

The Precision 7920 Rack systems feature the Intel Xeon scalable processor family (Skylake-SP) offers versatility across diverse workloads. These processors are designed for next-generation data centers running on, software defined infrastructure supercharged for efficiency, performance, and agile services delivery across cloud-native and traditional applications. The Intel Xeon scalable processor family support workloads for cloud, high-performance computing, networking, and also storage for data centers.

# Processor features

The new Intel Xeon scalable processor family is the next generation core architecture with improved Instructions per Cycle (IPC) and other architectural improvements. The Intel Xeon scalable processor family not only adds new features, but also improves upon many features of the predecessor Intel Xeon processor E5-2600 v4 product family, including:

- Virtual address space of 48 bits and a physical address space of 46 bits.
- Intel Hyper-Threading Technology (Intel® HT Technology) when enabled allow each core to support two threads.
- First Level Cache (FLC) 64 KB total. The FLC is comprised of a 32 KB ICU (Instruction Cache) and 32 KB DCU (Data Cache)
- MB Mid-Level Cache (MLC) per core (non-inclusive with the LLC).
- Intel® Advanced Vector Extensions 512 (Intel® AVX-512) with a single AVX512 fused multiply-add (FMA) execution units. processors which support Advanced RAS enable a 2nd FMA execution unit.

# Supported Processors

**Table 15. Supported Processors for Precision 7920 Rack**

Model	Intel SKU	SKU type	Dell DPN	Speed(GHz)	Cache(MB)	QPI(GT/s)	Max Memory Speed(MT/s)	Cores	Turbo	TDP
Intel Xeon Scalable Processor	3106	Bronze	FH30X	1.7	24.75	9.6	2133	8	No Turbo	85W
Intel Xeon Scalable Processor	3104	Bronze	JNFW5	1.7	19.25	9.6	2133	6	No Turbo	85W
Intel Xeon Scalable Processor	6148	Gold	MXCY0	2.4	27.5	10.4	2400	20	Turbo	150W
Intel Xeon Scalable Processor	6154	Gold	0H31R	3	24.75	10.4	2400	18	Turbo	200W
Intel Xeon Scalable Processor	6150	Gold	J9C40	2.7	24.75	10.4	2400	18	Turbo	165W
Intel Xeon Scalable Processor	6142	Gold	1JJHM	2.6	22	10.4	2400	16	Turbo	150W
Intel Xeon Scalable Processor	6132	Gold	PYJN7	2.6	19.25	10.4	2400	14	Turbo	140W
Intel Xeon Scalable Processor	6136	Gold	CVWTJ	3	24.75	10.4	2400	12	Turbo	150W
Intel Xeon Scalable Processor	6126	Gold	F56GN	2.6	19.25	10.4	2400	12	Turbo	125W



Model	Intel SKU	SKU type	Dell DPN	Speed(GHz)	Cache(MB)	QPI(GT/s)	Max Memory Speed(MT/s)	Cores	Turbo	TDP
Intel Xeon Scalable Processor	6134	Gold	NFXK9	3.2	24.75	10.4	2400	8	Turbo	130W
Intel Xeon Scalable Processor	6128	Gold	M6PT0	3.4	19.25	10.4	2400	6	Turbo	115W
Intel Xeon Scalable Processor	5122	Gold	6JMR6	3.6	16.5	10.4	2400	4	Turbo	105W
Intel Xeon Scalable Processor	6152	Gold	Y1HH1	2.1	30.25	10.4	2400	22	Turbo	140W
Intel Xeon Scalable Processor	6138	Gold	5R52V	2	27.5	10.4	2400	20	Turbo	125W
Intel Xeon Scalable Processor	6140	Gold	DTTYM	2.3	24.75	10.4	2400	18	Turbo	140W
Intel Xeon Scalable Processor	6130	Gold	XJ73T	2.1	22	10.4	2400	16	Turbo	125W
Intel Xeon Scalable Processor	5120	Gold	7051X	2.2	19.25	10.4	2400	14	Turbo	105W
Intel Xeon Scalable Processor	5118	Gold	4J8WW	2.3	16.5	10.4	2400	12	Turbo	105W
Intel Xeon Scalable Processor	5115	Gold	9JV7H	2.4	13.75	10.4	2400	10	Turbo	85W
Intel Xeon Scalable Processor	8180	Platinum	K2XNJ	2.5	38.5	10.4	2666	28	Turbo	205W
Intel Xeon Scalable Processor	8168	Platinum	1PCFM	2.7	33	10.4	2666	24	Turbo	205W
Intel Xeon Scalable Processor	8156	Platinum	HV7Y2	3.6	16.5	10.4	2666	4	Turbo	105W
Intel Xeon Scalable Processor	8176	Platinum	35TP4	2.1	22	10.4	2666	16	Turbo	120W
Intel Xeon Scalable Processor	8170	Platinum	OY6D1	2.1	35.75	10.4	2666	26	Turbo	165W



Model	Intel SKU	SKU type	Dell DPN	Speed(GHz)	Cache(MB)	QPI(GT/s)	Max Memory Speed(MT/s)	Cores	Turbo	TDP
Intel Xeon Scalable Processor	8164	Platinum	6X9YX	2	35.75	10.4	2666	26	Turbo	150W
Intel Xeon Scalable Processor	8160	Platinum	6DKVT	2.1	33	10.4	2666	24	Turbo	150W
Intel Xeon Scalable Processor	4116	Silver	D4NCN	2.1	16.5	9.6	2400	12	Turbo	85W
Intel Xeon Scalable Processor	4114	Silver	C6RY1	2.2	13.75	9.6	2400	10	Turbo	85W
Intel Xeon Scalable Processor	4112	Silver	6YC56	2.6	16.5	9.6	2400	4	Turbo	85W
Intel Xeon Scalable Processor	4110	Silver	7KW7T	2.1	24.75	9.6	2400	8	Turbo	85W
Intel Xeon Scalable Processor	4108	Silver	6YFV1	1.8	24.75	9.6	2400	8	Turbo	85W

## Processor Configurations

The Precision 7920 Rack supports up to two processors with up to 28 cores per processor.

## Single CPU Configuration

The Precision 7920 Rack will function normally if there is just a single processor placed in the CPU1 socket . However, CPU and memory blank associated with CPU2 are required to be populated for thermal reasons. The system will not boot if only CPU2 socket is populated. With single CPU configuration all three PCIe slots in Riser 1C and PCIe slot 6 in Riser 2A will be functional.

## Chipset

The Precision 7920 Rack systems use the Intel C620 chipset (Lewisburg PCH) that provides extensive I/O support. Functions and capabilities include:

- ACPI Power Management Logic Support, Revision 4.0a
- PCI Express\* Base Specification Revision 3.0
- Integrated Serial ATA host controller, supports data transfer rates of up to 6 Gb/s on all ports.
- xHCI USB controller with SuperSpeed USB 3.0 ports
- Direct Media Interface
- Serial Peripheral Interface
- Enhanced Serial Peripheral Interface
- Flexible I/O - Allows some high speed I/O signals to be configured as PCIe root ports, PCIe uplink for use with certain PCH SKUs, SATA (and sSATA), or USB 3.0.



- General Purpose Input Output (GPIO)
- Low Pin Count interface, interrupt controller, and timer functions
- System Management Bus Specification, Version 2.0
- Integrated Clock Controller / Real Time Clock Controller
- Intel® High Definition Audio and Intel® Smart Sound Technology
- Integrated 10/1 Gb Ethernet
- Integrated 10/100/1000 Mbps Ethernet MAC
- Supports Intel® Rapid Storage Technology Enterprise
- Supports Intel® Active Management Technology and System Platform Services
- Supports Intel® Virtualization Technology for Directed I/O
- Supports Intel® Trusted Execution Technology
- JTAG Boundary Scan support
- Intel® QuickAssist Technology
- Intel® Trace Hub for debug

For more information, visit [Intel.com](https://www.intel.com)

## System memory

The system supports DDR4 registered DIMMs (RDIMMs) and load reduced DIMMs (LRDIMMs). System memory holds the instructions that are executed by the processor.

**NOTE: MT/s indicates DIMM speed in MegaTransfers per second.**

Memory bus operating frequency can be 2133 MT/s, 2400 MT/s, or 2666 MT/s depending on the following factors:

- DIMM type (RDIMM or LRDIMM)
- Number of DIMMs populated per channel
- System profile selected (for example, Performance Optimized, Custom, or Dense Configuration Optimized)
- Maximum supported DIMM frequency of the processors

Your system contains 24 memory sockets split into two sets of 12 sockets, one set per processor. Each 12-sockets is organized into six channels. Two sockets per channel with the release tabs of the first socket marked white and the second socket black.

**NOTE: DIMMs in sockets A1 to A12 are assigned to processor 1 and DIMMs in sockets B1 to B12 are assigned to processor 2.**

**Table 16. Maximum memory module**

Frequency supported	Processors
2133	31xx series
2400	41xx series
2400	51xx series
2666	61xx series

Memory channels are organized as follows:

**Table 17. Memory channels**

Processor	Channel 0	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5
CPU 1	Slots A1, A7	Slots A2, A8	Slots A3, A9	Slots A4, A10	Slots B5, A11	Slots A6, A12
CPU2	Slots B1, B7	Slots B2, B8	Slots B3, B9	Slots B4, B10	Slots B5, B11	Slots B6, B12



# General memory module installation guidelines

**NOTE:** Memory configurations that fail to observe these guidelines can prevent your system from booting, stop responding during memory configuration, or operating with reduced memory.

Enabling the system to be configured and run in any valid chipset architectural configuration. The following are the recommended guidelines for installing memory modules:

- RDIMMs and LRDIMMs must not be mixed.
- x4 and x8 DRAM based memory modules can be mixed.
- Up to two RDIMMs can be populated per channel regardless of rank count.
- Up to two LR DIMMs can be populated per channel regardless of rank count.
- If memory modules with different speeds are installed, they will operate at the speed of the slowest installed memory module(s) or slower depending on the system DIMM configuration.
- Populate memory module sockets only if a processor is installed. For single-processor systems, sockets A1-A12 are available. For dual-processor systems, sockets A1 to A12 and sockets B1 to B12 are available.
- Populate all the sockets with white release tabs first, followed by the black release tabs.
- In a dual-processor configuration, the memory configuration for each processor should be identical. For example, if you populate socket A1 for processor 1, then populate socket B1 for processor 2, and so on.
- Populate six memory modules per processor (one DIMM per channel) at a time to maximize performance.

Main Memory			CPU2												CPU1												
			iMC1				iMC0				iMC1				iMC0												
ILM (Main memory only)			Ch5	Ch4	Ch3	Ch0	Ch1	Ch2	Ch5	Ch4	Ch3	Ch0	Ch1	Ch2	Ch5	Ch4	Ch3	Ch0	Ch1	Ch2							
Total (GB)	DPC	Frequency	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1					
8	1DPC	2667																									
16	1DPC	2667																									
32	1DPC	2667																									
48	1DPC	2667																									
96	2DPC	2667																									
192	2DPC	2667																									
384	2DPC	2667																									
64	1DPC	2667																									
128	1DPC	2667																									
384	1DPC	2667																									
512	2DPC	2667																									
768	2DPC	2667																									
16	1DPC	2667																									
32	1DPC	2667																									
64	1DPC	2667																									
96	1DPC	2667																									
128	2DPC	2667																									
192	2DPC	2667																									
256	2DPC	2667																									
384	2DPC	2667																									
512	2DPC	2667																									
768	2DPC	2667																									
128	1DPC	2667																									
256	1DPC	2667																									
512	1DPC	2667																									
768	1DPC	2667																									
1024	2DPC	2667																									
1536	2DPC	2667																									

			CPU2												CPU1											
			iMC1				iMC0				iMC1				iMC0											
			Ch5	Ch4	Ch3	Ch0	Ch1	Ch2	Ch5	Ch4	Ch3	Ch0	Ch1	Ch2	Ch5	Ch4	Ch3	Ch0	Ch1	Ch2						
			0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1	0	1				
DIMM Socket Latch Color	W	B	W	B	W	B	B	W	B	W	B	W	B	W	B	W	B	B	W	B	W	B	W			
Motherboard Silk Screen	B6	B12	B5	B11	B4	B10	B7	B1	B8	B2	B9	B3	A6	A12	A5	A11	A4	A10	A7	A1	A8	A2	A9	A3		

## Memory

The Precision 7920 Rack supports up to 24 DIMMs, with up to 1536GB of memory and speeds of up to 2666MT/s.



The Precision 7920 Rack supports registered (RDIMMs) and load reduced DIMMs (LRDIMMs) which use a buffer to reduce memory loading and provide greater density, allowing for the maximum platform memory capacity.

## DIMMs supported

**Table 18. Memory technologies supported**

Feature	Precision 7920 Rack (DDR4)
DIMM Type	RDIMM
	LRDIMM
Transfer Speed	2666 MT/s
	2400 MT/s
	2133 MT/s
Voltage	1.2V (DDR4)

**NOTE: Unbuffered DIMMs (UDIMMs) are not supported in Precision 7920 Rack**

The Precision 7920 Rack supports the following DIMMs.

**Table 19. DIMMs supported**

DIMM Capacity(GB)	DIMM Speed	DIMM Type	Ranks per DIMM	Data Width	SDDC Support	DIMM Voltage
8	2666MT/s	RDIMM	1	x8	Advanced ECC	1.2
16	2666MT/s	RDIMM	2	x8	Advanced ECC	1.2
32	2666MT/s	RDIMM	2	x4	All Modes	1.2
64	2666MT/s	LRDIMM	4	x4	All Modes	1.2

## Memory Speed

The Precision 7920 Rack supports memory speeds of 2666 MT/s, 2400 MT/s, and 2133 MT/s depending on the DIMM types installed and the configuration. All memory on all processors and channels run at the same speed and voltage. By default, this speed will be the highest speed supported by the CPU and the DIMMs. The operating speed of the DIMMs is also determined by the maximum speed supported by the processor, speed settings in the BIOS and the operating voltage of the system. Not all processors support 2666MT/s memory speed.

The table below lists the memory configuration and performance details for the Precision 7920 Rack, based on the quantity and type of DIMMs per memory channel.

**Table 20. DIMM Performance Details**

DIMM Type	DIMM Ranking	Capacity	DIMM Rated Voltage, Speed	1 DPC	2 DPC
RDIMM	1R/2R	8GB, 16GB, 32GB	DDR4 (1.2V)	i: 2666	i: 2400
				D:2666	D:2666
LRDIMM	4R	64GB	DDR4 (1.2V)	i: 2666	i: 2400
				D:2666	D:2666



# LCD panel

The LCD panel provides system information, status, and error messages to indicate if the system is functioning correctly or requires attention. The LCD panel can be used to configure or view the system's iDRAC IP address. For more information about error messages, see the *Dell Event and Error Messages Reference Guide* at [Dell.com/openmanagemanuals](https://Dell.com/openmanagemanuals) > **OpenManage software**.

The LCD panel is available only on the optional LCD bezel. The optional LCD bezel is hot pluggable.

The statuses and conditions of the LCD panel are outlined here:

- The LCD backlight is white during normal operating conditions.
- When the system needs attention, the LCD backlight turns amber, and displays an error code followed by descriptive text.

**NOTE:** If the system is connected to a power source and an error is detected, the LCD turns amber regardless of whether the system is turned on or off.

- When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.
- If the LCD panel stops responding, remove the bezel and reinstall it. If the problem persists, see the Getting help section.
- The LCD backlight remains off if LCD messaging is turned off using the iDRAC utility, the LCD panel, or other tools.




Figure 32. LCD panel features

Table 21. LCD panel features

Item	Button or display	Description
1	Left	Moves the cursor back in one-step increments.
2	Select	Selects the menu item highlighted by the cursor.
3	Right	Moves the cursor forward in one-step increments. During message scrolling: <ul style="list-style-type: none"><li>• Press and hold the right button to increase scrolling speed.</li><li>• Release the button to stop.</li></ul>
		<b>NOTE:</b> The display stops scrolling when the button is released. After 45 seconds of inactivity, the display starts scrolling.
4	LCD display	Displays system information, status, and error messages or iDRAC IP address.

## Viewing Home screen

The **Home** screen displays user-configurable information about the system. This screen is displayed during normal system operation when there are no status messages or errors. When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.

- 1 To view the **Home** screen, press one of the three navigation buttons (Select, Left, or Right).
- 2 To navigate to the **Home** screen from another menu, complete the following steps:
  - a Press and hold the navigation button till the up arrow  is displayed.



- b Navigate to the **Home** icon  using the up arrow .
- c Select the **Home** icon.
- d On the **Home** screen, press the **Select** button to enter the main menu.

## Setup menu

 **NOTE:** When you select an option in the Setup menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC	Select <b>DHCP</b> or <b>Static IP</b> to configure the network mode. If <b>Static IP</b> is selected, the available fields are <b>IP</b> , <b>Subnet (Sub)</b> , and <b>Gateway (Gtw)</b> . Select <b>Setup DNS</b> to enable DNS and to view domain addresses. Two separate DNS entries are available.
Set error	Select <b>SEL</b> to view LCD error messages in a format that matches the IPMI description in the SEL. This enables you to match an LCD message with an SEL entry.  Select <b>Simple</b> to view LCD error messages in a simplified user-friendly description. For more information about error messages, see the <i>Dell Event and Error Messages Reference Guide</i> at <a href="http://Dell.com/openmanagemanuals">Dell.com/openmanagemanuals</a> > <b>OpenManage software</b> .
Set home	Select the default information to be displayed on the <b>Home</b> screen. See View menu section for the options and option items that can be set as the default on the <b>Home</b> screen.

## View menu

 **NOTE:** When you select an option in the View menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC IP	Displays the <b>IPv4</b> or <b>IPv6</b> addresses for iDRAC9. Addresses include <b>DNS (Primary and Secondary)</b> , <b>Gateway</b> , <b>IP</b> , and <b>Subnet</b> (IPv6 does not have Subnet).
MAC	Displays the MAC addresses for <b>iDRAC</b> , <b>iSCSI</b> , or <b>Network</b> devices.
Name	Displays the name of the <b>Host</b> , <b>Model</b> , or <b>User String</b> for the system.
Number	Displays the <b>Asset tag</b> or the <b>Service tag</b> for the system.
Power	Displays the power output of the system in BTU/hr or Watts. The display format can be configured in the <b>Set home</b> submenu of the <b>Setup</b> menu.
Temperature	Displays the temperature of the system in Celsius or Fahrenheit. The display format can be configured in the <b>Set home</b> submenu of the <b>Setup</b> menu.

## Expansion cards and expansion card risers

An expansion card in the appliance is an add-on card that can be inserted into an expansion slot on the system board or riser card to add enhanced functionality to the appliance through the expansion bus.

 **NOTE:** A System Event Log (SEL) event is logged if an expansion card riser is unsupported or missing. It does not prevent your appliance from turning on and no BIOS POST message or F1/F2 pause is displayed.

# Expansion card installation guidelines

Depending on your system configuration, the following PCI Express (PCIe) generation 3 expansion cards are supported:

**Table 22. Expansion card riser specifications**

Expansion card riser	PCIe slots on the riser	Processor connection	Height	Length	Link	Slot width
Riser 1C	Slot 1	Processor 1	Full Height	Full Length	x16	x16
Riser 1C	Slot 2	Processor 1	Full Height	Full Length	x8	x16
Riser 1C	Slot 3	Processor 1	Full Height	Half Length	x8	x16
Riser 2A	Slot 4	Processor 2	Full Height	Full Length	x16	x16
Riser 2A	Slot 5	Processor 2	Full Height	Full Length	x8	x16
Riser 2A	Slot 6	Processor 1	Low Profile	Half Length	x8	x16
Riser 3A	Slot 7	Processor 2	Full Height	Full Length	x8	x16
Riser 3A	Slot 8	Processor 2	Full Height	Full Length	x16	x16

**NOTE:** The expansion card slots are not hot-swappable.

The following table provides guidelines for installing expansion cards to ensure proper cooling and mechanical fit. The expansion cards with the highest priority should be installed first using the slot priority indicated. All the other expansion cards should be installed in the card priority and slot priority order.

**Table 23. No riser configurations**

Card Type	Slot priority	Maximum number of cards
NDC	NDC Slot	1
PERC	3, 1, 2	1
GFX/GPU Compute (DW)	1,4,8	3
GFX (FH/SW)	1,4,8,2,5,7	up to 6
GFX (LP)	6	1
PCIe SSD (LP) - Zoom 2	6	1
PCIe SSD (FH) - Zoom 2	1,2,3,4,5,7,8	1
PCIe SSD (FH) - Zoom 4	1,4,8	2 (*See Note 7)
Teradici (P25) (LP)	6	1
Teradici (P25 or P45) (FH)	1,2,4,5,7,8	2
Serial (FH)	1,2,4,5,7,8	1
Serial (LP)	6	1
Audio (FH)	1,2,4,5,7,8	1
Audio (LP)	6	1



PCIe Cards		PERC H330	PERC H730P	PERC H740P	nVidia QP100	nVidia P1000	FirePro W3100 / WX P3100	nVidia P5000	nVidia P6000	Nvidia P6000 FH	Nvidia P6000 LP	Radeon WX 7100	nVidia P400 FH	nVidia EL100 LP	WX EL100 FH	WX EL100 LP	NV3310 LP	Zoom2 LP	Zoom2 FH	Zoom4 P25 LP	Zoom4 P25 FH	Zoom4 P45 FH	Teradici P25 LP	Teradici P25 FH	Teradici P45 LP	Teradici P45 FH	Serial Post LP	Serial Post FH	Audio FH	Audio LP	Intel(R) Gigabit DP 1350	Intel(R) Gigabit DP 1350/1355	Intel(R) Ethernet 10G DP	Intel(R) Ethernet 10G DP	
Type	Storage	Storage	Storage	PSGA x16	SHEGA x16	SHEGA x16	HEGA x16	MIRGAH x16	ELGA x16	ELGA x16	MIRGAH x16	MIRGAL x16	ELGA x16	ELGA x8	ELGA x8	ELGA x16	ULGA x8	SSD x8	SSD x16	SSD x16	AIC x1	AIC x1	AIC x1	AIC x1	AIC x1	AIC x1	AIC x1	AIC x1	COMM x8	COMM x8	COMM x8	COMM x8	COMM x8		
Width	x8	x8	x8																																
Gen	2 or 3	2 or 3	2 or 3	3	3	3	3	3	3	3	3	3	3	3	3	3	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
Power	23w	23w	23w	230w	230w	275w	180W	160W	40w	40w	150w	75W	40w	50W	50W	13.5w	25w	25w	30w	13w	13w	30w	7w	7w											
GPU power single required				X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X	X
Interface				DP, DVI-D	DP, DVI-D	DP, DVI-D	mDP	DP, DVI-D	DP	mDP	mDP	DP	DP	mDP	mDP	mDP	DP																		
Supported OS	All	All	Win 7 only	Win10/Linux	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	All	Win10/Linux
Min allowed	1	1	1	3	3	3	3	3	4	6	1	4	6	6	1	6	1	1	1	2	1	3	2	1	3	2	1	1	1	1	1	1	1	1	
100 NDC	NDC Slot																																		
200 PERC	3, 3, 2																																		
300 GFX/GPU Compute (DW)	1	X	X	X																															
400 GFX (FW/SW)	1,4,8,2,5,7				X	X	X	X	X	X		X	X	X	X	X																			
500 GFX (LP)	6																																		
600 PCIe SSD (LP) - Zoom 2	6																																		
600 PCIe SSD (FH) - Zoom 2	1,2,3,4,5,7,8																																		
700 PCIe SSD (FH) - Zoom 4	1,4,8																																		
800 Teradici (P25) (LP)	6																																		
900 Teradici (P25 or P45) (FH)	1,2,4,5,7,8																																		
1000 Serial (FH)	1,2,3,4,5,7,8																																		
1100 Serial (LP)	6																																		
1200 Audio (FH)	1,2,3,4,5,7,8																																		
1300 Audio (LP)	6																																		

- Notes:
1. Cards should be installed in the system, starting with the Card priority, then the slot priority. The first open slot priority should be used.
  2. Low profile (LP), Half-Height cards can only be installed in Slot 6.
  3. Slots 4, 5, 7, 8 require that CPU2 be installed in the system.
  4. Any cards > 75W require one or more external power cables to be installed (power cables are included in base system BOM).
  5. Graphics cards are of equal priority to each other. For multiple GPU card configs, cards must be matched (all same model).
  6. nVidia GPU's using SLI must reside in slots 4 and 7 with a 2nd CPU installed. An SLI cable must also be installed.
  7. Zoom4 - Dual Zoom4 requires dual CPU, and both Zoom cards must be populated on CPU2 (slots 4 & 8)

Riser	Slots							
	Slot 1	Slot 2	Slot 3	Slot 4	Slot 5	Slot 6	Slot 7	Slot 8
RSR1C - Bay 1 (right hand bay)	x16 FH/LP/DW	x8 FH/LP	x8 FH/LP	x16 FH/LP/DW	x8 LP			
RSR2A - Bay 2 (center bay)				x16 FH/LP/DW	x8 LP			
RSR3A - Bay 4 (left hand bay)				x16 FH/LP/DW	x8 LP			
Associated CPU	CPU1			CPU2		CPU1		CPU2
Slot Power	275w + 75w	75w + 25w	75w + 25w	225w + 75w	75w	225w + 75w	75w + 25w	225w + 75w

All Slots PCIe Gen5

**NOTE:**

1. Cards should be installed in the system, starting with the Card priority, then the slot priority. The first open slot priority should be used.
2. Low profile (LP), Half-Height cards can only be installed in Slot 6.
3. Slots 4, 5, 7, 8 require that CPU2 be installed in the system.
4. Any cards > 75W require one or more external power cables to be installed (power cables are included in base system BOM).
5. Graphics cards are of equal priority to each other. For multiple GPU card configs, cards must be matched (all same model).
6. nVidia GPU's using SLI must reside in slots 4 and 7 with a 2nd CPU installed. An SLI cable must also be installed.
7. Zoom4 - Dual Zoom4 requires dual CPU, and both Zoom cards must be populated on CPU2 (slots 4 & 8)
8. No Teradici P25 or P45 in slot 3

# Storage

The Precision 7920 Rack provide scalable storage that allows you to adapt to your workload and operational demands. The Precision 7920 Rack offers storage expansion with the front hard drive cage.

## Hard Drive

The Precision 7920 Rack system supports SAS, SATA.

# Supported Drives

Table 24. Supported Drives - SAS and SATA

Form Factor	Type	Speed	Rotational Speed	Capacities
2.5"	SATA, SSD	6Gb	N/A	256GB, 512GB, 480GB, 960GB
	SATA,SSD	12Gb	N/A	500GB, 1TB, 2TB
	SAS	12Gb	10K	400GB, 800GB
	SAS	12Gb	15K	1.8TB
	SAS	12Gb	15K	600GB



Form Factor	Type	Speed	Rotational Speed	Capacities
3.5"	SATA	6Gb	7.2K	1TB, 2TB, 8TB

**Table 25. Supported Drives - NVMe PCIe SD**

**Description**

256GB Device

512GB Device

1TB Device

## Power supply units

The power supply unit (PSU) is an internal hardware component which supplies power to the components in the system.

Your system supports the following:

- Two 1600 W or 1100 W AC power supply units (PSUs)

**NOTE:** For more information, see the **Technical specifications section**.

**CAUTION:** If two PSUs are installed, both the PSUs must have the **Extended Power Performance (EPP) label**. Mixing PSUs (even the PSUs that have the same power rating) from previous generations of Precision workstation is not supported. This results in a PSU mismatch condition or failure to turn the system on.

**NOTE:** Titanium PSU is nominally rated for 200 V AC to 240 V AC input only.

**NOTE:** When two identical PSUs are installed, power supply redundancy (1+1 – with redundancy or 2+0 – without redundancy) is configured in system BIOS. In redundant mode, power is supplied to the system equally from both PSUs when Hot Spare is disabled. When Hot Spare is enabled, one of the PSUs will be put into sleep mode when system utilization is low in order to maximize efficiency.

**NOTE:** If two PSUs are used, they must be of the same maximum output power.

## Hot spare feature

Your system supports the hot spare feature that significantly reduces the power overhead associated with power supply unit (PSU) redundancy.

When the hot spare feature is enabled, one of the redundant PSUs is switched to the sleep state. The active PSU supports 100 percent of the system load, thus operating at higher efficiency. The PSU in the sleep state monitors output voltage of the active PSU. If the output voltage of the active PSU drops, the PSU in the sleep state returns to an active output state.

If having both PSUs active is more efficient than having one PSU in the sleep state, the active PSU can also activate the sleeping PSU.

The default PSU settings are as follows:

- If the load on the active PSU is more than 50 percent of PSU rated power wattage, then the redundant PSU is switched to the active state.
- If the load on the active PSU falls below 20 percent of PSU rated power wattage, then the redundant PSU is switched to the sleep state.

You can configure the hot spare feature by using the iDRAC settings. For more information, see the iDRAC User’s Guide available at [Dell.com/idracmanuals](http://Dell.com/idracmanuals).



# Trusted platform module

The Trusted Platform Module (TPM) is used to generate and store keys, protect or authenticate passwords, and create and store digital certificates. The Intel's TXT (Trusted Execution Technology) functionality along with Microsoft's Platform Assurance feature in Windows Operating System is supported. TPM can also be used to enable the BitLocker hard drive encryption feature in Windows Operating System.

The TPM chip is on the Plug-in Module (PIM) and bound only to one system board.

The system board has a connector for the plug-in module, and it is factory-installed.



**Figure 33. Trusted platform module**

There are four types of TPM chip options:

- No TPM
- TPM 1.2 Nuvoton FIPS-CC-TCG
- TPM TPM 2.0 Nuvoton FIPS-CC-TCG
- TPM 2.0 NationZ

**NOTE:** In a scenario where both the control panel and system board are dispatched, Dell recommends you to replace the control panel first and try to turn on the system to complete the Easy Restore process (Service Tag, licenses, copy to the new control panel). Replace the system board.

# BIOS and UEFI

You can manage basic settings and features of a system without booting to the operating system by using the system firmware.

Topics:

- [Options to manage the pre-operating system applications](#)
- [System Setup](#)
- [Technical specifications](#)

## Options to manage the pre-operating system applications

Your system has the following options to manage the pre-operating system applications:

- System Setup
- Dell Lifecycle Controller
- Boot Manager
- Preboot Execution Environment (PXE)

## System Setup

By using the **System Setup** screen, you can configure the BIOS settings, iDRAC settings, and device settings of your system. These settings have already been preconfigured per solution requirements. Contact Dell before you change these settings.

**NOTE:** Help text for the selected field is displayed in the graphical browser by default. To view the help text in the text browser, press F1.

You can access system setup by using two methods:

- Standard graphical browser — The browser is enabled by default.
- Text browser — The browser is enabled by using Console Redirection.

## Viewing System Setup

To view the **System Setup** screen, perform the following steps:

- 1 Turn on, or restart your appliance.
- 2 Press F2 immediately after you see the following message:

F2 = System Setup

**NOTE:** If your operating system begins to load before you press F2, wait for the system to finish booting, and then restart your appliance and try again.



# System Setup Main Menu

Option	Description
<b>System BIOS</b>	Enables you to configure BIOS settings.
<b>iDRAC Settings</b>	Enables you to configure iDRAC settings. The iDRAC Settings utility is an interface to set up and configure the iDRAC parameters using UEFI. You can enable or disable various iDRAC parameters by using the iDRAC Settings utility. For more information about this utility, see the Integrated Dell Remote Access Controller User's Guide at <a href="http://dell.com/esmanuals">dell.com/esmanuals</a> .
<b>Device Settings</b>	Enables you to configure device settings.
<b>Service Tag Settings</b>	Enables service tag of the system

## System BIOS screen

You can use the **System BIOS** screen to view BIOS settings as well as edit specific functions such as boot order, system password, setup password, setting RAID mode, and enabling or disabling USB ports.

In the **System Setup Main Menu**, click **System BIOS**.

The **System BIOS** screen details are explained below.

Menu Item	Description
<b>System Information</b>	Displays information about the system such as the system model name, BIOS version, Service Tag, and so on.
<b>Memory Settings</b>	Displays information and options related to installed memory.
<b>Processor Settings</b>	Displays information and options related to the processor such as speed, cache size, and so on.
<b>SATA Settings</b>	Displays options to enable or disable the integrated SATA controller and ports.
<b>NVMe Settings</b>	Displays options to enable or disable the NVMe Settings.
<b>Boot Settings</b>	Displays options to specify the boot mode (BIOS or UEFI). Enables you to modify UEFI and BIOS boot settings.
<b>Network Settings</b>	Displays options to enable or disable the Network Settings
<b>Integrated Devices</b>	Displays options to enable or disable integrated device controllers and ports, and to specify related features and options.
<b>Serial Communication</b>	Displays options to enable or disable the serial ports and specify related features and options.
<b>System Profile Settings</b>	Displays options to change the processor power management settings, memory frequency, and so on.
<b>System Security</b>	Displays options to configure the system security settings like, system password, setup password, TPM security, and so on. It also enables or disables support for the power and NMI buttons on the system.
<b>Redundant OS Control</b>	Displays options to change the Redundant OS Control
<b>Miscellaneous Settings</b>	Displays options to change the system date, time, and so on.
<b>Debug Menu Settings</b>	This field controls serial debug output level for certain drivers.

# System information screen details

You can use the **System Information** screen allows to view system properties such as Service Tag, system model, and BIOS version. You can view the **System Information** screen by clicking **System Setup Main Menu > System BIOS > System Information**.

The **System Information** screen details are explained as follows:

Menu Item	Description
<b>System Model Name</b>	Displays the system model name.
<b>System BIOS Version</b>	Displays the BIOS version installed on the system.
<b>System Management Engine Version</b>	Displays the current revision of the Management Engine firmware.
<b>System Service Tag</b>	Displays the system Service Tag.
<b>System Manufacturer</b>	Displays the name of the system manufacturer.
<b>System Manufacturer Contact Information</b>	Displays the contact information of the system manufacturer.
<b>System CPLD Version</b>	Displays the current revision of the system CPLD firmware.
<b>UEFI Compliance Version</b>	Displays the system firmware UEFI compliance level.

# Memory settings screen details

You can use the **Memory Settings** screen to view all the memory settings as well as to enable or disable specific memory functions such as system memory testing and node interleaving.

You can view the **Memory Setting** screen by clicking **System Setup Main Menu > System BIOS > Memory Settings**.

The **Memory Settings** screen details are explained as follows:

Menu Item	Description
<b>System Memory Size</b>	Displays the amount of memory installed in the system.
<b>System Memory Type</b>	Displays the type of memory installed in the system.
<b>System Memory Speed</b>	Displays the system memory speed.
<b>System Memory Voltage</b>	Displays the system memory voltage.
<b>Video Memory</b>	Displays the amount of video memory.
<b>System Memory Testing</b>	Specifies whether system memory tests are run during system boot. Options are <b>Enabled</b> and <b>Disabled</b> . By default, the <b>System Memory Testing</b> option is set to <b>Disabled</b> .
<b>Memory Operating Mode</b>	Specifies the memory operating mode. By default <b>Optimizer Mode</b> .



Menu Item	Description
	<p><b>NOTE:</b> The Memory Operating Mode can have different defaults and available options based on the memory configuration of your system.</p> <p><b>NOTE:</b> The Dell Fault Resilient Mode establishes an area of memory that is fault resilient. This mode can be used by an operating system that supports the feature to load critical applications or enables the operating system kernel to maximize system availability.</p>
<b>Current State of Memory Operating Mode</b>	Specifies current state of memory operating mode. Option is <b>Optimizer</b> .
<b>Node Interleaving</b>	Specifies if Non-Uniform Memory architecture (NUMA) is supported. If this field is <b>Enabled</b> , memory interleaving is supported if a symmetric memory configuration is installed. If <b>Disabled</b> , the system supports NUMA (asymmetric) memory configurations. By default, <b>Node Interleaving</b> option is set to <b>Disabled</b> .

## Processor settings screen details

You can use the **Processor Settings** screen to view the processor settings and perform specific functions such as enabling virtualization technology, hardware prefetcher, and logical processor idling.

You can view the **Processor Settings** screen by clicking **System Setup Main Menu > System BIOS > Processor Settings**.

The **Processor Settings** screen details are explained as follows:

Menu Item	Description
<b>Logical Processor</b>	Enables or disables the logical processors and displays the number of logical processors. If the <b>Logical Processor</b> option is set to <b>Enabled</b> , the BIOS displays all the logical processors. If this option is set to <b>Disabled</b> , the BIOS only displays one logical processor per core. By default, the <b>Logical Processor</b> option is set to <b>Enabled</b> .
<b>Virtualization Technology</b>	Enables or disables the additional hardware capabilities provided for virtualization. By default, the <b>Virtualization Technology</b> option is set to <b>Enabled</b> .
<b>Adjacent Cache Line Prefetch</b>	Optimizes the system for applications that require high utilization of sequential memory access. By default, the <b>Adjacent Cache Line Prefetch</b> option is set to <b>Enabled</b> . You can disable this option for applications that require high utilization of random memory access.
<b>Hardware Prefetcher</b>	Enables or disables the hardware prefetcher. By default, the <b>Hardware Prefetcher</b> option is set to <b>Enabled</b> .
<b>DCU Streamer Prefetcher</b>	Allows you to enable or disable the Data Cache Unit (DCU) streamer prefetcher. By default, the <b>DCU Streamer Prefetcher</b> option is set to <b>Enabled</b> .
<b>DCU IP Prefetcher</b>	Enables or disables the Data Cache Unit (DCU) IP prefetcher. By default, the <b>DCU IP Prefetcher</b> option is set to <b>Enabled</b> .
<b>Sub NUMA Cluster</b>	Enables or disables the execute disable memory protection technology. By default, the <b>Execute Disable</b> option is set to <b>Enabled</b> .
<b>Logical Processor Idling</b>	Enables or disables the breaking up the LLC into disjoint clusters based on address range with each cluster bound to a subset the memory controllers. Option is set to <b>Disabled</b> .
<b>Configurable TDP</b>	Allows reconfiguration of Thermal Design Power (TDP) to lower levels. TDP refers to the maximum amount of power the cooling system is required to dissipate.  The options are <b>Normal (set by default)</b> , <b>Level 1</b> and <b>Level 2</b>
<b>X2Apic Mode</b>	Enables or disables the X2Apic mode.
<b>Dell Controlled Turbo</b>	<p><b>NOTE:</b> Depending on the number of installed CPUs, there may be up to four processor listings.</p> <p>Controls the turbo engagement. Enable this option only when <b>System Profile</b> is set to <b>Performance</b>.</p>
<b>Number of Cores per Processor</b>	Controls the number of enabled cores in each processor. By default, the <b>Number of Cores per Processor</b> option is set to <b>All</b> .

Menu Item	Description
<b>Processor Core Speed</b>	Displays the maximum core frequency of the processor.
<b>Processor 1</b>	 <b>NOTE:</b> Depending on the number of installed CPUs, there may be up to four processor listings. The following settings are displayed for each processor installed in the system.
<b>Family-Model-Stepping</b>	Displays the family, model and stepping of the processor as defined by Intel.
<b>Brand</b>	Displays the brand name reported by the processor.
<b>Level 2 Cache</b>	Displays the total L2 cache.
<b>Level 3 Cache</b>	Displays the total L3 cache.
<b>Number of Cores</b>	Displays the number of cores per processor.
<b>Processor 2</b>	 <b>NOTE:</b> Depending on the number of installed CPUs, there may be up to four processor listings. The following settings are displayed for each processor installed in the system.
<b>Family-Model-Stepping</b>	Displays the family, model and stepping of the processor as defined by Intel.
<b>Brand</b>	Displays the brand name reported by the processor.
<b>Level 2 Cache</b>	Displays the total L2 cache.
<b>Level 3 Cache</b>	Displays the total L3 cache.
<b>Number of Cores</b>	Displays the number of cores per processor.

## SATA settings screen details

You can use the **SATA Settings** screen to view the SATA settings of SATA devices and enable RAID on your system.

You can view the **SATA Settings** screen by clicking **System Setup Main Menu > System BIOS > SATA Settings**.

The **SATA Settings** screen details are explained below.

Menu Item	Description
<b>Embedded SATA</b>	Enables the embedded SATA to be set to <b>Off</b> , <b>AHCI Mode</b> , or <b>RAID Mode</b> modes. By default, the <b>Embedded SATA</b> option is set to <b>AHCI Mode</b> .
<b>Security Freeze Lock</b>	Sends Security Freeze Lock command to the Embedded SATA drives during POST. This option is only AHCI mode not RAID mode. Options is set to <b>Enabled</b>
<b>Write Cache</b>	Enables or disables the command for Embedded SATA drives during POST. Options is set to <b>Disabled</b>
<b>Port A</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port B</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port C</b>	Sets the drive type of the selected device.



Menu Item	Description
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port D</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port E</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port F</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port G</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port H</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port I</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port J</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Port K</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.

Menu Item	Description
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port L</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port M</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.
<b>Port N</b>	Sets the drive type of the selected device.
<b>Model</b>	Displays the drive model of the selected device.
<b>Drive Type</b>	Displays the type of drive attached to the SATA port.
<b>Capacity</b>	Displays the total capacity of the hard drive. The field is undefined for removable media devices such as optical drives.

## Boot settings screen details

You can use the **Boot Settings** screen to set the Boot mode to either **BIOS** or **UEFI**. It also allows you to specify the boot order. You can view the **Boot Settings** screen by clicking **System Setup Main Menu > System BIOS > Boot Settings**.

The **Boot Settings** screen details are explained as follows:

Menu Item	Description
<b>Boot Mode</b>	<p>Enables you to set the boot mode of the system.</p> <p> <b>CAUTION: Switching the boot mode may prevent the system from booting if the operating system is not installed in the same boot mode.</b></p> <p> <b>NOTE: Setting this field to UEFI disables BIOS Boot Settings menu. Setting this field to BIOS disables the UEFI Boot Settings menu.</b></p> <p>If the operating system supports UEFI, you can set this option to <b>UEFI</b>. Setting this field to <b>BIOS</b> allows compatibility with non-UEFI operating systems. By default, the <b>Boot Mode</b> option is set to <b>UEFI</b>.</p>
<b>Boot Sequence Retry</b>	Enables or disables the boot sequence retry feature. If this field is enabled and the system fails to boot, the system reattempts the boot sequence after 30 seconds. By default, the <b>Boot Sequence Retry</b> option is set to <b>Enabled</b> .
<b>Hard Disk Failover</b>	Specifies which devices in the <b>Hard-Disk Drive Sequence</b> are attempted in the boot sequence. When the option is <b>Disabled</b> , only the first hard disk device in the list is attempted to boot. When set to <b>Enabled</b> , all hard disk devices are attempted in order, as listed in the <b>Hard-Disk Drive Sequence</b> . This option is not enabled for UEFI Boot Mode.
<b>UEFI Boot Sequence</b>	This field controls the UEFI boot order Integrated NIC 1 Port 1 Partition 1
<b>Boot option Enable/Disable</b>	This field enables or disables the boot option in UEFI Boot Sequence.



## Network settings screen details

You can use the **Network Settings** screen to set the Boot mode from **UEFI**. It also allows you to specify the boot order. You can view the **Network Settings** screen by clicking **System Setup Main Menu > System BIOS > Network Settings**.

The **Network Settings** screen details are explained as follows:

Menu Item	Description
<b>UEFI PXE settings</b>	This field controls the system network settings.
<b>PXE Device1</b>	This field controls the system network settings. Option is set to <b>Enabled</b> .
<b>PXE Device2</b>	This field controls the system network settings. Option is set to <b>Disabled</b>
<b>PXE Device3</b>	This field controls the system network settings. Option is set to <b>Disabled</b>
<b>PXE Device4</b>	This field controls the system network settings. Option is set to <b>Disabled</b>
<b>PXE Device1 Settings</b>	NIC interface used for this PXE device. Option is set to <b>Enabled</b>
<b>Interface</b>	NIC interface used for this PXE device. Options are: Intergrated NIC Port 1 Partition 1  Intergrated NIC Port 2 Partition 1  Intergrated NIC Port 3 Partition 1  Intergrated NIC Port 4 Partition 1
<b>Protocol</b>	This field controls the PXE protocol used for PXE device. Options are <b>IPv4 (set default)</b> and <b>IPv6</b>
<b>VLAN</b>	Enables or disables PXE device. Options are <b>Enabled</b> and <b>Disabled (set default)</b>
<b>VLAN ID</b>	Displays the VLAN ID
<b>VLAN Priority</b>	Displays the VLAN Priority
<b>UEFI HTTP Settings</b>	This field enables the BIOS to create a UEFI boot option for the HTTP device. Option is set to <b>Disabled</b>
<b>HTTP Device1</b>	This field enables the BIOS to create a UEFI boot option for the HTTP device. Option is set to <b>Disabled</b>
<b>HTTP Device2</b>	This field enables the BIOS to create a UEFI boot option for the HTTP device. Option is set to <b>Disabled</b>
<b>HTTP Device3</b>	This field enables the BIOS to create a UEFI boot option for the HTTP device. Option is set to <b>Disabled</b>
<b>HTTP Device4</b>	This field enables the BIOS to create a UEFI boot option for the HTTP device. Option is set to <b>Disabled</b>
<b>UEFI ISCSI Settings</b>	This field specifies the name of the ISCSI initiator (iqn format).
<b>ISCSI Initiator Name</b>	This field specifies the name of the ISCSI initiator (iqn format).
<b>ISCSI Device1</b>	This field controls the configuration for ISCSI device.

## Integrated devices screen details

You can use the **Integrated Devices** screen to view and configure the settings of all integrated devices including the video controller, integrated RAID controller, and the USB ports.

You can view the **Integrated Devices** screen by clicking **System Setup Main Menu > System BIOS > Integrated Devices**.

The **Integrated Devices** screen details are explained below.

Menu Item	Description
<b>User Accessible USB Ports</b>	<p>Enables or disables the USB ports. Selecting <b>Only Back Ports On</b> disables the front USB ports, selecting <b>All Ports Off</b> disables all USB ports, selecting <b>All Ports Off (Dynamic)</b> disables all USB ports during P.O.S.T. The USB keyboard and mouse operates during boot process in certain operating systems. After the boot process is complete, the USB keyboard and mouse do not work if the ports are disabled.</p> <p><b>NOTE:</b> Selecting <b>Only Back Ports On</b> and <b>All Ports Off</b> will disable the USB management port and also restrict access to iDRAC features.</p>
<b>Internal USB Port</b>	Enables or disables the internal USB port. By default, the option is set to <b>On</b> .
<b>iDRAC Direct USB Port</b>	iDRAC Direct USB Port managed by iDRAC exclusively with no host visibility. When set to off iDRAC would not detect any USB device installed. Option is set to <b>On</b>
<b>Integrated Network Card 1</b>	Enables or disables the integrated network card.
<b>I/OAT DMA Engine</b>	Enables or disables the I/OAT option. Enable only if the hardware and software support the feature.
<b>Embedded Video Controller</b>	<p>Enables or disables the <b>Current state of Embedded Video Controller</b> . By default the option <b>Disabled</b>. <b>Current State of Embedded Video Controller</b> is a read only field, indicating the current state for the Embedded Video Controller. If the Embedded Video Controller is the only display capability in the system (that is, no add-in graphics card is installed), then the Embedded Video Controller is automatically used as the primary display even if the Embedded Video Controller setting is <b>Disabled</b>.</p> <p><b>NOTE: 1.</b> If the embedded video controller is <b>DISABLED</b> in BIOS and if you launch the Virtual Console from the iDRAC, the Virtual Console Viewer is blank.</p> <p><b>NOTE: 2.</b> All monitors must be plugged into the GPU at power on, and must remain plugged into the GPU until the system is booted into the operating system with the driver loaded. Once the system is booted into the operating system the monitor can be unplugged, and then hot plugged. The monitor will not be hot pluggable unless this process is followed.</p> <ul style="list-style-type: none"><li>• DP cable can be hot plugged</li><li>• mDP cable can be hot plugged</li><li>• DVI cable can be hot plugged</li><li>• DP to VGA dongle cable cannot be hot plugged</li></ul>
<b>Current State of Embedded Video Controller</b>	Displays the current state of the <b>Embedded Video Controller</b> . <b>Current State of Embedded Video Controller</b> is a read only field, indicating the current state for the Embedded Video Controller
<b>SR-IOV Global Enable</b>	Enables or disables the BIOS configuration of Single Root I/O Virtualization (SR-IOV) devices. By default, the <b>SR-IOV Global Enable</b> option is set to <b>Disabled</b> .
<b>OS Watchdog Timer</b>	If your system stops responding, this watchdog timer aids in the recovery of your operating system. When this field is set to <b>Enabled</b> , the operating system is allowed to initialize the timer. When the option is set to <b>Disabled</b> (the default), the timer will have no effect on the system.
<b>Memory Mapped I/O above 4GB</b>	Enables or disables the support for PCIe devices that require large amounts of memory. By default, the option is set to <b>Enabled</b> .
<b>Lower Memory Mapped I/O base to 512GB</b>	When set to enabled system will map MMIO base to 512 GB and reduce the maximum support for memory to less than 512 GB.
<b>Slot Disablement</b>	<p>Enables or disables the available PCIe slots on your system. The <b>Slot Disablement</b> feature controls the configuration of PCIe cards installed in the specified slot. Slot disablement must be used only when the installed peripheral card is preventing booting into the operating system or causing delays in system startup. If the slot is disabled, both the Option ROM and UEFI driver are disabled.</p> <p>This field controls the configuration of the card installed in the slot. You can set one of the following options for each of the .....(Press F1 for more information)</p> <p>1 Slot 1 Boot Driver</p>



Menu Item	Description
	<ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>
2	Slot 2 Boot Driver <ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>
3	Slot 3 Boot Driver <ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>
4	Slot 4 Boot Driver <ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>
5	Slot 5 Boot Driver <ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>
6	Slot 6 Boot Driver <ul style="list-style-type: none"> <li>• <b>Enabled (default)</b></li> <li>• Disabled</li> <li>• Boot Driver Disabled</li> </ul>

### Slot Bifurcation

1	Slot 1 Bifurcation <ul style="list-style-type: none"> <li>• x16 Bifurcation (default)</li> </ul>
2	Slot 2 Bifurcation <ul style="list-style-type: none"> <li>• x4 Bifurcation</li> <li>• x8 Bifurcation (default)</li> </ul>
3	Slot 3 Boot Driver <ul style="list-style-type: none"> <li>• x4 Bifurcation</li> <li>• x8 Bifurcation (default)</li> </ul>
4	Slot 4 Boot Driver <ul style="list-style-type: none"> <li>• x16 Bifurcation (default)</li> </ul>
5	Slot 5 Boot Driver <ul style="list-style-type: none"> <li>• x4 Bifurcation</li> <li>• x8 Bifurcation (default)</li> </ul>
6	Slot 6 Boot Driver <ul style="list-style-type: none"> <li>• x4 Bifurcation</li> <li>• x8 Bifurcation (default)</li> </ul>

# Serial Communication screen details

You can use the **Serial Communication** screen to view the properties of the serial communication port. You can view the **Serial Communication** screen by clicking **System Setup Main Menu > System BIOS > Serial Communication**. The **Serial Communication** screen details are explained below.

Menu Item	Description
<b>Serial Communication</b>	Selects serial communication devices (Serial Device 1 and Serial Device 2) in the BIOS. BIOS console redirection can also be enabled and the port address can be specified. By default, <b>Serial Communication</b> option is set to <b>Auto</b> .
<b>Serial Port Address</b>	Enables you to set the port address for serial devices. By default, the <b>Serial Port Address</b> option is set to <b>Serial Device 1=COM2, Serial Device 2=COM1</b> .  <b>NOTE:</b> Only Serial Device 2 can be used for Serial Over LAN (SOL). To use console redirection by SOL, configure the same port address for console redirection and the serial device.
<b>External Serial Connector</b>	Enables you to associate the external serial connector to serial device 1, serial device 2, or remote access device. By default, the <b>External Serial Connector</b> option is set to <b>Serial Device1</b> .  <b>NOTE:</b> Only Serial Device 2 can be used for SOL. To use console redirection by SOL, configure the same port address for console redirection and the serial device.
<b>Failsafe Baud Rate</b>	Displays the failsafe baud rate for console redirection. The BIOS attempts to determine the baud rate automatically. This failsafe baud rate is used only if the attempt fails and the value must not be changed. By default, the <b>Failsafe Baud Rate</b> option is set to <b>115200</b> .
<b>Remote Terminal Type</b>	Sets the remote console terminal type. By default, the <b>Remote Terminal Type</b> option is set to <b>VT 100/VT 220</b> .
<b>Redirection After Boot</b>	Enables or disables the BIOS console redirection when the operating system is loaded. By default, the <b>Redirection After Boot</b> option is set to <b>Enabled</b> .

# System profile settings screen details

You can use the **System Profile Settings** screen to enable specific system performance settings such as power management. You can view the **System Profile Settings** screen by clicking **System Setup Main Menu > System BIOS > System Profile Settings**. The **System Profile Settings** screen details are explained as follows:

Menu Item	Description
<b>System Profile</b>	Sets the system profile. If you set the <b>System Profile</b> option to a mode other than <b>Custom</b> , the BIOS automatically sets the rest of the options. You can only change the rest of the options if the mode is set to <b>Custom</b> . By default, the <b>System Profile</b>  <b>NOTE:</b> The following parameters are available only when the System Profile is set to Workstation Performance.
<b>CPU Power Management</b>	Sets the CPU power management. By default, the <b>Maximum Performance</b>
<b>Memory Frequency</b>	Sets the memory frequency. By default, the <b>Maximum Performance</b>
<b>Turbo Boost</b>	Enables or disables the processor to operate in turbo boost mode. By default, the <b>Turbo Boost</b> option is set to <b>Enabled</b> .
<b>Energy Efficient Turbo</b>	Enables or disables the <b>Energy Efficient Turbo</b> . Energy Efficient Turbo (EET) is a mode of operation where a processor's core frequency is adjusted within the turbo range based on workload.



Menu Item	Description
<b>C1E</b>	Enables or disables the processor to switch to a minimum performance state when it is idle. By default, the <b>C1E</b> option is set to <b>Disabled</b> .
<b>C States</b>	Enables or disables the processor to operate in all available power states. By default, the <b>C States</b> option is set to <b>Enabled</b> .
<b>Write Data CRC</b>	Enables or disables Write Data CRC. By default option is set to <b>Disabled</b> .
<b>Collaborative CPU Performance Control</b>	Enables or disables the CPU power management. When set to <b>Enabled</b> , the CPU power management is controlled by the OS DBPM and the System DBPM (DAPC). By default, the option is set to <b>Disabled</b> .
<b>Memory Patrol Scrub</b>	Sets the memory patrol scrub frequency. By default, the <b>Memory Patrol Scrub</b> option is set to <b>Standard</b> .
<b>Memory Refresh Rate</b>	Sets the memory refresh rate to either 1x or 2x. By default, the <b>Memory Refresh Rate</b> option is set to <b>1x</b> .
<b>Uncore Frequency</b>	Selects the <b>Processor Uncore Frequency</b> . Dynamic mode allows the processor to optimize power resources across the cores and uncore during runtime. The optimization of the uncore frequency to either save power or optimize performance is influenced by the setting of the <b>Energy Efficiency Policy</b> .
<b>Energy Efficient Policy</b>	Selects the <b>Energy Efficient Policy</b> . The CPU uses the setting to manipulate the internal behavior of the processor and determines whether to target higher performance or better power savings.
<b>Number of Turbo Boot Enabled Cores for Processor 1</b>	 <b>NOTE: If there are two processors installed in the system, you see an entry for Number of Turbo Boost Enabled Cores for Processor 2.</b> Controls the number of turbo boost enabled cores for processor 1. By default, the maximum number of cores is all.
<b>Monitor/Mwait</b>	Enables the Monitor/Mwait instructions in the processor. By default, the Monitor/Mwait option is set to <b>Enabled</b> for all system profiles, except <b>Custom</b> .  <b>NOTE: This option can be disabled only if the C States option in Custom mode is disabled.</b>  <b>NOTE: When C States is enabled in Custom mode, changing the Monitor/Mwait setting does not impact system power/performance.</b>
<b>CPU Interconnect Bus Link Power Management</b>	Enables or disables CPU Interconnect Bus Link Power Management. By default, the option is set to <b>Disabled</b> .
<b>PCI ASPM L1 Link Power Management</b>	Enables or disables PCI ASPM L1 Link Power Management. By default, the option is set to <b>Disabled</b> .

## System security settings screen details

You can use the **System Security** screen to perform specific functions such as setting the system password, setup password, and disabling the power button.

You can view the **System Security** screen by clicking **System Setup Main Menu > System BIOS > System Security Settings**.

The **System Security Settings** screen details are explained as follows:

Menu Item	Description
<b>Intel AES-NI</b>	Improves the speed of applications by performing encryption and decryption using the Advanced Encryption Standard Instruction Set and is set to <b>Enabled</b> by default.

Menu Item	Description
System Password	Sets the system password. This option is set to <b>Enabled</b> by default and is read-only if the password jumper is not installed in the system.
Setup Password	Sets the setup password. This option is read-only if the password jumper is not installed in the system.
Password Status	Locks the system password. By default, the <b>Password Status</b> option is set to <b>Unlocked</b> .
TPM Information	Changes the operational state of the TPM. By default option is set to <b>No TPM Present</b> .
Intel TXT	Enables or disables the Intel Trusted Execution Technology (TXT). To enable <b>Intel TXT</b> , Virtualization Technology must be enabled and TPM Security must be <b>Enabled</b> with Pre-boot measurements. By default, the <b>Intel TXT</b> option is set to <b>Off</b> .
Power Button	Enables or disables the power button on the front of the system. By default, the <b>Power Button</b> option is set to <b>Enabled</b> .
AC Power Recovery	Sets how the system reacts after AC power is restored to the system. By default, the <b>AC Power Recovery</b> option is set to <b>Last</b> .
AC Power Recovery Delay	Sets how the system supports staggering of power up after AC power is restored to the system. By default, the <b>AC Power Recovery Delay</b> option is set to <b>Immediate</b> .
User Defined Delay (60s to 240s)	Sets the <b>User Defined Delay</b> when the <b>User Defined</b> option for <b>0</b> is selected.
UEFI Variable Access	Provides varying degrees of securing UEFI variables. When set to <b>Standard</b> (the default) UEFI variables are accessible in the Operating System per the UEFI specification. When set to <b>Controlled</b> , selected UEFI variables are protected in the environment and new UEFI boot entries are forced to be at the end of the current boot order.
Secure ME PCI Cfg Space	Enabled this setting will hide the PCU configuration space for the management engine (ME) HECI device and is set to <b>Disabled</b> by default.
Secure Boot	Enables Secure Boot, where the BIOS authenticates each pre-boot image using the certificates in the Secure Boot Policy. Secure Boot is disabled by default.
Secure Boot Policy	When Secure Boot policy is <b>Standard</b> , the BIOS uses the system manufacturer's key and certificates to authenticate pre-boot images. When Secure Boot policy is <b>Custom</b> , the BIOS uses the user-defined key and certificates. Secure Boot policy is <b>Standard</b> by default.
Secure Boot Mode	This field enabled how to use Secure boot policy object (PK, KEK, db, dbx).
Secure Boot Policy Summary	Views the list of certificates and hashes that secure boot uses to authenticated images.

## Secure Boot Custom Policy Settings

Secure Boot Custom Policy Settings is displayed only when **Secure Boot Policy** is set to **Custom**.

In the **System Setup Main Menu**, click **System BIOS > System Security > Secure Boot Custom Policy Settings**.

The **Secure Boot Custom Policy Settings** screen details are explained as follows:

Menu Item	Description
Platform Key	Imports, exports, deletes, or restores the platform key (PK).
Key Exchange Key Database	Allows you to import, export, delete, or restore entries in the Key Exchange Key (KEK) Database
Authorized Signature Database	Imports, exports, deletes, or restores entries in the Authorized Signature Database (db).
Forbidden Signature Database	Imports, exports, deletes, or restores entries in the Forbidden Signature Database (dbx).



# Miscellaneous settings screen details

You can use the **Miscellaneous Settings** screen to perform specific functions such as updating the asset tag, and changing the system date and time.

You can view the **Miscellaneous Settings** screen by clicking **System Setup Main Menu > System BIOS > Miscellaneous Settings**.

The **Miscellaneous Settings** screen details are explained as follows:

Menu Item	Description
<b>System Time</b>	Enables you to set the time on the system.
<b>System Date</b>	Enables you to set the date on the system.
<b>Asset Tag</b>	Displays the asset tag and enables you to modify it for security and tracking purposes.
<b>Keyboard NumLock</b>	Enables you to set whether the system boots with the NumLock enabled or disabled. By default the <b>Keyboard NumLock</b> is set to <b>On</b> .     <b>NOTE: This option does not apply to 84-key keyboards.</b>
<b>F1/F2 Prompt on Error</b>	Enables or disables the F1/F2 prompt on error. By default, <b>F1/F2 Prompt on Error</b> is set to <b>Enabled</b> . The F1/F2 prompt also includes keyboard errors.
<b>Load Legacy Video Option ROM</b>	Enables you to determine whether the system BIOS loads the legacy video (INT 10H) option ROM from the video controller. Selecting <b>Enabled</b> in the operating system does not support UEFI video output standards. This field is only for UEFI boot mode. You cannot set this to <b>Enabled</b> if <b>UEFI Secure Boot</b> mode is enabled.
<b>Dell Wyse P25BIOS Access</b>	This option is enabled by default.
<b>Power Cycle Request</b>	Specifies how the system reacts when system transitions to S5 state and is set to <b>None</b> .

# Technical specifications


The technical and environmental specifications of your system are outlined in this section.

## System dimensions

Table 26. Dimensions

System	Xa	Xb	Y	Za (with bezel)	Za (without bezel)	Zb	Zc
Precision 7920 Rack	482.0 mm (18.98 inches)	434.0 mm (17.09 inches)	86.8 mm (3.42 inches)	35.84 mm (1.41 inches)	22.0 mm (0.87 inches)	678.8 mm (26.72 inches)	715.5 mm (28.17 inches)





## Chassis weight

Table 27. Chassis weight

System	Maximum weight (with all hard drives/SSDs)
3.5 inch hard drive systems	28.6 kg (63.05 lb)

## Processor specifications

The Precision 7920 Rack system supports up to two Intel Xeon scalable family processors.

## PSU specifications

The Precision 7920 Rack system supports up to two AC power supply units (PSUs).



**Table 28. PSU specifications**

PSU	Class	Heat dissipation (maximum)	Frequency	Voltage	Current
1100 W AC	Platinum	4100 BTU/hr	50/60 Hz	100–240 V AC, autoranging	12 A–6.5 A
1600 W AC	Platinum	6000 BTU/hr	50/60 Hz	100–240 V AC, autoranging	10 A

**NOTE:** Heat dissipation is calculated using the PSU wattage rating.

**NOTE:** This system is also designed to connect to the IT power systems with a phase to phase voltage not exceeding 230 V.

**NOTE:** If a system with 1600 W AC PSU operates at low line 100–120 V AC, then the power rating per PSU is derated to 800 W.

## System battery specifications

The Precision 7920 Rack system supports CR 2032 3.0-V lithium coin cell system battery.

## Expansion bus specifications

The Precision 7920 Rack system supports up to eight PCI express (PCIe) generation 3 expansion cards, that can be installed on the system board using expansion card risers. The following table provides detailed information about the expansion card riser specifications:

**Table 29. Expansion card riser configurations**

Expansion card riser	PCIe slots on the riser	Height	Length	Link	CPU
Riser 1C	Slot 1	Full Height	Full Length	x16	CPU1
	Slot 2	Full Height	Full Length	x8	CPU1
	Slot 3	Full Height	Half Length	x8	CPU1
Riser 2A	Slot 4	Full Height	Full Length	x16	CPU2
	Slot 5	Full Height	Full Length	x8	CPU2
	Slot 6	Low Profile	Half Length	x8	CPU1
Riser 3A	Slot 7	Full Height	Full Length	x8	CPU2
	Slot 8	Full Height	Full Length	x16	CPU2

## Memory specifications

**Table 30. Memory specifications**

Memory module sockets	Architecture	Memory capacity	Minimum RAM	Maximum RAM
Twenty four 288-pins	2666 MT/s, DDR4 RDIMMs, LRDIMMs, with support for advanced ECC or	64 GB quad rank (LRDIMMs)	64 GB with single processor	LRDIMM: up to 768 GB with single processor and 1536 with dual processors



Memory module sockets	Architecture	Memory capacity	Minimum RAM	Maximum RAM
	memory optimized operation	8 GB single rank (RDIMMs)	8 GB with single processor and 16 GB with dual processors (minimum one memory module per processor)	RDIMM: up to 192 GB with dual processors and 96 GB with single processor
		16 GB single rank (RDIMMs)	16 GB with single processor	RDIMM: up to 192 GB with single processor RDIMM: up to 384 GB with dual processors
		32 GB dual rank (RDIMMs)	32 GB with single processor	RDIMM: up to 384 GB with single processors RDIMM: up to 768 GB with dual processors

## Ports and connectors specifications

### USB ports

The Precision 7920 Rack system supports:

- Two USB 2.0-compliant ports on the front panel
- One internal USB 3.0-compliant port
- One USB 3.0-compliant port on the front panel
- One micro USB 2.0-compliant port in the front panel for iDRAC Direct
- Two USB 3.0-complaint ports on the back panel

### NIC ports

The Precision 7920 Rack system supports up to four Network Interface Controller (NIC) ports on the back panel, which are available in the following configurations:

- Four RJ-45 ports that support different combinations of 1Gbps and 10Gbps
- One RJ-45 ports that support iDRAC9 Enterprise Network connector

**NOTE:** vFlash card have dedicated slots on the system board.

### VGA ports

The Video Graphic Array (VGA) port enables you to connect the system to a VGA display. The Precision 7920 Rack system supports two 15-pin VGA ports on the front and back panels.

### Serial connector

The Precision 7920 Rack system supports one serial connector on the back panel, which is a 9-pin connector, Data Terminal Equipment (DTE), 16550-compliant.



## Internal Dual SD module vFlash card

The Precision 7920 Rack system supports vFlash card.

## Video specifications

The Precision 7920 Rack system supports integrated Matrox G200eW3 graphics controller with 16 MB of video frame buffer.

**Table 31. Supported video resolution options**

Resolution	Refresh rate (Hz)	Color depth (bits)
1024 x 768	60	8, 16, 32
1280 x 800	60	8, 16, 32
1280 x 1024	60	8, 16, 32
1360 x 768	60	8, 16, 32
1440 x 900	60	8, 16, 32
1600 x 900	60	8, 16, 32
1600 x 1200	60	8, 16, 32
1680 x 1050	60	8, 16, 32
1920 x 1080	60	8, 16, 32
1920 x 1200	60	8, 16, 32

**NOTE:** 1920 x 1080 and 1920 x 1200 resolutions are only supported in reduced blanking mode.

## Environmental specifications

**NOTE:** For additional information about environmental measurements for specific system configurations, see [Dell.com/environmental\\_datasheets](http://Dell.com/environmental_datasheets).

**Table 32. Temperature specifications**

Temperature	Specifications
Storage	-40°C to 65°C (-40°F to 149°F)
Continuous operation (for altitude less than 950 m or 3117 ft)	10°C to 35°C (50°F to 95°F) with no direct sunlight on the equipment.
Maximum temperature gradient (operating and storage)	20°C/h (68°F/h)

**Table 33. Relative humidity specifications**

Relative humidity	Specifications
Storage	5% to 95% RH with 33°C (91°F) maximum dew point. Atmosphere must be non-condensing at all times.
Operating	10% to 80% relative humidity with 29°C (84.2°F) maximum dew point.

**Table 34. Maximum vibration specifications**

Maximum vibration	Specifications
Operating	0.26 G <sub>rms</sub> at 5 Hz to 350 Hz (all three axes).
Storage	1.88 G <sub>rms</sub> at 10 Hz to 500 Hz for 15 min (all six sides tested).

**Table 35. Maximum shock specifications**

Maximum shock	Specifications
Operating	Six consecutively executed shock pulses in the positive and negative x, y, and z axes of 6 G for up to 11 ms.
Storage	Six consecutively executed shock pulses in the positive and negative x, y, and z axes (one pulse on each side of the system) of 71 G for up to 2 ms.

**Table 36. Maximum altitude specifications**

Maximum altitude	Specifications
Operating	3048 m (10,000 ft)
Storage	12,000 m (39,370 ft)

**Table 37. Operating temperature de-rating specifications**

Operating temperature de-rating	Specifications
Up to 35°C (95°F)	Maximum temperature is reduced by 1°C/300 m (1°F/547 ft) above 950 m (3,117 ft).
35°C to 40°C (95°F to 104°F)	Maximum temperature is reduced by 1°C/175 m (1°F/319 ft) above 950 m (3,117 ft).
40°C to 45°C (104°F to 113°F)	Maximum temperature is reduced by 1°C/125 m (1°F/228 ft) above 950 m (3,117 ft).

## Particulate and gaseous contamination specifications

The following table defines the limitations that help avoid any equipment damage or failure from particulate and gaseous contamination. If the levels of particulate or gaseous pollution exceed the specified limitations and result in equipment damage or failure, you may need to rectify the environmental conditions. Remediation of environmental conditions is the responsibility of the customer.



**Table 38. Particulate contamination specifications**

Particulate contamination	Specifications
Air filtration	<p>Data center air filtration as defined by ISO Class 8 per ISO 14644-1 with a 95% upper confidence limit.</p> <p><b>NOTE:</b> The ISO Class 8 condition applies to data center environments only. This air filtration requirement does not apply to IT equipment designed to be used outside a data center, in environments such as an office or factory floor.</p> <p><b>NOTE:</b> Air entering the data center must have MERV11 or MERV13 filtration.</p>
Conductive dust	<p>Air must be free of conductive dust, zinc whiskers, or other conductive particles.</p> <p><b>NOTE:</b> This condition applies to data center and non-data center environments.</p>
Corrosive dust	<ul style="list-style-type: none"> <li>· Air must be free of corrosive dust.</li> <li>· Residual dust present in the air must have a deliquescent point less than 60% relative humidity.</li> </ul> <p><b>NOTE:</b> This condition applies to data center and non-data center environments.</p>

**Table 39. Gaseous contamination specifications**

Gaseous contamination	Specifications
Copper coupon corrosion rate	<300 Å/month per Class G1 as defined by ANSI/ISA71.04-2013.
Silver coupon corrosion rate	<200 Å/month as defined by ANSI/ISA71.04-2013.

**NOTE:** Maximum corrosive contaminant levels measured at ≤50% relative humidity.



# Troubleshooting your system

## Safety first — for you and your system

- ① **NOTE:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that are shipped with your product.
- ① **NOTE:** Dell has optimized your appliance and recommends that you do not change any of these settings.
- ① **NOTE:** Solution validation was performed by using the factory shipped hardware configuration.

## Using system diagnostics

If you experience a problem with your system, run the system diagnostics before contacting Dell for technical assistance. The purpose of running system diagnostics is to test your system hardware without using additional equipment or risking data loss. If you are unable to fix the problem yourself, service and support personnel can use the diagnostics results to help you solve the problem.

## Dell Embedded System Diagnostics

- ① **NOTE:** The Dell Embedded System Diagnostics is also known as Enhanced Pre-boot System Assessment (ePSA) diagnostics.

The Embedded System Diagnostics provides a set of options for particular device groups or devices allowing you to:

- Run tests automatically or in an interactive mode
- Repeat tests
- Display or save test results
- Run thorough tests to introduce additional test options to provide extra information about the failed device(s)
- View status messages that inform you if tests are completed successfully
- View error messages that inform you of problems encountered during testing

## Running the Embedded System Diagnostics from Boot Manager

Run the Embedded System Diagnostics (ePSA) if your system does not boot.

- 1 When the system is booting, press F11.
- 2 Use the up arrow and down arrow keys to select **System Utilities > Launch Diagnostics**.
- 3 Alternatively, when the system is booting, press F10, select **Hardware Diagnostics > Run Hardware Diagnostics**.  
The **ePSA Pre-boot System Assessment** window is displayed, listing all devices detected in the system. The diagnostics starts executing the tests on all the detected devices.



# Running the Embedded System Diagnostics from the Dell Lifecycle Controller

- 1 As the system boots, press F10.
- 2 Select **Hardware Diagnostics** → **Run Hardware Diagnostics**.

The **ePSA Pre-boot System Assessment** window is displayed, listing all devices detected in the system. The diagnostics starts executing the tests on all the detected devices.

## System diagnostic controls

Menu	Description
<b>Configuration</b>	Displays the configuration and status information of all detected devices.
<b>Results</b>	Displays the results of all tests that are run.
<b>System health</b>	Provides the current overview of the system performance.
<b>Event log</b>	Displays a time-stamped log of the results of all tests run on the system. This is displayed if at least one event description is recorded.

