Always there to help you Register your product and get support at www.philips.com/welcome

DS8550





EN	User manual	Fl	Käyttöopas
DA	Brugervejledning	FR	Mode d'emploi
DE	Benutzerhandbuch	IT	Manuale utente
EL	Εγχειρίδιο χρήσης	NL	Gebruiksaanwijzing



Contents

1	Important	4
	Safety	4
	Notice	7
2	Your Docking Speaker	9
	Introduction	9
	What's in the box	9
	Overview of the main unit	10
	Overview of the remote control	11
3	Get started	13
	Prepare the remote control	13
	Connect power	14
	Turn on	16
4	Play	17
	Play from iPod/iPhone/iPad	17
	Play from Bluetooth device	18
	Play from an external device	19
	Adjust volume level	19
	Mute sound	20
5	Product information	20
	Specifications	20
6	Troubleshooting	21
	About Bluetooth device	21

1 Important

Safety

Important Safety Instructions

- 1 Read these instructions.
- Keep these instructions.
- Heed all warnings.
- (4) Follow all instructions.
- 5 Do not use this apparatus near water.
- (6) Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- (8) Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 10 Only use attachments/accessories specified by the manufacturer.
- (1) Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.



Unplug this apparatus during lightning storms or when unused for long periods of time.

- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 14 Battery usage CAUTION To prevent battery leakage which may result in bodily injury, property damage, or damage to the unit, the batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.
- (15) Apparatus shall not be exposed to dripping or splashing.
- (6) Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- Where the MAINS plug or an appliance coupler is used as the disconnect device, the disconnect device shall remain readily operable.
- (18) Use only power supplies listed in the user manual.

Safety-Important notes for users in the U.K. only

For users in the U.K.: please follow the instructions below

Mains plug

This apparatus is fitted with an approved 13 Amp plug. To change a fuse in this type of plug proceed as follows:

- (1) Remove fuse cover and fuse.
- (2) Fix new fuse which should be a BS1362 3 Amp, A.S.T.A. or BSI approved type.
- (3) Refit the fuse cover.

If the fitted plug is not suitable for your socket outlets, it should be cut off and an appropriate plug fitted in its place.

If the mains plug contains a fuse, this should have a value of 3 Amp. If a plug without a fuse is used, the fuse at the distribution board should not be greater than 3 Amp.

Note: The severed plug must be disposed off to avoid a possible shock hazard should it be inserted into a 13 Amp socket elsewhere.

How to connect a plug

The wires in the mains lead are coloured with the following code: blue = neutral (N), brown = live (L).

As these colours may not correspond with the colour markings identifying the terminals in your plug, proceed as follows:

- Connect the blue wire to the terminal marked N or colored black.
- Connect the brown wire to the terminal marked L or colored red.
- Do not connect either wire to the earth terminal in the plug, marked E (or ½) or colored green (or green and yellow).

Before replacing the plug cover, make certain that the cord grip is clamped over the sheath of the lead - not simply over the two wires.

Copyright in the U.K.

Recording and playback of material may require consent. see Copyright Act 1956 and The performer's Protection Acts 1958 to 1972.

Important warning for users in Australia and New Zealand

Instructions for changing fuses are included with this apparatus for users in the U.K only. Users in Australia and New Zealand should always engage a qualified electrician to perform any modifications to this apparatus. User-made modifications may result in property damage, personal injury or death.

Hearing safety

Listen at a moderate volume.

- Using headphones at a high volume can impair your hearing. This
 product can produce sounds in decibel ranges that may cause hearing
 loss for a normal person, even for exposure less than a minute. The
 higher decibel ranges are offered for those that may have already
 experienced some hearing loss.
- Sound can be deceiving. Over time your hearing 'comfort level'
 adapts to higher volumes of sound. So after prolonged listening, what
 sounds 'normal' can actually be loud and harmful to your hearing. To
 guard against this, set your volume to a safe level before your hearing
 adapts and leave it there.

To establish a safe volume level:

• Set your volume control at a low setting.

 Slowly increase the sound until you can hear it comfortably and clearly, without distortion.

Listen for reasonable periods of time:

- Prolonged exposure to sound, even at normally 'safe' levels, can also cause hearing loss.
- Be sure to use your equipment reasonably and take appropriate breaks.

Be sure to observe the following guidelines when using your headphones.

- Listen at reasonable volumes for reasonable periods of time.
- Be careful not to adjust the volume as your hearing adapts.
- Do not turn up the volume so high that you can't hear what's around you.
- You should use caution or temporarily discontinue use in potentially hazardous situations. Do not use headphones while operating a motorized vehicle, cycling, skateboarding, etc.; it may create a traffic hazard and is illegal in many areas.



Warning

- · Never remove the casing of this apparatus.
- · Never lubricate any part of this apparatus.
- Never place this apparatus on other electrical equipment.
- · Keep this apparatus away from direct sunlight, naked flames or heat.
- Ensure that you always have easy access to the power cord, plug or adaptor to disconnect the apparatus from the power.

Notice

Any changes or modifications made to this device that are not expressly approved by Philips Consumer Lifestyle may void the user's authority to operate the equipment.

C € 2150

This product complies with the radio interference requirements of the European Community.

Recycling



Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.

When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC:



Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste.



Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health. Always bring your product to a professional to remove the built-in battery.

Environmental information

All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet.) Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.



Note

The type plate is located on the bottom of the apparatus.

2 Your Docking Speaker

Congratulations on your purchase, and welcome to Philips! To fully benefit from the support that Philips offers, register your product at www.philips.com/welcome.

Introduction


With this unit, you can enjoy audio from the iPod/iPhone/iPad and other audio devices.

What's in the box

Check and identify the contents of your package:

- Main unit
- Remote control
- 1 x AC adaptor
- 1 x AC power cord
- 1 x UK power cord
- 1 x Aux-in cable
- 1 x iPad stand
- User manual
- · Quick Start Guide


Overview of the main unit



- 1) ()
 - Turn on/off the unit.
- 2 *
 - Select Bluetooth mode
 - Pair with Bluetooth device.

- (3) iPod/iPhone/iPad dock
- (4) +/-
 - Adjust volume.
- 5 Built-in battery LED indicator
- 6 Power supply socket
- 7 AUX IN
 - Jack for an external audio device.

Overview of the remote control



- (1) IX
 - Mute volume.
- **3** >
 - Select Bluetooth mode
 - Pair with Bluetooth device.
- 3) 6
 - Select Aux-in mode
- (4) Up/down keys
 - Navigate through the iPod/iPhone menu.

- (5) Fast forward/backward keys
 - Fast reverse or fast forward within a track or iPhone/iPod.
 - Skip to the previous/next track.
- (6) ►II
 - Start or pause play.
- (7) VOL +/-
 - Adjust volume.
- (8) MENU
 - Access the iPod menu.
- 9 OK
 - Confirm a selection.
- 10 🗆
 - Select iPod/iPhone dock mode

3 Get started

Always follow the instructions in this chapter in sequence.

If you contact Philips, you will be asked for the model and serial number of this apparatus. The model number and serial number are on the bottom of the apparatus. Write the numbers here:

Model No.	
Serial No.	

Prepare the remote control



Caution


 Risk of explosion! Keep batteries away from heat, sunshine or fire. Never discard batteries in fire.

For first-time use:

1 Remove the protective tab to activate the remote control battery.

To replace the remote control battery:

- 1 Open the battery compartment.
- 2 Insert one CR2032 battery with correct polarity (+/-) as indicated.
- 3 Close the battery compartment.






- · Before pressing any function button on the remote control, first select the correct source with the remote control instead of the main unit.
- If you are not going to use the remote control for a long time, remove the battery.

Connect power




Caution

- Risk of product damage! Ensure that the power supply voltage corresponds to the voltage printed on the bottom of the unit.
- Risk of electric shock! When you unplug the AC adaptor, always pull the plug from the socket. Never pull the cord.
- Before connecting the AC adaptor, ensure you have completed all other connections.
- Insert the plug from the AC adaptor to the DC IN socket on the back of the main unit.



Connect one end of the AC power cord to the AC adaptor.



3 Connect the other end of the AC power cord to the wall outlet.



Built-in Battery



Note

• Always bring your product to a professional to remove the built-in battery.



Caution

 Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

The unit can also operate on built-in rechargeable battery.

Battery power	LED indicator	
Low	Red	
Medium	Yellow	
Full	Green	



Note

Use only the supplied AC adapter to charge the battery.

To recharge the built-in battery:

Connect the unit to the mains power supply.

Turn on

Press () on the main unit

Switch to ECO standby

The unit switches to standby mode automatically, when:

- (at DOCK mode) the iPod/iPhone is disconnected from the unit.
- (at AUX mode) the device no longer playing music for more than 5 minutes
- (at Bluetooth mode) the Bluetooth device is disconnected from the unit for more than 5 minutes.



 In standby mode, press □ * or on the remote control, the unit switches on at the corresponding source.

About ECO power

You can switch the unit to ECO power standby mode to save power consumption.

- Press \circ for over 3 seconds.
 - → The unit turns into ECO power mode immediately.
 - → If the unit is powered via built-in battery, when it is in standby mode for 5 minutes, it switches to ECO power mode automatically.



· In ECO power mode, the remote control does not work.

To exit ECO power mode, press &.

FN

4 Play

Play from iPod/iPhone/iPad

You can enjoy audio from iPod/iPhone/iPad through this unit.

Compatible iPod/iPhone/iPad

Apple iPod, iPhone and iPad models with a 30-pin dock connector. Made for :

- iPod (5th generation)
- iPod nano (1st generation)
- · iPod nano (2nd generation)
- iPod nano (3rd generation)
- iPod nano (4th generation)
- iPod nano (5th generation)
- iPod classic
- iPod touch (1st generation)
- iPod touch (2nd generation)
 - iPod touch (3rd generation)
- iPhone
- iPhone 3G
- iPhone 3GS
- iPad.

Load the iPod/iPhone/iPad

1 Place the iPod/iPhone/iPad in the dock.



Remove the iPod/iPhone/iPad

1 Pull the iPod/iPhone/iPad out of the dock.

Listen to the iPod/iPhone/iPad

- 1 Ensure that the iPod/iPhone/iPad is loaded correctly.
- 2 Press

 to select dock mode.
- 3 Press ►II.
 - → The connected iPod/iPhone/iPad starts play.
 - To pause/resume play, press ►II.
 - To skip to a track, press fast forward/backward keys.
 - To search during play, press and hold fast forward/backward keys, then release to resume normal play.
 - To navigate the menu, press MENU, then press up/down keysto select, and press OK to confirm.

Charge the iPod/iPhone/iPad

When the unit is connected to AC power, the docked iPod/iPhone/iPad begins to charge.



Tip

- You can also charge your iPod/iPhone via the built-in battery. Before charging your iPod/iPhone via the built-in battery, ensure the Fidelio battery-charging function is turn on.
- You cannot charge your iPad via the built-in battery. To charge your iPad, connect the unit to AC power.

Play from Bluetooth device

Pair with Bluetooth deivces

- 1 Press \$ to select Bluetooth source.
 - → The unit starts searching for Bluetooth device. The Bluetooth indicator under \$ button on the main unit flashes rapidly.
- 2 Turn on Bluetooth function on your device.
- When "PHILIPS DS8550" displays, select it to start connection.
- 4 When prompted for a password, enter "0000".

- → If connection is successful, the unit beeps and the * indicator turns
 on stably.
- → If the pairing cannot be completed within one minute, the *
 indicator flashes slowly.



Tip

 If your Bluetooth device is already paired with DS8550 before, you just need to find out the "PHILIPS DS8550" on your Bluetooth menu, then confirm the connection.

To disconnect Bluetooth device.

- Move it beyond the communication range; or
- Press ♯; or
- Turn off the connected device

Play audio files from bluetooth devices



Note

- Make sure the Bluetooth connection between the unit and the device is active.
- To start play, press ► II on the remote control.
- To pause/resume play, press ► II again.
- To track up/down, press forward/backward keys.

Play from an external device

You can also listen to an external audio device through this unit.

- 1 Press **c** to select Aux-in mode.
- 2 Connect the supplied Aux-in link cable to:
 - the AUX IN jack (3.5mm) on the back of the unit.
 - the headphone jack on an external device.
- 3 Start to play the device (see the device user manual).

Adjust volume level

1 During play, press VOL +/- to increase/decrease the volume level.

Mute sound

During play, press MUTE to mute/unmute sound.

Product information



Note

· Product information is subject to change without prior notice.

Specifications

Am	ыl	ifi	۹	r
/\III	וע		c	

, amplifici	
Rated Output Power	2X15 W RMS
Signal to Noise Ratio	85 dB
Aux-in Link	0.6 V RMS 10 kohm

_		
General	intor	mation

acrici ai illioi illacion	
AC power (power adaptor)	For CE: OH-1065A1803500U2(EU) For USA: OH-1065A1803500U(UL) Input: 100-240V~, 50/60Hz, 1.5A; Output: 18V === 3.5A;
Operation Power	<40W
Consumption	
ECO Standby Power	<1W
Consumption	
Dimensions	
- Main Unit ($W \times H \times D$)	$169 \times 420 \times 108$ mm
Weight	
- Main Unit	2.22 kg

Bluetooth

Output power	0 dBm (Class 2)
Frequency band	2.4000 GHz - 2.4835 GHz ISM Band
Range	6 meters(free space)
Standard	Bluetooth 2.0 specification

6 Troubleshooting



Warning

Never remove the casing of this apparatus.

To keep the warranty valid, never try to repair the system yourself. If you encounter problems when using this apparatus, check the following points before requesting service. If the problem remains unsolved, go to the Philips web site (www.philips.com/support). When you contact Philips, ensure that the apparatus is nearby and the model number and serial number are available.

No power

- Ensure that the AC power plug of the unit is connected properly.
- Ensure that there is power at the AC outlet.

No sound

Adjust the volume.

No response from the unit

 Disconnect and reconnect the AC power plug, then turn on the unit again.

About Bluetooth device

Music playback is unavailable on the system even after successful Bluetooth connection

• The device cannot be used with the system to play music.

The audio quality is poor after connection with a Bluetooth-enabled device.

The Bluetooth reception is poor. Move the device closer to the system or remove any obstacle between the device and the system.

Cannot connect with the system.

- The device does not support the profiles required for the system.
- The Bluetooth function of the device is not enabled. Refer to the user manual of the device for how to enable the function.
- The system is not in the pairing mode.
- The system is already connected with another Bluetooth-enabled device. Disconnect that device or all other connected devices and then try again.

The paired device connects and disconnects constantly.

- The Bluetooth reception is poor. Move the device closer to the system or remove any obstacle between the device and the system.
- For some devices, the Bluetooth connection may be deactivated automatically as a power-saving feature. This does not indicate any malfunction of the system.

Philips Consumer Lifestyle B.V.



HK-1317-DS8550

(Document No. / Numéro du document)

Philips Consumer Lifestyle B.V.

2011/06

(Year, Month (yyyy/mm) in which the CE mark is affixed / Année/mois (aaaa/mm) au cours de laquelle le marquage CE a été apposé)

EUROPEAN DECLARATION OF CONFORMITY

(DECLARATION DE CONFORMITE CE)

We / Nous, PHILIPS CONSUMER LIFESTYLE B.V.

(Company name / Nom de l'entreprise)

TUSSENDIEPEN 4, 9206 AD DRACHTEN, THE NETHERLANDS

(address / adresse)						
declare under our responsibility (déclarons sous notre propre responsabilité q Philips		DS8550/1				
(brand name, nom de la marque)			or model, référence ou modèle)			
Docking Speaker						
(product description, description du produit)						
to which this declaration relates (auquel cette déclaration se rapporte, est con			ng harmonized standards:			
(title, number and date of issue of the st	tandard / titre, numéro	et date de parut	ion de la norme)			
EN 60065 2006+A1(2006)+A11(2008)+A2(2010)+A12(2011) EN 55013-2001+A1(2003)+A2(2006) EN 5502-2007-A11:2011 EN 61000-3-2:2006 + A1(2009)+A2(2009) EN 61000-3-3:2008 EN 62479-2010 EN 61000-3-3:2008 EN 62479-2011 EN 50564-2011						
following the provisions of : (conformément aux exigences essentielles et	following the provisions of : (conformément aux exigences essentielles et autres dispositions pertinentes de:)					
1995/5/EC (R&TTE Directive) 2006/95/EC (Low Voltage Directive) 2004/108/EC (Low Voltage Directive) 2004/108/EC (Roth Girective) 2011/65/EU (Rohs Directive) 2004/128/EC (Eco Design) - EC/1275/2008; EC/278/2009						
And are produced under a quality scheme at least in conformity with ISO 9001 or CENELEC Permanent Documents (Et sont fabriqués conformément à une qualité au moins conforme à la norme ISO 9001 ou aux Documents Permanents CENELEC)						
Only for Medical Devices and R&TTE p	roducts:					
The Notified Body: SGS/2150		performed:	Expert Opinion			
(L'Organisme Notifié) (Name and nu	mber/ nom et numéro)	(a effectué)	(description of intervention / description de 'intervention)			
and issued the certificate: ZG00						
	tificate number / numéro d	du certificat)				
Remarks:						
Drachten, Netherlands, April 24, 2013 A.Speelman, CL Compliance Manager						
(place.date / lieu. date)	N	(signature, i	name and function / signature, nom et fonction)			

23

template AMB 544-9056



@ 2013 Koninklijke Philips Electronics N.V. All rights reserved. $D\$8550_10_UM_V6.0$

