



ATEN Altusen™

KE Series & CCKM

KVM over IP Extender and
KE Matrix Manager Software
User Manual

Compliance Statements

FEDERAL COMMUNICATIONS COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

The device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Warning

Operation of this equipment in a residential environment could cause radio interference.

Achtung

Der Gebrauch dieses Geräts in Wohnumgebung kann Funkstörungen verursachen.



KCC Statement

유선 제품용 / A 급 기기 (업무용 방송 통신 기기)
 이 기기는 업무용 (A 급) 전자파적합기기로서 판매자 또는 사용자는 이
 점을 주의하시기 바라며, 가정 외의 지역에서 사용하는 것을 목적으로
 합니다.

Industry Canada Statement

This Class A digital apparatus complies with Canadian ICES-003.

CAN ICES-003 (A) / NMB-003 (A)

HDMI Trademark Statement

The terms HDMI, HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.



RoHS

This product is RoHS compliant.

User Information

Online Registration

Be sure to register your product at our online support center:

| | |
|---------------|---|
| International | http://eservice.aten.com |
|---------------|---|

Telephone Support

For telephone support, call this number:

| | |
|---------------|---|
| International | 886-2-8692-6959 |
| China | 86-400-810-0-810 |
| Japan | 81-3-5615-5811 |
| Korea | 82-2-467-6789 |
| North America | 1-888-999-ATEN ext 4988 1-949-428-1111 |

User Notice

All information, documentation, and specifications contained in this manual are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the manufacturer's software described in this manual is sold or licensed *as is*. Should the programs prove defective following their purchase, the buyer (and not the manufacturer, its distributor, or its dealer), assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any defect in the software.

The manufacturer of this system is not responsible for any radio and/or TV interference caused by unauthorized modifications to this device. It is the responsibility of the user to correct such interference.

The manufacturer is not responsible for any damage incurred in the operation of this system if the correct operational voltage setting was not selected prior to operation. **PLEASE VERIFY THAT THE VOLTAGE SETTING IS CORRECT BEFORE USE.**

Product Information

For information about all ATEN products and how they can help you connect without limits, visit ATEN on the Web or contact an ATEN Authorized Reseller. Visit ATEN on the Web for a list of locations and telephone numbers:

| | |
|---------------|---|
| International | http://www.aten.com |
| North America | http://www.aten-usa.com |

Package Contents

The contents contained in the standard package of each KE Series device is listed below. Check to make sure that all components are in working order. If you encounter any problem, please contact your dealer.

KE6900 / KE6940

KE6900T / KE6940T DVI Single / Dual Display KVM over IP Transmitter:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 DVI-D cable (KE6940T only)
- 1 foot pad set (4 pcs)
- 1 power adapter
- 1 mounting kit
- 1 user instructions

KE6900R / KE6940R DVI Single / Dual Display KVM over IP Receiver:

- 1 Receiver
- 1 power adapter
- 1 user instructions

KE6900A / KE6940A

KE6900AT / KE6940AT DVI-I Single / Dual Display KVM over IP Transmitter:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 DVI-D cable (KE6940AT only)
- 1 power adapter
- 1 foot pad et
- 1 mounting kit
- 1 user instructions

KE6900AR / KE6940AR DVI-I Single / Dual Display KVM over IP Receiver:

- 1 Receiver
- 1 power adapter
- 1 user instructions

KE6900AiT / KE6940AiT

KE6900AiT / KE6940AiT DVI Single / Dual Display KVM over IP Transmitter with Internet Port:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 DVI-D cable (KE6940AiT only)
- 1 foot pad set (4 pcs)
- 1 power adapter
- 1 mounting kit
- 1 user instructions

KE6900ST

KE6900ST DVI KVM over IP Transmitter Lite:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 foot pad set (4 pcs)
- 1 power adapter
- 1 mounting kit
- 1 user instructions

KE6910 / KE6912

KE6910T / KE6912T DVI-D Dual Link KVM over IP Transmitter:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 power adapter (KE6910T only)

- 1 foot pad set (4 pcs)
- 1 mounting kit
- 1 user instructions

KE6910R / KE6912R DVI-D Dual Link KVM over IP Receiver:

- 1 Receiver
- 1 power adapter (KE6910R only)
- 1 user instructions

KE6920 / KE6922

KE6920T DVI-D Dual Link KVM over IP Transmitter with Dual SFP /
KE6922T DVI-D Dual Link KVM over IP Transmitter with Dual SFP & PoE:

- 1 Transmitter
- 1 USB DVI-D KVM cable
- 1 power adapter (KE6910T only)
- 1 foot pad set (4 pcs)
- 1 mounting kit
- 1 user instructions

KE6920R DVI-D Dual Link KVM over IP Receiver with Dual SFP / KE6922R
DVI-D Dual Link KVM over IP Receiver with Dual SFP & PoE:

- 1 Receiver
- 1 power adapter (KE6910R only)
- 1 user instructions

KE8900S

KE8900ST Slim HDMI KVM over IP Transmitter:

- 1 Transmitter
- 1 USB HDMI KVM cable
- 1 foot pad set (4 pcs)
- 1 power adapter
- 1 mounting kit

- 1 HDMI Lockpro
- 1 user instructions

KE8900SR Slim HDMI KVM over IP Receiver:

- 1 Receiver
- 1 power adapter
- 1 mounting kit
- 1 HDMI Lockpro
- 1 user instructions

KE8950 / KE8952

KE8950T / KE8952T 4K HDMI Single Display KVM over IP Transmitter:

- 1 Transmitter
- 1 USB HDMI KVM cable
- 1 foot pad set (4 pcs)
- 1 power adapter (KE8950T only)
- 1 mounting kit
- 1 HDMI Lockpro
- 1 user instructions

KE8950R / KE8952R 4K HDMI Single Display KVM over IP Receiver:

- 1 Receiver
- 1 power adapter (KE8950R only)
- 1 HDMI Lockpro
- 1 user instructions

KE9900ST

KE9900ST Slim DisplayPort KVM over IP Transmitter:

- 1 Transmitter
- 1 DisplayPort cable
- 1 USB 2.0 Type-A to Type-B cable

- 1 power adapter
- 1 mounting kit
- 1 user instructions

KE9950 / KE9952

KE9950T / KE9952T 4K DisplayPort KVM over IP Transmitter:

- 1 Transmitter
- 1 DisplayPort cable
- 1 USB 2.0 Type-A to Type-B cable
- 1 foot pad set (4 pcs)
- 1 power adapter (KE9950T only)
- 1 mounting kit
- 1 user instructions

KE9950R / KE9952R 4K DisplayPort KVM over IP Receiver:

- 1 Receiver
- 1 power adapter (KE9950R only)
- 1 user instructions

Contents

| | |
|---------------------------------|------|
| Compliance Statements | ii |
| User Information | iii |
| Online Registration | iii |
| Telephone Support | iii |
| User Notice | iv |
| Product Information | iv |
| Package Contents | v |
| KE6900 / KE6940 | v |
| KE6900A / KE6940A | v |
| KE6900AiT / KE6940AiT | vi |
| KE6900ST | vi |
| KE6910 / KE6912 | vi |
| KE6920 / KE6922 | vii |
| KE8900S | vii |
| KE8950 / KE8952 | viii |
| KE9900ST | viii |
| KE9950 / KE9952 | ix |
| Contents | x |
| About This Manual | xix |
| Conventions | xxi |

Chapter 1. Introduction

| | |
|--|----|
| Overview | 1 |
| Features | 4 |
| Supported Video Resolutions | 7 |
| Requirements | 8 |
| Operating System | 8 |
| Console | 8 |
| Computers | 8 |
| Cables | 10 |
| CCKM Requirements | 10 |
| Components | 11 |
| KE6900T (Transmitter) Front View | 11 |
| KE6900T (Transmitter) Rear View | 12 |
| KE6900R (Receiver) Front View | 14 |
| KE6900R (Receiver) Rear View | 16 |
| KE6900AT (Transmitter) Front View | 18 |
| KE6900AT (Transmitter) Rear View | 19 |
| KE6900AR (Receiver) Front View | 21 |
| KE6900AR (Receiver) Rear View | 22 |
| KE6900AiT (Transmitter) Front View | 24 |
| KE6900AiT (Transmitter) Rear View | 25 |
| KE6910T / KE6912T (Transmitter) Front View | 27 |
| KE6910T / KE6912T (Transmitter) Rear View | 28 |

| | |
|--|----|
| KE6910R / KE6912R (Receiver) Front View | 30 |
| KE6910R / KE6912R (Receiver) Rear View | 31 |
| KE6920T / KE6922T (Transmitter) Front View | 33 |
| KE6920T / KE6922T (Transmitter) Rear View | 34 |
| KE6920R / KE6922R (Receiver) Front View | 36 |
| KE6920R / KE6922R (Receiver) Rear View | 37 |
| KE6940T (Transmitter) Front View | 39 |
| KE6940T (Transmitter) Rear View | 40 |
| KE6940R (Receiver) Front View | 42 |
| KE6940R (Receiver) Rear View | 44 |
| KE6940AT (Transmitter) Front View | 46 |
| KE6940AT (Transmitter) Rear View | 47 |
| KE6940AR (Receiver) Front View | 49 |
| KE6940AR (Receiver) Rear View | 50 |
| KE6940AiT (Transmitter) Front View | 52 |
| KE6940AiT (Transmitter) Rear View | 53 |
| KE6900ST (Transmitter) Front, Rear and Top View | 55 |
| KE8950T / KE8952T (Transmitter) Front View | 57 |
| KE8950T / KE8952T (Transmitter) Rear View | 58 |
| KE8950R / KE8952R (Receiver) Front View | 60 |
| KE8950R / KE8952R (Receiver) Rear View | 61 |
| KE8900ST (Transmitter) Front, Rear and Side View | 63 |
| KE8900SR (Receiver) Front, Rear and Side View | 65 |
| KE9900ST (Transmitter) Front, Rear and Side View | 67 |
| KE9950T / KE9952T (Transmitter) Front View | 69 |
| KE9950T / KE9952T (Transmitter) Rear View | 70 |
| KE9950R / KE9952R (Receiver) Front View | 72 |
| KE9950R / KE9952R (Receiver) Rear View | 73 |
| PoE Power Redundancy | 74 |

Chapter 2. Hardware Setup

| | |
|--|----|
| Mounting | 75 |
| Attaching the Mounting Bracket | 76 |
| Non-Slim Transmitters | 76 |
| Slim Transmitters — KE6900ST | 77 |
| Slim Transmitters — KE8900ST / KE9900ST | 77 |
| Rack Mount | 79 |
| Non-Slim Transmitters | 79 |
| Slim Transmitters — KE6900ST | 80 |
| Slim Transmitters — KE8900ST / KE9900ST | 80 |
| Wall Mount | 81 |
| Non-Slim Transmitters | 81 |
| Slim Transmitters — KE6900ST | 82 |
| Slim Transmitters — KE8900ST / KE9900ST | 82 |
| KE6900 / KE6940 Point-to-Point Installation | 83 |
| KE6900 / KE6940 Point-to-Point Installation 1 of 2 | 84 |

| | |
|---|-----|
| KE6900 / KE6940 Point-to-Point Installation 2 of 2 | 85 |
| KE6900A / KE6940A Point-to-Point Installation | 86 |
| KE6900A / KE6940A Point-to-Point Installation 1 of 2 | 87 |
| KE6900A / KE6940A Point-to-Point Installation 2 of 2 | 88 |
| KE6900AiT / KE6940AiT Point-to-Point Installation | 89 |
| KE6940AiT Point-to-Point Installation 1 of 2 | 90 |
| KE6940AiT Point-to-Point Installation 2 of 2 | 91 |
| KE6910 / KE6912 Point-to-Point Installation. | 92 |
| KE6910 / KE6912 Point-to-Point Installation 1 of 2. | 93 |
| KE6910 / KE6912 Point-to-Point Installation 2 of 2. | 94 |
| KE6920 / KE6922 Point-to-Point Installation. | 95 |
| KE6920 / KE6922 Point-to-Point Installation 1 of 2. | 96 |
| KE6920 / KE6922 Point-to-Point Installation 2 of 2. | 97 |
| KE8950 / KE8952 Point-to-Point Installation. | 98 |
| KE8950 / KE8952 Point-to-Point Installation 1 of 2. | 99 |
| KE8950 / KE8952 Point-to-Point Installation 2 of 2. | 100 |
| KE6900ST Point-to-Point Installation | 101 |
| Setting up a LAN Installation | 101 |
| KE8900S Point-to-Point Installation | 103 |
| Setting up a LAN Installation | 103 |
| KE9900ST Point-to-Point Installation | 105 |
| Setting up a LAN Installation | 105 |
| KE9950 / KE9952 Point-to-Point Installation. | 107 |
| KE9950 / KE9952 Point-to-Point Installation 1 of 2. | 108 |
| KE9950 / KE9952 Point-to-Point Installation 2 of 2. | 109 |
| KE6900 / KE6940 LAN Installation | 110 |
| KE6900 / KE6940 Network Installation Diagram 1 of 2. | 112 |
| KE6900 / KE6940 Network Installation Diagram 2 of 2. | 113 |
| KE6900A / KE6940A LAN Installation. | 114 |
| KE6900A / KE6940A Network Installation Diagram 1 of 2 | 115 |
| KE6900A / KE6940A Network Installation Diagram 2 of 2 | 116 |
| KE6900AiT / KE6940AiT LAN Installation. | 117 |
| KE6900AiT / KE6940AiT Network Installation Diagram 1 of 2 | 118 |
| KE6900AiT / KE6940AiT Network Installation Diagram 2 of 2 | 119 |
| KE6910 / KE6912 LAN Installation | 120 |
| KE6910 / KE6912 Network Installation Diagram 1 of 2. | 121 |
| KE6910 / KE6912 Network Installation Diagram 2 of 2. | 122 |
| KE6920 / KE6922 LAN Installation | 123 |
| KE6920 / KE6922 Network Installation Diagram 1 of 2. | 124 |
| KE6920 / KE6922 Network Installation Diagram 2 of 2. | 125 |
| KE8950 / KE8952 LAN Installation | 126 |
| KE8950 / KE8952 Network Installation Diagram 1 of 2. | 128 |
| KE8950 / KE8952 Network Installation Diagram 2 of 2. | 129 |
| KE9950 / KE9952 LAN Installation | 130 |
| KE9950 / KE9952 Network Installation Diagram 1 of 2. | 131 |
| KE9950 / KE9952 Network Installation Diagram 2 of 2. | 132 |

| | |
|---------------------------------|-----|
| Network Configuration | 133 |
| Exit OSD | 134 |
| Default IP Addresses | 134 |
| KE I/O Ports | 135 |
| LED Display | 136 |

Chapter 3.OSD Operation

| | |
|---|-----|
| Overview | 137 |
| Invoking the OSD | 137 |
| Touch Screen Calibration | 137 |
| OSD Hotkeys | 138 |
| Non-OSD Hotkeys. | 138 |
| Reverting to Previous | 138 |
| Hotkey Mode | 138 |
| Microphone Hotkey | 139 |
| OSD Interface | 139 |
| Logging in for the First Time | 140 |
| Receiver Configuration | 141 |
| Network | 141 |
| Properties | 142 |
| Regular Version. | 142 |
| Slim Version | 145 |
| System | 147 |
| Transmitter Configuration | 148 |
| Network | 148 |
| Properties | 149 |
| System | 152 |
| Internet Port (AiT Models only) | 153 |
| IP Installer | 154 |
| Service Ports | 154 |
| IPv4 Settings | 154 |
| IPv6 Settings | 155 |
| CCVSR | 156 |
| Working Mode | 156 |
| User Preferences | 157 |
| OSD Matrix Mode | 158 |
| Connections Page | 159 |
| List Mode | 159 |
| Array Mode | 162 |
| Profile Page | 164 |
| Push Content | 165 |
| Pull Content | 167 |

Chapter 4.Software Installation

| | |
|--|-----|
| Overview | 169 |
| Download | 169 |
| KE Matrix Manager Software Install | 171 |

| | |
|------------------------------|-----|
| Upgrading License | 174 |
| Linux Installation | 175 |

Chapter 5. Browser / Telnet Operation

| | |
|---|-----|
| Overview | 179 |
| Logging In | 179 |
| The KE Matrix Manager Main Page | 181 |
| Web Components | 181 |
| Installation Wizard | 183 |
| Adding Transmitters and Receivers | 184 |
| Adding Network Switches | 187 |
| Instant Link | 189 |
| RS-232 / Telnet | 191 |
| Telnet | 191 |
| RS-232 | 192 |
| Configuration Menu | 193 |
| Main Menu | 193 |
| 1. Network | 194 |
| 2. Properties | 194 |
| 3. System | 195 |

Chapter 6. System Status

| | |
|--|-----|
| Overview | 197 |
| System Status | 198 |
| Transmitter | 200 |
| SFP Module Detection | 201 |
| Transmitter Configuration | 202 |
| Internet Port (AiT models only) | 207 |
| Basic | 208 |
| CCVSR | 209 |
| Mode | 209 |
| IPv4 Settings | 209 |
| IPv6 Settings | 210 |
| Private Certificate | 210 |
| Certificate Signing Request | 211 |
| Copy & Paste | 213 |
| Virtual Transmitter | 214 |
| Intelligent Dual Video Output Management | 216 |
| Transmitter Group | 217 |
| Transmitter Permissions | 218 |
| Receiver | 220 |
| SFP Module Detection | 221 |
| Receiver Configuration | 222 |
| Copy & Paste | 225 |
| Receiver Group | 226 |
| Video Wall | 227 |
| Receiver Permissions | 230 |

| | |
|--|-----|
| Switch | 231 |
| Network Switch Configuration | 232 |
| Port Configuration | 233 |
| Account | 234 |
| Users | 235 |
| Adding Users | 235 |
| Modifying Users | 237 |
| Deleting Users | 237 |
| Groups | 238 |
| Adding Groups | 238 |
| Modifying Groups | 239 |
| Deleting Groups | 239 |
| Permissions | 240 |
| Assigning Device Permissions | 240 |
| Profile | 242 |
| Adding a Profile | 243 |
| Adding a Schedule | 246 |
| Log | 247 |

Chapter 7. System Settings

| | |
|---|-----|
| Overview | 249 |
| General | 249 |
| Connection Redundancy | 252 |
| Login Access Priority (AiT Models only) | 255 |
| ANMS | 256 |
| Event Destination | 256 |
| Authentication & Authorization | 258 |
| SNMP | 261 |
| FW Upgrade | 262 |
| Firmware Upgrade Recovery | 263 |
| Redundancy | 264 |
| Backup / Restore | 266 |
| Backup | 267 |
| Restore | 267 |
| Certificates | 268 |
| Private Certificate | 268 |
| Certificate Signing Request | 269 |
| Sessions | 271 |

Chapter 8. Connections

| | |
|-----------------------|-----|
| Overview | 273 |
| Connections | 274 |

Chapter 9. Scheduled Profile

| | |
|--------------------|-----|
| Overview | 277 |
|--------------------|-----|

Chapter 10.Sessions

| | |
|--------------------|-----|
| Overview | 279 |
|--------------------|-----|

Chapter 11.Remote Viewer (AiT Models only)

| | |
|---|-----|
| Introduction | 281 |
| Windows and Java Client Viewer (web access) | 282 |
| The Windows/Java Client AP | 284 |
| Download | 284 |
| Starting Up | 285 |
| The Control Panel | 287 |
| Control Panel Functions | 288 |
| Macros | 290 |
| Hotkeys | 290 |
| Video Settings | 292 |
| Gamma Adjustment | 293 |
| Virtual Media | 295 |
| Virtual Media Icons | 295 |
| Virtual Media Redirection | 295 |
| Smart Card Reader | 298 |
| Zoom | 298 |
| The On-Screen Keyboard | 299 |
| Mouse Pointer Type | 300 |
| Mouse DynaSync Mode | 300 |
| Automatic Mouse Synchronization (DynaSync) | 301 |
| Manual Mouse Synchronization | 301 |
| Control Panel Configuration | 302 |

Chapter 12.Firmware Upgrade Utility

| | |
|-------------------------------------|-----|
| Preparation | 305 |
| Starting the Upgrade | 306 |
| Upgrade Succeeded | 308 |
| Firmware Upgrade Recovery | 309 |

Chapter 13.CLI Commands

| | |
|--|-----|
| Serial Control Protocol Commands | 311 |
| Configuring the Serial Port | 311 |
| Device/Profile Commands | 312 |
| Telnet | 312 |
| Verification | 312 |
| Switch Port Command | 313 |
| Mute Command | 317 |
| Profile Command | 319 |
| EDID Command | 321 |
| Reset Command | 323 |
| RS-232 Command | 324 |
| OSD Command | 327 |
| List Command | 328 |

| | |
|--------------------|-----|
| Read Command | 330 |
| Set Command | 334 |

Appendix

| | |
|--|-----|
| Safety Instructions | 343 |
| General | 343 |
| Rack Mount | 345 |
| Technical Support | 346 |
| International | 346 |
| North America | 346 |
| Specifications | 347 |
| KE6900T / KE6940T | 347 |
| KE6900R / KE6940R | 349 |
| KE6900AT / KE6940AT | 350 |
| KE6900AR / KE6940AR | 352 |
| KE6900AiT / KE6940AiT | 353 |
| KE6900ST | 355 |
| KE6910 | 356 |
| KE6912 | 358 |
| KE6920 | 360 |
| KE6922 | 362 |
| KE8900S | 364 |
| KE8950T / KE8952T | 365 |
| KE8950R / KE8952R | 366 |
| KE9900ST | 367 |
| KE9950 | 368 |
| KE9952 | 370 |
| Optional Rack Mount | 372 |
| Dual Rack Mount | 372 |
| Transmitter Dual Rack Mount | 372 |
| Receiver Dual Rack Mount | 374 |
| Single Rack Mount | 376 |
| IP Installer | 378 |
| Trusted Certificates | 379 |
| Overview | 379 |
| Self-Signed Private Certificates | 380 |
| Examples | 380 |
| Importing the Files | 380 |
| Reset All Information | 381 |
| Default Password Pins | 382 |
| RS-232 Pin Assignments | 388 |
| Transmitter Front RS-232 Port | 388 |
| Multicast IP Address | 389 |
| KE Multicast Rule | 389 |
| Multicast IP Formula | 389 |
| If X is between 0 ~ 127 | 389 |

| | |
|--|-----|
| If X is between 128 ~ 192 | 390 |
| If X is 192 or higher | 390 |
| Keys to Network Performance | 391 |
| Build a Network Diagram | 391 |
| Other Factors | 391 |
| Choose a High Performance Switch | 393 |
| Layer 2 or Layer 3 Switches | 393 |
| Considerations | 393 |
| Number of ports | 393 |
| Stackable verse Standalone | 393 |
| What Stackable Switches Can do: | 394 |
| Switch Specifications | 394 |
| Configuring Switches and KE Devices | 395 |
| KE transmitter Settings: | 395 |
| Recommended Network Switches | 395 |
| Additional Mouse Synchronization Procedures. | 397 |
| Windows: | 397 |
| Sun / Linux | 398 |
| Virtual Media Support | 399 |
| WinClient ActiveX Viewer / WinClient AP | 399 |
| Java Applet Viewer / Java Client AP | 399 |
| Setup CCKM Server IP address on Windows. | 400 |
| Limited Warranty. | 401 |

About This Manual

This manual is provided to help you get the most out of your KVM over IP Matrix System. It covers all aspects of the device and system, including installation, configuration, and operation.

The KVM over IP Extender models covered in this user manuals are:

| Models | Product Names |
|-----------|---|
| KE6900 | DVI Single Display KVM over IP Extender (Transmitter & Receiver) |
| KE6900A | DVI-I Single Display KVM over IP Extender (Transmitter & Receiver) |
| KE6900AIT | DVI-I Single Display KVM over IP Extender (Transmitter) with Internet Access |
| KE6900ST | DVI KVM over IP Extender Lite |
| KE6910 | DVI-D Dual Link KVM over IP Extender (Transmitter & Receiver) |
| KE6912 | DVI-D Dual Link KVM over IP Extender (Transmitter & Receiver) with PoE |
| KE6920 | DVI-D Dual Link KVM over IP Extender (Transmitter & Receiver) with Dual SFP |
| KE6922 | DVI-D Dual Link KVM over IP Extender (Transmitter & Receiver) with Dual SFP & PoE |
| KE6940 | DVI Dual Display KVM over IP Extender (Transmitter & Receiver) |
| KE6940A | DVI-I Dual Display KVM over IP Extender (Transmitter & Receiver) |
| KE6940AIT | DVI-I Dual Display KVM over IP Extender (Transmitter) with Internet Access |
| KE8900S | Slim HDMI KVM over IP Extender (Transmitter & Receiver) |
| KE8950 | 4K HDMI Single Display KVM over IP Extender (Transmitter & Receiver) |
| KE8952 | 4K HDMI Single Display KVM over IP Extender (Transmitter & Receiver) with PoE |
| KE9900ST | Slim DisplayPort KVM over IP Extender (Transmitter) |
| KE9950 | 4K DisplayPort KVM over IP Extender (Transmitter & Receiver) |
| KE9952 | 4K DisplayPort KVM over IP Extender (Transmitter & Receiver) with PoE |

An overview of the information found in the manual is provided below.

Chapter 1, Introduction, introduces you to the KVM over IP Matrix System, its purpose, features, and benefits, with its front and back panel components described.

Chapter 2, Hardware Setup, provides step-by-step instructions for setting up your installation, and explains some basic operation procedures.

Chapter 3, OSD Operation, explains the fundamental concepts involved in operating the KE6900 / KE6900A / KE6900AiT / KE6900ST / KE6910 / KE6912 / KE6920 / KE6922 / KE6940 / KE6940A / KE6940AiT / KE8900S / KE8950 / KE8952 / KE9900ST / KE9950 / KE9952, and provides a complete description of the On Screen Displays (OSDs) and the functions contained.

Chapter 4, Software Installation, explains the administrative procedures that are required to download and install the KE Matrix Manager software on Windows and Linux systems.

Chapter 5, Browser / Telnet Operation, explains how to log in to the KE Matrix Manager with a web browser, and describes the various functions provided.

Chapter 6, System Status, explains how to use the KE Matrix Manager's system status panel to manage transmitters, receivers, switches, users, profiles, and logs.

Chapter 7, System Settings, explains the KE Matrix Manager's system settings, which are categorized into General, ANMS, LDAP/AD, RADIUS, TACACS+ authentication, F/W Upgrade, Redundancy, Backup/Restore, Certificates, and Sessions tabs.

Chapter 8, Connections, describes how to use the KE Matrix Manager's connections panel to quickly view, connect, and disconnect Transmitter-Receiver connections.

Chapter 9, Scheduled Profile, describes how to use the KE Matrix Manager's scheduled profile panel to view and manage profile schedules.

Chapter 10, Sessions, describes how to use the KE Matrix Manager's sessions panel to view and disconnect user sessions.

Chapter 11, Remote Viewer (AiT Models only), describes how to use remote viewer(s) to view and control video sources connected to AiT transmitters.

Chapter 12, Firmware Upgrade Utility, explains how to download and use the Firmware Upgrade Utility for upgrading the firmware of the devices connected.

Chapter 13, CLI Commands, provides a complete list of the serial protocol and TCP/IP commands used when utilizing the RS-232 serial port or a network connection to configure the KE devices.


Appendix, provides the technical and troubleshooting information of KE devices at the end of the manual.

Note:

- ◆ Read this manual thoroughly and follow the installation and operation procedures carefully to prevent any damage to the unit or connected devices.
 - ◆ ATEN regularly updates its product documentation for new features and fixes. For an up-to-date KE6900 / KE6900A / KE6900AiT / KE6900ST / KE6910 / KE6912 / KE6920 / KE6922 / KE6940 / KE6940A / KE6940AiT / KE8900S / KE8950 / KE8952 / KE9900ST / KE9950 / KE9952 documentation, visit <http://www.aten.com/global/en/>
-

Conventions

This manual uses the following conventions:

- | | |
|---|--|
| Monospaced | Indicates text that you should key in. |
| [] | Indicates keys you should press. For example, [Enter] means to press the Enter key. If keys need to be chorded, they appear together in the same bracket with a plus sign between them: [Ctrl+Alt]. |
| 1. | Numbered lists represent procedures with sequential steps. |
| ◆ | Bullet lists provide information, but do not involve sequential steps. |
| > | Indicates selecting consecutive options (such as on a menu or dialog box). For example, Start > Run means to open the <i>Start</i> menu, and then select <i>Run</i> . |
|  | Indicates critical information. |

Chapter 1

Introduction

Overview

The KVM over IP Matrix System is a solution that combines KE Series KVM over IP Extenders (KE6900, KE6900A, KE6900AiT, KE6940, KE6940A, KE6940AiT, KE6900ST, KE6910, KE6912, KE6920, KE6922, KE8900S, KE8950, KE8952, KE9900ST, KE9950, KE9952), with the KE Matrix Manager Software (CCKM) to extend, control and monitor access to computers, across a network, in a multitude of ways. The system lets you setup a matrix of remote KVM consoles that access computers across a network, with the flexibility to control and configure each connection.

The high-performance IP-based KE Extenders are consisted of a transmitter and a receiver. The transmitter connects to a computer to deliver the computer's data to the receiver to collectively provide console access from a remote or separate location. The computer can be accessed from the remote console via a standard TCP/IP network or direct Ethernet cable connection. This is perfect for any installation where you need to place the console where it is convenient, but you want the computer to reside in a secure location — away from the keyboard, mouse and display.

The extenders support flawless and lossless video compression quality with ultra low latency, some extenders also support 2K x 2K video resolution (2048 x 2048 @ 60Hz), which is used widely in the Air Traffic Control (ATC) industry. For a list of video resolution support, refer to *Supported Video Resolutions* on page 7.

For power redundancy, some extenders have dual power supplies, some provide single power supply with a Power over Ethernet (PoE) LAN port, while some provide dual power supplies and a PoE LAN port.

Some extenders support Fiber Channel over Ethernet via SFP fiber modules* which connect to a network switch at speeds up to 1 Gbps. The extenders can connect unit-to-unit or over a TCP/IP network via Gigabit Ethernet or the SFP ports. Connecting both methods allows network failover.

The non-slim KE over IP Extenders have local On Screen Display (OSD) on the receiver end to configure both receiver and transmitter — for easy setup and operation. Both the transmitter and receiver have RS-232 ports to connect

to a serial terminal for configuration or serial devices such as touchscreens and barcode scanners.

The AiT models can connect to an Office LAN to support the Control Center Video Session Recorder (CCVSR) software and WinClient/JavaClient. The CCVSR records all operations made on servers accessed through KVM over IP switches. Every operation and change are recorded and saved to a secure video file for security reference and troubleshooting purposes, etc. By using WinClient/JavaClient, you are provided with console access from a separate location over intranet and/or Internet.

Slimmer versions of KE over IP Extenders are also available. These are KE6900ST, KE8900S or KE9900ST, and are cost and space saving alternatives for installations with extenders that don't need a local console or audio transmission, but want the connectivity features of advanced KE models. KE6900ST is a slim KVM over IP Transmitter that supports DVI input. KE8900S offers a slim KVM over IP Transmitter (KE8900ST) and a slim KVM over IP Receiver (KE8900SR) to respectively support HDMI video input from the computer and one HDMI monitor output. KE9900ST is a slim KVM over IP Transmitter that supports DisplayPort input. In addition to a DC power jack, both the KE8900ST and KE9900ST transmitters have an extra DC terminal block each for convenient installation.

Since different KE over IP Extenders support different types of video interfaces (DVI, HDMI, DisplayPort, etc.), video resolutions, power redundancy function and network failover feature, administrators/users may select and tailor what is currently best for your environment, and for expected or unexpected future expansions.

Refer to the table below for the variations in interfaces, functions and features:

| Models | DVI | HDMI | DisplayPort | Power Redundancy via PoE* | Power Redundancy via Second Power Jack | Network Failover - SFP |
|-----------|-----|------|-------------|---------------------------|--|------------------------|
| KE6900 | 1 | - | - | - | - | - |
| KE6900A | 1 | - | - | - | 1 | 1 |
| KE6900AiT | 1 | - | - | - | 1 | 1 |
| KE6900ST | 1 | - | - | - | - | - |
| KE6910 | 1 | - | - | - | 1 | 1 |
| KE6912 | 1 | - | - | 1 | - | 1 |
| KE6920 | 1 | - | - | - | 1 | 2 |
| KE6922 | 1 | - | - | 1 | 1 | 2 |
| KE6940 | 2 | - | - | - | - | - |
| KE6940A | 2 | - | - | - | 1 | 1 |
| KE6940AiT | 2 | - | - | - | 1 | 1 |
| KE8900S | - | 1 | - | - | - | - |
| KE8950 | - | 1 | - | - | - | 1 |

| Models | DVI | HDMI | DisplayPort | Power Redundancy via PoE* | Power Redundancy via Second Power Jack | Network Failover - SFP |
|----------|-----|------|-------------|---------------------------|--|------------------------|
| KE8952 | - | 1 | - | 1 | - | 1 |
| KE9900ST | - | - | 1 | - | - | - |
| KE9950 | - | - | 1 | - | 1 | 1 |
| KE9952 | - | - | 1 | 1 | - | 1 |

*Power redundancy via PoE requires power board version B01G or later (see *PoE Power Redundancy* on page 74 for more details).

KVM over IP Extenders allow flexible setup as they can make console-to-computer connections in several ways: one-to-one (Extender mode), one-to-many (Splitter mode), many-to-one (Switch mode), or many-to-many (Matrix mode).

The KE Matrix Manager Software (CCKM) allows you to define the aforementioned matrix connections and manage KE Extenders with features such as auto-detection of KE Extenders, username/password authentication, switching and sharing of connections, scheduling, permissions and more. Whether you're extending computer access for Monitoring, Broadcasting, Editing or Workstation setup, the KVM over IP Matrix System gives you the flexibility and control to manage one or hundreds of extended connections. For more detailed feature list, refer to *Features* on page 4.

Note: The SFP module is sold separately. You can choose the 2A-136G, a multi-mode SFP module that provides 1 GbE connectivity up to 550 meters; or the 2A-137G, a single-mode SFP module that provides 1 GbE connectivity up to 10 kilometers. Visit ATEN's website or contact your ATEN dealer for more information.

Features

- ◆ Remote KVM console access of computers over LAN or Ethernet cable connection
- ◆ Dual console operation — control your system from both the Transmitter and Receiver by USB keyboard, monitor, and mouse
- ◆ RS-232 serial ports allows you to connect to a serial terminal for configuration, and serial devices such as touchscreens and barcode scanners¹
- ◆ Superior video quality² — up to 1920 x 1200 @ 60 Hz with 24-bit color depth (KE69 Series / KE8900S); up to 3840 x 2160 @ 30 Hz (4:4:4) with 36-bit color depth (KE99 Series); up to 3840 x 2160 @ 60 Hz (4:4:4) with 36-bit color depth (KE8950 / KE8952)
- ◆ Supports standard resolutions from 640 x 480 to 1920 x 1200 @ 60 Hz (KE69 Series / KE8900S); and resolutions from 640 x 480 to 3840 x 2160 @ 30 / 60 Hz (KE99 Series / KE8950 and KE8952)
- ◆ Supports 2K x 2K video resolution (2048 x 2048 @ 60 Hz) (KE6910 / KE6912 / KE6920 / KE6922)
- ◆ OSD (On Screen Display) on the Receiver configures Tx / Rx devices
- ◆ Supports KE Matrix Manager Web GUI administration³
- ◆ Supports Power over Ethernet (PoE) functionality — compliant with IEEE 802.3at and 802.3af standards (KE6912, KE6922, KE8952 and KE9952)
- ◆ Boundless Switching — simply move the mouse cursor across screen boundaries to switch between different receivers
- ◆ Intelligent Dual Video Output Management — split two video sources from a dual display Transmitter and connect to each from different Receivers (KE6940/KE6940A)
- ◆ Gigabit Ethernet port
- ◆ Remote login security
- ◆ DVI digital and analog monitor support (KE6900 / KE6900A / KE6900AiT / KE6900ST / KE6910 / KE6912 / KE6920 / KE6922 / KE6940 / KE6940A / KE6940AiT)
- ◆ HDMI monitor support (KE8900S / KE8950 / KE8952)
- ◆ DisplayPort monitor support (KE9900ST / KE9950 / KE9952)
- ◆ Built-in ESD protection and surge protection

- ◆ Supports 2 channel analog (KE69 Series) and 7.1 channel surround sound (KE89 / KE99 Series) stereo speakers and microphone
- ◆ Auto-MDIX — automatically detects cable type
- ◆ Supports widescreen formats
- ◆ Supports High-Quality Video streaming
- ◆ Virtual Media Support
- ◆ Hot pluggable
- ◆ Rack Mountable
- ◆ Upgradeable firmware
- ◆ Supports digital audio (KE8900S / KE8950 / KE8952 / KE9900ST / KE9950 / KE9952)
- ◆ Adaptive Fast Switching — automatically fast switches between different Tx video resolutions on a Rx display within 0.3 second (KE6910/KE6912)
- ◆ Authentication Lock — automatically logs in when the power of the system is resumed after power off
- ◆ Connection Redundancy — automatically connects to another transmitter (Tx) after disconnection with the original Tx, ensuring constant access to servers (KE6900A / KE6900AiT / KE6910 / KE6912 / KE6920 / KE6922 / KE6940A / KE6940AiT)
- ◆ Disconnection Alert — Pop-up warning message and looping alarm beeping notify users the disconnection status (KE6910/KE6912)
- ◆ Instant Link — Switch intuitively and efficiently between transmitter (Tx) on a receiver (Rx) display
- ◆ Supports recording of remotely-accessed computer operations using ATEN CCVSR Video Session Recording Software
- ◆ “Push” and “Pull” — shares content instantly to/from a single Rx or video wall by just one click
- ◆ Video Walls — create multiple video walls with up to 8 x 8 (64 displays max.) in each layout
- ◆ Four selectable access modes for multiple simultaneous access (Exclusive/ Occupy/Share/ View only mode)
- ◆ Supports remote access via WinClient / JavaClient over intranet or Internet
- ◆ Rx access control — users at the Tx local console can enable / disable Rx access by simply pressing a control button⁴

Note: 1. RS-232 serial ports support Tx/Rx/CTS/RTS/DTR/DSR signals only.

2. Refer to *Supported Video Resolutions* below for details.
 3. The KE Matrix Manager web GUI can be updated from the CCKM page on our website (www.aten.com) or via eService website (<http://eservice.aten.com>). The free version supports up to 8 KE devices. To obtain a license for the full version of the software, please contact your ATEN dealer.
 4. The KVM over IP Access Control Box (2XRT-0015G) is sold separately. Contact your ATEN dealer for product information.
-

Supported Video Resolutions

| Resolutions | KE6900 / KE6940 KE6900A / KE6940A KE6900AiT / KE6940AiT | KE6910 / KE6912 KE6920 / KE6922 | KE8950 / KE8952 | KE9950 / KE9952 | KE6900ST / KE8900S / KE9900ST |
|---|--|------------------------------------|--------------------|--------------------|-------------------------------------|
| 3840 x 2160 @ 60 Hz | | | • | | |
| 3840 x 2160 @ 24/25/30 Hz | | | | • | |
| 3440 x 1440 @ 50 Hz | | | | • | |
| 2560 x 2048 @ 50 Hz | | • | | | |
| 2560 x 1600 @ 60 Hz | | • | | • | |
| 2560 x 1440 @ 60 Hz | | • | | • | |
| 2560 x 1080 @ 24/25/30/50/ 60/100/120 Hz | | | | • | |
| 2048 x 2048 @ 30/60 Hz | | • | | | |
| 2048 x 1536 @ 60 Hz | | • | | • | |
| 2048 x 1536 @ 30 Hz | | • | | | |
| 2048 x 1152 @ 60 Hz | | • | | | |
| 1600 x 1600 @ 60 Hz | | • | | | |
| 1920 x 2160 @ 60 Hz | | • | | | |
| 1920 x 2160 @ 30 Hz | | • | | • | |
| 1920 x 1440 @ 60 Hz | | • | | • | |
| 1920 x 1200 @ 60 Hz | • | • | | • | • |
| 1920 x 1080 @ 60 Hz | • | • | | • | • |
| 1600 x 1200 @ 60 Hz | • | • | | • | • |
| 1680 x 1050 @ 60 Hz | • | • | | • | • |
| 1400 x 1050 @ 60 Hz | • | • | | • | • |
| 1280 x 1024 @ 60/75 Hz | • | • | | • | • |
| 1280 x 960 @ 60 Hz | • | • | | • | • |
| 1280 x 800 @ 60 Hz | | • | | | |
| 1600 x 900 @ 60 Hz | • | • | | • | • |
| 1440 x 900 @ 60 Hz | • | • | | • | • |
| 1152 x 864 @ 75 Hz | • | • | | • | • |
| 1366 x 768 @ 60 Hz | • | • | | • | • |
| 1280 x 720 @ 60 Hz | • | • | | • | • |
| 1024 x 768 @ 60/70/75/85 Hz | • | • | | • | • |
| 848 x 480 @ 60 Hz | | • | | | |
| 800 x 600 @ 56/60/72/75/85 Hz | • | • | | • | • |
| 720 x 400 @ 70/85 Hz | • | • | | • | • |
| 640 x 480 @ 60/72/75/85 Hz | • | • | | • | • |

Requirements

Operating System

KE series devices are compatible with the following operating systems:

| OS | | Versions |
|---------|--------|--|
| Windows | 32-bit | XP / 7 / 8 |
| | 64-bit | XP / 7 / 8 / 8.1 / 10 / Server 2008 R2 / Server 2012 / Server 2016 / Server 2019 |
| Linux | | <ul style="list-style-type: none">◆ CentOS◆ Ubuntu◆ openSUSE◆ Red Hat |

- ◆ Mac OS
- ◆ Oracle Solaris

Console

- ◆ (KE6900/KE6900A/KE6900AiT/KE6900ST/KE6910/KE6912/KE6920/KE6922) One DVI compatible monitor capable of the highest possible resolution
- ◆ (KE6940/KE6940A/KE6940AiT) Two DVI compatible monitors capable of the highest possible resolution
- ◆ (KE8900S/KE8950/KE8952) One HDMI compatible monitor capable of the highest possible resolution
- ◆ (KE9900ST/KE9950/KE9952) One DisplayPort compatible monitor capable of the highest possible resolution
- ◆ A USB mouse
- ◆ A USB keyboard
- ◆ Microphone and speakers

Computers

The following ports must be available on each computer that is to be connected to the system:

- ◆ (KE6900/KE6900A/KE6900AiT/KE6900ST/KE6910/KE6912/KE6920/KE6922) One DVI port

- ◆ (KE6940/KE6940A/KE6940AiT) Two DVI ports
- ◆ (KE8900S/KE8950/KE8952) One HDMI port
- ◆ (KE9900ST/KE9950/KE9952) One DisplayPort port
- ◆ USB Type A port
- ◆ Audio ports

Cables

- ◆ For optimal signal integrity and to simplify the setup, we strongly recommend that you only use the high quality custom USB KVM Cable that is provided with this package.

CCKM Requirements


The minimum hardware and software requirements for the computer running the KE Matrix Manager software are:

- ◆ Processor: Pentium 4, 2.60 GHz or above
- ◆ Memory: 1 GB or above
- ◆ HDD: 500 MB or above
- ◆ Web browser: Internet Explorer 10 (or later), Chrome 70 (or later), Firefox 62 (or later)
- ◆ Operating System Requirements:
 - ◆ Windows 7, 8.1, 10, server 2008, server 2012, or server 2016
 - ◆ Linux Ubuntu 16.04, CentOS 7

Note: Only Java Runtime Environment (JRE) 8 and OpenJDK 8 are supported.


Components

KE6900T (Transmitter) Front View



| No. | Component | Description |
|-----|--------------------|--|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (local or remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE6900T (Transmitter) Rear View



| No. | Component | Description |
|-----|--------------------|---|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |

| No. | Component | Description |
|------------|------------------|---|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 9 | DVI-I output | The cable from the local DVI monitor plugs in here. |


KE6900R (Receiver) Front View



| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |


| No. | Component | Description |
|-----|-----------|---|
| 8 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: 1. When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> <p>2. This USB port does not support isochronous endpoints, therefore USB peripherals that stream audio or video data, such as speakers or webcams, will not work.</p> |

KE6900R (Receiver) Rear View




| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: 1. When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> <p>2. This USB port does not support isochronous endpoints, therefore USB peripherals that stream audio or video data, such as speakers or webcams, will not work.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |

| No. | Component | Description |
|-----|---------------|---|
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. When using a keyboard or mouse with special functions, see <i>USB Mode</i> , page 224. |
| 9 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 10 | DVI-I output | The cable from the local DVI monitor plugs in here. |

KE6900AT (Transmitter) Front View


| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |

KE6900AT (Transmitter) Rear View




| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | power jack | The cable from the DC power adapter connects here. |

| No. | Component | Description |
|-----|-----------------|---|
| 6 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none">◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.*◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers.◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 9 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 10 | DVI-I output | The cable from the local DVI monitor plugs in here. |
| 11 | power jack | Connect a second power source for power redundancy. |


KE6900AR (Receiver) Front View

| No. | Component | Description |
|-----|---------------------|--|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Use this port for virtual media or a USB peripheral device. Note: When using a USB disk plugged into this port, see <i>USB Mode</i> , page 224. |


KE6900AR (Receiver) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 6 | power jack | The cable from the DC power adapter connects here. |
| 7 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 8 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |

| No. | Component | Description |
|-----|---------------|---|
| 9 | console ports | The unit's USB keyboard and USB mouse plug into these ports. When using a keyboard or mouse with special functions, see <i>USB Mode</i> , page 224. |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DVI-I output | The cable from the local DVI monitor plugs in here. |
| 12 | power jack | Connect a second power source for power redundancy. |


KE6900AiT (Transmitter) Front View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights Green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE6900AiT (Transmitter) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | Internet port | Connect an Internet-enabled Ethernet cable to allow access to the web interface or CCVSR recording. |
| 6 | power jack | The cable from the DC power adapter connects here. |

| No. | Component | Description |
|-----|-----------------|---|
| 7 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none">◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.*◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers.◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |
| 8 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 9 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DVI-I output | The cable from the local DVI monitor plugs in here. |
| 12 | power jack | Connect a second power source for power redundancy. |


KE6910T / KE6912T (Transmitter) Front View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | Remote / Local LED | Lights green to indicate which side of the installation (Local or Remote) has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE6910T / KE6912T (Transmitter) Rear View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |

| No. | Component | Description |
|-----|---------------------------|--|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE6912 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 9 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 10 | DVI-D output | The cable from the local DVI monitor plugs in here. |
| 11 | power jack (KE6910T only) | Connect a second power source for power redundancy. |


KE6910R / KE6912R (Receiver) Front View

| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Use this port for virtual media or a USB peripheral device. <p>Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |


KE6910R / KE6912R (Receiver) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |

| No. | Component | Description |
|-----|---------------------------|--|
| 9 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE6912 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DVI-D output | The cable from the local DVI monitor plugs in here. |
| 12 | power jack (KE6910R only) | Connect a second power source for power redundancy. |


KE6920T / KE6922T (Transmitter) Front View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (Local or Remote) has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE6920T / KE6922T (Transmitter) Rear View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |

| No. | Component | Description |
|-----|---------------|--|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE6922 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 9 | SFP slots | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN can be plugged here. |
| 10 | DVI-D output | The cable from the local DVI monitor plugs in here. |
| 11 | power jack | Connect a second power source for power redundancy. |


KE6920R / KE6922R (Receiver) Front View

| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Note: Use this port for virtual media or a USB peripheral device. When using a USB disk plugged into this port, see <i>USB Mode</i> , page 224. |

KE6920R / KE6922R (Receiver) Rear View


| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |

| No. | Component | Description |
|-----|--------------|---|
| 9 | LAN port | <p>The cable that connects the unit to the LAN plugs in here.</p> <p>This port is PoE enabled* for KE6922 for power redundancy or cable management.</p> <p>*Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details).</p> |
| 10 | SFP slots | <p>The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN can be plugged here.</p> |
| 11 | DVI-D output | <p>The cable from the local DVI monitor plugs in here.</p> |
| 12 | power jack | <p>Connect a second power source for power redundancy.</p> |

KE6940T (Transmitter) Front View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (Local or Remote) has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE6940T (Transmitter) Rear View



| No. | Component | Description |
|-----|--------------------|---|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |


| No. | Component | Description |
|------------|------------------|---|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 9 | DVI-I output | The cable from the local DVI monitor plugs in here. |

KE6940R (Receiver) Front View




| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |

| No. | Component | Description |
|-----|-----------|---|
| 8 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: 1. When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> <p>2. This USB port does not support isochronous endpoints, therefore USB peripherals that stream audio or video data, such as speakers or webcams, will not work.</p> |

KE6940R (Receiver) Rear View


| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: 1. When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> <p>2. This USB port does not support isochronous endpoints, therefore USB peripherals that stream audio or video data, such as speakers or webcams, will not work.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |

| No. | Component | Description |
|-----|---------------|--|
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 9 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 10 | DVI-I output | The cable from the local DVI monitors plug in here. |

KE6940AT (Transmitter) Front View


| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable and the DVI cable supplied with the package plugs into these ports to link the Transmitter to the computer. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights Green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |

KE6940AT (Transmitter) Rear View




| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | power jack | The cable from the DC power adapter connects here. |

| No. | Component | Description |
|-----|-----------------|---|
| 6 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none">◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.*◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers.◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 9 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 10 | DVI-I output | The cables from the local DVI monitors plug in here. |
| 11 | power jack | Connect a second power source for power redundancy. |


KE6940AR (Receiver) Front View

| No. | Component | Description |
|-----|---------------------|--|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Use this port for virtual media or a USB peripheral device. <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |


KE6940AR (Receiver) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 6 | Power jack | The cable from the DC power adapter connects here. |
| 7 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 8 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |

| No. | Component | Description |
|-----|---------------|---|
| 9 | console ports | The unit's USB keyboard and USB mouse plug into these ports. When using a keyboard or mouse with special functions, see <i>USB Mode</i> , page 224. |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DVI-I output | The cables from the local DVI monitors plug in here. |
| 12 | power jack | Connect a second power source for power redundancy. |

KE6940AiT (Transmitter) Front View


| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable and the DVI cable supplied with the package plugs into these ports to link the Transmitter to the computer. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |

KE6940AiT (Transmitter) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | Internet port | Connect an Internet-enabled Ethernet cable to allow access to the web interface or CCVSR recording. |
| 6 | power jack | The cable from the DC power adapter connects here. |


| No. | Component | Description |
|-----|-----------------|---|
| 7 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none">◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.*◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers.◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |
| 8 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 9 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DVI-I output | The cables from the local DVI monitors plug in here. |
| 12 | power jack | Connect a second power source for power redundancy. |

KE6900ST (Transmitter) Front, Rear and Top View




| No. | Component | Description |
|-----|--------------|--|
| 1 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 2 | KVM port | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | <p>This RS-232 serial port is for connecting to the computer for serial control.</p> <p>Note: When a LAN connection is detected serial commands bypass the KE6900ST and are sent across the network to the receiver. When no LAN connection is detected serial commands are automatically directed to the KE6900ST for local configuration and control.</p> |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |

| No. | Component | Description |
|-----|------------|--|
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none">◆ Lights when connected to the LAN and blinks when the Ethernet connection is active:<ul style="list-style-type: none">◆ Orange: 10 Mbps◆ Orange + Green: 100 Mbps◆ Green: 1000 Mbps◆ Off when not connected to the LAN. |
| 7 | power LED | Lights blue to indicate the unit is turned on. |

KE8950T / KE8952T (Transmitter) Front View


| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights Green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |

KE8950T / KE8952T (Transmitter) Rear View




| No. | Component | Description |
|-----|--------------------|---|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |

| No. | Component | Description |
|-----|---------------|--|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | Console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE8952 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 9 | SFP port | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 10 | HDMI output | The cable from the local HDMI monitor plugs in here. |

KE8950R / KE8952R (Receiver) Front View


| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Use this port for virtual media or a USB peripheral device. <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |

KE8950R / KE8952R (Receiver) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. When using a keyboard or mouse with special functions, see <i>USB Mode</i> , page 224. |


| No. | Component | Description |
|-----|-------------|--|
| 9 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE8952 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 10 | SFP port | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | HDMI output | The cable from the local HDMI monitor plugs in here. |

KE8900ST (Transmitter) Front, Rear and Side View



| No. | Component | Description |
|-----|--------------|--|
| 1 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |


| No. | Component | Description |
|-----|-----------------------|--|
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none">◆ Lights when connected to the LAN and blinks when the Ethernet connection is active:<ul style="list-style-type: none">◆ Orange: 10 Mbps◆ Orange + Green: 100 Mbps◆ Green: 1000 Mbps◆ Off when not connected to the LAN. |
| 3 | power LED | Lights blue to indicate the unit is turned on. |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. Note: When a LAN connection is detected serial commands bypass the KE8900ST and are sent across the network to the receiver. When no LAN connection is detected serial commands are automatically directed to the KE8900ST for local configuration and control. |
| 6 | USB Type-B port | The USB port that links the Transmitter to the computer. |
| 7 | HDMI input | The cable from the local HDMI monitor plugs in here. |
| 8 | 3-pole terminal block | Insert DC + and - wires (DC 12 ~ 48 V) to the terminal block for power input. |
| 9 | power jack | The cable from the DC power adapter connects here. |
| 10 | grounding terminal | The wire used to ground the unit connects here. |

KE8900SR (Receiver) Front, Rear and Side View

| No. | Component | Description |
|-----|---------------------|---|
| 1 | USB peripheral port | Use this port for virtual media or a USB peripheral device. Note: 1. When using a USB disk plugged into this port, see <i>USB Mode</i> , page 224. 2. This USB port does not support isochronous endpoints, therefore USB peripherals that stream audio or video data, such as speakers or webcams, will not work. |
| 2 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |


| No. | Component | Description |
|-----|--------------------|--|
| 3 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 4 | LAN LED | <p>This LED indicates the network status.</p> <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 5 | power LED | Lights blue to indicate the unit is turned on. |
| 6 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 7 | RS-232 port | <p>This RS-232 serial port is for connecting to the computer for serial control.</p> <p>Note: When a LAN connection is detected serial commands bypass the KE8900ST and are sent across the network to the receiver. When no LAN connection is detected serial commands are automatically directed to the KE8900ST for local configuration and control.</p> |
| 8 | HDMI output | The cable from the local HDMI monitor plugs in here. |
| 9 | power jack | The cable from the DC power adapter connects here. |
| 10 | grounding terminal | The wire used to ground the unit connects here. |

KE9900ST (Transmitter) Front, Rear and Side View




| No. | Component | Description |
|-----|--------------|--|
| 1 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more then three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |

| No. | Component | Description |
|-----|-----------------------|--|
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none">◆ Lights when connected to the LAN and blinks when the Ethernet connection is active:<ul style="list-style-type: none">◆ Orange: 10 Mbps◆ Orange + Green: 100 Mbps◆ Green: 1000 Mbps◆ Off when not connected to the LAN. |
| 3 | power LED | Lights blue to indicate the unit is turned on. |
| 4 | LAN port | The cable that connects the unit to the LAN plugs in here. |
| 5 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. Note: When a LAN connection is detected serial commands bypass the KE8900ST and are sent across the network to the receiver. When no LAN connection is detected serial commands are automatically directed to the KE8900ST for local configuration and control. |
| 6 | USB Type-B port | The USB port that links the Transmitter to the computer. |
| 7 | DisplayPort Input | The cable from the local DisplayPort monitor plugs in here. |
| 8 | 3-pole terminal block | Insert DC + and - wires (DC 12 to 48V) to the terminal block for power input. |
| 9 | power jack | The cable from the DC power adapter connects here. |
| 10 | grounding terminal | The wire used to ground the unit connects here. |


KE9950T / KE9952T (Transmitter) Front View

| No. | Component | Description |
|-----|--------------------|---|
| 1 | audio ports | These mini stereo ports are for the speakers (green) and microphone (pink). |
| 2 | KVM ports | The USB KVM cable supplied with the package that links the Transmitter to the computer plugs into these ports. |
| 3 | RS-232 port | This RS-232 serial port is for connecting to the computer for serial control. |
| 4 | remote / local LED | Lights green to indicate which side of the installation (Local or Remote) currently has KVM control of the computer. |
| 5 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 6 | power LED | Lights blue to indicate the unit is turned on. |


KE9950T / KE9952T (Transmitter) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | power jack | The cable from the DC power adapter connects here. |
| 5 | function switch | <p>Use this slide switch to set the unit's mode to:</p> <ul style="list-style-type: none"> ◆ Auto: Shared (simultaneous) KVM control of the computer at the Transmitter and Receiver console.* ◆ RS-232 Config/Access Control: The device is ready to be configured via serial commands through the RS-232 port. When connected to a KVM over IP Access Control Box (2XRT-0015G), users can enable / disable control privileges of the connected receivers. ◆ Local: Only the local Transmitter has KVM control of the computer. The Receiver's KVM access to the computer is locked. <p>Note: In Auto mode, RS-232 and audio functions will work on the Receiver but not on the Transmitter.</p> |

| No. | Component | Description |
|-----|---------------------------|--|
| 6 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |
| 7 | Console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 8 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE9952 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 9 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 10 | DisplayPort output | The cable from the local DisplayPort monitor plugs in here. |
| 11 | power jack (KE9950T only) | Connect a second power source for power redundancy. |

KE9950R / KE9952R (Receiver) Front View

| No. | Component | Description |
|-----|---------------------|---|
| 1 | power LED | Lights blue to indicate the unit is turned on. |
| 2 | LAN LED | This LED indicates the network status. <ul style="list-style-type: none"> ◆ Lights when connected to the LAN and blinks when the Ethernet connection is active: <ul style="list-style-type: none"> ◆ Orange: 10 Mbps ◆ Orange + Green: 100 Mbps ◆ Green: 1000 Mbps ◆ Off when not connected to the LAN. |
| 3 | local LED | Lights green to Indicate the Transmitter has KVM access of the computer. |
| 4 | remote LED | Lights green to Indicate the Receiver has KVM access of the computer. |
| 5 | graphics pushbutton | Sets the image quality of the display to the highest possible grade so that images are optimized. This toggle button turns off the Video Pushbutton option. Graphics mode is selected by default. |
| 6 | OSD pushbutton | Use this pushbutton to open the OSD menu. |
| 7 | video pushbutton | Sets the image quality of the display to a grade that is optimized for playing videos. This toggle button turns off the Graphics Pushbutton option. |
| 8 | USB port | Use this port for virtual media or a USB peripheral device. <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |


KE9950R / KE9952R (Receiver) Rear View

| No. | Component | Description |
|-----|--------------------|--|
| 1 | grounding terminal | The wire used to ground the unit connects here. |
| 2 | reset button | <p>This button must be pushed with a thin object, such as the end of a paper clip.</p> <ul style="list-style-type: none"> ◆ Press and release to reboot the device. ◆ Power off, hold reset then power on the device while pressing reset to recover from a firmware upgrade failure. ◆ Press and hold it in for more than three seconds resets the unit back to its factory default settings*. <p>Note: The Reset to Factory Default function resets everything but the login information (username/password) to the factory default settings. To reset the login information, refer to <i>Reset All Information</i> on page 381.</p> |
| 3 | audio ports | These mini stereo ports are for the local speakers (green) and microphone (pink). |
| 4 | USB port | <p>Use this port for virtual media or a USB peripheral device.</p> <p>Note: Note: When using a USB disk plugged into this port, see <i>USB Mode</i>, page 224.</p> |
| 5 | power jack | The cable from the DC power adapter connects here. |
| 6 | function switch | <p>Use this slide switch to set the unit's mode:</p> <ul style="list-style-type: none"> ◆ Extension: Sets the device to use the normal TX to RX extension mode. ◆ RS-232 Config: The device is ready to be configured via serial commands through the RS-232 port. |
| 7 | RS-232 port | This RS-232 serial port is for connecting to a serial terminal. |

| No. | Component | Description |
|-----|---------------------------|--|
| 8 | console ports | The unit's USB keyboard and USB mouse plug into these ports. |
| 9 | LAN port | The cable that connects the unit to the LAN plugs in here. This port is PoE enabled* for KE9952 for power redundancy or cable management. *Requires power board version B01G or later (see <i>PoE Power Redundancy</i> on page 74 for more details). |
| 10 | SFP slot | The Gigabit Ethernet (GbE) optical fiber cable that connects the unit to the LAN plugs in here. |
| 11 | DisplayPort output | The cable from the local DisplayPort monitor plugs in here. |
| 12 | power jack (KE9950R only) | Connect a second power source for power redundancy. |

PoE Power Redundancy

For power redundancy with PoE-enabled models, the unit's underside label must be printed with a "Power Board Version: B01G" string. An example is shown below and the string is indicated in the diagram:



Chapter 2

Hardware Setup



1. Important safety information regard the placement of this device is found on . Please review it before proceeding.
2. Make sure that the power of all devices to be connected is turned off. You must unplug the power of any computers with Keyboard Power-on function.
3. Please operate the device with caution when under high environmental temperatures, as the surface of the device may become overheated under such conditions. For instance, the surface temperature of the device may reach 70 °C or higher when the environmental temperature reaches close to 50 °C.

Mounting

For convenience and flexibility, the transmitters can be mounted onto a system racks or wall.

Note: Optional mounting options are available, refer to *Optional Rack Mount* on page 372 for more information.

It is highly recommended to mount AiT unit(s) onto a system rack or wall and avoid a stacked setup to ensure proper ventilation.

The following sections demonstrate how to mount transmitters using the mounting kit provided.


Attaching the Mounting Bracket

Follow the steps below to attach the mounting bracket to the unit:


Non-Slim Transmitters

Note: Steps for non-slim transmitters (KE6900, KE6900A, KE6900AiT, KE6910, KE6912, KE6920, KE6922, KE6940, KE6940A, KE6940AiT, KE8950, KE8952, KE9950, and KE9952) are the same, and are exemplified using KE6900.

1. Unscrew the screws from the side, as shown in the diagram below.




2. Use the screws from step 1 to attach the mounting bracket to the bottom of the transmitter, as shown below.



Slim Transmitters — KE6900ST


Using the screws from in the mounting kit, attach the mounting bracket to the bottom of the transmitter as shown below.




Slim Transmitters — KE8900ST / KE9900ST

The following diagrams are exemplified using KE8900ST.

1. Unscrew the screws from the side, as shown in the diagram below.



2. Use the screws from step 1 to attach the mounting bracket to the bottom of the transmitter, as shown below.




Rack Mount

Non-Slim Transmitters

Note: Steps for non-slim transmitters (KE6900, KE6900A, KE6900AiT, KE6910, KE6912, KE6920, KE6922, KE6940, KE6940A, KE6940AiT, KE8950, KE8952, KE9950, and KE9952) are the same, and are exemplified using KE6900.


Screw the mounting bracket on a convenient location of the rack.



Note: Rack screws are not provided. We recommend the use of M5 x 12 Phillips Type I cross recessed screws.

Slim Transmitters — KE6900ST


Screw the mounting bracket on a convenient location of the rack.



Note: Rack screws are not provided. We recommend the use of M5 x 12 Phillips Type I cross recessed screws.

Slim Transmitters — KE8900ST / KE9900ST

Screw the mounting bracket on any convenient location of the rack.




Wall Mount

Non-Slim Transmitters


Note: Steps for non-slim transmitters (KE6900, KE6900A, KE6900AiT, KE6910, KE6912, KE6920, KE6922, KE6940, KE6940A, KE6940AiT, KE8950, KE8952, KE9950, and KE9952) are the same, and are exemplified using KE6900.

Use the center hole to screw the mounting bracket onto a secure wall surface.




Slim Transmitters — KE6900ST

Use the center hole to screw the mounting bracket onto a secure wall surface.



Slim Transmitters — KE8900ST / KE9900ST

Use the mounting bracket's center screw hole to mount the unit onto a wall.



KE6900 / KE6940 Point-to-Point Installation

Setting up the KE6900 / KE6940 system in a point-to-point configuration is simply a matter of plugging in the cables.

Note: In a point-to-point configuration, no administrator setup is required.


Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:

1. On the transmitter side, plug the mouse, keyboard, DVI monitor, microphone and speakers into the ports on the console section of the KE6900T / KE6940T. Each port is labeled a corresponding icon for identification.*
2. Connect the USB KVM cable provided to the KVM ports on the front of the KE6900T / KE6940T.
3. Connect the other end of the USB KVM cable to the keyboard, video, mouse, speaker, and microphone ports on the computer.
4. For control of serial devices, connect the RS-232 serial port on the transmitter to a serial port on the computer.
5. Connect a Cat 5e/6 cable to the KE6900T / KE6940T's LAN port.
6. Plug the power adapter into an AC source, and plug the other end into the KE6900T / KE6940T's power jack.
7. On the receiver side, plug the mouse, keyboard, DVI monitor, microphone, and speakers into the ports on the console section of the KE6900R / KE6940R.**
8. Connect the other end of the Cat 5e/6 cable to the KE6900R / KE6940R's LAN port.
9. Plug the second power adapter into an AC source, and plug the other end into the KE6900R / KE6940R's power jack.
10. Power on the computer.

Note: 1. If installing the KE6940 with two DVI monitors, connect the second DVI monitor via a DVI cable into the additional ports on the KE6940 and computer.

Note: The diagram above shows KE6900T and KE6900R. The KE6940 installation is the same except that an additional DVI monitor can be connected at each end for a dual-display setup.

KE6900 / KE6940 Point-to-Point Installation 2 of 2



Note: The serial port on the transmitter (shown above) connects to the computer, while the serial port on the receiver (not shown) connects to a serial device (optional).

KE6900A / KE6940A Point-to-Point Installation

Setting up the KE6900A / KE6940A system in a point-to-point configuration is simply a matter of plugging in the cables.


Note: In a point-to-point configuration, no administrator setup is required.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:

1. (Optional) Connect a grounding wire between the extender's grounding terminal and a suitable grounded object.
2. On the transmitter side, plug the mouse, keyboard, DVI monitor, and serial devices into the ports on the console section of the transmitter (KE6900AT/KE6940AT)¹.
3. Connect the DVI-D cable and the USB 2.0 Type-A to Type-B cable provided with this package into the KVM ports on the front of the transmitter.
4. Connect the other end of the USB DVI-D KVM cable into the keyboard, video, mouse, speaker, and microphone ports on the computer.
5. For control of serial devices, connect the RS-232 port on the front of the transmitter to a serial port on the computer.
6. Connect a Cat 5e/6 cable to the transmitter's LAN port.
7. Plug the mouse, keyboard, DVI monitor, and serial devices into the ports on the console section of the receiver (KE6900AR/KE6940AR)².
8. Connect the other end of the Cat 5e/6 cable to the receiver's LAN port.
9. Instead of connecting through the LAN ports, you can choose to connect the extenders through the SFP slots. To do so, plug SFP modules into the transmitter and receiver's SFP slots, then connect each end of Gigabit Ethernet (GbE) optical fiber between the SFP modules³.
10. Plug the power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks respectively.
11. (Optional) For power redundancy, plug the second power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks.
12. Power on the computer.


- Note:**
1. If installing the KE6940A with two DVI monitors, connect the second DVI monitor via a DVI cable into the additional ports on the KE6940 and computer.
 2. A keyboard or mouse with special functions may be required to be connected using the USB ports for the functions to work (see *USB Mode*, page 224).
 3. The SFP module 2A-136G / 2A-137G is sold separately. Contact your ATEN dealer for product information.

KE6900A / KE6940A Point-to-Point Installation 1 of 2



Note: The diagram above shows KE6900AT and KE6900AR. The KE6940A installation is the same except that an additional DVI monitor can be connected at each end for a dual-display setup.

KE6900A / KE6940A Point-to-Point Installation 2 of 2



Note: The serial port on the transmitter (shown above) connects to the computer, while the serial port on the receiver (not shown) connects to a serial device (optional).

KE6900AiT / KE6940AiT Point-to-Point Installation

Setting up the KE6940AiT system in a point-to-point configuration is simply a matter of plugging in the cables. Since this is a transmitter-receiver setup, the below steps are demonstrated using a KE6940AR.

Note: In a point-to-point configuration, no administrator setup is required.

It is highly recommended to mount the AiT unit(s) onto a system rack or wall, and avoid a stacked setup to ensure proper ventilation.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:


1. (Optional) Connect a grounding wire between the extenders' grounding terminal and a suitable grounded object.
2. On the transmitter side, plug the mouse, keyboard, DVI monitor(s), and serial devices into the ports on the console section of the transmitter (KE6900AiT/KE6940AiT).
3. Connect the KVM cable (DVI-D, USB, audio) and the DVI-D cable (KE6940AiT only) provided into the KVM ports on the front of the transmitter.
4. Connect the other end of the KVM cable (DVI-D, USB, audio) and the DVI-D cable (KE6940AiT only) into the keyboard, video, mouse, speaker, and microphone ports on the computer.
5. For control of serial devices, connect the RS-232 port on the front of the transmitter to a serial port on the computer.
6. Plug the mouse, keyboard, DVI monitor(s), and serial devices into the ports on the console section of the receiver (KE6940AR is used as the example here)¹.
7. Connect a Cat 5e/6 cable to the transmitter's LAN port.
8. Connect the other end of the Cat 5e/6 cable to the receiver's LAN port.
9. To allow access to the web interface or CCVSR recording, use an Ethernet cable to connect the unit's Ethernet port to a network switch.
10. Instead of connecting through the LAN ports, you can choose to connect the extenders through the SFP slots. To do so, plug SFP modules into the transmitter and receiver's SFP slots, then connect each end of Gigabit Ethernet (GbE) optical fiber between the SFP modules².

11. Plug the power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks respectively.
12. (Optional) For power redundancy, connect another power adapter (available for purchase separately) to the power jack of each extender and make sure the adapter is powered.
13. Power on the computer.

Note: 1. For the advanced features of connecting a keyboard or mouse with special functions, see *USB Mode*, page 224.


2. The SFP module 2A-136G / 2A-137G is sold separately. Contact your ATEN dealer for product information.

KE6940AiT Point-to-Point Installation 1 of 2



Note: The diagram above shows a KE6940AiT installation with KE6940AR. The KE6900AiT installation is the same except with one less DVI monitor.

KE6940AiT Point-to-Point Installation 2 of 2



Note: The serial port on the transmitter (shown above) connects to the computer, while the serial port on the receiver (not shown) connects to a serial device (optional).

KE6910 / KE6912 Point-to-Point Installation

Setting up the KE6910 / KE6912 system in a point-to-point configuration is simply a matter of plugging in the cables.

Note: In a point-to-point configuration, no administrator setup is required.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:


1. (Optional) Use the grounding wire to connect the extender's grounding terminal to a suitable grounded object.
2. On the transmitter side, plug the mouse, keyboard, DVI-D monitor, serial devices, microphone, and speakers into the ports on the console section of the KE6910T / KE6912T.
3. Connect the USB DVI-D KVM cable provided with this package into the KVM ports and the audio ports on the front of the KE6910T / KE6912T.
4. Connect the other end of the USB DVI-D KVM cable into the keyboard, video, mouse, speaker, and microphone ports on the computer.
5. For control of serial devices, connect the RS-232 port on the front of the transmitter to a serial port on the computer.
6. Connect a Cat 5e/6 cable to the KE6910T / KE6912T's LAN port.
7. On the receiver side, plug the mouse, keyboard, DVI-D monitor, serial devices, microphone, and speakers into the ports on the console section of the KE6910R / KE6912R.
8. Connect the other end of the Cat 5e/6 cable to the KE6910R / KE6912R's LAN port.
9. Instead of connecting through the LAN ports, you can choose to connect the KE6910 / KE6912 through the SFP slots. To do so, plug SFP modules into the transmitter and receiver's SFP slots, then connect each end of Gigabit Ethernet (GbE) optical fiber between the SFP modules.*
10. Plug the power adapters into AC sources with the power cords; then plug the other ends into the transmitter and receiver's power jacks respectively. The KE6912 supports Power over Ethernet (PoE), thus the power can be supplied through PoE network switch, without the need of a power adapter.

11. (Optional) For power redundancy, plug the second power adapters into AC sources with the power cords; then plug the other ends into the transmitter and receiver's power jacks.**
12. Power on the computer.

Note: 1. The SFP module 2A-136G / 2A-137G is sold separately. Contact your ATEN dealer for product information.


2. Available for KE6910T and KE6910R only. The second power adapter with the power cord is sold separately. Contact your ATEN dealer for product information. Power redundancy for KE6912T and KE6912R can be achieved with the PoE function.

KE6910 / KE6912 Point-to-Point Installation 1 of 2



KE6910 / KE6912 Point-to-Point Installation 2 of 2

KE6910T (Front)



KE6920 / KE6922 Point-to-Point Installation

Setting up the KE6920 / KE6922 system in a point-to-point configuration is simply a matter of plugging in the cables.


Note: In a point-to-point configuration, no administrator setup is required.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:

1. (Optional) Connect a grounding wire between the extender's grounding terminal and a suitable grounded object.
2. On the transmitter side, plug the mouse, keyboard, DVI monitor, and serial devices into the ports on the console section of the transmitter (KE6920T/KE6922T).
3. Connect the DVI-D cable and the USB 2.0 Type-A to Type-B cable provided with this package into the KVM ports on the front of the transmitter.
4. Connect the other end of the USB DVI-D KVM cable into the keyboard, video, mouse, speaker, and microphone ports on the computer.
5. For control of serial devices, connect the RS-232 port on the front of the transmitter to a serial port on the computer.
6. Connect a Cat 5e/6 cable to the transmitter's LAN port.
7. Plug the mouse, keyboard, DVI monitor, and serial devices into the ports on the console section of the receiver (KE6920R/KE6922R).
8. Connect the other end of the Cat 5e/6 cable to the receiver's LAN port.
9. Instead of connecting through the LAN ports, you can choose to connect the extenders through the SFP slots. To do so, plug SFP modules into the transmitter and receiver's SFP slots, then connect each end of Gigabit Ethernet (GbE) optical fiber between the SFP modules¹.
10. Plug the power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks respectively.
11. (Optional) For power redundancy, plug the second power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks².
12. Power on the computer.


- Note:** 1. The SFP module 2A-136G / 2A-137G is sold separately. Contact your ATEN dealer for product information.
2. Available for KE6920T and KE6920R only. The second power adapter with the power cord is sold separately. Contact your ATEN dealer for product information. Power redundancy for KE6922T and KE6922R can be achieved with the PoE function.

KE6920 / KE6922 Point-to-Point Installation 1 of 2



KE6920 / KE6922 Point-to-Point Installation 2 of 2

KE6920T (Front)



KE8950 / KE8952 Point-to-Point Installation

Setting up the KE8950 / KE8952 system in a point-to-point configuration is simply a matter of plugging in the cables.


Note: In a point-to-point configuration, no administrator setup is required.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:

1. On the transmitter side, plug the mouse, keyboard, HDMI monitor, microphone, and speakers into the ports on the console section of the KE8950T / KE8952T. Each port is marked with an appropriate icon to indicate its function.
2. Connect the USB HDMI KVM cable provided into the KVM ports on the front of the KE8950T / KE8952T.
3. Connect the other end of the USB HDMI KVM cable into the keyboard, video, mouse, speaker, and microphone ports on the computer.
4. For control of serial devices, connect the RS-232 serial port on the transmitter to a serial port on the computer.
5. Connect a Cat 5e/6 cable to the KE8950T / KE8952T's LAN port, or a Gigabit Ethernet (GbE) optical fiber cable to the SFP port.
6. Plug the power adapter into an AC source, and plug the other end into the KE8950T / KE8952T's power jack.*
7. On the receiver side, plug the mouse, keyboard, HDMI monitor, microphone, and speakers into the ports on the console section of the KE8950R / KE8952R.
8. Connect the other end of the Cat 5e/6 cable to the KE8950R / KE8952R's LAN port; or the other end of the Gigabit Ethernet (GbE) optical fiber cable to the SFP port.
9. Plug the second power adapter into an AC source, and plug the other end into the KE8950R / KE8952R's power jack.*
10. Power on the computer.


Note: Power adapters are not provided with KE8952 units. Please contact your ATEN dealer to purchase additional power adapters.

KE8950 / KE8952 Point-to-Point Installation 1 of 2



Note: Power adapters are not provided with the KE8952. Please contact your ATEN dealer to purchase additional power adapters, or use the Power over Ethernet (PoE) feature to supply power to the KE8952.

KE8950 / KE8952 Point-to-Point Installation 2 of 2



Note: The serial port on the transmitter (shown above) connects to the computer, while the serial port on the receiver (not shown) connects to a serial device (optional).

KE6900ST Point-to-Point Installation

The KE6900ST DVI KVM over IP Extender Lite is a cost-saving alternative for installations with transmitters that don't need a local console or audio transmission but want the connectivity features of advanced KE models.


Setting up the KE6900ST system in a point-to-point configuration is simply a matter of plugging in the cables. Make sure that all equipment is powered off. Refer to the installation diagrams on the next page and do the following:

1. Connect the USB DVI-D KVM cable (provided with this package) to the USB and DVI-D ports on the front of the KE6900ST.
2. Connect the other end of the USB DVI-D KVM cable to USB and DVI video ports on the computer.
3. For control of serial devices, connect the RS-232 serial port on the KE6900ST to a serial port on the computer.
4. Plug the power adapter (provided with this package) into an AC source, and plug the other end into the KE6900ST's power jack.
5. Connect a Cat 5e/6 cable to the KE6900ST's LAN port.
6. Connect the other end of the Cat 5e/6 cable to the KE69x0R's* LAN port.
7. On the receiver side, plug the mouse, keyboard, and DVI monitor into the ports on the console section of the KE69x0R.*
8. Plug the second power adapter into an AC source, and plug the other end into the KE69x0R's power jack.
9. Power on the computer.

Note: KE69x0R units are required and sold separately.

Setting up a LAN Installation

Setting up the KE6900ST on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE69x0 devices on the same TCP/IP LAN. To set up a LAN installation, simply connect the Cat 5e/6 cable (in step 5 above) to the network instead of directly between two KE69x0 devices and see *KE6900 / KE6940 LAN Installation*, page 110 for details.



KE8900S Point-to-Point Installation


The KE8900S Slim HDMI KVM over IP Extender is a cost-saving alternative for installations that don't need a local console or audio transmission but want the connectivity features of advanced KE models.

Setting up the KE8900S system in a point-to-point configuration is simply a matter of plugging in the cables. Make sure that all equipment is powered off. Refer to the installation diagrams on the next page and do the following:

1. (Optional) Connect the grounding terminals of KE8900ST and KE8900SR to a suitable grounded object using grounding wires.
2. Connect the USB HDMI KVM cable provided between a computer and the KE8900ST. Please use the USB Type-B end of the USB HDMI KVM cable for the KE8900ST as it has a USB Type-B port.
3. Connect a Cat 5e/6 cable between the LAN ports of KE8900ST and KE8900SR.
4. Connect a USB mouse/keyboard to the front panel of the KE8900SR and HDMI monitor to the rear panel of the KE8900SR.
5. Plug the power adapters into power sockets, and plug the other ends respectively into the KE8900ST and KE8900SR's power jacks. For KE8900ST, you can choose to use the terminal block for power input. Insert DC + and - wires (DC 12 to 48 V) to the terminal block according to the icon.*
6. (Optional) For control of serial devices, connect the RS-232 serial port on the KE8900ST to a serial port on the computer.
7. Power on the computer.

Setting up a LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE Series devices on the same TCP/IP LAN. To set up a LAN installation, simply connect the Cat 5e/6 cable (in step 3) to the network instead of directly between two KE Series devices. As an example, please refer to *KE6900 / KE6940 LAN Installation*.



KE9900ST Point-to-Point Installation

The KE9900ST DisplayPort KVM over IP Extender Lite is a cost-saving alternative for installations with transmitters that don't need a local console or audio transmission but want the connectivity features of advanced KE models.

Setting up the KE9900ST system in a point-to-point configuration is simply a matter of plugging in the cables. Make sure that all equipment is powered off. Refer to the installation diagrams on the next page and do the following:


1. (Optional) Connect the grounding terminal of the KE9900ST to a suitable grounded object using a grounding wire.
2. Connect the supplied DisplayPort cable between the DisplayPort ports of the computer and the KE9900ST.
3. With the supplied USB 2.0 Type-A to Type-B cable, connect the USB Type-A end to the computer and the Type-B end to the KE9900ST.
4. (Optional) For control of serial devices, connect the RS-232 serial port on the KE9900ST to a serial port on the computer.
5. Connect a Cat 5e/6 cable between the LAN ports of KE9900ST and the receiver unit* (e.g. KE8900SR).
6. Connect a USB mouse/keyboard and HDMI monitor to their respective ports on the KE8900SR.
7. Power the KE8900SR (e.g. plugging power adapter between the unit and a power socket).
8. Plug the power adapter into a power socket, and plug the other end into KE9900ST's power jack. Alternatively, you can choose to use the terminal block for power input. Insert DC + and - wires (DC 12 to 48 V) to the terminal block according to the icon.
9. Power on the computer.

Note: A KE Series receiver unit is required and sold separately.

Setting up a LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE Series devices on the same TCP/IP LAN. To set up a LAN installation, simply connect the Cat 5e/6 cable (in step 5) to the network instead

of directly between two KE Series devices. As an example, please refer to *KE6900 / KE6940 LAN Installation*.



KE9950 / KE9952 Point-to-Point Installation

Setting up the KE9950 / KE9952 system in a point-to-point configuration is simply a matter of plugging in the cables.

Note: In a point-to-point configuration, no administrator setup is required.

Make sure that all equipment is powered off. Refer to the installation diagrams on the next two pages and do the following:

1. (Optional) Connect the extender's grounding terminal to a suitable grounded object using the grounding wire.
2. On the transmitter side, plug the mouse, keyboard, DisplayPort monitor, serial devices, microphone, and speakers into the ports on the console section of the KE9950T / KE9952T.
3. Connect the DisplayPort cable, the USB 2.0 Type-A to Type-B cable provided with this package, and audio cables into the KVM ports on the front of the KE9950T / KE9952T.
4. Connect the other end of the DisplayPort cable, the USB 2.0 Type-A to Type-B, and audio cables into the keyboard, video, mouse, speaker, and microphone ports on the computer.
5. For control of serial devices, connect the RS-232 port on the front of the transmitter to a serial port on the computer.
6. Connect a Cat 5e/6 cable to the KE9950T / KE9952T's LAN port.
7. On the receiver side, plug the mouse, keyboard, DisplayPort monitor, serial devices, microphone, and speakers into the ports on the console section of the KE9950R / KE9952R.
8. Connect the other end of the Cat 5e/6 cable to the KE9950R / KE9952R's LAN port.
9. Instead of connecting through the LAN ports, you can choose to connect the KE9950 / KE9952 through the SFP slots. To do so, plug SFP modules into the transmitter and receiver's SFP slots, then connect each end of Gigabit Ethernet (GbE) optical fiber between the SFP modules.*
10. Plug the power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's power jacks, respectively. The KE9952 supports Power over Ethernet (PoE) where power can be supplied through a PoE network switch instead of using a power adapter.


11. (Optional) For power redundancy, plug the second power adapters into AC sources with the power cords and plug the other ends into the transmitter and receiver's second power jacks.**

12. Power on the computer.

Note: 1. The SFP module 2A-136G / 2A-137G is sold separately. Contact your ATEN dealer for product information.

2. Available for KE9950T and KE9950R only. The second power adapter with the power cord is sold separately. Contact your ATEN dealer for product information. Power redundancy for KE9952T and KE9952R can be achieved with the PoE function.


KE9950 / KE9952 Point-to-Point Installation 1 of 2



Note: Power adapters are not provided with the KE9952. Please contact your ATEN dealer to purchase additional power adapters, or use the Power over Ethernet (PoE) feature to supply power to the KE9952.

KE9950 / KE9952 Point-to-Point Installation 2 of 2

KE9950T (Front)



Note: The serial port on the Transmitter (shown above) connects to the computer; the serial port on the Receiver (not shown) connects to a serial device (optional).

KE6900 / KE6940 LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE6900 / KE6900ST / KE6940 devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.


Make sure that all equipment is powered off. Refer to the installation diagram on the following page, and do the following:

1. On the Transmitter side, plug the mouse, keyboard, DVI monitor, microphone, and speakers into the ports on the console section of the KE6900T / KE6940T.* Each port is marked with an appropriate icon to indicate itself.
2. Connect the USB KVM cable provided to the KVM ports on the front of the KE6900T / KE6940T.


3. Connect the other end of the USB KVM cable to the keyboard, video, mouse, speaker, and microphone ports on the computer.
4. For control of serial devices, connect the RS-232 serial port on the transmitter to a serial port on the computer.
5. Use a Cat 5e/6 cable to connect the KE6900T / KE6940T's LAN port to the local area TCP/IP network.
6. Plug the power adapter into an AC source, and plug the other end into the KE6900T / KE6940T's power jack.
7. On the receiver side, plug the mouse, keyboard, DVI monitor, microphone, and speakers into the ports on the console section of the KE6900R / KE6940R.**
8. Use a Cat 5e/6 cable to connect the KE6900R / KE6940R's LAN port to the local area TCP/IP network.
9. Plug the second power adapter into an AC source, and plug the other end into the KE6900R / KE6940R's power jack.
10. Use the OSD on the receiver to configure the network settings for both devices (See *Network Configuration*, page 133).
11. Repeat these steps for each Transmitter and Receiver you wish to install on the network.
12. Power on the computer(s).

-
- Note:** 1. If installing the KE6940 with two DVI monitors, connect the second DVI monitor via a DVI cable into the additional ports on the KE6940 and computer.
2. For USB keyboards / mice with advanced function designs, see *USB Mode*, page 224.
-

KE6900 / KE6940 Network Installation Diagram 1 of 2



Note: The diagram above shows KE6900T and KE6900R. The KE6940 installation is the same except that an additional DVI monitor can be connected at each end for a dual-display setup.

KE6900 / KE6940 Network Installation Diagram 2 of 2

Note: The serial port on the transmitter (shown above) connects to the computer, while the serial port on the receiver (not shown) connects to a serial device (optional).

KE6900A / KE6940A LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple extender devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:


- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ The unit supports network redundancy. Where both LAN and SFP ports are connected, a network redundancy is established. Please note that if you use copper SFP modules, the module has to be removed for the unit to switch to the LAN port's network.
- ◆ For USB keyboards / mice with advanced function designs, see *USB Mode*, page 224.

Make sure that all equipment is powered off before the installation.

The installation is similar to that of *KE6900A / KE6940A Point-to-Point Installation* on page 86, with the difference in connecting the transmitter and the receiver to a local area TCP/IP network. Refer to the diagrams on the following page and connect accordingly.


Repeat these steps for each Transmitter and Receiver you wish to install on the network, and then power on the computer(s).

KE6900A / KE6940A Network Installation Diagram 1 of 2



KE6900A / KE6940A Network Installation Diagram 2 of 2

KE6900AT (Front)



KE6900AiT / KE6940AiT LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple extender devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ The unit supports network redundancy. Where both LAN and SFP ports are connected, a network redundancy is established. Please note that if you use copper SFP modules, the module has to be removed for the unit to switch to the LAN port's network.
- ◆ For USB keyboards / mice with advanced function designs, see *USB Mode*, page 224.
- ◆ Make sure that all equipment is powered off before the installation.


The installation is similar to that of *KE6900AiT / KE6940AiT Point-to-Point Installation* on page 89, with the difference in connecting the transmitter and the receiver to a local area TCP/IP network. Refer to the diagrams on the following page and connect accordingly.

Repeat these steps for each Transmitter and Receiver you wish to install on the network then power on the computer(s).

Note: If you wish to use CCVSR and/or remote access with WinClient/JavaClient, you will still need to connect the Internet Port of the KE6900AiT / KE6940AiT to an office LAN.


It is highly recommended to mount the AiT unit(s) onto a system rack or wall, and avoid stacked setup to ensure proper ventilation.

KE6900AiT / KE6940AiT Network Installation Diagram 1 of 2



KE6900AiT / KE6940AiT Network Installation Diagram 2 of 2

KE6940AiT (Front)



KE6910 / KE6912 LAN Installation


Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE6910 / KE6912 devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ Make sure that all equipment is powered off before the installation.


The installation is similar to that of *KE6910 / KE6912 Point-to-Point Installation* on page 92, with the difference in connecting the transmitter and the receiver to a local area TCP/IP network. Refer to the diagrams on the following page and connect accordingly.

Repeat these steps for each Transmitter and Receiver you wish to install on the network then power on the computer(s).

KE6910 / KE6912 Network Installation Diagram 1 of 2

KE6910 / KE6912 Network Installation Diagram 2 of 2

KE6910T (Front)



KE6920 / KE6922 LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE6920 / KE6922 devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ Make sure that all equipment is powered off before the installation.

The installation is similar to that of *KE6920 / KE6922 Point-to-Point Installation* on page 95, with the difference in connecting the transmitter and the receiver to a local area TCP/IP network. Refer to the diagrams on the following page and connect accordingly.


Repeat these steps for each Transmitter and Receiver you wish to install on the network then power on the computer(s).

Note: 1. The unit supports network redundancy. Where both LAN and SFP ports are connected, a network redundancy is established. Please note


that if you use copper SFP modules, the module has to be removed for the unit to switch to the LAN port's network.

2. The KE6922's LAN port provides Power over Ethernet (PoE) functionality which supplies power to the unit when connected to a compatible PoE network switch.
3. Power adapters are not provided with KE6922 units. Please contact your ATEN dealer to purchase additional power adapters, or use the Power over Ethernet (PoE) feature to supply power to KE6922 units.
4. For USB keyboards / mice with advanced function designs, see *USB Mode*, page 224.

KE6920 / KE6922 Network Installation Diagram 1 of 2



KE6920 / KE6922 Network Installation Diagram 2 of 2



KE8950 / KE8952 LAN Installation

Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE8950 / KE8952 devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ Make sure that all equipment is powered off.


Refer to the installation diagram on the following page, and do the following:

1. On the transmitter side, plug the mouse, keyboard, HDMI monitor, microphone and speakers into the ports on the console section of the KE8950T / KE8952T. Each port is marked with an appropriate icon to indicate itself.
2. Connect the USB KVM cable provided to the KVM ports on the front of the KE8950T / KE8952T.
3. Connect the other end of the USB KVM cable to the keyboard, video, mouse, speaker, and microphone ports on the computer.


4. For control of serial devices, connect the RS-232 serial port on the Transmitter to a serial port on the computer.
5. Connect a Cat 5e/6 cable to the LAN port, or a Gigabit Ethernet (GbE) optical fiber cable to the SFP port* to connect the KE8950T / KE8952T to the local area TCP/IP network.**
6. Plug the power adapter into an AC source, and plug the other end into the KE8950T / KE8952T's power jack.***
7. On the Receiver side, plug the mouse, keyboard, HDMI monitor, microphone, and speakers into the ports on the console section of the KE8950R / KE8952R.****
8. Connect a Cat 5e/6 cable to the LAN port, or a Gigabit Ethernet (GbE) optical fiber cable to the SFP port* to connect the KE8950R / KE8952R to the local area TCP/IP network.**
9. Plug the power adapter into an AC source, and plug the other end into the KE8950R / KE8952R's power jack.***
10. Use the OSD on the receiver to configure the network settings for both devices (See *Network Configuration*, page 133).
11. Repeat these steps for each Transmitter and Receiver you wish to install on the network.
12. Power on the computer(s).

-
- Note:**
1. The unit supports network redundancy. Where both LAN and SFP ports are connected, a network redundancy is established. Please note, though, that if you use copper SFP modules, the module has to be removed for the unit to switch to the LAN port's network.
 2. The KE8952's LAN port provides Power over Ethernet (PoE) functionality which supplies power to the unit when connected to a compatible PoE network switch.
 3. Power adapters are not provided with KE8952 units. Please contact your ATEN dealer to purchase additional power adapters, or use the Power over Ethernet (PoE) feature to supply power to KE8952 units.
 4. For USB keyboards / mice with advanced function designs, see *USB Mode*, page 224.
-

KE8950 / KE8952 Network Installation Diagram 1 of 2



Note: Power adapters are not provided with KE8952 units. Please contact your ATEN dealer to purchase additional power adapters, or use the Power over Ethernet (PoE) feature to supply power to KE8952 units.

KE8950 / KE8952 Network Installation Diagram 2 of 2

Note: The serial port on the Transmitter (shown above) connects to the computer; the serial port on the Receiver (not shown) connects to a serial device (optional).

KE9950 / KE9952 LAN Installation


Setting up the units on a network allows point-to-point, point-to-multipoint, and multipoint-to-multipoint computer to console operation by connecting multiple KE9950 / KE9952 devices on the same TCP/IP LAN. Prior to the setup, we recommend laying out the plans for your KE installation using our performance guide (see *Keys to Network Performance*, page 391).

A few points to note during your setup:

- ◆ The units are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
- ◆ In a network setup with multiple units, each Transmitter and Receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
- ◆ We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between KE Series devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
- ◆ In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
- ◆ If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
- ◆ To get the best performance, we suggest creating a private network for KE devices, as they are bandwidth-intensive devices.
- ◆ Make sure that all equipment is powered off.


The installation is similar to that of *KE6900 / KE6940 Point-to-Point Installation* on page 83, with the difference in connecting the transmitter and the receiver to a local area TCP/IP network. Refer to the diagrams on the following page and connect accordingly.

Repeat these steps for each Transmitter and Receiver you wish to install on the network then power on the computer(s).

KE9950 / KE9952 Network Installation Diagram 1 of 2

KE9950 / KE9952 Network Installation Diagram 2 of 2

KE9950T (Front)



Network Configuration

This section provides instructions to configure the network settings with a fixed IP address, subnet mask, and default gateway. To use the **IP Installer** to configure the IP address, see *IP Installer*, page 378.

-
- Note:**
1. Both devices are preconfigured with factory-default network settings. If you install only one set of KE Series units, you do not need to change these default network settings. See *Default IP Addresses*, page 134, for further details.
 2. In a network setup with multiple units, each transmitter and receiver must be configured with a unique IP address. See *Network Configuration*, page 133, for further details.
 3. We recommend using 1000-Mbps Gigabit Ethernet switches (wire speeds, non-blocking with 1 Gbps / 1.5 Mpps performance per port) between devices installed on different LAN segments. 10/100 Mbps switches might cause poor performance.
 4. In multipoint configurations, the IGMP and flow control function of your network switches/hubs must be enabled to avoid the deterioration of data throughput. To ensure functionality use a layer 3 switch that supports IGMP queries.
 5. If your network uses cascaded switches, please check to ensure the data throughput is sufficient.
 6. To get the best performance, we suggest creating a private network for KE device, as they are bandwidth-intensive devices.
-

To configure the network settings, do the following:

1. Set up the hardware and connect the transmitter and receiver to the local area network (see *KE6900 / KE6940 LAN Installation*, page 110, or *KE8950 / KE8952 LAN Installation*, page 126).
2. From the receiver, tap **[Scroll Lock]** twice to invoke the OSD.
3. Select the *Receiver* or *Transmitter* from the sidebar menu.
4. Enter the password and click **Configure**.
The default password is: password.
5. From the *Network* tab, select **Set IP address manually** and enter the following:

- ◆ *IP Address* — sets the IP address for the KE device. Key in a valid unique IP address.

Note: See *Default IP Addresses*, page 134, for the preconfigured factory-default settings.

- ◆ *Subnet Mask* — sets the subnet mask for the KE device. Key in a valid subnet mask value.

Note: The default setting is 255.255.255.0

- ◆ *Default Gateway* — sets the default gateway for the KE device. Key in a valid default gateway.

6. Click **Save**.

Exit OSD

To exit the OSD, press **[Esc]** on the keyboard, click **Logout**; tap **[Scroll Lock]** twice, or return to the OSD main page and press the front panel OSD pushbutton (receiver only).

At this point, the receiver can connect to the transmitter to access the remote computer (see *OSD Matrix Mode*, page 158 for instructions).

Default IP Addresses

The preconfigured factory-default IP addresses for the KE Series devices are as follows:

Transmitters – 192 . 168 . 0 . 61

Receivers – 192 . 168 . 0 . 60

KE I/O Ports

The following table provides the I/O port use of KE Series devices.

| Device | Port | Number |
|-------------------------|------------------|-------------------------------|
| KE Matrix Manager (TCP) | HTTP | 8080 |
| | HTTPS | 8443 |
| | Device TCP | 9110 |
| | CLI | 9111 |
| | Redundancy | 9120 |
| | Database Service | 1527 |
| KE Matrix Manager (UDP) | Port | 9110 |
| | Broadcast | 9000 |
| KE TX/RX Device (TCP) | Manager | 9110 |
| | Service | 9000 |
| | Telnet | 23 |
| | SSH | 22 |
| KE TX Device (TCP) | VM | 9001 |
| | vUSB | 9002 |
| | Serial | 9003 |
| | USB Access Mode | 9009 |
| KE RX Device (TCP) | CLI | 9130 |
| KE TX/RX Device (UDP) | Manager | 9110 |
| | Service | 9000 |
| | Array Mode | 9120 |
| | Video | 0xFE00(65024) - 0xFE03(65027) |
| | Audio | 0xFE04(65028) - 0xFE05(65029) |

LED Display

Both the Transmitter and Receiver have front panel LEDs to indicate their operating and power status, as explained in the table below:

| LED | Indication |
|--------|---|
| LAN | <p>This LED indicates the network status.</p> <ul style="list-style-type: none">◆ Lights when connected to the LAN and blinks when the Ethernet connection is active:<ul style="list-style-type: none">◆ Orange: 10 Mbps◆ Orange + Green: 100 Mbps◆ Green: 1000 Mbps◆ Off when not connected to the LAN. |
| Power | <ul style="list-style-type: none">◆ Lights blue when the unit is powered on.◆ OFF when power is off. |
| Local | <ul style="list-style-type: none">◆ Lights green to Indicate the Transmitter has KVM focus of the computer |
| Remote | <ul style="list-style-type: none">◆ Lights green to Indicate the Receiver has KVM focus of the computer. |

Chapter 3

OSD Operation

Overview

This chapter provides instructions to configure and operate KE Series devices using the local On Screen Display (OSD). To configure the network settings with the OSD, see *Network Configuration*, page 133.

Invoking the OSD

The On Screen Display (OSD) is a keyboard/mouse-driven application on the receiver used to configure the transmitter and receiver settings. Once the receiver has discovered the transmitter over a network* or Ethernet cable connection, you can use the OSD on the receiver to configure the transmitter.

To invoke the OSD, press the OSD pushbutton on the front of the receiver, or from the keyboard tap the **Scroll Lock** key twice. The *OSD* main page will appear (see *Press the Esc key to cancel.*, page 139).

To exit the OSD, press **[Esc]** on the keyboard; click **Logout**; tap the **Scroll Lock** key twice; or return to the OSD main page and press the OSD pushbutton on the front of the receiver. The OSD disappears and the computer desktop screen or the System Login prompt is displayed.

-
- Note:**
1. For the Receiver to discover the Transmitter over a network, both must be on the same subnet of the LAN.
 2. To change the OSD hotkeys, see page 157.
 3. If the keyboard/mouse won't work when the OSD is invoked, see *USB Mode*, page 224.
-

Touch Screen Calibration

If you're using a touch screen monitor and the OSD appears off center, you can use the blinking **+** at each corner to adjust the position of the OSD.

OSD Hotkeys

The OSD hotkeys navigate the Receiver's OSD screens. The hotkeys work after logging in from the *System Login* screen (see page 158) but not the *OSD Configuration* screen. Pressing a hotkey will immediately take you to the corresponding OSD screen.

| Hotkey | OSD Screen | Page |
|--------|-------------------------------------|------|
| [F1] | Connections Page 1 in List Mode | 159 |
| [F2] | Connections Page 1 in Array Mode | 162 |
| [F3] | Profile Page 1 | 164 |
| [F5] | Push Content Page 1 | 165 |
| [F6] | Pull Content Page 1 | 167 |
| [F7] | Receiver > Properties | 142 |
| [F8] | User Preferences | 157 |
| [F9] | OSD Login Screen (logs user off) | 158 |

Users can also use the [Page Up] and [Page Down] keys to jump to the previous and next configuration pages.

Non-OSD Hotkeys

The following are the hotkeys that can be used without entering the OSD screen:

Reverting to Previous

Users can use the [Alt] + [K] hotkey to switch back to the transmitter channel previously accessed.

Note: For KE6900 / KE8950 / KE9950, [Alt] + [K] is not supported, but the same operation can be achieved by pressing [K] under Hotkey Mode.

Hotkey Mode

The Hotkey Mode allows users to quickly switch from one transmitter to another. Either press [Num Lock] + [-] or [Ctrl] + [F12] to enter Hotkey Mode.

Once in Hotkey Mode, you can use the [Next Arrow] and [Previous Arrow] keys to quickly switch between different transmitters. You can also press a

[Number Key] + [S] / [O] / [E] / [V] to access a transmitter based on its order number in Favorites (see page 160) by Share / Occupy / Exclusive / View Only mode.

Microphone Hotkey


You can switch microphone access between Receivers with a hotkey:

1. Press and hold down [Num Lock].
2. Press and release [-].
3. Release [Num Lock].
4. Press 1.

Press the **Esc** key to cancel.

OSD Interface

After you invoke the OSD, the main page appears:



Note: A password is required to enter the OSD. The default password is: *password*. For security purposes, the system will prompt you to change the password.

The OSD components are described in the table below:

| No. | Item | Description |
|-----|--------------------|--|
| 1 | Receiver | Select this radio button, enter a password, and click Configure to enter the <i>Receiver Configuration</i> screen. |
| 2 | Transmitter | Select this radio button, enter a password, and click Configure to enter the <i>Transmitter Configuration</i> screen. Note: Receiver must first discover the transmitter over the network for this option to be available. |
| 3 | User Preferences | Select this radio button, enter a password, and click Configure to enter the <i>User Preferences</i> screen. |
| 4 | About | About provides information regarding the OSD version. |
| 5 | Password | Input the OSD password and click Configure to enter the selected configuration screen. See note for password. |
| 6 | Configure | After entering a password, click Configure to enter the selected configuration screen. |
| 7 | Back to Connection | Clicking this button exits the OSD and returns you to the computer's video display. |

Logging in for the First Time

If you are the administrator, and are logging in for the first time (Receiver or User Preference radio button), use the default password (*password*).

For security purposes, the system will prompt you to change the login password immediately as shown below:



Click **OK** and change the password in the dialog box shown below:



Enter the password and confirm it in the next field. The password must be different from your original password.

Receiver Configuration

Select the *Receiver* radio button and click **Configure** to login, the Network tab appears:

The screenshot shows the KE OSD interface. On the left is a sidebar with a 'Receiver' radio button selected, and options for 'Transmitter', 'User Preferences', 'About', and 'Logout'. Below the sidebar is a 'Password' field and a 'Configure' button. The main area has three tabs: 'Network' (selected), 'Properties', and 'System'. Under the 'Network' tab, there is an 'IP Installer' section with three radio buttons: 'Enable' (selected), 'View Only', and 'Disabled'. Below that is a 'Network Configuration' section with two radio buttons: 'Obtain IP address automatically' and 'Set IP address manually' (selected). Under 'Set IP address manually', there are three input fields: 'IP Address' (192.168.0.71), 'Subnet Mask' (255.255.255.0), and 'Default Gateway' (192.168.0.254). A 'Save' button is located at the bottom right of the main area.

Network

The Network tab allows you to configure the Receiver's IP address settings:

| Item | Description |
|-----------------------|---|
| IP Installer | <p>The IP Installer is an external Windows-based utility for assigning an IP address to the device. Click one of the radio buttons to select Enable, View Only, or Disable for the IP Installer utility. See <i>IP Installer</i>, page 378 for instructions.</p> <p>Note: For security, we strongly recommend that you set this to <i>View Only</i> or <i>Disable</i> after each use.</p> |
| Network Configuration | <p>For dynamic IP address assignment (DHCP), select the Obtain IP address automatically radio button.</p> <p>To specify a fixed <i>IP Address</i>, <i>Subnet Mask</i>, and <i>Default Gateway</i> select the Set IP address manually radio button and fill in the fields with values appropriate for your network.</p> <p>For help configuring network settings with the OSD, see <i>Network Configuration</i>, page 133.</p> |

After entering the information, click **Save**.


Properties

There are two versions of Properties for KE Series, a Regular Version, and a Slim Version.

The *Properties* tab allows you to configure the Receiver’s settings.

Note: KE8900ST, KE8900SR, and KE9900ST are Slim Version.

Regular Version



| Item | Description |
|------------|--|
| Mode | <p>Select Extender mode for simple one-to-one (Transmitter to Receiver) setups that are managed with the Receiver’s OSD menu.</p> <p>Select Matrix mode to manage devices and connections from the KE Matrix Manager web GUI. This mode is for advanced administration of Transmitter to Receiver connections (see <i>Browser / Telnet Operation</i>, page 179).</p> |
| Properties | <p>If you selected Extender mode (above) set the Transmitter IP address for the Receiver’s Video, Audio, USB, and RS232 source signals.</p> <p>If you selected Matrix mode (above) the <i>Properties</i> will be grayed out. Use Channels to configure the Transmitter connections (see <i>Browser / Telnet Operation</i>, page 179).</p> |

| Item | Description |
|--------------------------|---|
| RS232 Settings | Configure the serial device settings for the Receiver. The default settings are: Baud Rate: 9600 Parity: None Data Bits: 8 bits Stop bits: 1 bit Flow Control: None |
| Enable Media | Select which type of media the Receiver can stream from Transmitters: Video, Audio, USB, and RS232. For KE8950 Series models, use the radio button to set the source of the audio signal: HDMI, Analog, or Both. |
| Manager Address | Set the IP address and Port number of the computer running the KE Matrix Manager software. The default port number is 9110. |
| Beeper | Check this box to allow the Receiver to beep when configuration changes are made to it. |
| Touch Screen Calibration | Use this button to calibrate the surface of a USB touch screen connected to the unit. When the calibration screen appears, touch the flashing + symbol at each corner until the process is complete. |

| Item | Description |
|----------------------------|--|
| USB Mode | <p>Select the type of USB device you will connect to the USB ports:</p> <p>Virtual Media: Only select this option if you are plugging a USB disk into the USB ports. This will give you the highest data transfer speeds but will not allow other USB devices plugged into the USB ports to work. When Receivers connected to the same transmitter mount or unmount USB disk drives, the keyboard and mouse operations will experience a brief delay. Transmitters can support up to 12 virtual media connections at the same time (keyboard/mouse included).</p> <p>vUSB (Generic USB device): Use this option to plug USB peripherals* into the USB ports. This option also allows a keyboard and mouse with special functions to plug into the USB ports for console use. Use this only if the special functions of the keyboard or mouse are required but do not work when plugged into the console ports. When the keyboard and mouse are plugged into the USB ports, they will not work within the OSD menus. To work within the OSD menus, the keyboard and mouse must be plugged into the console ports. KE6900ST/KE8900ST/KE9900ST transmitters do not support vUSB (Generic USB Device) mode. In this mode, KE6900/KE6940 transmitters supports up to 2 USB connections, KE8950/KE8952 transmitters support up to 5 USB connections (keyboard/mouse excluded), and KE8900SR supports 1 vUSB connection.</p> <p>Encryption: Check this box to encrypt USB drives plugged into the USB ports.</p> |
| Receiver Keyboard | <p>Use the Keyboard Country Code drop-down menu to select the Receiver's language keyboard for use in the OSD.</p> |
| Disable front video button | <p>You can enable or disable the function (select video mode or graphic mode) of the video pushbutton on the front of the receiver.</p> <p>Check Disable to disable.</p> <p>Uncheck Disable to enable.</p> |

After entering the information, click **Save**.

Slim Version

| Item | Description |
|----------------|--|
| Mode | <p>Select Extender mode for simple one-to-one (Transmitter to Receiver) setups that are managed with the Receiver's OSD menu.</p> <p>Select Matrix mode to manage devices and connections from the KE Matrix Manager web GUI. This mode is for advanced administration of Transmitter to Receiver connections (see <i>Browser / Telnet Operation</i>, page 179).</p> |
| Properties | <p>If you selected Extender mode (above) set the Transmitter IP address for the Receiver's Video, Audio, USB, and RS232 source signals.</p> <p>If you selected Matrix mode (above) the <i>Properties</i> will be grayed out. Use Channels to configure the Transmitter connections (see <i>Browser / Telnet Operation</i>, page 179).</p> |
| RS232 Settings | <p>Configure the serial device settings for the Receiver. The default settings are:</p> <p>Baud Rate: 9600</p> <p>Parity: None</p> <p>Data Bits: 8 bits</p> <p>Stop bits: 1 bit</p> <p>Flow Control: None</p> |
| Enable Media | <p>Select which type of media the Receiver can stream from Transmitters: Video, Audio, USB, and RS232. For KE8950 Series models, use the radio button to set the source of the audio signal: HDMI, Analog, or Both.</p> |

| Item | Description |
|--|---|
| Manager Address | Set the IP address and Port number of the computer running the KE Matrix Manager software. The default port number is 9110. |
| Beeper | Check this box to allow the Receiver to beep when configuration changes are made to it. |
| Touch Screen Calibration | Use this button to calibrate the surface of a USB touch screen connected to the unit. When the calibration screen appears, touch the flashing + symbol at each corner until the process is complete. |
| USB Mode | <p>Select the type of USB device you will connect to the USB ports:</p> <p>Virtual Media: Only select this option if you are plugging a USB disk into the USB ports. This will give you the highest data transfer speeds but will not allow other USB devices plugged into the USB ports to work. When Receivers connected to the same transmitter mount or unmount USB disk drives, the keyboard and mouse operations will experience a brief delay. Transmitters can support up to 12 virtual media connections at the same time (keyboard/mouse included).</p> <p>vUSB (Generic USB device): Use this option to plug USB peripherals* into the USB ports. This option also allows a keyboard and mouse with special functions to plug into the USB ports for console use. Use this only if the special functions of the keyboard or mouse are required but do not work when plugged into the console ports. When the keyboard and mouse are plugged into the USB ports, they will not work within the OSD menus. To work within the OSD menus, the keyboard and mouse must be plugged into the console ports. KE6900ST/KE8900ST/KE9900ST transmitters do not support vUSB (Generic USB Device) mode. In this mode, KE6900/KE6940 transmitters supports up to 2 USB connections; and KE8950/KE8952 transmitters support up to 5 USB connections (keyboard/mouse excluded).</p> <p>Encryption: Check this box to encrypt USB drives plugged into the USB ports.</p> |
| Receiver Keyboard | Use the Keyboard Country Code drop-down menu to select the Receiver's language keyboard for use in the OSD. |
| Video Quality (KE8900ST / 8900SR / 9900ST) | You can select video mode or graphic mode for the video quality, the Slim Version KE Series does not have a physical pushbutton on the front of the receiver. |

After entering the information, click **Save**.

System

The *System* tab allows you to configure the Receiver's general settings:

The screenshot shows the 'System' configuration page with the following sections:


- Device Information:**
 - Name: KE694DR
 - Description: (empty)
 - IP Address: 192.168.0.60
 - MAC Address: 00:10:74:a8:01:37
 - F/W Version: V1.1.106 (May 2 2014 13:39:47)
 - Serial Number: (empty)
- Reboot:**
 - Reset to factory default
 - Reboot button
- User Station Password Change:**
 - Enable
 - Old Password: (masked)
 - New Password: (masked)
 - Confirm Password: (masked)
 - Save button

| Item | Description |
|--------------------------|--|
| Device Information | Enter the Name , and Description of the Receiver. It also displays the <i>IP Address</i> , <i>MAC Address</i> , <i>F/W Version</i> , and <i>Serial Number</i> of the Receiver. |
| Reboot | Check the box and click Reboot to reset the Receiver's settings back to the factory default. All custom settings (but not the login information) will be lost. |
| Receiver Password Change | Check Enable to require a password for access to the Receiver's OSD configuration screen. Enter the Old Password, enter a New Password, and confirm the new password in the Confirm Password box. |

After entering the information, click **Save**.

Transmitter Configuration

When you select the *Transmitter* radio button and click **Configure** to login, the Network tab appears:



Network

The *Network* tab allows you to configure the Transmitter's IP address settings:

| Item | Description |
|-----------------------|---|
| IP Installer | The IP Installer is an external Windows-based utility for assigning an IP address to the device. Click one of the radio buttons to select Enable , View Only , or Disable for the IP Installer utility. See <i>IP Installer</i> , page 378 for instructions. Note: For security, we strongly recommend that you set this to <i>View Only</i> or <i>Disable</i> after each use. |
| Network Configuration | For dynamic IP address assignment (DHCP), select the Obtain IP address automatically radio button. To specify a fixed <i>IP Address</i> , <i>Subnet Mask</i> , and <i>Default Gateway</i> select the Set IP address manually radio button and fill in the fields with values appropriate for your network. For help configuring network settings with the OSD, see <i>Network Configuration</i> , page 133. |

After entering the information, click **Save**.

Properties

The *Properties* tab allows you to configure the Transmitter's extender settings:

The screenshot shows the 'Properties' tab of a configuration interface. It contains the following sections and settings:

- Mode:** Extender, Matrix
- RS232 Settings:**
 - Baud Rate: 9600
 - Data Bits: 8
 - Parity: None
 - Stop Bits: 1
 - Flow Control: None
- Properties:**
 - OS Language: English (US)
 - Port OS: WIN
 - Enable Multicast Video
 - Enable Multicast Audio
 - EDID Mode Selection: Manual, EDID
 - Enable Media:**
 - Video
 - Audio
 - USB
 - RS232
- Manager Address:**
 - Manager IP: 192.168.0.12
 - Manager Port: 9110
- Transmitter Video Setting:**
 - Video Type: 1: DVI-D + 2: DVI-D
 - Video Quality: 5
 - Color Depth: 24 bits
 - Background Refresh: Every 32 frames
 - Bandwidth Limit: Unlimited
- Beeper:** Enable

A 'Save' button is located at the bottom right of the interface.

| Item | Description |
|------|--|
| Mode | <p>Select Extender mode for simple one-to-one (Transmitter to Receiver) setups that are managed with the Receiver's OSD menu.</p> <p>Select Matrix mode to manage devices and connections from the KE Matrix Manager web GUI. This mode is for advanced administration of Transmitter to Receiver connections (see <i>Browser / Telnet Operation</i>, page 179).</p> |

| Item | Description |
|-----------------|--|
| Properties | <p>Port OS: Use the drop-down menu to select the operating system of the computer connected to the Transmitter.</p> <p>OS Language: Use the drop-down menu to select the operating system language of the computer connected to the Transmitter.</p> <p>Enable Multicast Video: Check this box to allow a broadcast of the Transmitter's video signal to be sent out to multiple Receivers.</p> <p>Enable Multicast Audio: Check this box to allow a broadcast of the Transmitter's audio signal to be sent out to multiple Receivers.</p> <p>EDID Mode Selection: EDID contains a display's basic information and is used by the source device to utilize the best resolution across different monitors. When <i>Manual</i> or <i>Remix</i> is selected, the Receiver's OSD will have a button allowing the local EDID setting to be configured for the connection. Select how you want the source device to acquire the display's EDID:</p> <ul style="list-style-type: none"> ◆ Default: EDID is set to the default ATEN configuration. This setting must be used when connecting KE6900 devices to KE8950 devices. ◆ Auto: Checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays. ◆ Manual: Manually set the EDID configuration from the Connections Page (see page 159). ◆ Remix: Manually checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays (see page 159). |
| Enable Media | Select which type of media the Transmitter can stream to Receivers: Video, Audio, USB, and RS232. |
| RS232 Settings | <p>Configure the serial device settings for the Transmitter. The default settings are:</p> <p>Baud Rate: 9600</p> <p>Parity: None</p> <p>Data Bits: 8 bits</p> <p>Stop bits: 1 bit</p> <p>Flow Control: None</p> |
| Manager Address | Set the IP address and Port number of the computer running the KE Matrix Manager software. The default port number is 9110. |

| Item | Description |
|------------------------------|---|
| Transmitter Video Attributes | <p>To set the Transmitter's video settings:</p> <p>Video Type: Select the DVI video connector being used by the display: Digital (DVI-D) or Digital (DVI-I). This option is available for KE6900, KE6940, KE6900A, KE6940A units and will be grayed out for other models.</p> <p>Color Depth: Select the number of bits to use for the color depth: 24, 16, or 8. This is the number of bits used to describe the color of a single pixel. A bit depth determines the number of colors that can be displayed at one time.</p> <p>Bandwidth Limit: Select the maximum bandwidth that the Transmitter can use to transmit video over the network. A lower bandwidth setting transmits lower quality video; a higher bandwidth setting sends higher quality video but this can affect network speed.</p> <p>Video Quality: Select the video quality to use. 5 is the highest video quality, and 1 is the lowest video quality. Options are: 1~5.</p> <p>Background Refresh: Sets how often the Transmitter refreshes the background image on the connected display. Options are to refresh every 256,128, 64, 32,16, or 0 frames.</p> |
| Beeper | <p>Check this box to allow the device to beep every time a configuration change is made.</p> |
| Occupy Timeout | <p>Set a time threshold for devices whose Access Mode has been set to Occupy (see <i>Access Type</i>, page 219). If there is no activity from the Receiver occupying the port for the amount of time set here, the Receiver is timed out and the port is released. The first Receiver to send keyboard or mouse input after the port has been released gets to occupy the port. Input a value from 1 to 240 seconds.</p> |

After entering the information, click **Save**.

System

The *System* tab allows you to configure the Transmitter's general settings:

| Item | Description |
|-----------------------------|---|
| Device Information | Enter the Name and Description of the Transmitter. It also displays the <i>IP Address</i> , <i>MAC Address</i> , <i>F/W Version</i> , and <i>Serial Number</i> of the Transmitter. |
| Reboot | Check the box and click Reboot to reset the Transmitter's settings back to the factory default. All custom settings (but not the login information) will be lost. |
| Transmitter Password Change | Check Enable to require a password for access to the Transmitter's OSD configuration screen. Enter the Old Password, enter a New Password, and confirm the new password in the Confirm Password box. |

After entering the information, click **Save**.

Internet Port (AiT Models only)

The *Internet Port* tab allows you to configure the Transmitter's Internet Port settings:

The screenshot shows the 'Internet Port' configuration page with the 'IP Installer' tab selected. The 'Enable' radio button is selected. Below it are 'Previous Page' and 'Next Page' buttons. The 'Service Port' section contains three input fields: Program Port (9000), HTTP Port (80), and HTTPS Port (443). The 'IPv4 Settings' section has 'DHCP' selected, with fields for IP Address, Subnet Mask, and Default Gateway. It also has 'Obtain DNS server address automatically' selected, with fields for Preferred DNS Server and Alternate DNS Server. The 'IPv6 Settings' section also has 'DHCP' selected, with fields for IP Address, Subnet Prefix Length (0), and Default Gateway. It also has 'Obtain DNS server address automatically' selected, with fields for Preferred DNS Server and Alternate DNS Server. A 'Save' button is at the bottom right.

The screenshot shows the 'Internet Port' configuration page with the 'CCVSR' and 'Working Mode' sections. The 'CCVSR' section has 'Disabled' selected, with fields for MAC Address (e0:05:0b:00:00:06) and Service Port (0). The 'Working Mode' section has 'Enable ICMP' checked, 'Disable Browser Service' unchecked with a dropdown menu set to 'Disable HTTPS(SSL)', and 'Enable Client AP Device List' checked. A 'Save' button is at the bottom right.

IP Installer

The IP Installer is an external Windows-based utility for assigning IP addresses to the transmitter. Click one of the radio buttons to select *Enabled*, *Disabled*, or *View Only* for the IP Installer utility. See p. 378 for IP Installer details.

-
- Note:** 1. If you select *View Only*, you will be able to see the transmitter in the IP Installer's Device List, but you will not be able to change the IP address.
2. For security, we strongly recommend that you set this to *View Only* or *Disabled* after using it.
-

Service Ports

Specify the ports that the transmitter uses for various network services.

- ♦ **Program:** This is the port number for connecting to the transmitter from the Windows Client and Java Viewers, and from the Windows and Java Client AP programs. The default is 9000.
- ♦ **HTTP:** The port number for a browser login. The default is 80.
- ♦ **HTTPS:** The port number for a secure browser login. The default is 443.

-
- Note:** 1. Valid entries for all of the Service Ports are from 1–65535.
2. The service ports cannot have the same value. You must set a different value for each one.
3. If there is no firewall (on an intranet, for example), it does not matter what these numbers are set to, since they have no effect.
-

If a firewall is being used, the Administrator can specify the port numbers that the firewall will allow (and set the firewall accordingly). If a port other than the default is set, users must specify the port number as part of the IP address when they log in. If not, an invalid port number (or no port number) is specified, the transmitter will not be found.

IPv4 Settings

The transmitter can either have its IP address assigned dynamically at boot-up (DHCP), or it can be given a fixed IP address.

- ♦ For dynamic IP address assignment, select the **DHCP** radio button. (This is the default setting.)

- ◆ To specify a fixed IP address, select the **Manual** radio button and fill in the IP address.

Note: 1. If you choose *DHCP*, when the transmitter starts up it waits to get its IP address from the DHCP server. If it has not obtained the address after one minute, it automatically reverts to its factory default IP address, 192.168.0.61.

2. If the transmitter is on a network that uses DHCP to assign network addresses, and you need to ascertain its IP address, you can use the IP installer. See *IP Installer*, page 378 for information.

The transmitter can either have its DNS server address assigned automatically, or a fixed address can be specified.

- ◆ For automatic DNS Server address assignment, select the **Obtain DNS server address automatically** radio button.
- ◆ To specify a fixed address, select the **Set DNS server address manually** radio button and fill in the required information.

Note: Specifying at the alternate DNS Server address is optional.

IPv6 Settings

The transmitter can either have its IPv6 address assigned dynamically at boot-up (DHCP), or it can be given a fixed IPv6 address.

- ◆ For dynamic IP address assignment, select the **DHCP** radio button. (This is the default setting.)
- ◆ To specify a fixed IP address, select the **Manual** radio button and fill in the IP address.

The transmitter can either have its DNS server address assigned automatically, or a fixed address can be specified.

- ◆ For automatic DNS Server address assignment, select the **Obtain DNS server address automatically** radio button.
- ◆ To specify a fixed address, select the **Set DNS server address manually** radio button and fill in the required information.

Note: Specifying at the alternate DNS Server address is optional.

CCVSR

Important operations occur on the transmitter can be recorded using the CCVSR program.

Check **Enable** to enable the CCVSR function and specify the **MAC address** and the **Service Port** of the computer the CCVSR runs on.

Note: The valid port range is 1–65535. The port number must different than the one used for the *Program* port (see *Service Ports*, page 154).

Working Mode

Use this section to set the working mode parameters.

- ◆ **Enable ICMP:** Check to enable ICMP service.
- ◆ **Disable Browser Service:** Check to disable a particular access. Available options are: browser, http or https.
- ◆ **Enable Client AP Device List:** Check to enable this function. When enabled, the unit will be discoverable in the Server List when using the WinClient or Java Client AP (see *Starting Up* on page 285). Disabling this function will render the unit undiscoverable in the Server List but can still be connected to.

After entering the information, click **Save**.

User Preferences


When you select the *User Preferences* radio button and click **Configure** to login, the configuration screen appears:

| Item | Description |
|----------------------|---|
| User Password Change | This section allows you to change the OSD password: <ol style="list-style-type: none"> 1. Key in the old password in the Old password field. 2. Key in the new password in the New password field. 3. Key in the new password again in the Confirm password field. |
| OSD Language | Click the drop-down menu to select the language you want to use for OSD sessions. Choices are: English, Chinese (Simplified), Chinese (Traditional), Japanese, Korean, Dutch, French, Spanish, Portuguese, and Russian. |
| OSD Hotkey | Select the hotkey combination to invoke the OSD screen. |
| Logout Timeout | If there is no user input for the amount of time set with this function, the user is automatically logged out of the OSD. A login is necessary before the OSD can be accessed again. |
| Screen Blanker | Set how many minutes the OSD waits when a session is idle before turning off the display. |

When you have made your choices, Click **Save**.

OSD Matrix Mode

If you set the system to Matrix mode (in Properties), you will see the *System Login* screen when you enter the invoke the OSD, which provides access to the *Connection Page* by entering a username and password:



Note: 4. If the Receiver does not require a login, click *Login to system* (see *Login Required*, under *Basic*, page 204). For information about Extender and Desktop/Matrix modes, see *Mode*, page 142.

After you login the *Connection Page* appears, as shown on the next page.


| No. | Item | Description |
|-----|----------------|--|
| 4 | Connect | <p>To connect the Receiver to a Channel, click the access type:</p> <p>Exclusive: The first Receiver to access the Channel has exclusive control over the Channel. No other Receivers can view the Channel. The Timeout function does not apply to this setting.</p> <p>Occupy: The first Receiver to access the Channel has control over the Channel. However, additional Receivers may view the Channel's video display. If the Receiver controlling the Channel is inactive for longer than the time set in the Timeout box, control is transferred to the first Receiver to move the mouse or strike the keyboard.</p> <p>Share: Can simultaneously share control over the Channel. Input from the Receivers is placed in a queue and executed chronologically.</p> <p>View Only: Receiver connects with view only access to the Channels video display.</p> |
| 5 | Next Arrow | Use these two buttons to navigate to the next page or to the end of the list if there are more Channels available than can be seen on the page. |
| 6 | Previous Arrow | Use these two buttons to navigate to the previous page or to the beginning of the list if there are more Channels available than can be seen on the page. |
| 7 | Favorites | <p>Click Favorites to list only the Channels marked as favorites. Channels marked as favorites appear with a heart icon.</p> <p>To add/remove a Favorite, select a Channel and then right click with the mouse to select Add to Favorite or Remove from Favorite.</p> <p>Note: A maximum of 50 channels can be marked as <i>Favorites</i>.</p> |
| 8 | Array Mode | Click to view the Channel connections with a video preview of each source. The list will be shown in groups of six at a time. The Array Mode is discussed on page 162. |
| 9 | List Mode | This option appears after selecting <i>Array</i> mode. Click to view the Channel connections in a list that can be sorted by name or with favorites listed first. Click the Channel Name heading to change the sort. |

| No. | Item | Description |
|-----|----------------------------|--|
| 10 | EDID Mode | <p>When a Transmitter's EDID is configured, depending on its setting, different buttons will or won't appear to configure the Receiver's EDID for the connection. The following rules apply to the Receiver's OSD according to the Transmitter's EDID setting:</p> <ul style="list-style-type: none">◆ Under Default or Auto EDID mode, no EDID button appears as there is nothing to configure.◆ Under Manual or Remix EDID mode, the EDID button appears allowing you to select <i>Manual EDID</i> or <i>Remix EDID</i>. <p>Click Manual or Remix to adjust the EDID setting locally.</p> <p>To set the Transmitter's EDID Mode, see <i>Properties</i>, page 150.</p> |
| 11 | Logout | Click this button to log out of the Connection Page. |
| 12 | Go to Configuration Window | Click this button to return to the main OSD screen. |

Array Mode

Note that Array Mode is not supported by slim KVM over IP Receivers.

In *Array Mode* the screen is divided into a grid of panels, with each panel showing the video display of a particular Channel. Right-click a panel and select a mode to connect: **E**: Exclusive, **O**: Occupy, **S**: Share, **V**: View Only, **X**: Exit. While the mouse cursor hovers over a panel displaying video, if audio is being sent from that Transmitter, it can be heard at the Receiver.




| No. | Item | Description |
|-----|----------------|---|
| 1 | Next Arrow | Use these two buttons to navigate to the next page or to the end of the list if there are more Channels available than can be seen on the page. |
| 2 | Previous Arrow | Use these two buttons to navigate to the previous page or to the beginning of the list if there are more Channels available than can be seen on the page. |
| 3 | Grid Selection | Select a range for how many Channels you want to display. Options are: 2x2, 3x3, 4x4, 5x5, and 6x6. |

| No. | Item | Description |
|-----|-----------|---|
| 4 | Favorites | <p>Click Favorites to list only the Channels marked as favorites. Click All to list all Channels.</p> <p>To add/remove a Favorite, go to List Mode, select a Channel and then right click with the mouse to select Add to Favorite or Remove from Favorite.</p> <p>Note: A maximum of 50 channels can be marked as <i>Favorites</i>.</p> |
| 5 | List Mode | <p>Click to view the Channel connections in a list that can be sorted by name or with favorites listed first. Click the Channel Name heading to change the sort. <i>List Mode</i> is discussed on page 160.</p> |
| 6 | Logout | <p>Click this button to log out of the Connection Page.</p> |
| 10 | Configure | <p>Click this button to return to the main OSD screen.</p> |

Profile Page

Click the *Profile Page* tab and the following screen appears:




The *Profile Page* components are described in the table below:

| No. | Item | Description |
|-----|----------------------------|---|
| 1 | Name | Lists the Profiles available. Profiles give Receivers access to Channels and allow you to push the connection. |
| 2 | Description | The field provides a description of the Profile that was entered when it was created. |
| 3 | Connect | Click Connect and the Receiver will connect with the settings of that Profile (see <i>Adding a Profile</i> , page 243). |
| 4 | Disconnect | Click Disconnect to end the current Profile connection. |
| 5 | Next Arrow | Use these two buttons to navigate to the next page or to the end of the list if there are more Profiles available than can be seen on the page. |
| 6 | Previous Arrow | Use these two buttons to navigate to the previous page or to the beginning of the list if there are more Profiles available than can be seen on the page. |
| 7 | Logout | Click this button to log out of the Connection Page. |
| 8 | Go to Configuration Window | Click this button to return to the main OSD screen. |

Push Content

Push Content allows you to push the Receiver's computer connection to another Receiver's console, allowing both to access to the computer. Select the *Push Content* tab and the following screen appears:




The *Push Content Page* components are described in the table, below:

| No. | Item | Description |
|-----|---------------|---|
| 1 | Receiver Name | Lists the Receivers that can be selected to push the local Receiver's computer connection to. |
| 2 | Description | The field provides a description of the Receiver that was entered when it was created. |
| 3 | Connect | Click Push Content to push the local Receiver's computer connection to the selected Receiver's console. The local Receiver's computer connection will appear on the Receiver that it was pushed to and both will share access to the computer. The access mode selected at the local Receiver will determine how access is shared (see <i>Transmitter Permissions</i> , page 218 for details). |
| 5 | Next Arrow | Use these two buttons to navigate to the next page or to the end of the list if there are more choices available than can be seen on the page. |

| No. | Item | Description |
|-----|----------------------------|--|
| 6 | Previous Arrow | Use these two buttons to navigate to the previous page or to the beginning of the list if there are more choices available than can be seen on the page. |
| 9 | Logout | Click this button to log out of the Connection Page. |
| 10 | Go to Configuration Window | Click this button to return to the main OSD screen. |

Pull Content

Pull Content allows you to pull a Receiver's computer connection to the local Receiver's console, allowing both to access to the computer. Click the *Pull Content* tab and the following screen appears:



The *Pull Content Page* components are described in the table, below:

| No. | Item | Description |
|-----|----------------------------|--|
| 1 | Receiver Name | Lists the Receiver names currently connected to the Channel listed under <i>Channel Status</i> . |
| 2 | Channel Status | Lists the name, description and access type of each available Channel connection. |
| 3 | Connect | Click Pull Content and the Receiver will pull the Channel connection to the local console using the access mode displayed under Channel Status. |
| 5 | Next Arrow | Use these two buttons to navigate to the next page or to the end of the list if there are more choices available than can be seen on the page. |
| 6 | Previous Arrow | Use these two buttons to navigate to the previous page or to the beginning of the list if there are more choices available than can be seen on the page. |
| 9 | Logout | Click this button to log out of the Connection Page. |
| 10 | Go to Configuration Window | Click this button to return to the main OSD screen. |

This Page Intentionally Left Blank

Chapter 4

Software Installation


Overview

The *CCKMKE Matrix Manager Software* is a browser based GUI that provides management of KE Series devices over a network. You can download the KE Matrix Manager Software for free and manage up to 8 KE devices, or purchase a license for the KE Matrix Manager Software. To purchase a license, contact your local authorized ATEN dealer. To download the free KE Matrix Manager Software, use the instructions below.


Download

To download the KE Matrix Manager software, do the following:


1. Visit our website and click **Support & Downloads** → **ESERVICE**.




2. Under *Account*, click **Create New** or **Log In**.



- After logging in, click **Product Registration** to register the KE device(s) you have purchased.




- After you have registered the KE device(s), click **Trial Software Download**.



Note: The downloaded version of the KE Matrix Manager software includes full functions and can configure up to 8 KE Series devices. If you would like to configure more KE Series devices, please contact your ATEN reseller to purchase a license and upgrade the license of your software, see page 174.

- Click the software version you would like to download, then click **Save**.



- Unzip the *cckm_win_Vx.x.xxx.zip* or *cckm_linux_Vx.x.xxx.zip* file and double click the *.exe file to start the installation.
- Follow the instructions on the next page to install the software.


KE Matrix Manager Software Install

The following are instructions to install the full version of the KE Matrix Manager software on a primary or secondary computer. For software requirements, see *CCKM Requirements*, page 10.


1. Insert the USB license key into a USB port on your computer.

Note: If you have more than 8 KE Series devices in your setup, a USB license key is required to install the KE Matrix Manager.

2. Double click the *KEMatrixManagerSetup* file to start the setup. When the *Introduction* screen appears, click **Next**.




3. The *License Agreement* appears:




If you agree with the License Agreement, select *I accept the terms of the license agreement*, and click **Next**.

4. The *Choose Install Folder* screen appears:




Select where you would like to install the program, and click **Next**.

5. The *Choose Shortcut Folder* screen appears:




Select where to create shortcuts for the program by selecting the options provided, and click **Next**.

6. The *Pre-Installation Summary* screen appears:



Confirm the settings you've selected. If you want to make a change click **Previous** to go back, or click **Install** to begin the software installation.

7. When the process is done, the *Install Complete* screen appears:



Click **Done**.

Upgrading License

After you purchase a license to upgrade the KE Matrix Manager software, go to the *Settings - General* tab (see page 249), and at the top page, select **Click to Upgrade**:


The screenshot displays the 'General' settings page for KE Matrix Manager. The 'Basic' section is expanded, showing the current version as 2.1.202 (2018-02-06 02:03). A red box highlights the 'Click to Upgrade' button next to the 'Serial Number' field. Other fields include 'KE Matrix Manager Name' (KE Matrix Manager), 'Description', 'Language' (English), 'Beeper' (Enable/Disable), and 'CCKM Timeout' (30 min/1-180/Disable). The 'Network Ports' section shows 'HTTP Port' (8080), 'HTTPS Port' (8443), and 'Device Port' (9110). The 'Fast Switching' section has 'Fast Switching' (Disable/Enable) and a dropdown menu (1920x1200). The 'Account Policy' section shows 'Enforce Password History' (3) and a checked 'Disable' checkbox.

| Section | Field | Value |
|----------------|---------------------------|----------------------------|
| Basic | KE Matrix Manager Version | 2.1.202 (2018-02-06 02:03) |
| | Serial Number | Click to Upgrade |
| | KE Matrix Manager Name | KE Matrix Manager |
| | Description | |
| | Language | English |
| | Beeper | Enable |
| Network Ports | HTTP Port | 8080 |
| | HTTPS Port | 8443 |
| | Device Port | 9110 |
| Fast Switching | Fast Switching | Disable |
| | Resolution | 1920x1200 |
| Account Policy | Enforce Password History | 3 |
| | Disable | Checked |


Linux Installation

The following are instructions to install the full version of the KE Matrix Manager software on a Linux server. For software requirements, see *CCKM Requirements*, page 10.

1. Download the KE Matrix Manager installation file to the Linux server.
2. Change the properties of the installation file so that its executable by running the command: `chmod a+x filename`
Example: `chmod a+x kemanager_setup.bin`
3. Start the installation with the command:
`sudo sh ./kemanager_setup.bin`
4. When the *Introduction* screen appears, click **Next**:



5. The *License Agreement* appears:



If you agree with the License Agreement, select *I accept the terms of the license agreement*, and click **Next**.

6. When the *Choose Install Folder* screen appears, select the location and continue through the installation by clicking **Next**.
7. After the software installs successfully, a directory provides useful links:

```

mitch@mitch-945GCM-S2L:/$ sudo -i
[sudo] password for mitch:
root@mitch-945GCM-S2L:~# ls -al
total 40
drwx----- 7 root root 4096  +- 14 13:42 .
drwxr-xr-x 25 root root 4096  +- 14 10:04 ..
-rw----- 1 root root 65  +- 14 13:42 .bash_history
-rw-r--r-- 1 root root 3106  + 23 2015 .bashrc
drwx----- 2 root root 4096  7 20 04:49 .cache
drwx----- 3 root root 4096  +- 13 16:07 .gnupg
drwxrwxr-x 4 root root 4096  +- 14 13:29 .java
drwxrwxr-x 5 root root 4096  +- 14 13:39 KeManager
drwxrwxr-x 2 root root 4096  +- 14 09:58 .oracle_jre_usage
-rw-r--r-- 1 root root 148  八 17 2015 .profile
root@mitch-945GCM-S2L:~# cd KeManager/
root@mitch-945GCM-S2L:~/KeManager# ls
kemanager          Query_Service      Uninstall_Matrix_Manager
_kemanager_installation Service_Manager
root@mitch-945GCM-S2L:~/KeManager#

```

8. The "Uninstall_Matrix_Manager" can be used to uninstall the software. By default the root folder can be accessed as shown below:

```
sudo -i cd /root cd KeManager sudo ./Uninstall_Matrix_Manager
```

9. To check and stop the KE Matrix Manager service, use the following commands:

```
cd KeManager sudo ./Query_Service Stop service: sudo ./Stop_Service
```

```

root@mtch-945GCM-52L:~/KeManager# sudo ./Query_Service
java version "1.8.0_121"
Java(TM) SE Runtime Environment (build 1.8.0_121-b13)
Java HotSpot(TM) 64-Bit Server VM (build 25.121-b13, mixed mode)
YAJSW: yajsw-stable-11.04
OS : Linux/4.4.0-92-generic/amd64
JVM : Oracle Corporation/1.8.0_121
Sep 07, 2017 2:13:51 PM org.apache.commons.vfs2.VfsLog info
INFO: Using "/tmp/vfs_cache" as temporary files store.
Sep 07, 2017 2:13:52 PM org.rzo.yajsw.os.posix.PosixService init
INFO: /etc/init.d/kenananager-service already exists
Sep 07, 2017 2:13:52 PM org.rzo.yajsw.os.posix.PosixService getPid
INFO: wrapper pid file: /run/wrapper.kenananager-service.pid
Name :
kenananager-service
Installed : true
Running : false
Interactive : false
Automatic : false
Manual : false
Disabled : false
Paused : false
Unknown : false
Press [Enter] ...
root@mtch-945GCM-52L:~/KeManagers# cd Service_Manager/
root@mtch-945GCM-52L:~/KeManager/Service_Manager# ls
Install_Service Start_Service Stop_Service Uninstall_Service
root@mtch-945GCM-52L:~/KeManager/Service_Manager# sudo ./Stop_Service
java version "1.8.0_121"
Java(TM) SE Runtime Environment (build 1.8.0_121-b13)
Java HotSpot(TM) 64-Bit Server VM (build 25.121-b13, mixed mode)
YAJSW: yajsw-stable-11.04
OS : Linux/4.4.0-92-generic/amd64
JVM : Oracle Corporation/1.8.0_121
Sep 07, 2017 2:15:01 PM org.apache.commons.vfs2.VfsLog info
INFO: Using "/tmp/vfs_cache" as temporary files store.
Sep 07, 2017 2:15:02 PM org.rzo.yajsw.os.posix.PosixService init
INFO: /etc/init.d/kenananager-service already exists
***** STOPPING kenananager-service *****
Sep 07, 2017 2:15:04 PM org.rzo.yajsw.os.posix.PosixService stop
INFO: Stopping kenananager-service ...
YAJSW: yajsw-stable-11.04
OS : Linux/4.4.0-92-generic/amd64
JVM : Oracle Corporation/1.8.0_121
***** STOPPING kenananager-service *****
Service kenananager-service stopped

```

Query Service

Stop Service

10. To check and start the KE Matrix Manager service, use the following commands:

```
cd KeManager sudo ./Query_Service Stop service: sudo ./Start_service
```

```

root@mtch-945GCM-52L:~/KeManager/Service_Manager# sudo ./Start_Service
java version "1.8.0_121"
Java(TM) SE Runtime Environment (build 1.8.0_121-b13)
Java HotSpot(TM) 64-Bit Server VM (build 25.121-b13, mixed mode)
YAJSW: yajsw-stable-11.04
OS : Linux/4.4.0-92-generic/amd64
JVM : Oracle Corporation/1.8.0_121
Sep 07, 2017 2:17:27 PM org.apache.commons.vfs2.VfsLog info
INFO: Using "/tmp/vfs_cache" as temporary files store.
Sep 07, 2017 2:17:28 PM org.rzo.yajsw.os.posix.PosixService init
INFO: /etc/init.d/kenananager-service already exists
***** STARTING kenananager-service *****
Sep 07, 2017 2:17:28 PM org.rzo.yajsw.os.posix.PosixService getPid
INFO: wrapper pid file: /run/wrapper.kenananager-service.pid
Sep 07, 2017 2:17:33 PM org.rzo.yajsw.os.posix.PosixService start
INFO: Starting kenananager-service ...
YAJSW: yajsw-stable-11.04
OS : Linux/4.4.0-92-generic/amd64
JVM : Oracle Corporation/1.8.0_121
***** STARTING kenananager-service *****
Service kenananager-service started
Sep 07, 2017 2:17:33 PM org.rzo.yajsw.os.posix.PosixService getPid
INFO: wrapper pid file: /run/wrapper.kenananager-service.pid
Sep 07, 2017 2:17:34 PM org.rzo.yajsw.os.posix.PosixService getPid
INFO: wrapper pid file: /run/wrapper.kenananager-service.pid
Sep 07, 2017 2:17:34 PM org.rzo.yajsw.os.posix.PosixService getPid
INFO: wrapper pid file: /run/wrapper.kenananager-service.pid
Service kenananager-service started
root@mtch-945GCM-52L:~/KeManager/Service_Manager#

```

Start Service

This Page Intentionally Left Blank

Chapter 5

Browser / Telnet Operation

Overview

The *CCKM KE Matrix Manager* software can be accessed through most standard web browsers and via Telnet. Once users log in and are authenticated, the browser GUI comes up. The first section explains the login procedure and web browser components. The last section provides details for connecting via Telnet.

Logging In

To log into the KE Matrix Manager, do the following:


1. Open the browser and specify the IP address of the computer installed with the KE Matrix Manager software, in the browser's URL location bar.

Note: If the administrator has configured the HTTP or HTTPS port setting as something other than the default, you must include **http://** or **https://** before the IP address, and specify the port number along with the IP address. For example:

```
https://192.168.1.20:8443
```

Where *8443* is the https port number, or *8080* is the http port number, and a colon is inserted between it and the IP address.

2. If a Security Alert box appears, accept the certificate – it can be trusted (See *Trusted Certificates*, page 379 for details). The Login page appears:




The screenshot shows a login interface with the following elements:

- An orange header with the word "Login" in white.
- A "Username" label followed by a text input field.
- A "Password" label followed by a text input field.
- A language selection dropdown menu with a globe icon and the text "English".
- A checkbox labeled "Remember this account" which is checked.
- A blue button with the word "Login" in white.


3. Enter the *Username* and *Password* and click **Login**.

Note: Only administrator accounts can be used to log in. By default, the username and password are *administrator* and *password*, respectively.

4. For security purposes, the system will prompt you to change the password immediately.




Click **OK** for the password change dialog box.



5. Enter the new password and confirm it by entering the password again.
6. Click **OK** to complete the change and the KE matrix manager main page appears. Refer to the next page for more details.

The KE Matrix Manager Main Page

After you have successfully logged in, the web browser's main page appears:









Web Components

The web components are described in the table below:

| No. | Item | Description |
|-----|---------------------------|--|
| 1 | Install Wizard | This icon helps you locate Transmitters/Receivers on the LAN to add them to the KE Matrix Manager (see <i>Installation Wizard</i> , page 183). If a device can't be found, check the Network settings in the device's OSD menu (see page 141 & 148). |
| 2 | System Settings | Click this icon to enter the <i>System Setting</i> section where you can configure the KE Matrix Manager software. The Settings are discussed on page 249. |
| 3 | Logout | Click this button to log out of your KE Matrix Manager web session. |
| 4 | Interactive Display Panel | This is your main work area. Scroll the page up or down to view the various selections. Some items can be clicked to open a settings page, while others provide status information. |
| 5 | Instant Link | Clicking this icon opens the lower bar which allows you to instantly connect KE devices. Instant Link is discussed on page 189. |

Interactive Display Panel

The functions associated with each of the icons on the main interactive display panel are explained in the table below:

| Icon | Function |
|---|--|
|  | <p>System Status: System Status provides an overview of the transmitter, receiver, user, profile, and log status. Each heading can be clicked to open the respective settings page. System Status is discussed on page 197.</p> |
|  | <p>Connections: Connections provides a visual display of current transmitter and receiver connections. Connections is discussed on page 273.</p> |
|  | <p>Scheduled Profile: Scheduled Profile provides an overview of connection profiles that are scheduled to run. Scheduled Profile is discussed on page 277.</p> |
|  | <p>Sessions: Sessions provides a list of current user sessions. Sessions is discussed on page 279.</p> |
|  | <p>Refresh: The Refresh button provides a way to update the information currently being displayed on the page.</p> |
|  | <p>To Top: This button appears at the bottom right corner of the Interactive Display Panel and allows you to jump back to the top of the page.</p> |

Installation Wizard

Use the *Install Wizard* to add transmitters, receivers, and/or network switches to the CCKM. The wizard locates devices on the network and walks you through adding them. To add devices, do the following:

1. Connect all transmitters, receivers, and/or network switches to the LAN.
2. On the CCKM main page, click the **Install Wizard** icon (page 181). This dialog box appears.



- ◆ To add transmitters and/or receivers, select **Transmitter or Receiver**, click **Next**, and refer to *Adding Transmitters and Receivers*, page 184.
- ◆ To add network switches, select **Network Switch**, click **Next**, and refer to *Adding Network Switches*, page 187.

Adding Transmitters and Receivers

1. On the installation wizard for transmitters and receivers, select options to locate the devices:

Install Wizard

1. Connect all Transmitters and Receivers to the local area network.

Search Local
 Search Subnet

↻

Transmitter

2


[1]00-10-74-A9-01-12
 [2]00-10-74-A9-00-00

Receiver

2

[1]00-10-74-A8-00-00
 [2]00-10-74-A8-01-03

CANCEL
NEXT

| Item | Description |
|---|---|
| Search Local | Check this box and click the <i>Refresh</i> button to search the local area network for Transmitters/Receivers. |
| Search Subnet | Check this box, enter a subnet IP and then click the <i>Refresh</i> button to search the subnet for Transmitters/Receivers. |
| Transmitter / Receiver | Displays the number of <i>Transmitters</i> and <i>Receivers</i> that have been discovered on the network. Use the check boxes next to the Transmitters/Receivers to select the devices you want to add. |
|  | The <i>Refresh</i> button provides a way to update the information currently being displayed in the install wizard window. |

2. Check the boxes under *Transmitter / Receiver* to select the devices you want to add, then click **Next**.
3. Under *Assign IP Address* select an option to configure the network settings, then click **Next**.

Install Wizard

2. Assign IP Address.

Transmitter
Receiver

2
2

IP Range

Transmitter ~

Receiver ~

DHCP

Use Original IP Setting

[BACK](#) [NEXT](#)

| Item | Description |
|-------------------------|--|
| IP Range | Select the <i>IP Range</i> radio button to enter a series of static IP addresses to assign to the <i>Transmitters/Receivers</i> that you are adding. |
| DHCP | Select the <i>DHCP</i> radio button for dynamic IP address assignment. |
| Use Original IP Setting | Select this radio button to use the IP address currently configured on the Transmitter/Receiver. |

4. Use the *Naming Rule* radio button to create a naming convention (*Title + Number*); or *Use Original Name* to use the name currently configured on the Transmitter/Receiver, then click **Next**.

Install Wizard

3. Rename devices automatically.

Naming Rule

Transmitter + Number start from

Receiver + Number start from



Use Original Name

[BACK](#) [NEXT](#)

5. Confirm each Transmitter's *Name*, *IP Address*, *Audio* setting and check the boxes to set *Permissions**, then click **Next** and repeat the process for Receivers.

Install Wizard

4. Confirm Transmitter information.
Permissions view Only Occupy Exclusive

| No. | MAC | Name | IP Address | |
|-----|-------------------|--|---|---|
| 1 | 00-10-74-A9-01-12 | <input type="text" value="KE6940T61"/> | <input type="text" value="192.168.0.61"/> |  |
| 2 | 00-10-74-BD-01-23 | <input type="text" value="KE8950T"/> | <input type="text" value="192.168.0.63"/> |  |

[BACK](#) [NEXT](#)

Note: See *Transmitter Permissions*, **page 218**, and *Receiver Permissions*, **page 230** for information about setting permissions.

6. Click **Done**.

Adding Network Switches

1. On the installation wizard for network switches, specify the search parameters to locate the devices:

Switch Wizard
✕

1. Please enter a specific IP address and range to discover devices

IP Range ~

Switch Manufacturer ▼

Search via SNMP v1

Port

Community / User Name

Timeout Milliseconds

Search via SNMP v2c

Search via SNMP v3

[BACK](#)
[NEXT](#)

| Item | Description |
|-------------------------------|---|
| IP Range | Specify the IP address range to search for the network switch to be added. |
| Switch Manufacturer | Selects the manufacturer of the network switch to be added. |
| Search via SNMP v1 / v2c / v3 | Select to search via SNMP v1 / v2c / v3 by entering the corresponding <i>Port</i> , <i>Community / Username</i> and <i>Timeout</i> parameters |

2. Check the boxes next to the network switch devices you want to add.

- Optionally modify the *Device Name* of the network switch(es) to be added, then click **Next**.

| <input checked="" type="checkbox"/> | Device Name | Model | MAC Address | IP Address |
|-------------------------------------|--------------------------|--------|-------------------|------------|
| <input checked="" type="checkbox"/> | [ES0152-QA_11-g11111111] | ES0152 | 00-40-C7-75-EB-3E | 10.0.92.11 |

BACK NEXT

- For optimal working with the KE Matrix System, make sure to enable the related network services and click **Next**.

3. Enable services for better connection

In order to make sure the switch(es) could work well with KE system.
The following configurations need to be enabled before you start to use.

| | |
|-------------------------------------|------------------------|
| <input checked="" type="checkbox"/> | IGMP Snooping |
| <input checked="" type="checkbox"/> | IGMP Querier |
| <input checked="" type="checkbox"/> | Fast Leaver |
| <input checked="" type="checkbox"/> | Unregistered Multicast |
| <input checked="" type="checkbox"/> | Flow Control |
| <input checked="" type="checkbox"/> | Speed Mode set to Auto |


SKIP NEXT

- Click **Done** to finish.





Instant Link

At the bottom of the KE Matrix Manager Main Page is the *Instant Link* bar. In this section you can quickly connect Receivers to Transmitters.

The top panel provides the **Receiver List**, and the bottom panel provides the **Transmitter List**. To create a connection, click a Receiver in the top panel and use the drop-down menu to select a Transmitter (as shown in the image below); or drag-and-drop Transmitters from the bottom panel to Receivers in the top panel. Configure as many Receiver to Transmitter connections as needed, and then click **Apply**.



| Item | Description |
|------------------|---|
| Instant Link | The Instant Link bar provides access to quickly connect Receivers to Transmitters. Click the bar to open the panel, click again to minimize the panel. The top panel provides a list of all the Receivers discovered on the LAN. Click a Receiver and use the drop-down menu to select a Transmitter. |
| Transmitter List | Click the Transmitter List bar to open the panel. The panel provides a list of all the Transmitters discovered on the LAN. Drag-and-drop Transmitters in the bottom panel to Receivers in the top panel to establish connections. The panel size of the Transmitter List is adjustable by clicking-and-dragging its border. |
| Location | Use the drop-down menu to select a location to filter the Receivers or Transmitters displayed on the page. |

| Item | Description |
|---|---|
| Ratio | Use the drop-down list to adjust the icon size of the Receivers / Transmitters. |
|  | Click and type keywords to filter/search for Receivers / Transmitters. |
|  | Click this icon to show individual Receivers. |
|  | Click this icon to show only video wall Receivers. |
|  | Click this icon to show only Receiver Group Receivers. |
| Access Mode | Click a device and use the drop-down box to set the access mode: <i>Occupy</i> , <i>View Only</i> , or <i>Exclusive</i> . |
| Auto Apply | Checking this box allows you to drag and drop devices and apply the connection immediately without having to click the <i>Apply</i> button. |
| Apply | Click Apply to connect the devices. |
| Cancel | Click Cancel to exit without connecting. |

RS-232 / Telnet

The KE Series can be operated and configured via a remote terminal session using Telnet. This is a useful means for configuring devices when they are first set up and connected to the network.


Telnet

To log into the KE Series device by means of a Telnet session, do the following:

1. On your computer, open a terminal (command line) session.
2. At the prompt, key in the KE device's IP address with port 23 in the following way:

```
telnet [IP address] [port]
```

3. Please press **"T / t"** to start **"TextMenu"** The login screen appears. At the login prompt, provide the Password.



```
COM6 - PUTTY
Welcome to ATEN KE8950 User Station
Copyright(c) 2009-2013 ATEN International Co., Ltd.

--Press ENTER to start CLI session
--Press T/t to start TextMenu :
Password:*****

+++++
KE8950 User Station
  --  --  --  --  --
      User Station Confiuration
+++++
  1. Network
  2. Properties
  3. System
  Q. Logout
Select one: █
```

Note: The default password for Telnet sessions is *password*.

RS-232

To log into the KE Series device by means of a RS-232 session, do the following:

1. The controller's serial port should be configured the same as the Receiver's default configuration, as shown below:

| | |
|--------------|------|
| Baud Rate | 9600 |
| Data Bits | 8 |
| Parity | None |
| Stop Bits | 1 |
| Flow Control | None |

The Receiver's **Function Switch** should be set to *RS-232 Config* (see page 44). Before executing RS-232 commands across a network you must install the KE Matrix Manager software on a computer and ensure that it is online. For the Slim Version of KE Series (KE8900ST/8900SR/9900ST). Please make sure the RS-232 Serial Port is not connected before executing commands.

2. Please press “**T / t**” to start “**TextMenu**” The login screen appears. At the login prompt, provide the Password.

```

COM6 - PuTTY
Welcome to ATEN KE8950 User Station
Copyright(c) 2009-2013 ATEN International Co., Ltd.

--Press ENTER to start CLI session
--Press T/t to start TextMenu :
Password:*****

+++++
KE8950 User Station
-----
User Station Configuration
+++++
1. Network
2. Properties
3. System
Q. Logout
Select one: █

```

Note: The default password for Telnet sessions is *password*.

Configuration Menu

Once a Telnet connection to the KE device is established, the device's text-based Configuration Menu comes up, allowing you to select options by entering a number on the following screens:

Main Menu

```
+++++
```

KE6900 Receiver

```
-----
```

Receiver Configuration

```
+++++
```

1. Network

2. Properties

3. System

Q. Logout

Select one:

1. Network

+++++
KE6900 Receiver

Network Settings

- +++++
1. IP Installer [Enabled]
2. DHCP [Disabled]
3. IP Address [172.17.17.34]
4. Subnet Mask [255.255.255.0]
5. Default Gateway [172.17.17.254]

Q. Exit

Select one:

2. Properties

+++++
KE6900 Receiver

Device Properties

- +++++
1. Mode [Matrix]
2. Transmitter Video IP Address [172.17.17.35]
3. Transmitter Audio IP Address [172.17.17.35]
4. Transmitter USB IP Address [172.17.17.35]
5. Transmitter RS232 IP Address [172.17.17.35]
6. UART Configuration
7. Video [Enabled]
8. Audio [Enabled]
9. USB [Enabled]
10. RS232 [Enabled]
11. KE Matrix Manager IP [172.17.17.33]
12. KE Matrix Manager Port [9110]
13. Beeper [Enabled]
14. USB Mode [VM]
15. USB Secure Transmit [Disabled]

Q. Exit

Select one:

3. System

++++
KE6900 Receiver

System Setting

++++

1. Device Name [KE6900R]
2. Device Description [Receiver1]

Device IP Address: 172.17.17.34

Device MAC Address: 00:10:74:A8:01:23

Device FW Version: V1.1.109

Device Serial Number:

3. Password [Enabled]
4. Change Password
5. System Reboot/Reset to Factory Default

Q. Exit

Select one:

Note: The Reset to Factory Default function resets everything but the login information to the factory default settings. To reset the login information, refer to *Reset All Information* on page 381.

This Page Intentionally Left Blank

Chapter 6

System Status

Overview

The *System Status* panel is found at the top of the **KE Matrix Manager** main page. This section provides status information about Transmitters, Receivers, Network Switches, Users, Profiles, and Logs. Click on a selection to open a *Settings* page, which are discussed in the sections that follow.

The screenshot shows the KE Matrix Manager interface. At the top, there is a header with the ATEN logo, 'CCKM KE Matrix Manager', and navigation icons. Below the header, a user notification reads 'administrator>Welcome to the KE Matrix Manager'. The main content area is titled 'System Status' and contains several data cards:


| Transmitter | | | | Receiver | | | | Switch | | |
|-------------|---------|---------|-------|----------|---------|---------|-------|--------|---------|-------|
| Active | Standby | Offline | Total | Active | Standby | Offline | Total | Active | Offline | Total |
| 0 | 0 | 14 | 14 | 0 | 0 | 9 | 9 | 2 | 0 | 2 |

| Users | | Profile | | Log | | |
|--------|------|---------|---------------|---------|-------|-------------|
| Online | Idle | Total | Next Schedule | Warning | Error | Information |
| 1 | 8 | 3 | None | 211 | 58 | 446 |

Below the data cards, there is a 'Redundancy Status: (Primary) (Working)' indicator. A 'Connections' section shows 'TX-RX' and 'RX-TX' buttons. At the bottom, there are tabs for 'Receiver' and 'Transmitter', and an 'Instant Link' button.

System Status

The *System Status* panel contains six sections that provide information and a link to each settings page. Each settings page can be accessed by **Clicking** within the section: Transmitter, Receiver, Switch, Users, Profile, or Log. Each section is explained in the table below and the Settings on the pages that follow.




| Item | Description |
|-------------|---|
| Transmitter | <p>This section provides an overview of the Transmitters added to the KE Matrix Manager:</p> <ul style="list-style-type: none"> ♦ Active: Shows the number of Transmitters that are currently online and connected to a Receiver. ♦ Standby: Shows the number of Transmitters that are online but not connected to a Receiver. ♦ Offline: Shows the number of Transmitters added to the KE Matrix Manager that are not online. ♦ Total: Displays the total number of Transmitters added to the KE Matrix Manager. |
| Receiver | <p>This section provides an overview of the Receivers added to the KE Matrix Manager:</p> <ul style="list-style-type: none"> ♦ Active: Shows the number of Receivers that are currently online and connected to a Transmitter. ♦ Standby: Shows the number of Receivers that are online but not connected to a Transmitter. ♦ Offline: Shows the number of Receivers added to the KE Matrix Manager that are not online. ♦ Total: Displays the total number of Receivers added to the KE Matrix Manager. |








| Item | Description |
|-------------------|---|
| Switch | <p>This section provides an overview of the Network Switches added to the KE Matrix Manager:</p> <ul style="list-style-type: none"> ◆ Active: Shows the number of Network Switches added to the KE Matrix Manager that are currently online. ◆ Offline: Shows the number of Network Switches added to the KE Matrix Manager that are not online. ◆ Total: Displays the total number of Network Switches added to the KE Matrix Manager. |
| Users | <p>This section provides an overview of users with KE Matrix Manager sessions:</p> <ul style="list-style-type: none"> ◆ Online: Shows the number of users that are logged into OSD or KE Matrix Manager web sessions. ◆ Idle: Shows the number of users not logged into OSD or KE Matrix Manager web sessions. |
| Profile | <p>This section provides an overview of Profile and Profile Schedules:</p> <ul style="list-style-type: none"> ◆ Total: Shows the total number of Profiles available. ◆ Next scheduled to run: Shows the name of the next Profile scheduled to run. ◆ Days later: Shows the number of days until the next Profile is scheduled to run. |
| Log | <p>This section provides an overview of system logs:</p> <ul style="list-style-type: none"> ◆ Warning: Shows the number of warnings logs generated since the event log was cleared. ◆ Error: Shows the number of error logs generated since the event log was cleared. ◆ Information: Shows the number of information logs generated since the log was cleared. |
| Redundancy Status | <p>This section provides information about the Redundancy mode. The first set of brackets shows which server is hosting the KE Matrix Manager database: [Primary] or [Secondary]. If Redundancy is disabled the first bracket will read: [Standalone]. The second set of brackets show the status:</p> <ul style="list-style-type: none"> ◆ [Working]: The server is actively hosting the KE Matrix Manager database. ◆ [Standby]: This message appears when database operations are idle. |






Transmitter

Click **Transmitter** in the *System Status* panel to open the settings. On this page you can add, delete and configure *Transmitters* (physical transmitters), *Virtual Transmitters* (multi-source) and *Transmitter Groups* (multi-video source). The KE Matrix Manager automatically adds Transmitters connected to the local area network with a valid IP address.








The meanings of the icons and headings on the page are straightforward and let you view and configure Transmitters.

- ◆  *Active* refers to a Transmitter connection that is online and in use.
- ◆  *Standby* refers to a Transmitter connection that is online.
- ◆  *Offline* refers to a Transmitter connection that is offline.
- ◆  **All Devices** Use this drop-down menu to filter Transmitters by location. Use Locations to limit the Transmitters seen on the page.
 - ◆  Click to add a new **Location**.
 - ◆  Select a Transmitter and click the **Move to** icon to add devices to a Location.
 - ◆  Select a Location from the drop-down menu and click this icon to delete it.

- ♦  Select a Location and click this icon to change the name.
- ♦  /  Click to turn Beeper & LED Flashing on/off.
- ♦  Click to delete selected Transmitters.
- ♦  Click an option to have selected Transmitters:
 - ♦ **Copy & Paste:** Copy settings from one Transmitter and paste them to another (see *Copy & Paste*, page 213).
 - ♦ **Reboot:** Shut down and restart.
 - ♦ **Reset to Factory:** Reset all setting to the factory default.

Note: The Reset to Factory function resets everything but the login information to the factory default settings. To reset the login information, refer to *Reset All Information* on page 381.

- ♦  Click to *Create Virtual TX* or *Create TX Group* (page 214 & 217).
- ♦  Click to set Transmitter permissions (page 218).
- ♦  Click to search for Transmitters.
- ♦  Click to filter Transmitters shown on the page.
- ♦  Click to switch between *Grid View* and *List View*.

SFP Module Detection

When an SFP module is used on the Transmitter added, the CCKM can automatically detect and display its type, between **Fiber** and **Copper**, as exemplified below.



Transmitter Configuration

When the KE Matrix Manager discovers Transmitters on the network they appear on the *Transmitter* settings page. Double-click a Transmitter to configure its settings.

Transmitter Configuration

| Basic | Video Settings |
|--|---|
| Device Name: <input type="text" value="KE6900T-1"/> Description: <input type="text"/> Location: <input type="text" value="All"/> Mode: <input checked="" type="radio"/> Extender <input type="radio"/> Matrix Enable Media: <input checked="" type="checkbox"/> Video <input checked="" type="checkbox"/> Audio <input checked="" type="checkbox"/> USB <input checked="" type="checkbox"/> RS232 EDID Mode: <input type="text" value="ATEN Default"/> Multicast Video: <input checked="" type="radio"/> Enable <input type="radio"/> Disable Multicast Audio: <input checked="" type="radio"/> Enable <input type="radio"/> Disable Occupy Timeout: <input type="text" value="5"/> sec(0-240) Port OS: <input type="text" value="Win10 version 1803 or later"/> OS Language: <input type="text" value="English (US)"/> CCKM IP: <input type="text" value="10.0.92.96"/> <input type="text" value="9110"/> IP Installer: <input checked="" type="radio"/> Enable <input type="radio"/> Disable <input type="radio"/> View Only | Video Type: <input type="text" value="DVI-D + DVI-D"/> Color Depth: <input type="text" value="24"/> Bandwidth: <input type="text" value="Unlimited"/> Video Quality: <input type="text" value="Lossless"/> Background Refresh: <input type="text" value="Every 32 frames"/> |
| RS232 Settings Baud Rate: <input type="text" value="9600"/> Stop Bits: <input type="text" value="1"/> Parity: <input type="text" value="None"/> Flow Control: <input type="text" value="None"/> Data Bits: <input type="text" value="8"/> | IP Settings <input checked="" type="radio"/> DHCP <input type="radio"/> Manual IP Address: <input type="text" value="192.168.0.61"/> Subnet Mask: <input type="text" value="255.255.255.0"/> Default Gateway: <input type="text"/> |
| | Password Protection <input type="radio"/> Disable <input checked="" type="radio"/> Enable Password: <input type="text"/> Confirm: <input type="text"/> |

CANCEL SAVE

Note: For transmitter models with Internet Port (AiT models), the settings page above is under the “Main” tab. An extra “Internet Port” tab is available. For more information, refer to *Internet Port (AiT models only)* on page 207.

Transmitter Configuration

| Main | Internet Port |
|--|---|
| Basic Device Name: <input type="text" value="KE6940AIT"/> Description: <input type="text"/> | Video Settings Video Type: <input type="text" value="DVI-D + DVI-D"/> Color Depth: <input type="text" value="24"/> |

| Item | Description |
|-------|--|
| Basic | <p>Device Name: Enter a name for the Transmitter.</p> <p>Description: Enter a description for the Transmitter.</p> <p>Location: Use the drop-down menu to select a Location for the device. Locations filter the Transmitters seen on the settings page.</p> <p>Mode: Use the radio button to select how the Transmitter will be installed and managed:</p> <ul style="list-style-type: none">◆ Select Extender mode for simple one-to-one (Transmitter to Receiver) setups that are managed at the Receiver's OSD menu.◆ Select Matrix mode to manage devices and connections over the LAN from the KE Matrix Manager software. This mode is for advanced administration of Transmitter and Receiver connections configured within the KE Matrix Manager Web GUI. <p>Enable Media: Select which source type the Transmitter can stream: Video, Audio, USB and RS232.</p> <p>Audio Input: Use this option to select the Transmitter's audio source signal: <i>HDMI</i>, <i>Analog</i>, or <i>Auto</i>. This setting should reflect the audio setting configured on the computer.*</p> |

| Item | Description |
|-------|--|
| Basic | <p>EDID Mode: EDID contains a display's basic information and is used by the source device to utilize the best resolution across different monitors. When <i>Manual</i> or <i>Remix</i> is selected, the Receiver's OSD will have a button allowing the local EDID setting to be configured for the connection (see <i>EDID Mode</i>, page 161). Select how you want the source device to acquire the display's EDID:</p> <ul style="list-style-type: none"> ◆ ATEN Default: EDID is set to the default ATEN configuration. This setting must be used when connecting KE6900 devices to KE8950 devices. ◆ Auto: Checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays. ◆ Manual: Manually set the EDID configuration from the Receiver's OSD (see <i>EDID Mode</i>, page 161). ◆ Remix: Manually checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays (see <i>EDID Mode</i>, page 161). <p>Multicast Video: Select Enable to allow a broadcast of the Transmitter's video signal to be sent to multiple Receivers.</p> <p>Multicast Audio: Select Enable to allow a broadcast of the Transmitter's audio signal to be sent to multiple Receivers.</p> <ul style="list-style-type: none"> ◆ Occupy Timeout: Set a time threshold for Receivers whose Access Mode has been set to Occupy. If there is no activity from the Receiver occupying the port for the amount of time set here, the Receiver is timed out and the port is released. The first Receiver to send keyboard or mouse input after the port has been released gets to occupy the port. Input a value from 1 to 240 seconds. <p>Port OS: Use the drop-down menu to select the operating system on the computer connected to the Transmitter.</p> <p>OS Language: Use the drop-down menu to select the operating system language on the computer connected to the Transmitter.</p> <p>CCKM IP: Set the IP address and Port number of the computer running the KE Matrix Manager software. The default port number is 9110.</p> <p>IP Installer: The IP Installer is an external Windows-based utility for assigning an IP address to the device. Click a radio button to select Enable, Disable or View Only for the IP Installer utility. See <i>IP Installer</i>, page 378 for instructions.</p> |

| Item | Description |
|---------------------|---|
| Video Settings | <p>These refer to the Transmitter's video settings:</p> <p>Video Type: Select the DVI video connector being used by the display: Digital (DVI-D) or Digital (DVI-I). This option is only available for KE6900 units.</p> <p>Color Depth: Select the number of bits to use for the color depth: 24, 16, or 8. This is the number of bits used to describe the color of a single pixel. A bit depth determines the number of colors that can be displayed at one time.</p> <p>Bandwidth Limit: Select the maximum bandwidth that the Transmitter can use to transmit video over the network. A lower bandwidth transmits lower quality video; a higher bandwidth sends higher quality video but this can affect network speed.</p> <p>Video Quality: Select the video quality to use, with the highest to lowest quality being Lossless > Light Compression > Medium Compression > Heavy Compression > Maximum Compression.</p> <p>Background Refresh: Sets how often the Transmitter refreshes the background image on the connected display. Options are to refresh every 256,128, 64, 32,16, or 0 frames.</p> |
| IP Settings | <p>For dynamic IP address assignment, select the DHCP radio button.</p> <p>To specify a fixed IP Address, Subnet Mask, and Default Gateway select the Manual radio button and fill in the fields with values appropriate for your network.</p> <p>For information to configure the network settings locally on the device, see <i>Network Configuration</i>, page 133.</p> |
| Password Protection | <p>Select Enable to require a password to access the Transmitter's OSD configuration screens (see page 141).</p> <p>Enter a <i>Password</i>, and confirm the password in the <i>Confirm</i> box.</p> |
| RS232 Settings | <p>Configure the serial device settings for the Transmitter. The default settings are:</p> <p>Baud Rate: 9600</p> <p>Parity: None</p> <p>Data Bits: 8 bits</p> <p>Stop bits: 1 bit</p> <p>Flow Control: None</p> |

| Item | Description |
|----------------|---|
| Replace Device | <p>Click Replace Device in the top left corner to replace an old Transmitter with a new one.* All settings are copied from the old Transmitter to the new Transmitter. Before using this feature, connect the new Transmitter to the network. After clicking <i>Replace Device</i>, use the drop-down menu to select the new Transmitter where the settings will be applied.</p> <p>Note:</p> <ol style="list-style-type: none">1. This option only appears when a Transmitter is offline.2. This feature can be used for both Receivers and Transmitters. Replacement should be carried out on a similar model. |
| Save | Click Save to save changes to the properties. |
| Cancel | Click Cancel to exit without saving. |

Internet Port (AiT models only)

For transmitter models (AiT models) with Internet Port, an “Internet Port tab” is available for configuration.

Transmitter Configuration

Main
Internet Port

Basic

IP Installer Enable Disable View Only

Program Port

HTTP Port

HTTPS Port

CCVSR

Disable

Enable

MAC address

Service Port

Working Mode

Enable ICMP

Disable Browser Service Disable Browser

Enable Client AP Device List

IPv4 Settings

DHCP

Manual

IP Address

Subnet Mask

Default Gateway

Obtain DNS server address automatically

Set DNS server address manually

Perferred DNS server:

Alternate DNS server:

IPv6 Settings

DHCP

Manual

IP Address

Prefix length

Default Gateway

Obtain DNS server address automatically

Set DNS server address manually

Perferred DNS server:

Alternate DNS server:

Private Certificate

Private Key

Certificate

Certificate Signing Request

Certificate

CANCEL SAVE

Basic

■ IP Installer

The IP Installer is an external Windows-based utility for assigning IP addresses to the transmitter. Click one of the radio buttons to select *Enabled*, *Disabled*, or *View Only* for the IP Installer utility. See p. 378 for IP Installer details.

-
- Note:**
1. If you select *View Only*, you will be able to see the transmitter in the IP Installer's Device List, but you will not be able to change the IP address.
 2. For security, we strongly recommend that you set this to *View Only* or *Disabled* after using it.
-

■ Ports

Specify the ports that the transmitter uses for various network services.

- ♦ **Program:** This is the port number for connecting to the transmitter from the Windows Client and Java Viewers, and from the Windows and Java Client AP programs. The default is 9000.
- ♦ **HTTP:** The port number for a browser login. The default is 80.
- ♦ **HTTPS:** The port number for a secure browser login. The default is 443.

-
- Note:**
1. Valid entries for all of the Service Ports are from 1–65535.
 2. The service ports cannot have the same value. You must set a different value for each one.
 3. If there is no firewall (on an intranet, for example), it does not matter what these numbers are set to, since they have no effect.
-

If a firewall is being used, the Administrator can specify the port numbers that the firewall will allow (and set the firewall accordingly). If a port other than the default is set, users must specify the port number as part of the IP address when they log in. If not, an invalid port number (or no port number) is specified, the transmitter will not be found.

CCVSR

Important operations occur on the transmitter can be recorded using the CCVSR program.

Check **Enable** to enable the CCVSR function and specify the **MAC address** and the **Service Port** of the computer the CCVSR runs on.

Note: The valid port range is 1–65535. The port number must different than the one used for the *Program* port (see *Ports*, page 208).

Mode

Use this section to set the working mode parameters.

- ♦ **Enable ICMP:** Check to enable ICMP service.
- ♦ **Disable Browser Service:** Check to disable a particular access. Available options are: browser, http or https.
- ♦ **Enable Client AP Device List:** Check to enable this function. When enabled, the unit will be discoverable in the Server List when using the WinClient or Java Client AP (see *Starting Up* on page 285). Disabling this function will render the unit undiscoverable in the Server List but can still be connected to.

IPv4 Settings

The transmitter can either have its IP address assigned dynamically at boot-up (DHCP), or it can be given a fixed IP address.

- ♦ For dynamic IP address assignment, select the **DHCP** radio button. (This is the default setting.)
- ♦ To specify a fixed IP address, select the **Manual** radio button and fill in the IP address.

Note: 1. If you choose *DHCP*, when the transmitter starts up it waits to get its IP address from the DHCP server. If it has not obtained the address after one minute, it automatically reverts to its factory default IP address, 192.168.0.61.

2. If the transmitter is on a network that uses DHCP to assign network addresses, and you need to ascertain its IP address, you can use the IP installer. See *IP Installer*, page 378 for information.
-

The transmitter can either have its DNS server address assigned automatically, or a fixed address can be specified.

- ♦ For automatic DNS Server address assignment, select the **Obtain DNS server address automatically** radio button.
- ♦ To specify a fixed address, select the **Set DNS server address manually** radio button and fill in the required information.

Note: Specifying at the alternate DNS Server address is optional.

IPv6 Settings

The transmitter can either have its IPv6 address assigned dynamically at boot-up (DHCP), or it can be given a fixed IPv6 address.

- ♦ For dynamic IP address assignment, select the **DHCP** radio button. (This is the default setting.)
- ♦ To specify a fixed IP address, select the **Manual** radio button and fill in the IP address.

The transmitter can either have its DNS server address assigned automatically, or a fixed address can be specified.

- ♦ For automatic DNS Server address assignment, select the **Obtain DNS server address automatically** radio button.
- ♦ To specify a fixed address, select the **Set DNS server address manually** radio button and fill in the required information.

Note: Specifying at the alternate DNS Server address is optional.

Private Certificate

When logging in over a secure (SSL) connection, a signed certificate is used to verify that the user is logging in to the intended site. For enhanced security, the Private Certificate section allows you to use your own private encryption key and signed certificate, rather than the default ATEN certificate.

There are two methods for establishing your private certificate: generating a self-signed certificate and importing a third-party certificate authority (CA) signed certificate.

Generating a Self-Signed Certificate

If you wish to create your own self-signed certificate, a free utility – openssl.exe – is available for download over the web. See *Self-Signed Private Certificates*, page 380 for details about using OpenSSL to generate your own private key and SSL certificate.

Obtaining a CA Signed SSL Server Certificate

For the greatest security, we recommend using a third party certificate authority (CA) signed certificate. To obtain a third party signed certificate, go to a CA (Certificate Authority) website to apply for an SSL certificate. After the CA sends you the certificate, save it to a convenient location on your computer.

Importing the Private Certificate

To import the private certificate, do the following:

1. Click **Browse** to the right of **Private Key**, navigate to where your private encryption key file is located and select it.
2. Click **Browse** to the right of **Certificate**, navigate to where your certificate file is located and select it.
3. Click **Upload** to complete the procedure.

Note: Both the private encryption key and the signed certificate must be imported at the same time.

You can click **Restore Default** to restore any changes made previously.

Certificate Signing Request

The Certificate Signing Request (CSR) section provides an automated way of obtaining and installing a CA signed SSL server certificate.

To perform this operation, do the following:

1. Click **Create CSR**. The following dialog box appears:

Certificate Signing Request

| | |
|-------------------------|---|
| Country (2 letter code) | <input style="width: 100%;" type="text"/> |
| State or Province | <input style="width: 100%;" type="text"/> |
| Locality | <input style="width: 100%;" type="text"/> |
| Organization | <input style="width: 100%;" type="text"/> |
| Unit | <input style="width: 100%;" type="text"/> |
| Common Name | <input style="width: 100%;" type="text"/> |
| Email Address | <input style="width: 100%;" type="text"/> |

CANCEL
CREATE

- Fill in the form – with entries that are valid for your site – according to the example information in the following table:

| Information | Example |
|-------------------------|---|
| Country (2 letter code) | TW |
| State or Province | Taiwan |
| Locality | Taipei |
| Organization | Your Company, Ltd. |
| Unit | Techdoc Department |
| Common Name | mycompany.com This must be the exact domain name of the site that you want the certificate to be valid for. If the site's domain name is <i>www.mycompany.com</i> , and you only specify <i>mycompany.com</i> , the certificate will not be valid. |
| Email Address | administrator@yourcompany.com |

- After filling in the form (all fields are required), click **Create**.
A self-signed certificate based on the information you just provided is now stored on the transmitter.
- Click **Get CSR**, and save the certificate file (*csr.cer*) to a convenient location on your computer
This is the file that you give to the third party CA to apply for their signed SSL certificate.
- After the CA sends you the certificate, save it to a convenient location on your computer. Click **Browse** to locate the file; then click **Upload** to store it on the transmitter.

Note: When you upload the file, the transmitter checks the file to make sure the specified information still matches. If it does, the file is accepted; if not, it is rejected.

If you want to remove the certificate (to replace it with a new one because of a domain name change, for example), simply click **Remove CSR**.

Copy & Paste

Copy & Paste allows you to copy settings from one Transmitter and paste them to another. To copy Transmitter settings to another device, do the following:

1. Select a Physical Transmitter.
2. On the Transmitter menu bar, click **Copy & Paste** (page 201).
3. Check the boxes of the settings you want to copy, and click **Next**.

Copy & Paste

1. Please select the items you want to copy.

Select All

Unselect All

Basic

- Description
- Location
- Mode
- Enable Media
- EDID Mode
- Multicast Video
- Multicast Audio
- Occupy Timeout
- Port OS
- OS Language
- CCKM IP
- IP Installer

RS232 Settings

- Baud Rate
- Parity
- Data Bits
- Stop Bits
- Flow Control

Video Settings

- Video Type
- Color Depth
- Bandwidth
- Video Quality
- Background Refresh

CANCEL
NEXT

4. Select the Transmitter(s) where you want to apply the settings, and click **Done**.

Copy & Paste

2. Please select the targets you want to paste.

KE6940T6Z
 KE8950T

PREVIOUS
DONE

Virtual Transmitter

Creating a *Virtual Transmitter* allows you to create one connection that sources media (KVM, audio, USB, serial) from different Transmitters. Virtual Transmitters appear on the *Transmitter* settings page with **Virtual TX** in the top right corner. Simply select an online Transmitter for each media source. Dual Display Transmitters can be added as two separate Virtual Transmitters.

To create a Virtual Transmitter, in *Transmitter* settings click **+** and then select **Create Virtual TX**.

Create Virtual TX

| | |
|--------------------------|--|
| Name | <input type="text" value="VirtualTX"/> |
| Description | <input type="text"/> |
| Location | <input type="text" value="All Devices"/> ▾ |
| <hr/> | |
| Video + Keyboard + Mouse | <input type="text" value="--"/> ▾ |
| Audio | <input type="text" value="--"/> ▾ |
| USB Peripheral | <input type="text" value="--"/> ▾ |
| Serial | <input type="text" value="--"/> ▾ |

←
CANCEL APPLY

| Item | Description |
|-------------|--|
| Name | Enter a name for the Virtual Transmitter. |
| Description | Enter a description for the Virtual Transmitter. |
| Location | Use the drop-down menu to select a location for the Virtual Transmitter or leave it as All Devices. See <i>Location</i> , page 200, for details. |


| Item | Description |
|--------------------------------|---|
| Video + Keyboard + Mouse | Use the drop-down menu to select a KVM (keyboard, video, mouse) source for the Virtual Transmitter. |
| Audio | Use the drop-down menu to select an audio source for the Virtual Transmitter. |
| USB Peripheral | Use the drop-down menu to select a USBPeripheral source for the Virtual Transmitter. |
| Serial | Use the drop-down menu to select a serial source for the Virtual Transmitter. |
| Apply | Click Apply to save the changes. |
| Cancel | Click Cancel to exit without saving. |

Intelligent Dual Video Output Management

For the A models (KE6900A, KE6940A), the *Intelligent Dual Video Output Management* feature allows the separation of a Dual Display Transmitter's (KE6940AT) video outputs (DVI:1 and DVI:2) as two separate Virtual Transmitters. These separated outputs can be accessed from different Receivers (KE6900AR or KE6940AR). Receivers can switch between and connect to both Virtual Transmitters independently with the *Access Type* determining which Receiver has control (see page 218).

To use this setup, install the KE devices as shown below and create two Virtual Transmitters, selecting **DVI:1** and **DVI:2** as the *KVM* source for each Virtual Transmitter.


For non-A model receivers (e.g. KE6910R, KE6912R), you can select between DVI:1 or DVI:2, but you will always be getting video output from DVI:1.



When connecting to either of the two Virtual Transmitters in the setup shown above, the mouse cursor may reside on the **main** or **extended** dual display screen, out of view. Therefore even if you have control of the mouse it may not be visible. To bring the mouse cursor into view on either of the dual display screens, first enable Boundless Switching (see *Boundless Switching*, page 229) and then use the hotkey **F8+F9**.

Transmitter Group

Creating a *Transmitter Group* allows you to create a connection that sources the video from multiple Transmitters to view at across multiple Receiver displays. To use this feature, connect a **Transmitter Group** to a **Receiver Group** (page 226). Transmitter Groups appear at the bottom of the *Transmitter* settings page.

To create a Transmitter Group, in *Transmitter* settings click  and then select **Create Group TX**.

Create Group TX

Name Description Location

Audio USB Serial From the same PC video output

Select a physical transmitter...

KE6940T67
KE6940T

KE6940T1
KE6940T

KE6900ST
KE6900ST

KE8950T61
KE8950T

CANCEL
SAVE

Fill in the appropriate information and then double-click or drag-and-drop Transmitters to add or remove them in the top panel. The Transmitters in the top panel will be used as the video source for the Receiver Group at the Receiver.


| Item | Description |
|-------------------------------|---|
| Name | Enter a name for the Transmitter Group. |
| Description | Enter a description for the Transmitter Group. |
| Location | Use the drop-down menu to select a location for the Transmitter Group or leave as All Devices. See <i>Location</i> , page 200, for details. |
| From the same PC video output | Enable to indicate that all of the video outputs in this Transmitter Group are from the same multi-screen PC. |
| Save | Click Save to save the changes. |
| Cancel | Click Cancel to exit without saving. |

- Note:** 1. You can create up to 4 transmitter groups.
2. Any transmitter can only be added to 1 transmitter group with the *From the same PC video output* option selected at a time.

Transmitter Permissions

Transmitter Permissions sets the users and groups that can access a **Transmitter, Virtual Transmitter, and Transmitter Group**.

Select a device under **Transmitter List**, and then next to each user or group click *All*, *View*, *Occupy*, or *Exclusive* to grant them permission to connect to the Transmitter with this access type. A green block denotes that the user has access.

To set Transmitter Permissions, in *Transmitter* settings, click  .

Set Transmitter Permissions

Transmitter List

[Select All](#) [Unselect All](#) [Select All](#) [Unselect All](#) [Select All](#) [Unselect All](#) [Select All](#) [Unselect All](#) [Select All](#) [Unselect All](#)

| | | <input type="checkbox"/> All | <input type="checkbox"/> View | <input checked="" type="checkbox"/> Share | <input type="checkbox"/> Occupy | <input checked="" type="checkbox"/> Exclusive |
|-----------|-----------|------------------------------|-------------------------------|---|---------------------------------|---|
| GroupTX | User | | | | | |
| GroupTX1 | | | | | | |
| VirtualTX | testtest1 | | | | | |
| TransMit2 | Hary | | | | | |
| KE6940T67 | | | | | | |
| KE6940T1 | | | | | | |
| KE6900ST | | | | | | |
| KE8950T61 | | | | | | |


■ Group Inherited
 ■ Permission Granted
 No Permission
 CANCEL APPLY

| Item | Description |
|------------------|--|
| Transmitter List | Lists Transmitters, Virtual Transmitters and Transmitter Groups that can be selected to set permissions. |
| Drop-Down Menu | Use the drop-down menu to select User or Group . After making a selection, the list of users or groups appears. Set permissions by selecting the access type (All, View, Share, Occupy, Exclusive) next to each user or group. |








| Item | Description |
|-------------|---|
| Access Type | <p>Select the access you want to grant to a user or group by clicking the boxes under the headings. This defines how the Transmitter can be accessed by a user or group. The access type will appear available for the user in the Receiver's OSD Connections menu. To disable an access type, uncheck a box in the heading.</p> <p>All: Select to grant all access permissions, <i>View</i>, <i>Share</i>, <i>Occupy</i> and <i>Exclusive</i>, to the users or user groups.</p> <p>View: User can only view the remote screen, and cannot perform operations on it.</p> <p>Share: All users accessing the Transmitter can simultaneously share control of the Transmitter. Input from the users is placed in a queue and executed chronologically.</p> <p>Occupy: The first user to access the Transmitter has control. However, additional users may view the Transmitter's video. If the user who controls the Transmitter is inactive for longer than the time set in the Transmitter's Timeout box, control is transferred to the first user to move the mouse or strike the keyboard.</p> |
| Access Type | <p>Exclusive: The first user to access the Transmitter has exclusive control over the Transmitter. No other users can view the Transmitter. The Timeout function does not apply when Transmitters are accessed with this setting.</p> |
| Apply | Click Apply to save the changes. |
| Cancel | Click Cancel to exit without saving. |






Receiver

Click **Receiver** in the *System Status* panel to open the settings. The Receiver page allows you to add, delete and configure *Receivers* (physical receivers), *Receiver Groups*, and *Video Walls*. The KE Matrix Manager automatically adds Receivers connected to the local area network with a valid IP address.








The meanings of the icons and headings on the page are straightforward and let you view and configure Receivers.

- ◆  *Active* refers to a Receiver connection that is online and in use.
- ◆  *Standby* refers to a Receiver connection that is online.
- ◆  *Offline* refers to a Receiver connection that is offline.
- ◆  **All Devices** Use this drop-down menu to filter Receivers by location. Use Locations to limit the Receivers seen on the page.
 - ◆  Click to add a new **Location**.
 - ◆  Select a Receiver and click the **Move to** icon to add devices to a Location.
 - ◆  Select a Location from the drop-down menu and click this icon to delete it.


- ♦  Select a Location and click this icon to change the name.
- ♦  /  Click to turn Beeper & LED Flashing on/off.
- ♦  Click to delete selected Receivers.
- ♦  Click an option to have selected Receivers:
 - ♦ **Copy & Paste:** Copy settings from one Receiver and paste them to another (see *Copy & Paste*, page 225).
 - ♦ **Reboot:** Shut down and restart.
 - ♦ **Reset to Factory:** Reset all setting to the factory default.

Note: The Reset to Factory function resets everything but the login information to the factory default settings. To reset the login information, refer to *Reset All Information* on page 381.

- ♦  Click to *Create Receiver Group* or *Video Wall* (page 226 & 227).
- ♦  Click to set Receiver permissions (page 230).
- ♦  Click to search for Receivers.
- ♦  Click to filter Receivers shown on the page.
- ♦  Click to switch between *Grid View* and *List View*.

SFP Module Detection

When an SFP module is used on the Receiver added, the CCKM can automatically detect and display its type, between **Fiber** and **Copper**, as exemplified below.



Receiver Configuration

When the KE Matrix Manager discovers Receivers on the network they appear on the *Receiver* settings page. Double-click a Transmitter to configure its settings.

Receiver Configuration

| | |
|--|---|
| <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 5px;"> <p>Basic</p> <p>Device Name: <input type="text" value="KE6940R.17"/></p> <p>Description: <input type="text"/></p> <p>Location: <input type="text" value="All"/></p> <p>Mode: <input checked="" type="radio"/> Extender <input type="radio"/> Matrix</p> <p>Enable Media: <input checked="" type="checkbox"/> Video <input type="checkbox"/> Audio <input checked="" type="checkbox"/> USB <input type="checkbox"/> RS232</p> <p>CCKM IP: <input type="text" value="10.0.90.152"/> <input type="text" value="9110"/></p> <p>IP Installer: <input checked="" type="radio"/> Enable <input type="radio"/> Disable <input type="radio"/> View Only</p> </div> <div style="border: 1px solid #ccc; padding: 5px;"> <p>RS232 Settings</p> <p>Baud Rate: <input type="text" value="9600"/></p> <p>Parity: <input type="text" value="None"/></p> <p>Data Bits: <input type="text" value="8"/></p> <p>Stop Bits: <input type="text" value="1"/></p> <p>Flow Control: <input type="text" value="None"/></p> </div> | <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 5px;"> <p>Extender Properties</p> <p>Transmitter Video IP: <input type="text" value="192.168.0.61"/></p> <p>Transmitter Audio IP: <input type="text" value="192.168.0.61"/></p> <p>Transmitter USB IP: <input type="text" value="192.168.0.61"/></p> <p>Transmitter RS232 IP: <input type="text" value="192.168.0.61"/></p> </div> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 5px;"> <p>IP Settings</p> <p><input checked="" type="radio"/> DHCP <input type="radio"/> Manual</p> <p>IP Address: <input type="text" value="192.168.0.60"/></p> <p>Subnet Mask: <input type="text" value="255.255.255.0"/></p> <p>Default Gateway: <input type="text"/></p> </div> <div style="border: 1px solid #ccc; padding: 5px; margin-bottom: 5px;"> <p>Password Protection</p> <p><input checked="" type="radio"/> Disable <input type="radio"/> Enable</p> <p>Password: <input type="text"/></p> <p>Confirm: <input type="text"/></p> </div> <div style="border: 1px solid #ccc; padding: 5px;"> <p>USB Mode</p> <p>Mode: <input checked="" type="radio"/> Virtual Media <input type="radio"/> Generic USB Device</p> <p>Encryption: <input type="checkbox"/> Enable</p> </div> |
|--|---|

| Item | Description |
|---------------------|---|
| Basic | <p>Device Name: Enter a name for the Receiver.</p> <p>Description: Enter a description for the Receiver.</p> <p>Location: Use the drop-down menu to select a Location for the device. Locations help organize how you view Receivers on the settings page.</p> <p>Mode: Use the radio button to select how the Receivers will be installed and managed:</p> <ul style="list-style-type: none"> ◆ Select Extender mode for simple one-to-one (Transmitter to Receiver) setups that are managed with the Receiver's OSD menu. ◆ Select Matrix mode to manage devices and connections over the LAN from the KE Matrix Manager software. This mode is for advanced administration of Transmitter and Receiver connections configured within the KE Matrix Manager Web GUI. <p>Enable Media: Select which source type the Receiver can stream: Video, Audio, USB and RS232.</p> <p>Audio Output: Use this option to independently stream <i>HDMI</i>, <i>Analog</i>, or <i>Both</i> audio signals to digital or analog audio output devices (speakers) connected to the Receiver.*</p> <p>CCKM IP: Set the IP address and Port number of the computer running the KE Matrix Manager software. The default port number is 9110.</p> <p>IP Installer: The IP Installer is an external Windows-based utility for assigning an IP address to the device. Click a radio button to select Enable, Disable or View Only for the IP Installer utility. See <i>IP Installer</i>, page 378 for instructions.</p> |
| RS232 Settings | <p>Configure the serial device settings for the Transmitter. The default settings are:</p> <p>Baud Rate: 9600</p> <p>Parity: None</p> <p>Data Bits: 8 bits</p> <p>Stop bits: 1 bit</p> <p>Flow Control: None</p> |
| Extender Properties | <p>If you selected Extender mode (under Basic) set the Transmitter IP address for the Receiver's Video, Audio, USB, and RS232 source.</p> <p>If you selected Matrix mode (under Basic) the <i>Properties</i> will be grayed out. Use Transmitters, Virtual Transmitters, and Transmitter Groups to configure the connections (see <i>Transmitter</i>, page 200).</p> |

| Item | Description |
|---------------------|--|
| IP Settings | <p>For dynamic IP address assignment, select the DHCP radio button.</p> <p>To specify a fixed IP Address, Subnet Mask, and Default Gateway select the Manual radio button and fill in the fields with values appropriate for your network.</p> <p>For information to configure the network settings locally on the device, see <i>Network Configuration</i>, page 133.</p> |
| Password Protection | <p>Select Enable to require a password to access the Receiver's OSD configuration screen (see page 139).</p> <p>Enter a <i>Password</i>, and confirm the password in the <i>Confirm</i> box.</p> |
| USB Mode | <p>Select the type of USB device you will connect to the USB ports:</p> <p>Virtual Media: Select this option only if you are plugging a USB disk drive (including USB HDD/optical disk) into the USB ports. This will give you the highest data transfer speeds but will not allow other USB devices to work when plugged into the USB ports. When Receivers connected to the same transmitter mount or unmount USB disk drives, the keyboard and mouse operations will experience a brief delay. Transmitters can support up to 12 virtual media connections at the same time (keyboard/mouse included).</p> <p>vUSB (Generic USB device): Use this option to plug USB peripherals into the USB ports. KE6900ST/KE8900ST/KE9900ST do not support the Generic USB Device mode. In this mode, KE6900/KE6940 Transmitters support up to 2 USB connections; and allover KE Series Transmitters support up to 5 USB connections (keyboard/mouse excluded).</p> <p>Encryption: Check this box to encrypt USB disk drives plugged into the USB ports.</p> <p>Note: The vUSB option also allows a keyboard and mouse with special functions to plug into the USB ports for console use. Use this only if the special functions of the keyboard or mouse are required but do not work when plugged into the console ports. When the keyboard and mouse are plugged into the USB ports, they will not work within the OSD menus. To work within the OSD menus, the keyboard and mouse must be plugged into the console ports.</p> |
| Replace Device | <p>Click Replace Device in the top left corner to replace an old Receiver with a new one.* All settings are copied from the old Receiver to the new Receiver. Before using this feature, connect the new Receiver to the network. After clicking <i>Replace Device</i>, use the drop-down menu to select the new Receiver where the settings will be applied.</p> <p>Note:</p> <ol style="list-style-type: none"> 1. This option only appears when a Transmitter is offline. 2. This feature can be used for both Receivers and Transmitters. Replacement should be carried out on a similar model. |

| Item | Description |
|--------|--|
| Save | Click Save to save changes to the properties. |
| Cancel | Click Cancel to exit without saving. |

Copy & Paste

Copy & Paste allows you to copy settings from one Receiver and paste them to another. To copy Receiver settings to another device, do the following:

1. Select a Physical Receiver.
2. On the Receiver menu bar, click **Copy & Paste** (page 221).
3. Check the boxes of the settings you want to copy, and click **Next**.

Copy & Paste

1. Please select the items you want to copy.

Select All

Unselect All

Basic

- Description
- Location
- Mode
- Enable Media
- CCKM IP
- IP Installer

RS232 Settings

- Baud Rate
- Parity
- Data Bits
- Stop Bits
- Flow Control

USB Mode

- Mode
- Encryption

Extender Properties

- Transmitter Video IP
- Transmitter Audio IP
- Transmitter USB IP
- Transmitter RS232 IP

CANCEL
NEXT

4. Select the Receiver(s) where you want to apply the settings, and click **Done**.

Copy & Paste

2. Please select the targets you want to paste.

Select All


Unselect All


KE8940R62
 KE8950R94

PREVIOUS
DONE

Receiver Group

Creating a *Receiver Group* allows you to connect the video from multiple transmitters to multiple Receiver displays. To use this feature, connect a **Transmitter Group** (page 217) to a **Receiver Group** (see *Instant Link*, page 189). Receiver Groups appear at the bottom of the *Receiver* settings page.

To create a Receiver Group, in *Receiver* settings, click  and then select **Create RX Group**.




Fill in the appropriate information and then double-click or drag-and-drop Receivers to add or remove them in the top panel. The Receivers in the top panel will be used to view the video from the Transmitter Group. To connect a Transmitter Group to a Receiver Group, see *Instant Link*, page 189.


| Item | Description |
|---------------------|---|
| Name | Enter a name for the Receiver Group. |
| Description | Enter a description for the Receiver Group. |
| Location | Use the drop-down menu to select a location for the Receiver Group or leave it as All Devices. See <i>Location</i> , page 200, for details. |
| Boundless Switching | Use the radio button to enable or disable Boundless Switching. See <i>Boundless Switching</i> , page 229 for details. |
| Group Login | When enabled, users logging into or out of 1 receiver automatically logs into or out of all other receivers within the Receiver Group, using the same set of credentials. |
| Save | Click Save to save the changes. |
| Cancel | Click Cancel to exit without saving. |

Note: You can create up to 4 receiver groups.

Video Wall


Creating a *Video Wall* allows you to create connections that combine Receiver displays to form a large video wall. Use the options to group multiple Receivers in the video wall. A video wall can contain multiple forms of single displays and grouped displays in various layouts. Video Walls appear listed below Receivers, on the *Receivers* settings page.





To create a Video Wall, in *Receiver* settings, click  and then select **Create Video Wall**.




Select the number of displays and then group multiple displays to form large screens and/or use single displays for independent screens to create the video wall's layout. Click the bar -- under the display icon to select a Receiver for each display. This configuration should match the actual video wall layout.

| Item | Description |
|--------------------|---|
| Name | Enter a name for the Video Wall. |
| Description | Enter a description for the Video Wall. |
| Number of Displays | Use the Horizontal and Vertical drop-down menus to select the number of displays that make up the video wall (a maximum of 64 are supported). Match this to the physical layout of the displays. Click the refresh icon to update the layout. |


| Item | Description |
|--|--|
| Bezel Dimension | Use the two boxes to increase/decrease the frame size of each active display. |
| Lock / Unlock  | Click the monitor to Lock the (2) bezel settings, so that when one size is changed they all change. Click the monitor to Unlock the (2) bezel settings, so that each size can be set independently. |
| Layout Selection | Click + or X to add or remove additional layouts to the Video Wall. The options listed here will appear in a drop-down menu for the Video Wall, allowing you to quickly choose different layouts from the Receiver settings page. Arrows below the Layout Selection box allow you to move up or down in the list. Three layout templates are available for quick setup. The Videowall and Splitter options can not be changed but allow you to select the Receivers. These three layouts can not be deleted. <ul style="list-style-type: none"> ◆ <i>Video Wall</i> provides a basic full screen layout where one Transmitter connects to multiple Receivers to display the video together as one full screen. ◆ <i>Splitter</i> provides a layout that connects a Transmitter to multiple Receivers that show the same video displayed on separate screens independently. <ol style="list-style-type: none"> 3. <i>Customized</i> provides a basic full screen layout that can be configured into groups (see Group below) as desired.*When using the KE6940R in <i>Customized</i> layouts, only the KE6940's first video port will display video because each port's video source is independent. When using the KE6940R in <i>Video Wall</i> or <i>Splitter</i> layouts both video ports will display video. Video wall only supports Share, View Only and Occupy access modes. |
| Location | Use the drop-down menu to select a location for the Video Wall or leave it as All Devices. See <i>Location</i> , page 200, for details. |
| Group Login | When enabled, users logging into or out of 1 receiver automatically logs into or out of all other receivers within the Video Wall, using the same set of credentials. |

| Item | Description |
|---|--|
| Boundless Switching | <p>Enable this feature to allow you to switch KVM control between different receivers by moving the mouse cursor across screen boundaries. This option is disabled by default.</p> <p>When Boundless Switching is enabled, make sure to disable the following settings:</p> <ul style="list-style-type: none"> ◆ On the computer, under Control Panel - Mouse Properties - Pointer Options, uncheck Enhance pointer precision. ◆ On the CCKM Main page, click <i>Settings</i> (page 249), then on the <i>General</i> tab scroll down and disable Fast Switching. <p>Note:</p> <ul style="list-style-type: none"> ◆ Dual Display Transmitters can be set up as two independent Virtual Transmitters with Boundless Switching. The placement of the KE6940 setup must have DVI-1 as the main display on the left and DVI-2 as a secondary display on the right. Boundless Switching supports both single and dual video outputs from any one computer. ◆ For multi-display PCs, make sure of the following: <ol style="list-style-type: none"> 1. All video outputs are aligned in a row with top alignment and the main screen on the far left. 2. The transmitter's port OS has been properly set, see page 204. 3. Users can optionally group all video outputs from the same PC into a transmitter group. See p. 217. ◆ If the mouse cursor disappears under a Linux operating system, execute this command: <pre>gsettings set org.gnome.setting-daemon.plugins.cursor active false</pre> |
|  | Use the slide bar to zoom in or out for a better view of the Video Wall layout. |
|  | Click this icon to reset the zoom back to full size. |
|  | Select multiple display icons and click the Group button to group the displays into one screen. |
|  | Select a group and click Ungroup to ungroup the displays. |
| Fit Mode | <p>Select how the video wall will be displayed:</p> <p>Height: Fits the video to the height of the display.</p> <p>Width: Fits the video to the width of the display.</p> <p>Scale: Fits the video on the entire display.</p> |

| Item | Description |
|---|--|
|  | Use the RX OSD button to enable/disable showing the Receiver's name and IP address in the top left corner of the connected display. This helps identify which Receiver is connected to the display. |
| Save | Click Save to save the changes. |
| Cancel | Click Cancel to exit without saving. |

Receiver Permissions

Receiver Permissions sets which users and groups can access a Receiver. Select a device under the **Receiver List**, and then click under Operation to grant a user or group permission to access the device. This will allow the user to login to the Receiver's OSD menu to access the Connections tab.

To set Receiver Permissions, in *Receiver* settings, click  .

Set Receiver Permissions

Receiver List

- KE6900R71
- KE6940R70
- KE8950R72

User ▾

testtest1

Harry

Select All Unselect All

Operation

■ Group Inherited
 ■ Permission Granted
 □ No Permission

CANCEL
APPLY

| Item | Description |
|----------------|--|
| Receiver List | Lists the Receivers which can be selected to set permissions. |
| Drop-Down Menu | Use the drop-down menu to select <i>User</i> or <i>Group</i> . After making a selection, the list of users or groups appears. Set permissions by selecting the Operation box next to each user or group. |









| Item | Description |
|-----------|--|
| Operation | Click the Operation box next to each user or group to apply access rights on the selected device. This gives users and groups permission to log in to the Receiver's OSD. If a user inherits its permissions from a group, the box will be Blue. To disable access rights for all users, uncheck the box in the heading. |
| Apply | Click Apply to save the changes. |
| Cancel | Click Cancel to exit without saving. |




Switch

Click **Switch** in the *System Status* panel to open the settings. On this page you can edit and delete *Network Switches* added to the CCKM (for adding switches, see *Adding Network Switches*, page 187).



The meanings of the icons and headings on the page are straightforward and let you view and configure Network Switches.

- ◆  *Active* refers to a Network Switch connection that is online.
- ◆  *Offline* refers to a Network Switch connection that is offline.
- ◆  Use this drop-down menu to filter Network Switches by location. Use Locations to limit the Switches seen on the page.
 - ◆  Click to add a new **Location**.
 - ◆  Select a Switch and click the **Move to** icon to add devices to a Location.
 - ◆  Select a Location from the drop-down menu and click this icon to delete it.
 - ◆  Select a Location and click this icon to change the name.
- ◆  Click to delete selected Network Switches.

-  Click to search for Network Switches.
-  Click to filter Network Switches shown on the page.
-  Click to switch between *Grid View* and *List View*.

Network Switch Configuration

When Network Switches are added to the KE Matrix Manager, they appear on the *Switch* settings page. Double-click a Network Switch to configure its settings.

Optionally click **Re-sync parameters** to automatically update the Network Switch by enabling IGMP Snooping, IGMP Querier, Fast Leave, Unregistered Multicast Flooding, Flow Control, and Speed Mode (Auto for Port 1-48 / 10 Gbps FDX for Port 49-52).

Switch Configuration
Re-sync parameters

General
Port Configuration

Basic

Device Name

Description

Location

Unallocated

SNMP Agent Settings

SNMP Version

V1
 V2
 V3

NMS IP / Host Name

Port

Community / User Name

Timeout

Milliseconds

Detect interval

Seconds


CANCEL
SAVE

| Item | Description |
|-------|---|
| Basic | <p>Device Name: Enter a name for the Network Switch.</p> <p>Description: Enter a description for the Network Switch.</p> <p>Location: Use the drop-down menu to select a Location for the device. Locations filter the Network Switches seen on the settings page.</p> |

| Item | Description |
|---------------------|---|
| SNMP Agent Settings | <p>SNMP Version: Select the version of the SNMP used.</p> <p>NMS IP / Host Name: Defines the IP address or the host name of the Network Switch.</p> <p>Port: Defines the port value of the Network Switch.</p> <p>Community / Username: Specifies the SNMP community of the Network Switch.</p> <p>Timeout: Defines timeout threshold in which the Network Switch's connection is reestablished.</p> <p>Detect Interval: Defines the interval in which the connection of the Network Switch is checked for.</p> |

Port Configuration

The *Port Configuration* tab sets the speed mode of each port of the Network Switch.



Click **Save** to finish.

Account

Click **Users** in the *System Status* panel to open the settings. The *Account* page allows you to add, delete and configure users and groups. Instructions for adding users and groups is provide on page 235.

| User Account | | | | | |
|--|---------------|--------|--------------|-------------|-------|
| Users | | Group | | | |
| Name | Type | Status | OSD Language | Description | Group |
| <input type="checkbox"/> Brett | Super User | Active | English | | |
| <input type="checkbox"/> Harry | Super User | Active | English | | |
| <input type="checkbox"/> Testtest | Administrator | Active | English | | |
| <input type="checkbox"/> administrator | Administrator | Active | English | | |
| <input type="checkbox"/> testtest1 | Super User | Active | Japanese | | |

- ◆ The Users and Group buttons appear at the top of the page.
 - ◆ Depending on the item selected, either Users or Groups are listed on the page.
- ◆ The sort order of the information displayed can be changed by clicking the column headings.
- ◆ Three icons in the right corner are used to add users, groups and set permissions, as explained in the sections that follow.


Users

The KE Matrix Manager supports three types of accounts, shown in the table below:

| User Type | Role |
|---------------|---|
| Administrator | Access, push/pull and management of the KE Matrix Manager, including configuration and setting up of devices. Manage Users, Groups, Transmitters, Receivers, Profiles and Video Walls. Configure personal working environments. |
| Super User | Access and push/pull Receivers, Transmitters and Profiles they have been given permission for. |
| User | Access Receivers to connect to Transmitters they have been given permission for. |

Adding Users

To add a user, do the following:

1. Click  on the menu bar.
2. Select **Add New User**. The *Add New User* window opens:

Add New User

Username Local User

Password

Confirm Password

Description

Type Administrator
 Super User
 Users

Status Active
 Disable

OSD Language

Toolbar Hotkey

Logout Timeout min (1-180) Disable

Screen Blanker min(1-30) Disable

OSD Title Bar Duration sec(3-100) Disable

Welcome Message Enable Username

Group

Enter the required information in the fields provided. A description of each is given in the table below:

| Field | Description |
|------------------|--|
| Username | From 1 to 32 characters are allowed depending on the Account Policy settings. |
| Local User | Check the Local User box if the account is for logging in to the KE Matrix Manager software or a Receiver. Uncheck the Local User box if the account is authenticated with a 3rd party external source, such as RADIUS, LDAP/AD, or TACACS+. See <i>ANMS</i> , page 256 for details. |
| Password | From 6 to 32 characters are allowed depending on the Account Policy settings. |
| Confirm Password | To be sure there is no mistake in the password, you are asked to enter it again. The two entries must match. |
| Description | Additional information about the user that you may wish to include. |
| Type | There are three account categories: Administrator, Super User and User. <ul style="list-style-type: none"> ◆ The Administrators have full access to make changes within the KE Matrix Manager software, which includes adding and removing Transmitters, Receivers, accounts, preferences, and configuration settings. ◆ The Super Users have access to the Receiver's OSD menu and can connect Channels and Profiles. ◆ The Users can log in to Receivers to connect channels. |
| Status | Status allows you to control the user's account and access, as follows: <ul style="list-style-type: none"> ◆ <i>Active</i> provides the user with access and permissions as granted. ◆ <i>Disable</i> lets you suspend a user's account without actually deleting it, so that it can be easily reinstated in the future. |
| OSD Language | Click the drop-down menu to select the language you want to use during OSD sessions for this user. Options are: Chinese (Traditional), Simplified Chinese, Japanese, German, Korean, Russian, French, Spanish, and Portuguese. |
| Toolbar Hotkey | Select the hotkey combination to call the Tool Bar function for this user. The Tool Bar is used when accessing the computer from the Transmitter or Receiver side. |
| Logout Timeout | If there is no user input for the amount of time set with this function, the user is automatically logged out. A login is necessary before the KE Matrix Manager can be accessed again. The default is 30 minutes. |
| Screen Blanker | Set how many minutes the device waits when a session is idle before turning off the display. |

| Field | Description |
|------------------------|--|
| OSD Title Bar Duration | When the accessing a port, the top left-hand corner will show a title bar displaying the access mode and the device name. Select how long you wish the title bar is to be displayed for, or check Disable to not show any title bar. |
| Welcome Message | If you want the Welcome Message to appear on screen when the user logs into the KE Matrix Manager, select Enable . If you want the user's Screen Name to appear with the Welcome Message, check the Username check box. |
| Group | Click Select and check a box to add the user to a group. |
| Apply | Click Apply to save the changes. |
| Cancel | Click Cancel to exit without saving. |

3. When your selections have been made click **Apply**.
4. When the *Operation Succeeded* message appears, click **OK**.
5. The new user appears on the main panel.
 - ♦ The columns show the Username; User Level, Status, OSD Language, Description; and Group.


Modifying Users

To modify a user, do the following:

1. In the main panel, double-click the user's name.
2. In the *Edit User* page that comes up, make your changes, then click **Apply**.

Deleting Users

To delete a user, do the following:


1. In the main panel, check the box next to the user's name.
2. Click  .
3. Click **OK**.


Groups

Groups allow administrators to easily and efficiently manage users and devices. Since device access rights apply to anyone who is a member of the group, administrators need only set them once for the group, instead of having to set them for each user individually. Multiple groups can be defined to allow some users access to specific devices, while restricting other users from accessing them. Device permissions are discussed on page 240.

Adding Groups

To create a group, do the following:

1. Click *Group* on the Account page.
2. Click  and then select **Add New Group**. The *Add New Group* window opens:



3. Enter the required information in the appropriate fields. A description of each of the fields is given in the table below:

| Field | Description |
|-------------|--|
| Group Name | A maximum of 32 characters is allowed. |
| Description | Additional information about the user that you may wish to include. A maximum of 32 characters is allowed. |
| Member | Lists the users that are currently in the group. To add users, click the Edit button. |

4. At this point you can assign users to the group by clicking **Edit**.
5. When your selections have been made click **Apply**.

6. When the *Operation Succeeded* message appears, click **OK**.
7. The new group appears in the main panel.
 - ♦ The columns show the Group Name, Description and Members that are in the group.

Repeat the above procedure to add additional groups.


Modifying Groups

To modify a group, do the following:

1. In the main panel, double-click the group's name.
2. Make your changes, then click **Apply**.

Deleting Groups

To delete a group, do the following:

1. In the main panel, check the box next to the group's name.
2. Click  .
3. Click **OK**.

Permissions

You can assign Transmitter, Receiver and Profile permissions for users and groups from the *Account* page.

Assigning Device Permissions

To assign permissions for a user or group from the *Account* page, do the following:

1. Click  on the menu bar. The *Set User Permissions* window opens:



2. To set the permissions, select a user or group, then a device and select the Access Type under each column so that it turns green. Make your permission settings for each user or group on each device according to the information provided below:

| Item | Description |
|----------------|---|
| User List | Use the radio button to view the Users or Group list. Click a user or group to configure their permissions. |
| Drop-Down Menu | Use the drop-down menu to select <i>Transmitter</i> , <i>Receiver</i> or <i>Profile</i> . After making a selection, a list of devices or profiles appears. Set permissions by selecting the access type (All, View, Share, Occupy, Exclusive) next to the device. |

| Item | Description |
|-------------|---|
| Access Type | <p>Select the access you want to grant to a user or group by clicking under the heading(s) next to each device. This defines how the device can be accessed by the user or group. When granted, the access types (All, View, Occupy, Exclusive) for Transmitters will appear available for the user in the Receiver's OSD Connection page (see page 159).</p> <p>All: Select to grant all access permissions, <i>View</i>, <i>Share</i>, <i>Occupy</i> and <i>Exclusive</i>, to the users or user groups.</p> <p>View: User can only view the remote screen, and cannot perform operations on it.</p> <p>Share: All users accessing the Transmitter can simultaneously share control of the Transmitter. Input from the users is placed in a queue and executed chronologically.</p> <p>Occupy: The first user to access the Transmitter has control. However, additional users may view the Transmitter's video. If the user who controls the Transmitter is inactive for longer than the time set in the Transmitter's Timeout box, control is transferred to the first user to move the mouse or strike the keyboard.</p> <p>Exclusive: The first user to access the Transmitter has exclusive control over the Transmitter. No other users can view the Transmitter. The Timeout function does not apply when Transmitters are accessed with this setting.</p> <p>Operation (Receiver and Profile): The <i>Operation</i> access type for Receivers allows users to log into Receivers, and for Profiles allows a user to connect the Profile from a Receiver.</p> |
| Apply | Click Apply to save the changes. |
| Cancel | Click Cancel to exit without saving. |








3. When you have finished making your choices, click **Apply**.
4. In the confirmation popup that appears, click **OK**.

Profile

Click **Profile** in the *System Status* panel to open the settings. The *Profile* page allows you to create, run and schedule connection profiles. Profiles channel specific Receiver to Transmitter connections and can be instantly connected from the Profile page at anytime. Profiles can be also scheduled to run automatically at specific times.

| Transmitter Receiver User Account Profile Log | | | | | |
|---|-------------|-------------|-------------|----------|--|
| Profile | | Schedule | | | |
| Name | Description | Access Mode | Login Check | Lock OSD | |
| <input checked="" type="checkbox"/> | Profile1 | Share | No | No | |
| <input type="checkbox"/> | Profile2 | Share | No | No | |
| <input type="checkbox"/> | Profile3 | Share | No | No | |


The meanings of the icons and headings on the page are straightforward and let you view and configure Profiles.


-  Click to connect the selected Profile.
-  Click to disconnect the selected Profile.
-  Click to delete the selected Profile.
-  Click to *Create Profile* or *Create Schedule* (page 243 & 246).
-  Click and enter text to search for a Profile.
- Check the box next to a **Profile** and click the *Connect* or *Disconnect* icon to start/stop profile connections. Check the box next to a **Schedule** and click the *Enable* or *Disable* icon to enable/disable a schedule.
-  Appears on the *Schedule* page, click to enable the selected schedule.
-  Appears on the *Schedule* page, click to disable the selected schedule.

Adding a Profile




Creating a Profile allows you to quickly connect single or multiple Receiver to Transmitter connections.

To add a Profile, do the following:



1. On the *Profile* page click  and then select **Create Profile**. The *Create Profile* window appears:



| Item | Description |
|-------------|--|
| Name | Enter a name for the Profile. |
| Description | Enter a description for the Profile. |
| Permissions | Click Select and check the box of the users / groups you want to allow to connect this Profile. When the user logs into a Receiver, the profile will appear listed in the OSD menu on the Profile page (see page 164), allowing them to connect it. |

| Item | Description |
|---|---|
| Access Mode | <p>This defines how the Transmitter in a Profile can be accessed by Receivers when multiple users attempt to access it.</p> <p>View Only: Receivers only have view access to the Transmitter's video display.</p> <p>Share: All users accessing the Transmitter can simultaneously share control of the Transmitter. Input from the users is placed in a queue and executed chronologically.</p> <p>Occupy: Set a time threshold for Receivers whose Access Mode has been set to Occupy. If there is no activity from the Receiver occupying the port for the amount of time set here, the Receiver is timed out and the port is released. The first Receiver to send keyboard or mouse input after the port has been released gets to occupy the port. Input a value from 1 to 240 seconds.</p> <p>Exclusive: The first Receiver to access the Transmitter has exclusive control over the Transmitter. No other users can view the Transmitter. The Timeout function does not apply to Transmitters which have this setting.</p> |
| Login Check | <p>Check this box to require a user to be logged in to the Receiver before a Profile can connect it to a Transmitter. When enabled, a user must be logged into the Receiver or it will not connect to the Transmitter when the Profile is initiated.</p> |
| Lock OSD | <p>Checking this box will lock the Receiver's OSD screen when the Profile connects it to a Transmitter.</p> |
| Location | <p>Use the drop-down menu to select a location to filter the Receivers displayed on the page.</p> |
|  | <p>Click this icon to show individual Receivers.</p> |
|  | <p>Click this icon to show only video wall Receivers.</p> |
|  | <p>Click this icon to show only Receiver Group Receivers.</p> |
| Save | <p>Click to save the changes.</p> |
| Cancel | <p>Click to exit without saving.</p> |

- After filling in the information, click a Receiver, select **Select TX** and use the drop-down menu select a Transmitter; or use *Transmitter List* at the bottom of the page to drag-and-drop Transmitters to Receivers to create the connection.

3. After configuring the connections, click **Save**. The new Profile appears on the *Profile* page.
4. To connect Profiles, check the box of the Profile(s) you want to connect, and click  .
5. To disconnect Profiles, click  .



Adding a Schedule

Creating a Schedule allows you to connect Profiles at specific dates, times and intervals.

To add a Schedule, do the following:

1. On the *Profile* page click **Schedule**.
2. Click **+** and then select **Create Schedule**. The *Create Schedule* window appears:

Create Schedule

| | | |
|--|---|---|
| Profile | <input type="text" value="Select Profile"/> | |
| Frequency | <input type="text" value="Once"/> | |
| Start Date | <input type="text" value="2018/2/15"/> |  |
| End Date | <input type="text" value="2018/2/15"/> |  |
| Start Time | <input type="text" value="AM"/> : <input type="text" value="00"/> : <input type="text" value="00"/> | <input type="checkbox"/> Disable |
| End Time | <input type="text" value="AM"/> : <input type="text" value="00"/> : <input type="text" value="00"/> | <input type="checkbox"/> Disable |
| CANCEL SAVE | | |




| Item | Description |
|------------|---|
| Profile | Use the drop-down menu to select a Profile to schedule. |
| Frequency | Use the drop-down menu to select how often the Profile should run: Once, Daily, Weekly and Monthly. When you select Weekly/Monthly an additional drop-down menu appears to select the <i>Week Day/Month Day</i> on which the profile will run. |
| Start Date | Enter the date on which you want the schedule to begin running. |
| End Date | Enter the date on which you want the schedule to stop running. |
| Start Time | Enter the time of day that you want the profile to connect. |
| End Time | Enter the time of day that you want the profile to disconnect. |
| Every | If you select Daily, Monthly or Weekly, the <i>Every</i> option appears allowing you to enter how often you want the schedule to run. For example, enter 3 months if you want the profile to run once every three months. If you want to run the schedule once a day, once a week or once a month, use the default entry of 1. |


3. After the schedule is configured, click **Save**.

Log

Click **Log** in the *System Status* panel to open the settings. The *Log* page lists events that take place and provides a breakdown of the time, user, severity, device, and log information. You can change the sort order of the display by clicking on the column headings.

| Transmitter | | Receiver | | Account | | Profile | | Log | |
|--------------|------------|---------------|---------------------|--|--|---------|--|-----|--|
| All logs | | | | | | | | | |
| All Severity | All Device | All User | Time | Log Information | | | | | |
| Information | | | 2017/08/24 10:20:16 | Session terminated normally(Sessionid=*****bam0). | | | | | |
| Information | | Brett | 2017/08/24 10:20:16 | User logout(username=Brett) | | | | | |
| Information | | | 2017/08/24 09:46:37 | Session created(Sessionid=*****bam0) from ip 192.168.0.71. | | | | | |
| Information | | Brett | 2017/08/24 09:46:37 | User login succeeded(username=Brett) | | | | | |
| Information | | Brett | 2017/08/23 22:51:14 | User logout(username=Brett) | | | | | |
| Information | | | 2017/08/23 22:51:14 | Session terminated normally(Sessionid=*****9vnc). | | | | | |
| Information | KE694DR70 | administrator | 2017/08/23 22:33:08 | Connection VIAJIS to channel KE6950T61[001074RD01230000] established | | | | | |
| Warning | | | 2017/08/23 22:21:07 | Session killed(Sessionid=*****amp0). | | | | | |
| Information | | | 2017/08/23 22:21:07 | Session created(Sessionid=*****9vnc) from ip 192.168.0.71. | | | | | |
| Information | | Brett | 2017/08/23 22:21:07 | User login succeeded(username=Brett) | | | | | |
| Information | | | 2017/08/23 22:21:07 | Session created(Sessionid=*****amp0) from ip 192.168.0.71. | | | | | |
| Information | | Brett | 2017/08/23 22:21:07 | User login succeeded(username=Brett) | | | | | |
| Information | | | 2017/08/23 22:15:30 | Session created(Sessionid=*****ts26) from ip 192.168.0.70. | | | | | |
| Information | | administrator | 2017/08/23 22:14:32 | User login succeeded(username=administrator) | | | | | |

- ◆ Click the drop-down menu beside a heading to filter events into subcategories. Selecting a subcategory allows you to view only the logs that relate to the choice. The meanings of the headings at the top of the page are straightforward:
 - ◆ *All Severity* refers to the event's severity type: Information, Error, or Warning
 - ◆ *All Device* refers to the Transmitter or Receiver that relates to the event. If no device is listed the event refers to the KE Matrix Manager software.
 - ◆ *All User* refers to the username that the event relates to. If no username appears, the event is general system information.
 - ◆ *Time* refers to the date and time that the event occurred.
 - ◆ *Log Information* provides detailed information about each event.
- ◆  Click to delete the logs currently displayed in the list.
- ◆  Click and enter text to search for an event log.
- ◆  Click to save the log contents to a file on your computer.


 Click to open a pop-up window that allows you to set how many days or the number of records to record before over-writing old log files. Use the radio button to select *By Period (Days)* or *By Records* and enter the number to use before overwriting the oldest log files.

This Page Intentionally Left Blank


Chapter 7


System Settings

Overview

The *System Settings* are accessed by clicking  from the *System Status* page (see *System Status*, page 197). There are 7 tabs to configure the KE Manager system settings: *General*, *ANMS*, *FW Upgrade*, *Redundancy*, *Backup/Restore*, *Certificates*, and *Sessions*.

General

Clicking  from the system status page opens the *General* tab, as shown below:



The screenshot shows the 'General' tab of the System Settings page. The page is divided into several sections, each with a dropdown arrow on the left:

- Basic**: Contains fields for KE Matrix Manager Version (2.2.217), Hardware Version (CCKM7538707CA3F18B21, CCKME17D18E7AZZCF3), Serial Number (0000000002), KE Matrix Manager Name (KE Matrix Manager), Description (Enable engineering mode), Language (English), Bootup (Enable), CCKM Timeout (min(1-180)), Authentication Lock (seconds(120-99999)), Boundless Switching Focus (seconds(0-30)), and Push/Pull Login Check (Disable).
- Network Ports**: Contains fields for HTTP port (4080), Device Port (9110), and HTTPS port (4443).
- Fast Switching**: Contains a Fast Switching toggle (Enable).
- Account Policy**: Contains Enhanced Password History (Enable) and Enhanced Password Rule (what is it? Enable).
- CLI Mode**: Contains a CLI Login toggle (Enable).
- Receiver Login Setting**: Contains Anonymous Login (Device List) and Anonymous Login User (Administrator).
- EDID Mode**: Contains EDID Mode (Customized) and a link to Edit.
- Connection Redundancy**: Contains a Connection Redundancy toggle (Enable).
- Pop-up Alert**: Contains a Pop-up Alert toggle (Enable).
- JavaClient/Winclient**: Contains a table for Login access priority:

| | |
|---|-----------|
| 1 | Share |
| 2 | Ownership |
| 4 | |

| Heading | Item | Description |
|-------------------------|---|--|
| Basic | KE Manager Version | This provides the version of the KE Manager software. |
| | Serial Number | This provides the serial number and a link to upgrade the software. |
| | KE Manager Name | Enter a name for the KE Manager. |
| | Description | Enter a description for the KE Manager. |
| | Language | Select the language for the KE Manager. Choices are: English, Chinese (Traditional), Simplified Chinese, Japanese, German, Korean, Russian, French, Spanish, and Portuguese. |
| | Beeper | Select Enable to sound a beep from the Transmitter/Receiver every time a configuration change is made. |
| | CCKM Timeout | If there is no user input for the amount of time entered in the box, a user logged into the CCKM is automatically logged out. Check Disable to turn this function off. |
| | Authentication Lock | <p>When a temporary disconnection happens, this function allows the user to retain his/her settings upon resuming connection within the time threshold set. The user keeps the same authentication and display.</p> <ul style="list-style-type: none"> ◆ Uncheck Disable to turn this function on. ◆ Specify a time (in seconds) you wish to keep the authentication and display for. <p>When disabled or if enabled but after the time threshold set, the user is prompted to be authenticated upon resuming the connection.</p> |
| | Boundless Switching Focus | <p>When using Boundless Switching(see <i>Boundless Switching</i>, page 229) across multiple receivers within a receiver group or video wall, a colored border is shown on the receiver display currently being accessed (focus receiver).</p> <ul style="list-style-type: none"> ◆ Uncheck Always to only display the colored border for a set time interval immediately after switching the focus receiver. ◆ Specify a time (in seconds) you wish to display the colored border for upon switching the focus receiver. |
| Push / Pull Login Check | Enable to check the access rights of the users receiving transmitter sessions upon push / pull. | |

| Heading | Item | Description |
|----------------|--------------------------|--|
| Network Ports | HTTP Port | Sets the HTTP service port used to access the KE Manager. This is the port number to use for a browser login. The default is 8080. |
| | Device Port | Sets the Device service port used to access the KE Manager. Configure this port number on the Transmitter and Receiver to access to the KE Manager software (see <i>Manager Address</i> , page 143 and 150). The default is 9110. |
| | HTTPS Port | Sets the HTTPS service port used to access the KE Manager. This is the port number to use for a secure browser login. The default is 8443. Example: To access the KE Manager with an IP address of 192.168.0.100 using a secure browser login, enter: <i>https://192.168.0.100:8443</i> |
| Fast Switching | | Select the default resolution to use so that you can switch faster when changing Receiver to Transmitter connections. If the monitor you are using does not support fast switching the video may not display correctly when this setting is enabled. Note: Make sure to disable Boundless Switching when Fast Switching is enabled. |
| Account Policy | Enforce Password History | This setting determines the number of unique new passwords that must be used before an old password can be reused. Uncheck the box and enter a number to enforce the password history policy. |
| | Enhance Password Rule | Select Enable to enforce rules for creating passwords, as follows: <ul style="list-style-type: none"> ◆ The password length must be at least 8 characters. ◆ The password must contain both upper and lowercase characters. ◆ The password must contain a number (0 through 9). ◆ If a user types in the wrong password 5 times consecutively, their account will be locked out for 10 minutes. |
| CLI Mode | CLI Mode Login | Use the radio button to Enable or Disable command line interface logins to the KE Manager. Warning: If <i>Disable</i> CLI Mode Login is selected, anybody can login via Telnet with administrator privileges without needing to authenticate, allowing control of the entire installation. For installations requiring a high level of security, it's recommended that <i>Enable</i> CLI Mode Login be applied. |


| Heading | Item | Description |
|-------------------------|----------------------|---|
| Receiver Login Settings | Anonymous Login | Use this to anonymously login a user at select Receivers. This option allows users to access the Receiver and connect to Transmitters without needing to login. Click Device List to display the list and check the box next to the Receiver(s) to enable the <i>Anonymous Login</i> feature. |
| | Anonymous Login User | When <i>Anonymous Login</i> (above) is enabled for Receivers, select a user from the drop-down menu to use as the default account to anonymously login to the Receiver. |
| EDID Mode | EDID Mode | Use this drop-down menu to set the default EDID mode for all Transmitters. To set a different EDID mode for each Transmitter, use the drop-down menu to select Customized and then click Edit . A Transmitter list will appear with drop-down menus to configure each device's EDID mode. |
| Connection Redundancy | | Use this drop-down menu to set connection redundancy function. You can setup priority connection with this function. Please refer to <i>Connection Redundancy</i> on page 252. |
| Pop-up Alert | | Enable and click Edit to select the types of events to automatically trigger and display a pop-up message. |
| JavaClient / WinClient | | For AiT models only, click and drag to rearrange the login priorities of the different access modes, among <i>Share</i> , <i>Occupy</i> , <i>View Only</i> , and <i>Exclusive</i> . See <i>Login Access Priority (AiT Models only)</i> , page 255 for details. |
| Save | | Click to save the changes. |
| Cancel | | Click to cancel the changes. |

Connection Redundancy

You can setup priority connection for receivers. Where a transmitter fails, this function allows the receiver to connect to the transmitter of the highest priority that is available.

Follow the steps below to setup the priority list.


1. Click **Enable** to enable this function.
2. Click **Edit**. A window will pop-up to allow editing.




- For Alarm Sound, click **Enable**.

Alarm Sound Enable Disable

- To create a new list, click **New**. A Priority List 1 will be shown. (Click **New** again to create another list.)




5. Select the transmitters you wish to be in the list from the “Available TX” list and click **Add**. The added transmitter will be shifted to the “Selected TX” list.



The screenshot shows the "Connection Redundancy" configuration window. At the top, there is a title bar with the text "Connection Redundancy". Below the title bar, there are two radio buttons for "Alarm Sound": "Enable" (selected) and "Disable". The window is divided into three main sections: "Priority List", "Available TX", and "Selected TX". The "Priority List" section contains a single entry "Priority List 1". The "Available TX" section contains a list with one entry "KE6910T1". The "Selected TX" section contains a list with one entry "KE6910T2". Between the "Available TX" and "Selected TX" sections, there are two buttons: "Add" with a right-pointing arrow and "Remove" with a left-pointing arrow. Below these sections, there is a "Target RX" section with a dropdown menu currently showing an empty field. At the bottom left, there are two buttons: "New" and "Delete". At the bottom right, there are two buttons: "CANCEL" and "SAVE".

To deselect the transmitter, click to select the transmitter from the “Selected TX” list and click **Remove**. The transmitter will be shifted back to the “Available TX” list.

6. Select a target receiver by first clicking the drop-down menu “Target RX”, and select a receiver.




This screenshot is identical to the previous one, but the "Target RX" dropdown menu is now open and shows the selected receiver "KE6912R".

7. Repeat steps 4-6 to add more priority lists.
8. Click **Save** to save the settings.

Login Access Priority (AiT Models only)

If your system includes an AiT device, “JavaClient/WinClient” (for remote viewer) will appear at the bottom of the *General* tab to let you select the login access priority depending on the user.



Share: User has full control and can simultaneously share control of the remote viewer. Input from the users is placed in a queue and executed chronologically.

Occupy: The first user to access the remote viewer has control. However, additional users may view the remote viewer. If the user controlling the remote viewer is inactive for longer than the time set in the Transmitter’s Timeout box, control is transferred to the first user to move the mouse or strike the keyboard.

View only: User can only view the remote viewer but cannot perform operations on it.

Exclusive: The first user to access the remote viewer has exclusive control. No other users can view the remote viewer. The Timeout function does not apply when Transmitters are accessed with this setting.

ANMS

The *ANMS* (Advanced Network Management Settings) tab is used to set up login authentication and authorization management from external sources, and SNMP configurations. It is organized into three pages, as described below.

Event Destination

General ANMS FW Upgrade Redundancy Backup/Restore Certificates Sessions

Event Destination Authentication & Authorization

▼ SMTP Settings

Enable report from the following SMTP Server

Log Level: Information

SMTP Server: [Text Box]

SMTP Port: 25

Server requires authentication

Account Name: [Text Box]

Password: [Text Box]

From: [Text Box]

To: [Text Box]

▼ Syslog Settings

Enable

Log Level: Information

Server IP: [Text Box]

Service Port: 514

SAVE CANCEL

◆ SMTP Settings

To have the KE Manager email reports from the SMTP server to you, do the following:

1. Enable the *Enable report from the following SMTP Server*, select the *Log Level* (Information, Warning, or Error), and key in the *SMTP Server* IP address and *SMTP Port*.

Note: The SMTP server used can either be TLS-encrypted or unencrypted. CCKM shall send TLS-encrypted or unencrypted

email reports depending on the type of the SMTP server connected.

2. If your server requires authentication, check the *Server requires authentication* checkbox, and key in the appropriate information for the *Account Name* and *Password* fields.
3. Key in the email address of where the report is being sent from in the *From* field.

Note: 1. Only one email address is allowed in the *From* field, and it cannot exceed 64 Bytes.

2. 1 Byte = 1 English alphanumeric character.

4. Key in the email address (addresses) of where you want the SMTP reports sent to in the *To* field.

Note: If you are sending the report to more than one email address, separate the addresses with a semicolon. The total cannot exceed 256 Bytes.

5. Click **Save**.

1. Once set, an SMTP report will be sent to the recipients for every 100 logs accumulated or once every 30 minutes.
2. An immediate SMTP report will also be sent whenever an error log occurs.

◆ *Syslog Settings*

To record all the events that take place on the KE Manager and write them to a Syslog server, do the following:

1. Check **Enable**.
2. Use the drop-down menu to select the *Log Level* (Information, Warning, or Error).
3. Key in the *Server IP* address of the Syslog server.
4. Key in the *Service Port* number. The valid port range is 1-65535.
5. Click **Save**.

Authentication & Authorization

| General | ANMS | FW Upgrade | Redundancy | Backup/Restore | Certificates | Sessions |
|---------------------------------------|---|-----------------------------------|------------|----------------|--------------|----------|
| Event Destination | Authentication & Authorization | | | | | |
| <input type="checkbox"/> Enable | | | | | | |
| Preferred RADIUS Server | | <input type="text"/> | | | | |
| Preferred RADIUS Server Port | | <input type="text" value="1812"/> | | | | |
| Alternate RADIUS Server | | <input type="text"/> | | | | |
| Alternate RADIUS Server Port | | <input type="text" value="1645"/> | | | | |
| Timeout | | <input type="text" value="3"/> | | | | |
| Retries | | <input type="text" value="3"/> | | | | |
| Shared Secret (at least 6 characters) | | <input type="text"/> | | | | |

◆ *RADIUS Settings*

To allow authentication and authorization through a RADIUS server, do the following:

1. Check **Enable**.
2. Fill in the IP addresses and service port of the *Preferred RADIUS Server* and *Alternate RADIUS Server*.
3. In the *Timeout* field, set the time in seconds that the KE Manager waits for a RADIUS server reply before it times out.
4. In the *Retries* field, set the number of allowed retries.
5. In the *Shared Secret* field, key in the character string that you want to use for authentication between the KE Manager and the RADIUS Server. A minimum of 6 characters is required.
6. On the RADIUS server, Users can be authenticated with any of the following methods:
 - ◆ Use the same Username on both the RADIUS server and the KE Manager.
 - ◆ Use the same Group name on both the RADIUS server and the KE Manager.
 - ◆ Use the same Username/Group name on both the RADIUS server and the KE Manager.

In each case, the user's access rights are the ones assigned that were assigned when the User or Group was created on the KE Manager.

◆ *LDAP / AD Settings:*

▼ LDAP / AD Settings

Enable

Enable SSL

Preferred LDAP Server

Preferred LDAP Server Port

Alternate LDAP Server

Alternate LDAP Server Port

Timeout

Admin DN

Admin Name

Password

Search DN

To allow authentication and authorization for the KE Manager via LDAP / AD, refer to the information in the table, below:

| Item | Action |
|-------------------------|---|
| Enable | Put a check in the Enable checkbox to allow LDAP / AD authentication and authorization. |
| Enable SSL | Put a check in the Enable checkbox to allow SSL connections. |
| LDAP Server IP and Port | Fill in the IP address and port number for the LDAP / AD server. <ul style="list-style-type: none"> ◆ You can use the IPv4 address, the IPv6 address or the domain name in the LDAP Server field. ◆ For LDAP, the default port number is 389. |
| Timeout | Set the time in seconds that the KE Manager waits for an LDAP / AD server reply before it times out. |
| Admin DN | Consult the LDAP / AD administrator to ascertain the appropriate entry for this field. For example, the entry might look like this: ou=kn4132,dc=aten,dc=com |
| Admin Name | Key in the LDAP administrator's username. |
| Password | Key in the LDAP administrator's password. |
| Search DN | Set the distinguished name of the search base. This is the domain name where the search starts for user names. |

On the LDAP / AD server, Users can be authenticated with any of the following methods:

- ◆ With MS Active Directory schema.

Note: If this method is used, the LDAP schema for MS Active Directory must be extended. Without schema – Only the Usernames used on the KE Manager are matched to the names on the LDAP / AD server. User privileges are the same as the ones configured in the KE Manager.

- ◆ Without schema – Only the Usernames used on the KE Manager are matched to the names on the LDAP server. User privileges are the same as the ones configured in the KE Manager software.
 - ◆ Without schema – Only Groups in AD are matched. User privileges are the ones configured for the groups he belongs to in the KE Manager.
 - ◆ Without schema – Usernames and Groups in AD are matched. User privileges are the ones configured for the User and the Groups in the KE Manager.
-
- ◆ *TACACS+ Settings:*

The screenshot shows the 'TACACS+ Settings' configuration window. It features a 'TACACS+ Settings' title with a dropdown arrow, an 'Enable' checkbox, and two sets of input fields for server configuration. The first set is for the 'Preferred TACACS+ Server' and the second is for the 'Alternate TACACS+ Server'. Each set includes a text field for the server name, a text field for the server port (both containing '49'), and a text field for the shared secret (with a note 'at least 6 characters').

| ▼ TACACS+ Settings | |
|---------------------------------------|---------------------------------|
| <input type="checkbox"/> Enable | |
| Preferred TACACS+ Server | <input type="text"/> |
| Preferred TACACS+ Server Port | <input type="text" value="49"/> |
| Shared Secret (at least 6 characters) | <input type="text"/> |
| Alternate TACACS+ Server | <input type="text"/> |
| Alternate TACACS+ Server Port | <input type="text" value="49"/> |
| Shared Secret (at least 6 characters) | <input type="text"/> |

- ◆ **Enable TACACS+** and enter the following information:
 - ◆ Preferred TACACS+ Server
 - ◆ Preferred TACACS+ Service Port
 - ◆ Shared Secret 1
 - ◆ Alternate TACACS+ Server
 - ◆ Alternate TACACS+ Service Port
 - ◆ Shared Secret 2

SNMP

The screenshot shows the 'SNMP' configuration page under 'Authentication & Authorization'. It is divided into two main sections: 'SNMP Trap' and 'SNMP Agent'.

SNMP Trap: The 'Enable' radio button is selected. There are input fields for 'Server IP', 'Port', and a 'Notification' dropdown menu showing '0 items' and a 'Select' button.

SNMP Agent: The 'Enable' radio button is selected. There are 'Add New' and 'Delete' buttons. Below is a table of configured agents:

| <input type="checkbox"/> | Community / User Name | NMS IP / Host Name | Version | Access Type |
|--------------------------|-----------------------|--------------------|---------|--------------|
| <input type="checkbox"/> | Administrator | 10.0.92.87 | V1 | Read + Write |
| <input type="checkbox"/> | Administrator | 10.0.92.87 | V3 | Read + Write |
| <input type="checkbox"/> | Administrator | 10.0.92.87 | V3 | Read + Write |

At the bottom of the page are 'SAVE' and 'CANCEL' buttons.

◆ *SNMP Trap & SNMP Agent*

To be notified of SNMP trap events, do the following:

1. Check **Enable** SNMP Trap.
2. Enter the **Server IP** and the **Port** of the PC / server to be notified of SNMP trap events.
3. Next to **Notification**, click **Select** and check the types of events for sending SNMP notifications.
4. Check **Enable** SNMP Agent.
5. Check / uncheck the SNMP Agents for sending SNMP trap events.

To add additional SNMP Agents, you must first **Disable** SNMP Agent.

6. Click **Save**.

FW Upgrade

In *FW Upgrade* all KE devices that are online are listed, allowing you to select which devices get upgraded. New firmware versions can be downloaded from our website as they become available. Check the website regularly to find the latest upgrade packages.

To upgrade the firmware do the following:

1. Go to our website and download the firmware upgrade package appropriate to your KE device.
2. Open your browser and log in to the KE Manager with an administrator's account.
3. Click the **Settings** icon; select the **FW Upgrade** tab, the *FW Upgrade* page appears:

| <input type="checkbox"/> | Type | Device Name | Model | IP | FW Version |
|--------------------------|-------------|---------------|----------|-------------|------------|
| <input type="checkbox"/> | Transmitter | 40T-win71-d12 | KE6900ST | 10.0.92.145 | 9.2.916 |
| <input type="checkbox"/> | Receiver | 00R_4 | KE6950R | 10.0.92.140 | 9.2.916 |
| <input type="checkbox"/> | Transmitter | Win7-3 | KE6950T | 10.0.92.141 | 1.3.121 |
| <input type="checkbox"/> | Transmitter | 40T-win71-d12 | KE6900ST | 10.0.92.145 | 9.2.916 |
| <input type="checkbox"/> | Receiver | 00R_4 | KE6950R | 10.0.92.140 | 9.2.916 |

Check FW Version

All the devices that are capable of being upgraded are listed.

Note: Only online devices show up in the list. Offline devices do not get upgraded.

4. Check the checkbox in front of the devices you want to upgrade. Uncheck the devices that you do not want to upgrade.
5. Click **Browse**. Navigate to the directory where the firmware upgrade file is located and select it.
6. Enable or disable *Check FW Version*
 - ◆ If you enabled *Check FW Version* the current firmware level is compared with that of the upgrade file. If the current version is equal to

or higher than the upgrade version, a popup message appears, to inform you of the situation and stops the upgrade procedure.

- ♦ If you didn't enable *Check FW Version*, the upgrade file is installed without checking what its level is.
 - ♦ If you cancel the firmware upgrade, you have to wait 12 seconds before you can disable *Check FW Version* and restart the firmware upgrade.
7. Click **Upgrade** to start the upgrade procedure. As the upgrade proceeds, progress information is shown on the screen. Once the upgrade completes successfully, the devices will reset.
 8. Log in to each device and check the firmware version to be sure it is the new one.

Firmware Upgrade Recovery

If the Upgrade Succeeded screen doesn't appear or the upgrade procedure is abnormally halted (due to computer crash, power failure, etc.), the device may become inoperable. If you find that the device does not work following a failed or interrupted upgrade, do the following

1. Power off the KE device.
2. Press the **Reset** button, then power on the KE device while holding Reset.
3. Hold **Reset** for 7 seconds after the device is powered on.
4. The device will revert to a previous firmware version and recover from the failure.
5. Upgrade the firmware to the most current version available.

Redundancy


The *Redundancy* tab allows you to set up a backup computer in case the computer hosting the KE Manager goes offline. If the KE Manager goes offline, the secondary computer will automatically take over operations, allowing all connections to continue without disruption – with only a brief period of 30 seconds when new connections can't be started. When the primary computer comes back online it retrieves the updated database from the secondary computer and re-takes all KE Manager operations.


A CCKM supports up to 5 secondary servers.

To set up Redundancy, do the following:

1. Install KE Manager on a secondary computer with a USB license key. For detailed instructions, see page 171.

Note: A second USB license key is required if you have more than 8 KE Series devices in your setup.

2. On the secondary computer, log in to the KE Manager, click  and go to the *Redundancy* tab.





The screenshot shows the 'Redundancy' configuration tab in the KE Manager interface. The tab is selected among other tabs: General, ANMS, FW Upgrade, Redundancy, Backup/Restore, Certificates, and Sessions. The configuration options are as follows:

- Mode:** Radio buttons for 'Primary' and 'Secondary'. The 'Secondary' radio button is selected.
- Server ID:** A text input field.
- Server Status:** A text input field.
- Database Status:** A text input field.
- Enable Redundancy:** A checked checkbox.
- Primary Server IP:** A dropdown menu.

At the bottom of the form, there are two buttons: 'SAVE' (highlighted in blue) and 'CANCEL'.

3. Check **Enable Redundancy** and select the **Secondary** radio button.
4. Use the **Primary Server IP** drop-down menu to select the primary IP address.
5. Click **Save**.
6. Redundancy is now running on the secondary computer.

7. On the primary computer, log in to the KE Manager, click  and go to the *Redundancy* tab.



General ANMS FW Upgrade **Redundancy** Backup/Restore Certificates Sessions

Mode Primary Secondary

Server ID 708BCD7FD11E0000

Server Status Working

Database Status --

Enable Redundancy

Secondary Server IP 10.0.70.98

Username

Password

8. Check **Enable Redundancy** and select the **Primary** radio button.
9. Use the **Secondary Server IP** drop-down menu to select the secondary IP address.
10. Enter the **Username** and **Password** of the secondary computer's local administrator account.
11. Click **Save**.
12. Information about the *Redundancy* status can be found in the event log (see *Log*, page 247 for details).

Backup / Restore

The *Backup/Restore* tab is divided into three panels: **Backup**, **Restore**, and **Export Device List**:

The screenshot shows the 'Backup/Restore' tab selected in a navigation menu. Below the menu are three panels:

- Backup:** Contains a blue 'BACKUP' button, a checkbox labeled 'Add Password', and an empty text input field.
- Restore:** Contains a grey button labeled 'Click to browse backup file...', a grey 'RESTORE' button, and a 'Password' label with an empty text input field.
- Export Device List:** Contains a blue 'EXPORT' button.

The operations to perform backup/restore procedures are described in the table below and in the section that follows:

| Procedure | Operation |
|--------------------|---|
| Backup | Backs up the KE Manager configuration – including profile and schedule configurations, user and group accounts, user profiles, logs, and system settings. |
| Restore | Deletes the current profile and schedule configurations, user and group accounts, user profiles, logs, and system settings; then restores those settings to the values that exist in the previously saved backup file. |
| Export Device List | Clicking Export allows you to save a file with a complete list of the devices added to the KE Manager. The file contains the ID, name, description and IP address of each transmitter and receiver. An Existing column also lists if the device is available: Yes, it exists and is available, or No, it is offline or has been removed. |

Backup

To back up system configuration settings, do the following:

1. (Optional) In the *Backup* panel, check **Add Password**, and provide a password for the backup file.

Note: Providing a password is a security feature – if you provide a password, you will need to give the same password in order to restore the configuration settings from this file.

2. Click **Backup**.
3. In the dialog box that comes up, Click **Save** to save the configuration file (*System.conf*) to a location on your hard disk.
4. Navigate to the directory where you want to save the file and click **Save**.

Restore

To restore system configuration settings, do the following:

1. In the *Restore* panel, click **Browse**.
2. Navigate to the directory where the backup file is located and select it.
3. When you return to the *Backup/Restore* page enter the password you set when the backup file was created.

Note: If you did not set a password for the file, leave the field blank.

4. Click **Restore**.
5. Click **OK** to confirm that you want to restore the configuration data.

When the Restore procedure is in process, a message stating that the KE Manager will restart will appear. After a short while the KE Manager closes and refreshes at the log in screen. When it comes back up the configuration settings that were restored from the backup file are in effect.

Certificates

This tab provides information about *Private Certificates*:

| Issued To | |
|------------------------|----------------------------|
| Common Name (CN) | ATEN INTERNATIONAL CO.,LTD |
| Organization (O) | ATEN INTERNATIONAL CO.,LTD |
| Organization Unit (OU) | R&D |
| Country (C) | TW |
| State or Province (ST) | New Taipei City |
| Locality (L) | Sijhih District |
| Email Address (E) | eservice@aten.com.tw |
| Serial Number | 00:9D:5D:A9:CA:7F:40:B5:3B |

| Issued By | |
|------------------------|----------------------------|
| Common Name (CN) | ATEN INTERNATIONAL CO.,LTD |
| Organization (O) | ATEN INTERNATIONAL CO.,LTD |
| Organization Unit (OU) | R&D |

| Validity | |
|------------|---------------------|
| Issued On | 2016/03/17 05:40:43 |
| Expires On | 2026/03/16 05:40:43 |

| Fingerprints | |
|------------------|---|
| SHA1 Fingerprint | EE:55:7F:72:13:B7:A9:40:00:32:E8:A0:AB:8C:9F:4B:C8:65:B5:A5 |

NEW GET CSR IMPORT RESTORE DEFAULT

Private Certificate

When logging in over a secure (SSL) connection, a signed certificate is used to verify that the user is logging in to the intended site. For enhanced security, the *Private Certificate* section allows you to use your own private encryption key and signed certificate, rather than the default ATEN certificate.

There are two methods for establishing your private certificate: generating a self-signed certificate; and importing a third-party certificate authority (CA) signed certificate.

- ◆ **Generating a Self-Signed Certificate**

If you wish to create your own self-signed certificate, a free utility – openssl.exe – is available for download over the web. See *Self-Signed Private Certificates*, page 380 for details about using OpenSSL to generate your own private key and SSL certificate.

- ◆ **Obtaining a CA Signed SSL Server Certificate**

For the greatest security, we recommend using a third party certificate authority (CA) signed certificate. To obtain a third party signed certificate,

go to a CA (Certificate Authority) website to apply for an SSL certificate. After the CA sends you the certificate and private encryption key, save them to a convenient location on your computer.

- ◆ **Importing the Private Certificate**

To import the private certificate, do the following:

1. Click **Import** from the bottom of the Private Certificate page, shown here:



2. Click **Browse** to the right of *Certificate Filename*; and browse to where your certificate file is located; and select it.
3. Click **Import** to complete the procedure.

Note: Clicking **Restore Defaults** returns the device to using the default ATEN certificate.

Certificate Signing Request

The Certificate Signing Request (CSR) section provides an automated way of obtaining and installing a CA signed SSL server certificate.

To perform this operation do the following:

1. Click **New**. The following dialog box appears:

 A dialog box titled 'New Certificate' with an orange header bar. The form contains the following fields:

- Country (2 letter code):
- State or Province (ST):
- Locality (L):
- Organization (O):
- Organization Unit (OU):
- Common Name (CN):
- Email Address (E):

 At the bottom of the form are two buttons: 'CANCEL' and 'CREATE'.

2. Fill in the form – with entries that are valid for your site – according to the example information in the following table:

| Information | Example |
|-------------------------|---------|
| Country (2 letter code) | TW |
| State or Province | Taiwan |

| Information | Example |
|-------------------|--|
| Locality | Taipei |
| Organization | Your Company, Ltd. |
| Organization Unit | Tech Department |
| Common Name | mycompany.com Note: This must be the exact domain name of the site that you want the certificate to be valid for. If the site's domain name is <i>www.mycompany.com</i> , and you only specify <i>mycompany.com</i> , the certificate will not be valid. |
| Email Address | administrator@yourcompany.com |

3. After filling in the form (all fields are required), click **Create**.
A self-signed certificate based on the information you just provided is now stored on the KE Manager software.
4. Click Get CSR, and save the certificate file (*csr.cer*) to a convenient location on your computer.
This is the file that you give to the third party CA to apply for their signed SSL certificate.
5. After the CA sends you the certificate, save it to a convenient location on your computer. Click **Import** to locate the file; then click **Import** to store it on the KE Manager.

Note: When you upload the file, the KE Manager checks the file to make sure the specified information still matches. If it does, the file is accepted; if not, it is rejected.

If you want to remove the certificate (to replace it with a new one because of a domain name change, for example), simply click **Restore Defaults**.

Sessions

The *Sessions* tab shows all of the users that are logged into KE Manager and OSD sessions and provides information concerning the “who, where and when” of each session. This page also gives the administrator the option of forcing a user logout by selecting the user and clicking **Kill Session** next to each user.

| Sessions | | | | | | |
|---------------|---------------|---------|--------------|---------------------|---------------------|---|
| Username | User Type | Service | IP | Login Time | Last Access | Operation |
| autocli | Administrator | SDK | 192.168.0.72 | 2017/08/23 22:31:14 | 2017/08/23 22:36:26 | <input type="button" value="Kill Session"/> |
| Harry | Super User | OSD | 192.168.0.71 | 2017/08/25 14:54:02 | 2017/08/25 14:54:02 | <input type="button" value="Kill Session"/> |
| administrator | Administrator | HTTPS | 192.168.0.11 | 2017/08/25 16:03:00 | 2017/08/25 16:03:14 | <input type="button" value="Kill Session"/> |

- ◆ *Username* refers to the user that logged in to establish a session.
- ◆ *User Type* refers to the account type of the user.
- ◆ *Service* refers to how the user logged into their session – via KE Manager, Command Line, or OSD.
- ◆ *IP* refers to the IP address from which the user has logged in.
- ◆ *Login Time* refers to the date/time that the user logged into the session.
- ◆ *Last Access* refers to the last time the user session was active.
- ◆ *Operation* provides the **Kill Session** button to force a user logout.

This Page Intentionally Left Blank


Chapter 8

Connections

Overview


The *Connections* panel is found on the **KE Matrix Manager** main page, just below System Status. Connections provides a diagram of current Transmitter to Receiver connections. Before connections are established the panel appears blank, as shown below. To connect Receivers to Transmitters, use the *Instant Link* panel (page 189), or create a connection *Profile* (page 242).




When connections are made, clicking a device in the left column provides a way to view the connection, hovering the mouse cursor over the connection diagram in the right column allows you to disconnect the device, as explained in the sections that follows.




Connections

When Receivers connect to Transmitters, they appear in the *Connections* panel. There are two columns – each lists either Transmitters or Receivers. The columns can be swapped by clicking the **TX-RX** or **RX-TX** button. Devices in the left column can be clicked to display their connection to devices, shown in the right column. Connections, shown in the right column, can be disconnected by clicking the **X** over the connection diagram.



| Item | Description |
|---|---|
|  | On the heading bar under <i>Connections</i> , click this icon to change the sort order of the Transmitters or Receivers listed in the left column. |
| Left Column | Click a device in the left column to view its connection in the right column. A diagram to its connected device(s) appears in the right column. |
| Right Column | The right column displays a connection diagram when a device in the left column is selected. Move the mouse cursor over the diagram and click X to disconnect the devices. This column also shows the user and access type (Exclusive, Occupy, Share, View Only) used to establish the connection. |
| Transmitter | Lists Transmitters that are online and connected to Receivers. |
| Receiver | Lists Receivers that are online and connected to Transmitters. |
|  | Click to view Transmitter to Receiver connections. This will list Transmitters in the left column so that they can be selected to view their connection diagram, shown in the right column. |
|  | Click to view Receiver to Transmitter connections. This will list Receivers in the left column so that they can be selected to view their connection diagram, shown in the right column. |

| Item | Description |
|---|--|
|  | Click this icon to Refresh the Transmitters and Receivers list in Connections panel. |
| Undo | Click this icon to undo the most recent disconnection. |

Based on the different access types, users attempting to connect to device ports that are already being accessed by another user may or may not be able to connect. See the table below for scenarios where users are granted (O) or denied access (X).


| New Connect Attempt Currently Connected | Exclusive | Share | Occupy | View Only |
|--|------------------|--------------|---------------|------------------|
| EXCLUSIVE | X | X | X | X |
| Share | X | O | X | O |
| Occupy | X | X | O | O |
| View Only | X | O | O | O |
| None | O | O | O | O |


This Page Intentionally Left Blank

Chapter 9 Scheduled Profile

Overview

The *Scheduled Profile* panel is found on the **KE Matrix Manager** main page, just below Connections. Scheduled Profiles displays connection profiles that have been scheduled. Click **Go to Schedule** to edit and create profile schedules (page 242). To create Profiles, see page 243.



| Item | Description |
|---|---|
| Headings | The headings provide the schedules: <i>Name</i> , <i>Description</i> , <i>Start</i> , <i>End</i> , and <i>Status</i> . Start and End show the time/date the profile is scheduled to begin and end. Status displays the number of days until to the next scheduled run. |
| Go to Schedule | Clicking Go to Schedule opens the <i>Profile</i> settings page which allows you to create and edit connection profiles. See <i>Profile</i> , page 242 for details. |
|  | Click this icon to Refresh the connections list in the right column. |
| Undo | Click this icon to undo the most recent disconnection. |


This Page Intentionally Left Blank

Chapter 10 Sessions

Overview

The *Sessions* panel is found at the bottom of the **KE Matrix Manager** main page, just below Scheduled Profile. Sessions displays information about users logged into devices and the KE Matrix Manager web GUI. Click **Go to Sessions** to view the settings page (see page 271).

The screenshot shows the KE Matrix Manager interface. At the top, there is a navigation bar with the ATEN logo, 'CCKM KE Matrix Manager', and a 'Welcome to the KE Matrix Manager' message. Below this, there are two main panels. The first panel is 'Scheduled Profile', which contains a table with columns: Profile, Description, Start, End, and Status. The second panel, highlighted with a red box, is 'Sessions'. It contains a table with columns: Username, User Level, Service, IP, Login Time, Last Access, and Operation. The table lists three users: Brett (Super User, OSD, 192.168.0.71), administrator (Administrator, HTTPS, 192.168.0.11), and Jessy (Administrator, OSD, 192.168.0.72). Each user has a 'Kill Session' button next to their 'Last Access' time. The interface also shows a 'Go to Sessions' link and a refresh icon.

| Item | Description |
|---|--|
| Headings | The headings provide information about each user session: <i>Username</i> , <i>User Level</i> , <i>Service</i> , <i>IP</i> , <i>Login Time</i> , and <i>Last Access</i> . For more details about each heading, see <i>Sessions</i> , page 271. |
| Go to Sessions | Clicking Go to Sessions opens the <i>Sessions</i> settings page which provides a page displaying the same information found in this panel. |
|  | Click this icon to Refresh the Sessions list. |

This Page Intentionally Left Blank

Chapter 11

Remote Viewer (AiT Models only)

Introduction

If the video source(s) of your AiT model is connected, the remote viewer can be used to access these video source(s) as if it were your local system.

A window will be presented and the remote server is displayed inside this window.


- ◆ You can maximize the window, drag the borders to resize the window and use the scrollbars to move around the screen.
- ◆ Due to net lag, there might be a slight delay before your keystrokes show up. You may also have to wait a bit for the remote mouse to catch up to your local mouse before you click.
- ◆ Due to net lag, or insufficient computing power on the local machine, some images, especially motion images, may display poorly.

There are several ways you can access the remote servers and are listed below:

1. **Windows viewer** accessed directly from the web browser GUI.
2. **Java viewer** accessed directly from the web browser GUI.
3. **Windows Client Viewer AP** (without browser). On the browser login page, a “Download Windows Client AP” is available. Refer to *The Windows/Java Client AP* on page 284 for more information.
4. **Java Client Viewer AP** (without browser). Since the control is identical to the windows client viewer, refer to *The Control Panel* on page 287 on the control of the viewer interface.

Windows and Java Client Viewer (web access)

The Windows and Java Client Viewer is accessible via a web browser.



At the login screen of the Remote Viewer page, enter the username/password and click **Login**. You can change the login language by using the language drop-down menu.

A second or two after, the video source(s)' display appears as a window on your desktop:



The control/access is laid out in the control panel. Refer to *The Control Panel* on page 287 for access/control information.


By default, if you use Internet Explorer as your browser, the Windows Client viewer is used. If you use other browsers, the Java Client viewer is used.

If you manually set the preference to Java Client when you use Internet Explorer as your browser, the Java Client viewer is also used.

The Windows/Java Client AP

Download

To download the stand-alone Windows or Java Client program, go to the browser login page and click the **Download Windows Client AP** or **Download Java Client AP** button.




Note: Make sure your system has JRE 6 Update 3 or later installed. Java is available for free download from Sun's Java web site (<http://java.sun.com>).

Starting Up


For the first time running the AP, right-click the Windows/Java Client AP and click “Run as administrator” to start.

The Client Connection Screen is shown below and each components are described in the table. Windows Client will be the example shown here.



| Item | Description |
|-----------------------|---|
| Server List | When you run the Client program, it automatically searches the user's local LAN segment for AiT units, and lists whichever ones it finds in this box. If you want to connect to one of these units, double-click to connect. |
| Server | If the AiT unit you wish to connect to is at a remote location, it will not be found on your LAN. You can enter its IP address and port yourself. If you don't know the Port number, contact the Administrator. When the IP address and Port number for the unit you wish to connect to have been specified, click Connect to start the connection. |
| Connect | Starts connecting to the AiT unit. |
| Disconnect | These buttons become active once you log into the AiT unit. |
| Switch to remote view | |
| Message panel | The blank field on the right of the Server section shows the current status of the server connection. |


1. Double-click the unit. When the unit is connected, a login window appears:



2. Provide a valid Username and Password and click **OK** to continue.

Note: The default Username is *administrator* and the default Password is *password*.

After you have successfully logged in, the connection screen reappears:



At this time there are two active buttons and are described in the table below:

| Button | Action |
|-----------------------|---|
| Disconnect | Breaks the connection to the unit. |
| Switch to remote view | Opens a window on the user's desktop containing the remote server's display that is the same as the one that appears with the browser-based Windows client. |

3. Click **Switch to remote view** to access the video source(s)' display(s).

Refer to *The Control Panel* on page 287 for information about the remote access interface.


The Control Panel

The control panel is hidden at the upper or lower center of the screen (the default is up). It becomes visible when you move the mouse pointer over it:













- Note:**
1. The above image shows the complete Control Panel. The icons that appear can be customized. See *Control Panel Configuration*, page 302, for details.
 2. To move the Control Panel to a different location, click and drag the Control Panel.





- ◆ The panel is consisted of two rows.
- ◆ The second row shows the video resolution of the remote display, the bus the user is on, and an information button where you can click it for a menu-style version of the control panel toolbar (see below).
- ◆ Right clicking the second row area also brings up the menu-style control panel. This menu allows you to select options for the *Screen Mode*, *Zoom*, *Mouse Pointer type*, and *Mouse Sync Mode*. These functions are discussed in the sections that follow.



Control Panel Functions

The Control Panel functions are described in the table below.

| Icon | Function |
|---|--|
|  | This is a toggle. Click to ping the Control Panel to the window where it is always displayed on top of other screen elements. Click again to have it display normally. |
|  | Click to bring up the Video Options dialog box. (See <i>Video Settings</i> , page 292, for details). |
|  | Toggles the display between <i>Full Screen Mode</i> and <i>Windowed Mode</i> . |
|  | Click to take a snapshot (screen capture) of the remote display. To configure the Snapshot parameters, refer to <i>Snapshot</i> on page 303. |
|  | Click to toggle the remote display between color and grayscale. |
|  | Click to zoom the remote display window. Note: This feature is only available in windowed mode (Full Screen Mode is off). See <i>Zoom</i> , page 298 for details. |
|  | Click to send a <i>Ctrl+Alt+Del</i> signal to the remote system. |
|  | Click to bring up the on-screen keyboard (see <i>The On-Screen Keyboard</i> , page 299). |
|  | Click to select the mouse pointer type. Note: This icon changes depending on which mouse pointer type is selected (see <i>Mouse Pointer Type</i> , page 300). |
|  | Click to toggle Automatic or Manual mouse sync. <ul style="list-style-type: none"> ◆ When the selection is <i>Automatic</i>, a green mark appears on the icon. ◆ When the selection is <i>Manual</i>, a red mark appears on the icon. See <i>Mouse DynaSync Mode</i> , page 300 for a complete explanation of this feature. |

| Icon | Function |
|---|---|
|  | <p>These icons show the Num Lock, Caps Lock, and Scroll Lock status of the remote computer.</p> <ul style="list-style-type: none"> ◆ When the lock state is <i>On</i>, the LED is bright orange. ◆ When the lock state is <i>Off</i>, the LED is dull blue. <p>Click on the icon to toggle the status.</p> <p>Note: These icons and your local keyboard icons are in sync. Clicking an icon causes the corresponding LED on your keyboard to change accordingly. Likewise, pressing a Lock key on your keyboard causes the icon's color to change accordingly.</p> |
|  | <p>Click to bring up the Macro dialog box (see <i>Macros</i>, page 290 for more details).</p> |
|  | <p>Click to bring up the <i>Virtual Media</i> dialog box. The icon changes when a virtual media device is mounted on the port. See <i>Virtual Media</i>, page 295, for specific details.</p> <p>Note: This icon displays in gray when the function is disabled or not available to the user.</p> |
|  | <p>Click to bring up the Control Panel Configuration dialog box. See <i>Control Panel Configuration</i>, page 302, for details on configuring the Control Panel.</p> |




Macros

The Macros icon provides access to three functions found in the Macros dialog box: Hotkeys, User Macros, and System Macros. Each of these functions is described in the following sections.

Hotkeys

Various actions, corresponding to clicking the Control Panel icons, can be accomplished directly from the keyboard with hotkeys. Selecting the Hotkeys radio button lets you configure which hotkeys perform the actions. The actions are listed to the left; their hotkeys are shown to the right. Use the checkbox to the left of an action's name to enable or disable its hotkey.



If you find the default Hotkey combinations inconvenient, you can reconfigure them as follows:

1. Highlight an *Action*, then click **Set Hotkey**.
2. Press your selected Function keys (one at a time). The key names appear in the **Hotkeys** field as you press them.
 - ◆ You can use the same function keys for more than one action, as long as the key sequence is not the same.
 - ◆ To cancel setting a hotkey value, click **Cancel**; to clear an action's Hotkeys field, click **Clear**.
3. When you have finished keying in your sequence, click **Save**.

To reset all the hotkeys to their default values, click **Reset**.


An explanation of the Hotkey actions is given in the table below:

| Action | Explanation |
|------------------------|--|
| Exit remote location | Exits the remote view. This is equivalent to clicking the <i>Exit</i> icon on the Control Panel. The default keys are F2, F3, F4. |
| Adjust Video | Brings up the <i>Video Settings</i> dialog box. This is equivalent to clicking the <i>Video Settings</i> icon on the Control Panel. The default keys are F5, F6, F7. |
| Toggle Control Panel | Toggles the Control Panel Off and On . The default keys are F3, F4, F5. |
| Toggle Mouse Display | <p>If you find the display of the two mouse pointers (local and remote) to be confusing or annoying, you can use this function to shrink the non-functioning pointer down to a barely noticeable tiny circle, which can be ignored. Since this function is a toggle, use the hotkeys again to bring the mouse display back to its original configuration. This is equivalent to selecting the <i>Dot</i> pointer type from the <i>Mouse Pointer</i> icon on the Control Panel. The default keys are F7, F8, F9.</p> <p>Note: The Java Control Panel does not have this feature.</p> |
| Adjust mouse | This synchronizes the local and remote mouse movements. The default keys are F8, F7, F6. |
| Video Auto-sync | This combination performs an auto-sync operation. It is equivalent to clicking the <i>Video Autosync</i> icon on the Control Panel. The default keys are F6, F7, F8. |
| Show/Hide Local Cursor | Toggles the display of your local mouse pointer off and on. This is equivalent to selecting the <i>Null</i> pointer type from the <i>Mouse Pointer</i> icon on the Control Panel. The default keys are F4, F5. |
| Substitute Ctrl key | If your local computer captures Ctrl key combinations, preventing them from being sent to the remote system, you can implement their effects on the remote system by specifying a function key to substitute for the Ctrl key. If you substitute the F11 key, for example, pressing [F11 + 5] would appear to the remote system as [Ctrl + 5]. The default key is F11. |
| Substitute Alt key | Although all other keyboard input is captured and sent to the remote system, [Alt + Tab] and [Ctrl + Alt + Del] work on your local computer. In order to implement their effects on the remote system, another key may be substituted for the Alt key. If you substitute the F12 key, for example, you would use [F12 + Tab] and [Ctrl + F12 + Del]. The default key is F12. |



Video Settings

The *Video Settings* dialog box allows you to adjust the placement and picture quality of the remote screen display on your monitor.




The adjustment options are as follows:

| Option | Usage |
|-------------|---|
| | Click this to control the transparency of the Video Settings dialog box. |
| Performance | Select the type of Internet connection that exists between the Local Client computer and the unit. The unit will use that selection to automatically adjust the <i>Video Quality</i> settings to optimize the quality of the video display. Since network conditions vary, if none of the preset choices seem to work well, you can select <i>Customize</i> and use the Video Quality slider bars to adjust the settings to suit your conditions. |
| Advanced | See page 293 for details. |

Gamma Adjustment

For greater control and if it is necessary to correct the gamma level for the remote video display, use the Gamma function of the **Advanced** Video Settings by clicking the **Advanced** button.

For gamma level, there are ten preset and four user-defined levels to choose from. Click the drop-down menu and choose the most suitable one.



The additional options in the Advanced screen are as follows:

| Option | Usage |
|--------|---|
| RGB | <p>Drag the slider bars to adjust the RGB (Red, Green, Blue) values. When an RGB value is increased, the RGB component of the image is correspondingly increased.</p> <p>If you enable <i>Set to Grayscale</i>, the remote video display is changed to grayscale.</p> |
| Gamma | <p>This section allows you to adjust the video display's gamma level.</p> <p>Click and drag the diagonal line at as many points as you wish to achieve the display output you desire.</p> <p>Click <i>Save As</i> to save up to four user-defined configurations derived from this method. Saved configurations can be recalled from the list box at a future time.</p> <p>Click <i>Reset</i> to abandon any changes and return the gamma line to its original diagonal position.</p> |

| Option | Usage |
|---------------------|--|
| Video Quality | Drag the slider bar to adjust the overall video quality. The larger the value, the clearer the picture and the more video data goes through the network. Depending on the network bandwidth, a high value may adversely affect response time. |
| Enable Refresh | <p>The unit can redraw the screen every 1 to 99 seconds, eliminating unwanted artifacts from the screen. Select Enable Refresh and enter a number from 1 through 99. The unit will redraw the screen at the interval you specify. This feature is disabled by default. Click to put a check mark in the box next to <i>Enable Refresh</i> to enable this feature.</p> <p>Note:</p> <ol style="list-style-type: none">1. The switch starts counting the time interval when mouse movement stops.2. Enabling this feature increases the volume of video data transmitted over the network. The lower the number specified, the more often the video data is transmitted. Setting too low a value may adversely affect overall operating responsiveness. |
| Transparency | Drag the slider bars to adjust the transparency of the remote display. |
| Color Depth Control | This setting determines the richness of the video display by adjusting the amount of color information. |

Click **OK** to save your changes and close the dialog box.

Click **Cancel** to abandon your changes and close the dialog box.

Note: For best results, change the gamma while viewing a remote computer.






Virtual Media

The *Virtual Media* feature allows a drive, folder, image file, or removable disk on a local client computer to appear and act as if it were installed on the remote server.

Virtual Media also supports a smart card reader function that allows a reader plugged into a local client computer to appear as if it were plugged into the remote server.

Virtual Media Icons


The *Virtual Media* icon on the **Control Panel** changes to indicate whether the virtual media function is available, or if a virtual media device has already been mounted on the remote server, as shown in the table below:

| Icon | Function |
|---|---|
|  | The icon displays as shown on the left to indicate that the virtual media function is disabled or not available. |
|  | The icon displays as shown on the left to indicate that the virtual media function is available. Click the icon to bring up the virtual media dialog box. |
|  | The icon displays as shown on the left to indicate that a virtual media device has been mounted on the remote server. Click the icon to unmount all redirected devices. |

Virtual Media Redirection

To implement the virtual media redirection feature, do the following:

1. Click the Virtual Media icon to bring up the *Virtual Media* dialog box:




2. Click **Add** and select the media source.




Depending on your selection, additional dialog boxes appear enabling you to select the drive, file, folder, or removable disk you desire. See *Virtual Media Support*, page 399 for details about mounting these media types.

3. To add additional media sources, click **Add**, and select the source.
Up to three virtual media choices can be added. To rearrange the selection order, highlight the device you want to move, then click the **Up** or **Down** Arrow button to promote or demote it in the list.
4. *Read* refers to the redirected device being able to send data to the remote server. *Write* refers to the redirected device being able to have data from the remote server written to it. The default is *Read*. If you want the redirected device to be writable, check the *Enable Write* checkbox:



-
- Note:**
1. If a redirected device cannot be written to, or if a user does not have write permissions, it appears in gray and cannot be selected.
 2. See *Virtual Media Support*, page 399, for a list of supported virtual media types.
-

5. To remove an entry from the list, highlight it and click **Remove**.
6. After you have made your media source selections, click **Mount**. The dialog box closes. The virtual media devices that you have selected are redirected to the remote system, where they show up as drives, files and folders on the remote system's file system.



Once mounted, you can treat the virtual media as if they were really on the remote server – drag and drop files to/from them; open files on the remote system for editing and save them to the redirected media, etc.

Files that you save to the redirected media will actually be saved on your local system. Files that you drag from the redirected media will actually come from your local system.

7. To end the redirection, bring up the *Control Panel* and click on the *Virtual Media* icon. All mounted devices are automatically unmounted.

Smart Card Reader

Note: This feature is only available when using the *WinClient Viewer* or the *Windows Client AP*.

The smart card reader function allows a reader plugged into a local client computer's USB port to be redirected, and appear as if it were plugged into the remote server. One purpose of smart cards (Common Access Cards, for example), is to allow authentication to the remote server from the local client.

When a smart card reader is connected to the local client computer, an entry for it appears when you bring up the **Virtual Media** dialog box and click **Add**:



Make your selection and click **Mount** to complete the redirection.



Zoom


The *Zoom* icon controls the zoom factor for the remote view window. Settings are as follows:

| Setting | Description |
|---------|---|
| 100% | Sizes and displays the remote view window at 100%. |
| 75% | Sizes and displays the remote view window at 75%. |
| 50% | Sizes and displays the remote view window at 50%. |
| 25% | Sizes and displays the remote view window at 25%. |
| 1:1 | Sizes and displays the remote view window at 100%. The difference between this setting and the 100% setting is that when the remote view window is resized its contents don't resize – they remain at the size they were. To see any objects that are outside of the viewing area move the mouse to the window edge, to have the screen scroll. |



The On-Screen Keyboard

The unit supports an on-screen keyboard, available in multiple languages, with all the standard keys for each supported language. Click this icon to pop up the on-screen keyboard:




One of the major advantages of the on-screen keyboard is that if the keyboard languages of the remote and local systems are not the same, you do not have to change the configuration settings for either system. The user just has to bring up the on-screen keyboard; select the language used by the computer on the port he is accessing; and use the on-screen keyboard to communicate with it.

Note: You must use your mouse to click on the keys. You cannot use your actual keyboard.


To change languages, do the following:

1. Click the down arrow next to the currently selected language to drop down the language list.



2. Select the new language from the list.

To display/hide the expanded keyboard keys, click the arrow to the right of the language list arrow.



Mouse Pointer Type

The CN9600 offers a number of mouse pointer options when working in the remote display. Click this icon to select the type that you would like to work with:



- Note:**
1. The Dot pointer is not available with the Java Client Viewer or the Java Client AP.
 2. Selecting the Single pointer has the same effect as the *Toggle mouse display* hotkey function (see *Toggle Mouse Display*, page 291 for details).
 3. The icon on the toolbar changes to match your choice.




Mouse DynaSync Mode

Clicking this icon selects whether synchronization of the local and remote mouse pointers is accomplished either automatically or manually.

The icon on the toolbar indicates the synchronization mode status as follows:

| Icon | Function |
|------|--|
| | The green mark on this icon indicates that Mouse DynaSync is available and is enabled . This is the default setting when Mouse DynaSync is available. |

| Icon | Function |
|---|--|
|  | The red mark on this icon indicates that Mouse DynaSync is available but is not enabled . |

When *Mouse DynaSync is available*, clicking the icon toggles between enabled and disabled. If you choose to disable Mouse DynaSync mode, you must use the manual syncing procedures described in the next section.

Automatic Mouse Synchronization (DynaSync)

Mouse DynaSync provides automatic locked-in syncing of the remote and local mouse pointers – eliminating the need to constantly re-sync the two movements.

Manual Mouse Synchronization


If you are using Manual mouse synchronization instead of automatic DynaSync and the local mouse pointer goes out of sync with the remote system's mouse pointer, there are a number of methods to bring them back into sync:

1. Invoke the **Adjust Mouse** function with the *Adjust Mouse* hotkeys (see *Adjust mouse*, page 291, for details).
2. Move the pointer into all 4 corners of the screen (in any order).
3. Drag the Control Panel to a different position on the screen.
4. Set the mouse speed and acceleration for each problematic computer attached to the switch. See *Additional Mouse Synchronization Procedures*, page 397, for instructions.



Control Panel Configuration

Clicking the *Customize Control Panel* icon brings up a dialog box that allows you to configure the items that appear on the Control Panel, as well as its graphical settings:



The dialog box is organized into five main sections as described in the table below:

| Item | Description |
|-------------------------|--|
| Customize Control Panel | Allows you to select which icons are displayed in the Control Panel. |
| Control Panel Style | <ul style="list-style-type: none"> ◆ Enabling <i>Transparent</i> makes the Control Panel semi-transparent, so that you can see through it to the display underneath. ◆ Enabling <i>Icon</i> causes the Control Panel to display as an icon until you mouse over it. When you mouse over the icon, the full panel comes up. |

| Item | Description |
|-----------------------|--|
| Screen Options | <ul style="list-style-type: none"> ◆ If Full Screen Mode is enabled, the remote display fills the entire screen. ◆ If Full Screen Mode is not enabled, the remote display appears as a window on the client desktop. If the remote screen is larger than what is able to fit in the window, scroll bars will appear. ◆ If Keep Screen Size is enabled, the remote screen is not resized. <ul style="list-style-type: none"> ◆ If the remote resolution is smaller than that of the client monitor, its display appears like a window centered on the screen. ◆ If the remote resolution is larger than that of the client monitor, its display is scaled to the client monitor size. ◆ If Keep Screen Size is not enabled, the remote screen is resized to fit the client monitor's resolution. |
| Scrolling Method | <p>In cases where the remote screen display is larger than your monitor, you can choose how to scroll to the areas that are off-screen.</p> <ul style="list-style-type: none"> ◆ If you select <i>Mouse Movement</i>, the screen will scroll when you move the mouse pointer to your screen border. ◆ If you select <i>Scroll Bars</i>, scroll bars appear around the screen borders that you can use to scroll to the off-screen areas. |
| User Info | <p>If <i>User Numbers</i> is enabled, the total number of users logged into the unit displays beside the resolution on the second row of the Control Panel (See the <i>Control Panel</i> diagram on page 287 for an example.)</p> |
| Snapshot | <p>These settings let the user configure the unit's screen capture parameters (see the <i>Snapshot</i> description under <i>The Control Panel</i>, page 287):</p> <ul style="list-style-type: none"> ◆ Path lets you select a directory that the captured screens automatically get saved to. Click Browse; navigate to the directory of your choice; then click OK. If you don't specify a directory here, the snapshot is saved to your desktop. ◆ Click a radio button to choose whether you want the captured screen to be saved as a BMP or a JPEG (JPG) file. ◆ If you choose JPEG, you can select the quality of the captured file with the slider bar. The higher the quality, the better looking the image, but the larger the file size. |
| Keyboard Pass Through | <p>When this is enabled, the Alt-Tab key press is passed to the remote server and affects that server. If it is not enabled, Alt-Tab acts on your local client computer.</p> |
| Window Title | <p>Use the drop-down menu to select which remote server information is displayed on the window title.</p> |

This Page Intentionally Left Blank

Chapter 12

Firmware Upgrade Utility

The Windows-based Firmware Upgrade Utility (FWUpgrade.exe) provides a smooth, automated process for upgrading the firmware. The Utility comes as part of a Firmware Upgrade Package that is specific for each device. New firmware upgrade packages are posted on our web site as new firmware revisions become available. Check the web site regularly to find the latest packages and information relating to them:

<http://www.aten.com>

For browser based firmware upgrade, please refer to *FW Upgrade* on page 262.


Preparation

1. From a computer that is not part of your installation go to our Internet support site and choose the model name that relates to your KE device to get a list of available Firmware Upgrade Packages.
2. Choose the Firmware Upgrade Package you want to install (usually the most recent), and download it to your computer.
3. Be sure that the computer is connected to the same LAN segment as the KE devices.

Starting the Upgrade


To upgrade your firmware:

1. Run the downloaded Firmware Upgrade Package file - either by double clicking the file icon, or by opening a command line and entering the full path to it. The Firmware Upgrade Utility Welcome screen appears:




Note: The screens shown in this section are for reference only.


2. Read the License Agreement (enable the *I Agree* radio button).
3. Click **Next**. The Firmware Upgrade Utility main screen appears:



4. The Utility inspects your installation. All the devices capable of being upgraded by the package are listed in the *Select Master Device* list.



5. After you have made your device selection, Click **OK** and then **Next** to begin the upgrade.



If you enabled *Check Firmware Version*, the Utility compares the device's firmware level with that of the upgrade files. If it finds that the device's version is higher than the upgrade version, it brings up a dialog box informing you of the situation and gives you the option to **Continue** or **Cancel**.

If you didn't enable *Check Firmware Version*, the Utility installs the upgrade files without checking whether they are a higher level, or not.

As the Upgrade proceeds status messages appear in the Status Messages panel, and the progress toward completion is shown on the *Progress* bar.

Firmware Upgrade Recovery

If the Upgrade Succeeded screen doesn't appear or the upgrade procedure is abnormally halted (due to computer crash, power failure, etc.), the device may become inoperable. If you find that the device does not work following a failed or interrupted upgrade, do the following

1. Power off the KE device.
2. Press the **Reset** button, then power on the KE device while holding Reset.
3. Hold **Reset** for 7 seconds after the device is powered on.
4. The device will revert to a previous firmware version and recover from the failure.
5. Upgrade the firmware to the most current version available.

This Page Intentionally Left Blank

Chapter 13

CLI Commands

Serial Control Protocol Commands

The KE Series's built-in bi-directional RS-232 serial interface and LAN port connection allows system control via Receivers through a high-end controller or PC. This control feature can also be accessed via TCP/IP through a computer running Telnet. The port for Telnet commands should be set to 9130.


Configuring the Serial Port

The controller's serial port should be configured the same as the Receiver's default configuration, as shown below:

| | |
|--------------|------|
| Baud Rate | 9600 |
| Data Bits | 8 |
| Parity | None |
| Stop Bits | 1 |
| Flow Control | None |

The Receiver's **Function Switch** should be set to *RS-232 Config* (see page 12). Before executing RS-232 commands across a network you must install the KE Matrix Manager software on a computer and ensure that it is online. For the Slim Version of KE Series (KE8900ST/8900SR/9900ST). Please make sure the RS-232 Serial Port is not connected before executing commands.

On your computer, open a terminal (command line) session. Please press "Enter" or "T/t" to start "CLI Session" or "Text Menu".



```
COM6 - PuTTY
Welcome to ATEN KE8950 User Station
Copyright(c) 2009-2013 ATEN International Co., Ltd.

--Press ENTER to start CLI session
--Press T/t to start TextMenu :

Welcome to CLI mode

USER_NAME:administrator
PASSWORD:
#>
```

Device/Profile Commands

When typing a device or profile into a command string, you can enter the name by: **IP address** (device only), **ID** or **@** with the List number for the device/profile in the command line interface.


Note: To find out about the List number for a device/profile, execute a List command (page 328).

Telnet

The KE Series can be operated and configured via a remote terminal session using Telnet. This is a useful means for configuring devices when they are first setup and connected to the network.

To log into the KE Series device by means of a Telnet session, do the following:

1. On your computer, open a terminal (command line) session.
2. At the prompt, key in the KE device's IP address with port 9130 in the following way:
telnet [IP address] [port]
3. Press Enter. The login screen appears. At the login prompt, provide the Password.

A screenshot of a terminal window titled "192.168.0.71 - PuTTY". The terminal displays the following text:

```
Welcome to CLI mode  
USER NAME:administrator  
PASSWORD:password  
#>
```

A green cursor is visible after the prompt "#>".

Verification

After sending a command, a verification message appears at the end of the command line. Use the echo command to identify a command by number:

- ♦ **Command OK** - the command is correct and performed successfully
- ♦ **Command incorrect** - the command has the wrong format and/or values.
- ♦ **Echo Command** - at the end of a command string, type: **e1234** – where 1234 can be any number. The verification message returns with the echo number.

Switch Port Command

The formula for Switch Port commands is as follows:

Command + Output + Num1 + Input + Num2 + Mode + Stream + Connect + [Enter]

1. For example, if you want to switch the Receiver's connection to Transmitter (192.168.0.20), type the following:
sw i192.168.0.20 [Enter]
2. For example, if you want to disconnect the Receiver from its Transmitter connections, type the following:
sw off [Enter]
3. For example, if you want to connect Receiver (192.168.0.99) to Transmitter (192.168.0.79) with exclusive access to stream video and audio, type the following:
sw o192.168.0.99 i192.168.0.79 exclusive video audio on [Enter]
4. For example, to disconnect Receiver (192.168.0.11) from the video stream and return it to the OSD menu, type the following:
sw o192.168.0.11 off [Enter]
5. For example, to disconnect Receiver (192.168.0.09) from the video stream and logout the OSD, type the following:
sw o192.168.0.09 logout [Enter]
6. For example, to disconnect the Receiver's USB stream, type the following:
sw usb off [Enter]
7. For example, to switch the Receiver to the 5th Transmitter listed in the command line interface, type the following:
sw i@5 exclusive all on [Enter]
8. For example, to switch the Receiver to the 7th Transmitter listed in the command line interface with echo command 4312, type the following:
sw i@7 exclusive all on e4312
9. For example, to switch Receiver (192.168.0.12) to the 14th Transmitter listed in the command line interface with occupy access to stream video audio and USB, type the following:
sw o192.168.0.12 i@14 occupy video audio usb on [Enter]

The following tables show the possible values for the Switch Port commands:

| Command | Description |
|---------|---------------------|
| sw | Switch port command |

| Output | Description |
|--------|--------------------------|
| o | Output port command (RX) |

| Num1 | Description |
|------|---|
| xx | Output port xx: Receiver ID or IP address |
| @zz | List # zz: 1~99 To use the 4th Receiver listed in the command line interface, type: o@4 |

| Input | Description |
|-------|--------------------|
| i | Input command (TX) |

| Num2 | Description |
|------|--|
| yy | Input port yy: Transmitter ID or IP address |
| @zz | List # zz: 1~99 To use the 8th Transmitter listed in the command line interface, type: i@8 |

| Mode | Description |
|-----------|--|
| exclusive | Sets the Access Mode to exclusive. |
| share | Sets the Access Mode to share. |
| occupy | Sets the Access Mode to occupy. |
| viewonly | Sets the Access Mode to view only. If the mode is omitted, view only is used by default. |

| Stream | Description |
|--------|-------------------------------|
| video | Sets the video source stream |
| audio | Sets the audio source stream |
| serial | Sets the serial source stream |

| Stream | Description |
|--------|----------------------------|
| usb | Sets the USB source stream |
| all | Sets all source streams |

| Connect | Description |
|---------|-------------|
| on | Connect |
| off | Disconnect |
| logout | Logout OSD |

The following table lists the available Switch Port commands:

| Command | Output | Num1 | Input | Num2 | Mode | Stream | Connect | Description |
|---------|--------|------|-------|------|-----------|--|---------|---|
| sw | o | xx | i | yy | exclusive | video audio serial usb all | on | Switch output xx to input yy with exclusive access to source(s). xx: Receiver ID yy: Transmitter ID |
| sw | o | xx | i | yy | share | video audio serial usb all | on | Switch output xx to input yy with share access to stream source(s). xx: Receiver ID yy: Transmitter ID |
| sw | o | xx | i | yy | occupy | video audio serial usb all | on | Switch output xx to input yy with occupy access to stream source(s). xx: Receiver ID yy: Transmitter ID |
| sw | o | xx | i | yy | viewonly | video audio serial usb all | on | Switch output xx to input yy with viewonly access to stream source(s). xx: Receiver ID yy: Transmitter ID |
| sw | o | xx | | | | | off | Switch output xx, disconnect streams, return to OSD menu. xx: Receiver ID |
| sw | o | xx | | | | | logout | Switch output xx, disconnect streams and logout from OSD menu. xx: Receiver ID |
| sw | | | | | | video audio serial usb all | off | Switch Receiver stream(s) to disconnect. |

| Command | Output | Num1 | Input | Num2 | Mode | Stream | Connect | Description |
|---------|--------|------|-------|------|--|--|---------|--|
| sw | | | | | | | off | Switch Receiver disconnect streams, return to OSD menu. |
| sw | | | i | @zz | exclusive share occupy viewonly | video audio serial usb all | on | Switch Receiver to input @zz with [mode] access to stream source(s). zz: Transmitter # by order listed in the command line interface. |
| sw | o | xx | i | @zz | exclusive | video audio serial usb all | on | Switch output xx to input @zz with [mode] access to stream source(s). xx: Receiver ID zz: Transmitter # by order listed in command line interface. |

- Note:**
1. Each command string can be separated with a space.
 2. The **Mode** command string can be skipped and **view only** will be used by default.
 3. Skip the **Output** and **Num1** command strings to configure the local Receiver.

Mute Command

The Mute command allows you to enable or disable the audio.

The formula for the Mute command is as follows:

Command + Output + Num1 + Control + [Enter]

1. For example, to turn mute off (audio on) for the Receiver, type the following:

mute off [Enter]

2. For example, to turn mute on for Receiver (192.168.0.11), type the following:

mute o192.168.0.11 on [Enter]

3. For example, to turn mute off for Receiver (192.168.0.18), type the following:

mute o192.168.0.18 off [Enter]

The following tables show the possible values for the Mute commands:

| Command | Description |
|---------|--|
| mute | Mute command |
| Output | Description |
| o | Output port command |
| Num1 | Description |
| xx | Output number xx: Receiver ID or IP address |
| Control | Description |
| on | Mute on; audio disabled |
| off | Mute off; audio enabled (default) |

The following table lists the available Mute commands:

| Command | Output | Num1 | Control | Description |
|---------|--------|------|---------|--|
| mute | o | xx | on | Turn mute on for output xx xx: Receiver ID |
| mute | o | xx | off | Turn mute off for output xx xx: Receiver ID |

| Command | Output | Num1 | Control | Description |
|---------|--------|------|---------|----------------------------|
| mute | | | on | Turn mute on for Receiver |
| mute | | | off | Turn mute off for Receiver |

- Note:**
1. Each command string can be separated with a space.
 2. The **Control** command string can be skipped and **off** will be used by default.
 3. Skip the **Output** and **Num1** command strings to configure the local Receiver.
-

Profile Command

The Profile command allows you to connect profiles and video walls.

The formula for Profile commands is as follows:

Command + Profile + Num1 + Control + [Enter]

1. For example, to connect profile 8 and lock the OSD menu, type the following:
profile f8 [Enter]
2. For example, to connect profile 4 with access to the OSD menu, type the following:
profile f4 release [Enter]
3. For example, to disconnect profile 12 and return to the Receiver to the OSD menu, type the following:
profile f12 back [Enter]

The following tables show the possible values for the Profile commands:

| Command | Description |
|----------------|--------------------|
| profile | Profile command |

| Profile | Description |
|----------------|--------------------|
| f | Profile ID |

| Num1 | Description |
|-------------|--------------------------------------|
| xx | Profile or Video Wall ID xx: 1-99 |

| Control | Description |
|----------------|--|
| lock | Connect profile, lock access to OSD menu (default) |
| release | Connect profile, allow access to OSD menu |
| back | Disconnect profile, return Receiver to OSD menu |

The following table lists the available Profile commands:

| Command | Profile | Num1 | Control | Description |
|---------|---------|------|---------|---|
| profile | f | xx | lock | Connect profile xx, lock OSD access xx: 1~99 |
| profile | f | xx | release | Connect profile xx, allow OSD access xx: 1~99 |
| profile | f | xx | back | Disconnect profile xx and return Receiver to OSD menu xx: 1~99 |

-
- Note:** 1. Each command string can be separated with a space.
2. The **Control** command string can be skipped and **lock** will be used by default.
 3. For functional **lock** and **release** commands, make sure the **Lock OSD when connecting** option is checked during *Create Profile*. Refer to *Lock OSD*, page 244 for more information.
-

EDID Command

Extended Display Identification Data (EDID) is a data that contains a display's basic information and is used to communicate with the video source. The EDID commands allow you to change the EDID setting of a Transmitter. For more information on configuring EDID settings, see *Properties*, page 149.

The formula for the EDID command is as follows:

Command + Address + Number + Control + [Enter]

1. For example, if you want to configure device (192.168.0.3) to use the remix EDID mode, type the following:

edid a192.168.0.3 remix [Enter]

The following tables show the possible values for the EDID commands:

| Command | Description |
|---------|--|
| edid | EDID command |
| Address | Description |
| a | Address command |
| Number | Description |
| xx | Address number xx: Receiver ID or IP address |
| Control | Description |
| auto | Checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays. |
| remix | Manually checks the EDID of all connected displays and the ATEN default EDID to use the best common resolution for all displays (see <i>EDID Mode</i> , page 161). |
| default | Implements ATEN's default EDID. (default) |
| manual | Manually set the EDID configuration from the Receiver's OSD (see <i>EDID Mode</i> , page 161). |

The following table lists the available EDID commands:

| Command | Address | Number | Control | Enter | Description |
|----------------|----------------|---------------|----------------|--------------|---|
| edid | a | xx | auto | [Enter] | Set EDID of address xx to auto. xx: Device ID or IP Address |
| edid | a | xx | remix | [Enter] | Set EDID of address xx to remix. xx: Device ID or IP Address |
| edid | a | xx | default | [Enter] | Set EDID of address xx to default. xx: Device ID or IP Address |
| edid | a | xx | manual | [Enter] | Set EDID of address xx to manual. xx: Device ID or IP Address |

Reset Command

The Reset command allows you to reset a device back to the default factory settings. Reset includes resetting the devices IP address.

Note: The Reset command resets everything but the login information to the factory default settings. To reset the login information, refer to *Reset All Information* on page 381.

The formula for the Reset command is as follows:

Command + Address + Number + [Enter]

- For example, to reset device (192.168.0.95), type the following:
reset a192.168.0.95 [Enter]
- For example, to reset the Receiver, type the following:
reset [Enter]

The following tables show the possible values for the **Reset** command:

| Command | Description |
|---------|---------------|
| reset | Reset command |

| Address | Description |
|---------|-----------------|
| a | Address command |

| Number | Description |
|--------|---|
| xx | Address number xx: Receiver ID or IP address |

The following table lists the available Reset commands:

| Command | Address | Num | Enter | Description |
|---------|---------|-----|---------|--|
| reset | a | xx | [Enter] | Reset address xx back to the factory default settings xx: Device ID or IP Address |
| reset | | | [Enter] | Resets the Receiver settings |

Note: 1. Each command string can be separated with a space.

- Skip the **Address** and **Number** command strings to reset the local Receiver.

RS-232 Command

The RS-232 command allows you to set the RS-232 settings for a device.

The formula for the RS-232 command is as follows:

Command + Address + Number + Baud Rate + Parity + Data Bit + Stop Bit + Flow Control [Enter]

1. For example, to set device (192.168.0.33) with a baud rate of 38400, parity of none, data bit of 8, and stop bit of 1, type the following:

baud a192.168.0.33 38400 none 8 1 [Enter]

2. For example, to set the local device with a baud rate of 19200, type the following:

baud 19200 [Enter]

The following tables show the possible values for the RS-232 command:

| Command | Description |
|----------------|--------------------|
| baud | RS-232 command |

| Address | Description |
|----------------|--------------------|
| a | Address command |

| Num1 | Description |
|-------------|---|
| xx | Address number xx: Device ID or IP address |

| Baud Rate | Description |
|------------------|----------------------|
| 9600 | Use 9600 baud rate |
| 19200 | Use 19200 baud rate |
| 38400 | Use 38400 baud rate |
| 115200 | Use 115200 baud rate |

| Parity | Description |
|---------------|-------------------------|
| None | Sets the parity to none |
| Even | Sets the parity to even |
| Odd | Sets the parity to odd |

| Data Bit | Description |
|-----------------|------------------------|
| 5 | Sets the data bit to 5 |
| 6 | Sets the data bit to 6 |

| Data Bit | Description |
|--------------|-------------------------------|
| 7 | Sets the data bit to 7 |
| 8 | Sets the data bit to 8 |
| Stop Bit | Description |
| 1 | Sets the stop bit to 1 |
| 2 | Sets the stop bit to 2 |
| Flow Control | Description |
| None | Sets flow control to none |
| Hardware | Sets flow control to hardware |
| Xon | Sets flow control to Xon |
| Xoff | Sets flow control to Xoff |

The following table lists the available Baud Rate commands:

| Com mand | Address | Num 1 | Baud Rate | Parity | Data Bit | Stop Bit | Flow Control | Description |
|-------------|---------|----------|--------------|---------------------|------------------|-------------|------------------------------|---|
| baud | a | xx | 9600 | None Even Odd | 5 6 7 8 | 1 2 | None Hardware Xon/Xoff | Set address xx baud rate to 9600, with parity/ data bit/ stop bit / flow control setting |
| baud | a | xx | 19200 | None Even Odd | 5 6 7 8 | 1 2 | None Hardware Xon/Xoff | Set address xx baud rate to 19200, with parity/ data bit/ stop bit / flow control setting |
| baud | a | xx | 38400 | None Even Odd | 5 6 7 8 | 1 2 | None Hardware Xon/Xoff | Set address xx baud rate to 38400, with parity/ data bit/ stop bit / flow control setting |
| baud | a | xx | 115200 | None Even Odd | 5 6 7 8 | 1 2 | None Hardware Xon/Xoff | Set address xx baud rate to 115200, with parity/ data bit/ stop bit / flow control setting |

| Com mand | Address | Num 1 | Baud Rate | Parity | Data Bit | Stop Bit | Flow Control | Description |
|-------------|---------|----------|--------------|--------|-------------|-------------|-----------------|--|
| baud | | | 9600 | | | | | Set local device baud rate to 9600 |
| baud | | | 19200 | | | | | Set local device baud rate to 19200 |
| baud | | | 38400 | | | | | Set local device baud rate to 38400 |
| baud | | | 115200 | | | | | Set local device baud rate to 115200 |

- Note:** 1. Each command string can be separated with a space.
2. The **Baud Rate** value is required but **Parity**, **Data Bit** and **Stop Bit** can be skipped and their setting will not change.
 3. Skip the **Address** and **Number** command strings to configure the local device settings.
-

OSD Command

To enable or disable the On-Screen Display (OSD) menu for a Receiver, use the following command:

Command + Output + Number + Control + [Enter]

1. For example, to enable the OSD for Receiver 192.168.0.51, type:
osd o192.168.0.51 on [Enter]
2. For example, to disable the OSD for the local Receiver, type:
osd off [Enter]

The following tables show the possible values for the OSD command:

| Command | Description |
|---------|-------------|
| osd | OSD command |

| Output | Description |
|--------|----------------|
| o | Output command |

| Number | Description |
|--------|--|
| xx | Output number xx: Receiver ID or IP address |

| Control | Description |
|---------|---------------------------------|
| on | Enable OSD functions |
| off | Disable OSD functions (default) |

The following table lists the available OSD commands:

| Command | Output | Number | Control | Enter | Description |
|---------|--------|--------|---------|---------|--|
| osd | o | xx | on | [Enter] | Enable OSD functions for output xx xx: Receiver ID or IP address |
| osd | o | xx | off | [Enter] | Disable OSD functions for output xx off (default) xx: Receiver ID or IP address |

Note: 1. Each command string can be separated with a space.

2. Skip the **Output** and **Number** command strings to configure the local Receiver.

List Command

The List command allows you to retrieve information about users, settings and connections.

The formula for the List command is as follows:

Command + Output + Input + Number + Control [Enter]

1. For example, for a complete list of available channels, type the following:
list channel [Enter]
2. For example, for a complete list of available profiles, type the following:
list profile [Enter]
3. For example, to list all users logged into all OSD menus, type the following:
4. list login [Enter]
5. For example, to list the user logged into the OSD on Receiver (192.168.0.44), type the following:
list o192.168.0.44 login [Enter]
6. For example, for a complete list of available connections, type the following:
list connection [Enter]
7. For example, to list the current connections on Transmitter (192.168.0.88), type the following:
list i192.168.0.88 connection [Enter]

The following tables show the possible values for the List command:

| Command | Description |
|---------|--------------|
| list | List command |

| Output | Description |
|--------|----------------|
| o | Output command |

| Input | Description |
|-------|---------------|
| i | Input command |

| Number | Description |
|--------|---|
| xx | Output or Input number xx: Device ID or IP address |

| Control | Description |
|------------|---|
| channel | Lists information about the available channel(s) |
| profile | Lists information about the available profile and TV wall connections |
| rx | Lists information about the Receiver |
| login | Lists information about users logged into to the OSD menu |
| connection | Lists information about a Transmitters current connections |

The following table lists the available List commands:

| Command | Output | Input | Number | Control | Description |
|---------|--------|-------|--------|------------|--|
| list | o | | xx | login | List output xx user logged into OSD. |
| list | o | | xx | rx | List output xx Receiver information |
| list | | i | xx | connection | List input xx Transmitter information |
| list | | | | channel | List all available channel information |
| list | | | | profile | List all available profile information |
| list | | | | rx | List information about all Receivers |
| list | | | | login | List information about all OSD logins |
| list | | | | connection | List information about all connections |

Note: 1. Each command string can be separated with a space.

2. Skip the **Output** or **Input** and **Number** command strings to view the local Receiver.

Read Command

The Read command allows you to retrieve the properties of a device.

The formula for the Read command is as follows:

Command + Output + Input + Number + Control [Enter]

1. For example, to read all of the local Receiver's properties, type the following:
read all [Enter]
2. For example, to read all of Receiver (192.168.0.19) device properties, type the following:
read o192.168.0.19 all [Enter]
3. For example, to read all of Transmitter (192.168.0.28) device properties, type the following:
read i192.168.0.28 all [Enter]
4. For example, to read the basic properties of Receiver (192.168.0.61), type the following:
read o192.168.0.61 basic [Enter]
5. For example, to read the network properties of Transmitter (192.168.0.71), type the following:
read i192.168.0.71 network [Enter]

The following tables show the possible values for the Read command:

| Command | Description |
|----------------|--------------------|
| read | Read command |

| Output | Description |
|---------------|--------------------|
| o | Output command |

| Input | Description |
|--------------|--------------------|
| i | Input command |

| Number | Description |
|---------------|---|
| xx | Output or Input number xx: Device ID or IP address |

| Control | Description |
|----------------|----------------------------|
| all | Read all device properties |

| Control | Description |
|-----------------|--|
| basic | Read basic properties |
| network | Read network properties |
| ipsettings | Read IP settings |
| rs232 | Read RS232 properties |
| properties | Read connection properties |
| manager | Read KE Matrix Manager software properties |
| streams | Read enable media properties |
| tx | Read source stream IP properties (Receiver) |
| usbmode | Read USB mode properties (Receiver) |
| multicast | Read multicast properties (Transmitter) |
| videoqyadvanced | Read advanced video properties (Transmitter) |
| ossettings | Read OS properties (Transmitter) |

The following table lists the available Read commands:

| Command | Output | Input | Number | Control | Description |
|---------|--------|-------|--------|------------|--|
| read | o | i | xx | all | Read output or input xx all device properties xx: Device ID or IP address |
| read | o | i | xx | basic | Read output or input xx basic properties xx: Device ID or IP address |
| read | o | i | xx | network | Read output or input xx network properties xx: Device ID or IP address |
| read | o | i | xx | ipsettings | Read output or input xx IP address properties xx: Device ID or IP address |

| Command | Output | Input | Number | Control | Description |
|---------|--------|-------|--------|-----------------|---|
| read | o | i | xx | rs232 | Read output or input xx RS-232 properties xx: Device ID or IP address |
| read | o | i | xx | properties | Read output or input xx connection properties xx: Device ID or IP address |
| read | o | i | xx | manager | Read output or input xx KE Matrix Manager IP and port properties xx: Device ID or IP address |
| read | o | i | xx | streams | Read output or input xx enable media properties xx: Device ID or IP address |
| read | o | | xx | tx | Read output xx source stream IP address properties xx: Receiver ID or IP address |
| read | o | | xx | usbmode | Read output xx USB mode properties xx: Receiver ID or IP address |
| read | i | | xx | multicast | Read input xx multicast properties xx: Transmitter ID or IP address |
| read | i | | xx | videoqyadvanced | Read input xx advanced video properties xx: Transmitter ID or IP address |
| read | i | | xx | ossettings | Read input xx OS properties xx: Transmitter ID or IP address |
| read | | | | all | Read all properties of local Receiver |

| Command | Output | Input | Number | Control | Description |
|---------|--------|-------|--------|--|---|
| read | | | | basic network ipsettings rs232 properties manager streams tx usbmode | Read [control] properties of local Receiver. |

Note: 1. Each command string can be separated with a space.

2. Skip the **Output** or **Input** and **Number** command strings to read the local Receiver properties.
-

Set Command

The Set command allows you to configure the properties of a device. Some settings require that both the device and Matrix Manager are online or the command will fail.

The formula for the Set command is as follows:

Command + Output + Input + Number + Control + Value + [Enter]

1. For example, to set the name of the local Receiver to KE6940TX1, type the following:

set Name=KE6940TX1 [Enter]

2. For example, to set the description of Transmitter (192.168.0.33) to KE Room B, type the following:

set o192.168.0.19 Description=KE Room B [Enter]

3. For example, to set the DHCP settings of Transmitter (192.168.0.28) to static, type the following:

set i192.168.0.28 dhcpFlag=STATIC [Enter]

4. For example, to set the IP settings of the local Receiver to 192.168.0.2, type the following:

set ipAddr=192.168.0.2 [Enter]

5. For example, to set the Transmitter Video IP setting to 192.168.0.44 for Receiver (192.168.0.56), type the following:

set o192.168.0.56 TxVideoIP=192.168.0.44 [Enter]

The following tables show the possible values for the Set command:

| Command | Description |
|----------------|--------------------|
| set | Set command |

| Output | Description |
|---------------|--------------------|
| o | Output command |

| Input | Description |
|--------------|--------------------|
| i | Input command |

| Number | Description |
|---------------|---|
| xx | Output or Input number xx: Device ID or IP address |

| Control | Description |
|-----------------|---|
| Name | Sets the device name |
| Description | Sets the device description |
| ipInstallerFlag | Sets the IP installer option |
| dhcpFlag | Sets the DHCP setting |
| ipAddr | Sets the IP address |
| netmask | Sets the subnet mask |
| gw | Sets the default gateway |
| modeFlag | Sets the device mode |
| BaudRate | Sets the baud rate setting |
| Parity | Sets the parity setting |
| DataBit | Sets the data bit setting |
| StopBit | Sets the stop bit setting |
| FlowCtrl | Sets the flow control setting |
| TxVideoIP | Sets the Transmitter video IP setting |
| TxAudioIP | Sets the Transmitter audio IP setting |
| TxUSBIP | Sets the Transmitter USB IP setting |
| TxRSIP | Sets the Transmitter RS-232 IP setting |
| VideoEnFlag | Sets the (enable media) video source stream |
| AudioEnFlag | Sets the (enable media) audio source stream |
| USBEnFlag | Sets the (enable media) USB source stream |
| RSEnFlag | Sets the (enable media) RS232 source stream |
| ManagerIP | Sets the KE Matrix Manager software IP |
| ManagerPort | Sets the KE Matrix Manager software port |
| Beeper | Sets the beeper |
| RxVM | Sets the USB mode setting |
| USBSecure | Sets the USB encryption |
| PortOS | Sets the port OS setting |
| OSLanguage | Sets the OS language |
| videoMCastEn | Sets the enable multicast video setting |

| Control | Description |
|----------------|---|
| audioMCastEn | Sets the enable multicast audio setting |
| Edid | Sets the EDID mode selection setting |
| VideoType | Sets the video type setting |
| ColorDepth | Sets the color depth setting |
| BandwidthLimit | Sets the bandwidth limit setting |
| VideoQty | Sets the video quality setting |
| BGRefresh | Sets the background refresh setting |
| Beeper | Sets the beeper setting |
| OccupyTimeout | Sets the occupy timeout setting |
| Resolution | Sets the resolution setting |

| Value | Description |
|-------|---|
| =yy | Set value to yy yy: Enter a value that corresponds to the control being used |

The following table lists the available Set commands:

| Command | Output | Input | Number | Control | Value | Description |
|---------|--------|-------|--------|-----------------|-------|--|
| Set | o | i | xx | Name | yy | Set output or input xx Name to yy xx: Device ID or IP address yy: Name value |
| Set | o | i | xx | Description | yy | Set output or input xx Description to yy xx: Device ID or IP address yy: Description value |
| Set | o | i | xx | ipInstallerFlag | yy | Set output or input xx ipInstallerFlag to yy xx: Device ID or IP address yy: enable, viewonly, disable |

| Comm and | Output | Input | Number | Control | Value | Description |
|----------|--------|-------|--------|----------|-------|--|
| Set | o | i | xx | dhcpFlag | yy | Set output or input xx dhcpFlag to yy xx: Device ID or IP address yy: dhcp, static |
| Set | o | i | xx | ipAddr | yy | Set output or input xx ipAddr to yy xx: Device ID or IP address yy: IP address value |
| Set | o | i | xx | netmask | yy | Set output or input xx netmask to yy xx: Device ID or IP address yy: Subnet mask value |
| Set | o | i | xx | gw | yy | Set output or input xx gw to yy xx: Device ID or IP address yy: Default gateway value |
| Set | o | i | xx | modeFlag | yy | Set output or input xx modeFlag to yy xx: Device ID or IP address yy: extender, matrix |
| Set | o | i | xx | BaudRate | yy | Set output or input xx BaudRate to yy xx: Device ID or IP address yy: 9600, 19200, 38400, 115200 |
| Set | o | i | xx | Parity | yy | Set output or input xx Parity to yy xx: Device ID or IP address yy: none, even, odd |
| Set | o | i | xx | DataBit | yy | Set output or input xx DataBit to yy xx: Device ID or IP address yy: 5, 6, 7, 8 |

| Comm and | Output | Input | Number | Control | Value | Description |
|----------|--------|-------|--------|-------------|-------|---|
| Set | o | i | xx | StopBit | yy | Set output or input xx StopBit to yy xx: Device ID or IP address yy: 1, 1.5, 2 |
| Set | o | i | xx | FlowCtrl | yy | Set output or input xx FlowCtrl to yy xx: Device ID or IP address yy: none, hardware, Xon, Xoff |
| Set | o | i | xx | TxVideoIP | yy | Set output xx TxVideoIP to yy xx: Device ID or IP address yy: IP address value |
| Set | o | | xx | TxAudioIP | yy | Set output xx TxAudioIP to yy xx: Device ID or IP address yy: IP address value |
| Set | o | | xx | TxUSBIP | yy | Set output xx TxUSBIP to yy xx: Device ID or IP address yy: IP address value |
| Set | o | | xx | TxRSIP | yy | Set output xx TxRSIP to yy xx: Device ID or IP address yy: IP address value |
| Set | o | i | xx | VideoEnFlag | yy | Set output or input xx VideoEnFlag to yy xx: Device ID or IP address yy: enable, disable |
| Set | o | i | xx | AudioEnFlag | yy | Set output or input xx AudioEnFlag to yy xx: Device ID or IP address yy: enable, disable |

| Command | Output | Input | Number | Control | Value | Description |
|---------|--------|-------|--------|-------------|-------|--|
| Set | o | i | xx | USBEnFlag | yy | Set output or input xx USBEnFlag to yy xx: Device ID or IP address yy: enable, disable |
| Set | o | i | xx | RSEnFlag | yy | Set output or input xx RSEnFlag to yy xx: Device ID or IP address yy: enable, disable |
| Set | o | i | xx | ManagerIP | yy | Set output or input xx ManagerIP to yy xx: Device ID or IP address yy: KE Matrix Manager software IP address |
| Set | o | i | xx | ManagerPort | yy | Set output or input xx ManagerPort to yy xx: Device ID or IP address yy: KE Matrix Manager software port |
| Set | o | i | xx | Beeper | yy | Set output or input xx Beeper to yy xx: Device ID or IP address yy: enable, disable |
| Set | o | | xx | RxVM | yy | Set output xx RxVM to yy xx: Device ID or IP address yy: vm, vusb |
| Set | o | | xx | USBSecure | yy | Set output xx USBSecure to yy xx: Device ID or IP address yy: on, off |
| Set | | i | xx | PortOS | yy | Set input xx PortOS to yy xx: Device ID or IP address yy: win, mac, sun, other |

| Command | Output | Input | Number | Control | Value | Description |
|---------|--------|-------|--------|--------------|-------|---|
| Set | | i | xx | OSLanguage | yy | Set input xx OSLanguage to yy xx: Device ID or IP address yy: english, japanese, french, german, spanish, korean, chinese(traditional), english(uk), swedish, arabic, belgian, canadian-bilingual, french(canada), czech, danish, finnish, greek, hebrew, hungarian, international(iso), italian, latin american, dutch, norwegian, persian(farsi), polish, portuguese, russian, slovak, french (switzerland), german (switzerland), switzerland, reserved, turkish-q, reserved, serbo-croatian |
| Set | | i | xx | videoMCastEn | yy | Set input xx videoMCastEn to yy xx: Device ID or IP address yy: enable, disable |
| Set | | i | xx | audioMCastEn | yy | Set input xx audioMCastEn to yy xx: Device ID or IP address yy: enable, disable |
| Set | | i | xx | Edid | yy | Set input xx Edid to yy xx: Device ID or IP address yy: default, auto, manual, remix |
| Set | | i | xx | VideoType | yy | Set input xx VideoType to yy xx: Device ID or IP address yy: dvi-d, dvi-a |

| Command | Output | Input | Number | Control | Value | Description |
|---------|--------|-------|--------|----------------|-------|--|
| Set | | i | xx | ColorDepth | yy | Set input xx ColorDepth to yy xx: Device ID or IP address yy: 8, 16, 24, and 36 (only for KE89 Series) |
| Set | | i | xx | BandwidthLimit | yy | Set input xx BandwidthLimit to yy xx: Device ID or IP address yy: unlimited, 100, 200, 500 |
| Set | | i | xx | VideoQty | yy | Set input xx VideoQty to yy xx: Device ID or IP address yy: 1, 2, 3, 4, 5 |
| Set | | i | xx | BGRefresh | yy | Set input xx BGRefresh to yy xx: Device ID or IP address yy: off, 16, 32, 64, 128, 256 |
| Set | | i | xx | OccupyTimeout | yy | Set input xx OccupyTimeout to yy xx: Device ID or IP address yy: 1~240 |

| Command | Output | Input | Number | Control | Value | Description |
|---------|--------|-------|--------|------------|-------|--|
| Set | | i | xx | Resolution | yy | Set input xx Resolution to yy xx: Device ID or IP address yy: 1920x1200, 1920x1080, 1680x1050, 1600x1200, 1600x900, 1440x900, 1400x1050, 1366x768, 1280x1024, 1280x960, 1280x720, 1152x864, 1024x768, 800x600, 720x400, 640x480, 2560x1080*, 3840x2160*, 1920x1440*, 2560x1600*, 2560x1440*, 2048x1536* *Only for KE89 Series |

Safety Instructions

General

- ◆ This product is for indoor use only.
- ◆ Read all of these instructions. Save them for future reference.
- ◆ Follow all warnings and instructions marked on the device.
- ◆ Do not place the device on any unstable surface (cart, stand, table, etc.). If the device falls, serious damage will result.
- ◆ Do not use the device near water.
- ◆ Do not place the device near, or over, radiators or heat registers.
- ◆ The device cabinet is provided with slots and openings to allow for adequate ventilation. To ensure reliable operation, and to protect against overheating, these openings must never be blocked or covered.
- ◆ The device should never be placed on a soft surface (bed, sofa, rug, etc.) as this will block its ventilation openings. Likewise, the device should not be placed in a built in enclosure unless adequate ventilation has been provided.
- ◆ Never spill liquid of any kind on the device.
- ◆ Avoid circuit overloads. Before connecting equipment to a circuit, know the power supply's limit and never exceed it. Always review the electrical specifications of a circuit to ensure that you are not creating a dangerous condition or that one doesn't already exist. Circuit overloads can cause a fire and destroy equipment.
- ◆ Unplug the device from the wall outlet before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- ◆ The device should be operated from the type of power source indicated on the marking label. If you are not sure of the type of power available, consult your dealer or local power company.
- ◆ To prevent damage to your installation it is important that all devices are properly grounded.
- ◆ Do not allow anything to rest on the power cord or cables. Route the power cord and cables so that they cannot be stepped on or tripped over.
- ◆ Position system cables and power cables carefully; Be sure that nothing rests on any cables.

- ◆ Never push objects of any kind into or through cabinet slots. They may touch dangerous voltage points or short out parts resulting in a risk of fire or electrical shock.
- ◆ Do not attempt to service the device yourself. Refer all servicing to qualified service personnel.
- ◆ If the following conditions occur, unplug the device from the wall outlet and bring it to qualified service personnel for repair.
 - ◆ The power cord or plug has become damaged or frayed.
 - ◆ Liquid has been spilled into the device.
 - ◆ The device has been exposed to rain or water.
 - ◆ The device has been dropped, or the cabinet has been damaged.
 - ◆ The device exhibits a distinct change in performance, indicating a need for service.
 - ◆ The device does not operate normally when the operating instructions are followed.
- ◆ Only adjust those controls that are covered in the operating instructions. Improper adjustment of other controls may result in damage that will require extensive work by a qualified technician to repair.

Rack Mount

- ◆ Before working on the rack, make sure that the stabilizers are secured to the rack, extended to the floor, and that the full weight of the rack rests on the floor. Install front and side stabilizers on a single rack or front stabilizers for joined multiple racks before working on the rack.
- ◆ Always load the rack from the bottom up, and load the heaviest item in the rack first.
- ◆ Make sure that the rack is level and stable before extending a device from the rack.
- ◆ Use caution when pressing the device rail release latches and sliding a device into or out of a rack; the slide rails can pinch your fingers.
- ◆ After a device is inserted into the rack, carefully extend the rail into a locking position, and then slide the device into the rack.
- ◆ Do not overload the AC supply branch circuit that provides power to the rack. The total rack load should not exceed 80 percent of the branch circuit rating.
- ◆ Make sure that all equipment used on the rack – including power strips and other electrical connectors – is properly grounded.
- ◆ Ensure that proper airflow is provided to devices in the rack.
- ◆ Ensure that the operating ambient temperature of the rack environment does not exceed the maximum ambient temperature specified for the equipment by the manufacturer.
- ◆ Do not step on or stand on any device when servicing other devices in a rack.

Technical Support

International

- ◆ For online technical support – including troubleshooting, documentation, and software updates: **<http://support.aten.com>**
- ◆ For telephone support, see *Telephone Support*, page iii.

North America

| | | |
|--------------------------|--|---|
| Email Support | | support@aten-usa.com |
| Online Technical Support | Troubleshooting Documentation Software Updates | http://www.aten-usa.com/support |
| Telephone Support | | 1-888-999-ATEN ext 4988 1-949-428-1111 |

When you contact us, please have the following information ready beforehand:

- ◆ Product model number, serial number, and date of purchase.
- ◆ Your computer configuration, including operating system, revision level, expansion cards, and software.
- ◆ Any error messages displayed at the time the error occurred.
- ◆ The sequence of operations that led up to the error.
- ◆ Any other information you feel may be of help.

Specifications

KE6900T / KE6940T

| Function | | KE6900T | KE6940T | |
|-------------------|------------------|--------------------------|--|--|
| Connectors | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | | RS-232 | 1 x DB-9 Male (Black) | |
| | KVM Ports | KB / Mouse | USB Type B Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack (Green) | |
| | | Mic. | 1 x Mini Stereo Jack (Pink) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | RS-232 | 1 x DB-9 Female (Black) | |
| | Power | | 1 x DC Jack (Black) | |
| | LAN | | 1 x RJ-45 Female (Black) | |
| | Switches | Function | 1 x Slide switch (Black) (Auto, RS-232 Config, Local) | |
| | | Reset | 1 x Semi-recessed Pushbutton | |
| LEDs | LAN | 1 (Green / Orange) | | |
| | Power | 1 x Blue | | |
| | Local | 1 x Green | | |
| | Remote | 1 x Green | | |
| Emulation | Keyboard / Mouse | USB | | |
| Power Consumption | | DC 5 V, 7.34 W | DC 5 V, 8.91 W | |
| Video Resolution | | Up to 1920 x 1200 | | |
| Environment | Operating Temp. | 0 – 50 °C | | |
| | Storage Temp. | -20 – 60 °C | | |
| | Humidity | 0–95% RH, Non-condensing | | |

| Function | | KE6900T | KE6940T |
|---------------------|------------------------|-------------------------|---------|
| Physical Properties | Housing | Metal | |
| | Weight | 1.14 kg | 1.15 kg |
| | Dimensions (L x W x H) | 21.50 x 16.29 x 4.18 cm | |

KE6900R / KE6940R

| Function | | KE6900R | KE6940R | |
|---------------------|------------------------|-------------------|--|--------------------------|
| Connectors | USB Virtual Media | | 2 x USB Type A Female (White) | |
| | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x DVI-I Female (White) | 2 x DVI-I Female (White) |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | RS-232 | | 1 x DB-9 Male (Black) | |
| | Power | | 1 x DC Jack (Black) | |
| | LAN | | 1 x RJ-45 Female (Black) | |
| Switches | OSD | | 1 x Pushbutton | |
| | Video | | 1 x Pushbutton | |
| | Graphics | | 1 x Pushbutton | |
| | Function | | 1 x Slide Switch (Black) (Extension, RS-232 Config) | |
| | Reset | | 1 x Semi-recessed Pushbutton | |
| LEDs | LAN | | 1 (Green / Orange) | |
| | Power | | 1 x Blue | |
| | Local | | 1 x Green | |
| | Remote | | 1 x Green | |
| Emulation | Keyboard / Mouse | | USB | |
| Power Consumption | | DC 5 V, 6.9 W | DC 5 V, 9.53 W | |
| Video Resolution | | Up to 1920 x 1200 | | |
| Environment | Operating Temp. | | 0 – 50 °C | |
| | Storage Temp. | | -20 – 60 °C | |
| | Humidity | | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | | Metal | |
| | Weight | | 1.25 kg | 1.25 kg |
| | Dimensions (L x W x H) | | 22.75 x 17.16 x 5.48 cm | |

KE6900AT / KE6940AT

| Function | | KE6900AT | KE6940AT | |
|-------------------|------------------|--|---|--|
| Connectors | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | | RS-232 | 1 x DB-9 Male (Black) | |
| | KVM Ports | KB / Mouse | 1 x USB Type B Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack (Green) | |
| | | Mic. | 1 x Mini Stereo Jack (Pink) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | RS-232 | 1 x DB-9 Female (Black) | |
| | Power | | 2 x DC Jack (Black) | |
| | LAN | | 1 x RJ-45 Female (Black) 1 x SFP Slot | |
| | Switches | Function | 1 x Slide switch (Black) (Auto, RS-232 Config/Access Control, Local) | |
| | | Reset | 1 x Semi-recessed Pushbutton | |
| LEDs | LAN | 1 (10: Orange / 100: Orange & Green / 1000: Green) | | |
| | Power | 1 x Blue | | |
| | Local | 1 x Green | | |
| | Remote | 1 x Green | | |
| Emulation | Keyboard / Mouse | USB | | |
| Power Consumption | | DC 5 V, 7.95 W | DC 5 V, 12.2 W | |
| Video Resolution | | Up to 1920 x 1200 @ 60Hz | | |
| Environment | Operating Temp. | 0 – 50 °C | | |
| | Storage Temp. | -20 – 60 °C | | |
| | Humidity | 0–95% RH, Non-condensing | | |

| Function | | KE6900AT | KE6940AT |
|---------------------|---------------------------|---|-------------------|
| Physical Properties | Housing | Metal | |
| | Weight | 1.15 kg (2.53 lb) | 1.17 kg (2.58 lb) |
| | Dimensions (L x W x H) | 21.50 x 16.33 x 4.18 cm (8.46 x 6.43 x 1.65 in.) | |

KE6900AR / KE6940AR

| Function | | KE6900AR | KE6940AR | |
|---------------------|--|--|-------------------------------------|--------------------------|
| Connectors | USB Virtual Media | | 2 x USB Type A Female (White) | |
| | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x DVI-I Female (White) | 2 x DVI-I Female (White) |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | | RS-232 | 1 x DB-9 Male (Black) | |
| | Power | 2 x DC Jack (Black) | | |
| LAN | 1 x RJ-45 Female (Black) 1 x SFP Slot | | | |
| Switches | OSD | 1 x Pushbutton | | |
| | Video | 1 x Pushbutton | | |
| | Graphics | 1 x Pushbutton | | |
| | Function | 1 x Slide Switch (Black) (Extension, RS-232 Config) | | |
| | Reset | 1 x Semi-recessed Pushbutton | | |
| LEDs | LAN | 1 (10: Orange / 100: Orange & Green / 1000: Green) | | |
| | Power | 1 x Blue | | |
| | Local | 1 x Green | | |
| | Remote | 1 x Green | | |
| Emulation | Keyboard / Mouse | USB | | |
| Power Consumption | | DC 5 V, 6.35 W | DC 5 V, 8.51 W | |
| Video Resolution | | Up to 1920 x 1200 @ 60Hz | | |
| Environment | Operating Temp. | 0 – 50 °C | | |
| | Storage Temp. | -20 – 60 °C | | |
| | Humidity | 0–95% RH, Non-condensing | | |
| Physical Properties | Housing | Metal | | |
| | Weight | 1.30 kg (2.86 lb) | 1.31 kg (2.89 lb) | |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | | |

KE6900AiT / KE6940AiT

| Function | | KE6900AiT | KE6940AiT | |
|-------------------|------------------|--|---|--|
| Connectors | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | | RS-232 | 1 x DB-9 Male (Black) | |
| | KVM Ports | KB / Mouse | 1 x USB Type B Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack (Green) | |
| | | Mic. | 1 x Mini Stereo Jack (Pink) | |
| | | Video | 1 x DVI-I Female (White) 2 x DVI-I Female (White) | |
| | | RS-232 | 1 x DB-9 Female (Black) | |
| | Power | | 2 x DC Jack (Black) | |
| | LAN | | 1 x RJ-45 Female (Black) 1 x SFP Slot | |
| | Internet Port | | 1 x RJ-45 Female (Black) | |
| | Switches | Function | 1 x Slide switch (Black) (Auto, RS-232 Config/Access Control, Local) | |
| Reset | | 1 x Semi-recessed Pushbutton | | |
| LEDs | LAN | 1 (10: Orange / 100: Orange & Green / 1000: Green) | | |
| | Power | 1 x Blue | | |
| | Local | 1 x Green | | |
| | Remote | 1 x Green | | |
| Emulation | Keyboard / Mouse | USB | | |
| Power Consumption | | DC 12 V : 12 W : 60 BTU | DC 12 V : 18.36 W : 90 BTU | |
| Video Resolution | | Up to 1920 x 1200 @ 60Hz | | |
| Environment | Operating Temp. | 0 – 50 °C | | |
| | Storage Temp. | -20 – 60 °C | | |
| | Humidity | 0–95% RH, Non-condensing | | |

| Function | | KE6900AiT | KE6940AiT |
|---------------------|---------------------------|---|-------------------|
| Physical Properties | Housing | Metal | |
| | Weight | 1.16 kg (2.56 lb) | 1.18 kg (2.60 lb) |
| | Dimensions (L x W x H) | 21.50 x 16.33 x 4.18 cm (8.46 x 6.43 x 1.65 in.) | |

KE6900ST

| Function | | | KE6900ST |
|---------------------|------------------------|------------|------------------------------|
| Connectors | KVM Ports | KB / Mouse | USB Type B Female (White) |
| | | Video | 1 x DVI-D Male (White) |
| | RS-232 | | 1 x DB-9 Female (Black) |
| | Power | | 1 x DC Jack (Black) |
| | LAN | | 1 x RJ-45 Female (Black) |
| Switch | Reset | | 1 x Semi-recessed Pushbutton |
| LEDs | LAN | | 1 (Green / Orange) |
| | Power | | 1 x Blue |
| Emulation | Keyboard / Mouse | | USB |
| Power Consumption | | | 5 V / 7.3 W |
| Video Resolution | | | Up to 1920 x 1200 |
| Environment | Operating Temp. | | 0 – 50 °C |
| | Storage Temp. | | -20 – 60 °C |
| | Humidity | | 0–95% RH, Non-condensing |
| Physical Properties | Housing | | Metal |
| | Weight | | 0.43 kg |
| | Dimensions (L x W x H) | | 14.39 x 10.30 x 3.00 cm |

KE6910

| Function | | KE6910R | KE6910T |
|------------|-----------------------------------|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | 2 x USB Type A Female (White) |
| | | 1 x DVI-D Female (White) | 1 x DVI-D Female (White) |
| | | 1 x Mini Stereo Jack (Green) | 1 x Mini Stereo Jack (Green) |
| | | 1 x Mini Stereo Jack (Pink) | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | 1 x DB-9 Male (Black) |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DVI-D Female (White) |
| | | | 1 x Mini Stereo Jack (Green) |
| | | | 1 x Mini Stereo Jack (Pink) |
| Power | 2 x DC Jack (Black) | 2 x DC Jack (Black) | |
| LAN | 1 x RJ-45 (Black) 1 x SFP Slot | | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | N/A |
| | Graphics | 1 x Pushbutton | N/A |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |

| Function | | KE6910R | KE6910T |
|---------------------|------------------------|---------------------------|------------------------|
| Power Consumption | | DC 5 V, 9.02 W | DC 5 V, 10.02 W |
| Video Resolution | | Up to 2560 x 2048 @ 50 Hz | |
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.26 kg | 1.13 kg |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm | 21.5 x 16.33 x 4.18 cm |

KE6912

| Function | | KE6912R | KE6912T |
|------------|---|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | 2 x USB Type A Female (White) |
| | | 1 x DVI-D Female (White) | 1 x DVI-D Female (White) |
| | | 1 x Mini Stereo Jack (Green) | 1 x Mini Stereo Jack (Green) |
| | | 1 x Mini Stereo Jack (Pink) | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | 1 x DB-9 Male (Black) |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DVI-D Female (White) |
| | | | 1 x Mini Stereo Jack (Green) |
| | | | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | |
| Power | 1 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | 1 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | |
| LAN | 1 x RJ-45 (Black, PoE) 1 x SFP Slot | 1 x RJ-45 (Black, PoE) 1 x SFP Slot | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | N/A |
| | Graphics | 1 x Pushbutton | N/A |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |

| Function | | KE6912R | KE6912T |
|---------------------|------------------------|---------------------------|-------------------------|
| Power Consumption | | DC 48 V / 11.27 W (PoE) | DC 48 V / 12.53 W (PoE) |
| Video Resolution | | Up to 2560 x 2048 @ 50 Hz | |
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.28 kg | 1.17 kg |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm | 21.5 x 16.33 x 4.18 cm |

KE6920

| Function | | KE6920R | KE6920T |
|------------|-----------------------------------|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | 2 x USB Type A Female (White) |
| | | 1 x DVI-D Female (White) | 1 x DVI-D Female (White) |
| | | 1 x Mini Stereo Jack (Green) | 1 x Mini Stereo Jack (Green) |
| | | 1 x Mini Stereo Jack (Pink) | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | 1 x DB-9 Male (Black) |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DVI-D Female (White) |
| | | | 1 x Mini Stereo Jack (Green) |
| | | | 1 x Mini Stereo Jack (Pink) |
| | Power | 2 x DC Jack (Black) | 2 x DC Jack (Black) |
| LAN | 1 x RJ-45 (Black) 2 x SFP Slot | | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | N/A |
| | Graphics | 1 x Pushbutton | N/A |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |

| Function | | KE6920R | KE6920T |
|---------------------|------------------------|---|---|
| Power Consumption | | DC 5 V, 8.86 W | DC 5 V, 10.87 W |
| Video Resolution | | Up to 2560 x 2048 @ 50 Hz / 2560 x 1600 @ 60 Hz | |
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.27 kg (2.8 lb) | 1.15 kg (2.53 lb) |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | 21.50 x 16.33 x 4.18 cm (8.46 x 6.43 x 1.65 in.) |

KE6922

| Function | | KE6922R | KE6922T |
|------------|---|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | 2 x USB Type A Female (White) |
| | | 1 x DVI-D Female (White) | 1 x DVI-D Female (White) |
| | | 1 x Mini Stereo Jack (Green) | 1 x Mini Stereo Jack (Green) |
| | | 1 x Mini Stereo Jack (Pink) | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | 1 x DB-9 Male (Black) |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DVI-D Female (White) |
| | | | 1 x Mini Stereo Jack (Green) |
| | | | 1 x Mini Stereo Jack (Pink) |
| | | 1 x DB-9 Male (Black) | |
| Power | 2 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | 2 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | |
| LAN | 1 x RJ-45 (Black, PoE) 2 x SFP Slot | 1 x RJ-45 (Black, PoE) 2 x SFP Slot | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | N/A |
| | Graphics | 1 x Pushbutton | N/A |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |

| Function | | KE6922R | KE6922T |
|---------------------|------------------------|---|---|
| Power Consumption | | DC 48 V / 11.54 W | DC 48 V / 13.59 W |
| Video Resolution | | Up to 2560 x 2048 @ 50 Hz / 2560 x 1600 @ 60 Hz | |
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.30 kg (2.86 lb) | 1.18 kg (2.6 lb) |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | 21.50 x 16.33 x 4.18 cm (8.46 x 6.43 x 1.65 in.) |

KE8900S

| Function | | KE8900SR | KE8900ST |
|---------------------|------------------------|--|--------------------------------|
| Connectors | Virtual Media | 2 x USB Type A Female (Black) | N/A |
| | Console Ports | 2 x USB Type A Female (Black) | N/A |
| | | 1 x HDMI Female (Black) | |
| | | 1 x DB-9 Male (Black) | |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x HDMI Female (Black) |
| | | | 1 x DB-9 Male (Black) |
| Power | 1 x DC Jack (Black) | 1 x DC Jack (Black) | |
| | | 1 x 3-Pole Terminal Block Connector (Green) | |
| LAN | 1 x RJ-45 (Black) | | |
| Switches | Reset | 1 x Semi-recessed Pushbutton | |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| Emulation | Keyboard / Mouse | USB | |
| Power Consumption | | DC 5V, 4.35 W | DC 5V, 3.8 W DC 48V, 5.53 W |
| Video Resolution | | Up to 1920 x 1200 @ 60 Hz | |
| Environment | Operating Temp. | 0–50°C | |
| | Storage Temp. | -20–60°C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 0.64 kg | 0.65 kg |
| | Dimensions (L x W x H) | 18.20 x 11.75 x 2.87 cm | |

KE8950T / KE8952T

| Function | | | KE8950T | KE8952T | |
|---------------------|------------------------|-----------------------------------|---|-------------------------------|--|
| Connectors | Console Ports | Keyboard | 1 x USB Type A Female (White) | | |
| | | Video | 1 x HDMI Female (Silver) | | |
| | | Mouse | 1 x USB Type A Female (White) | | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | | |
| | | RS-232 | 1 x DB-9 Male (Black) | | |
| | KVM Ports | KB / Mouse | 1 x USB Type B Female (White) | | |
| | | Speaker | 1 x Mini Stereo Jack (Green) | | |
| | | Mic. | 1 x Mini Stereo Jack (Pink) | | |
| | | Video | 1 x HDMI Female (Silver) | | |
| | | RS-232 | 1 x DB-9 Female (Black) | | |
| | LAN | | 1 x RJ-45 Female (Black) | 1 x RJ-45 Female (Black; PoE) | |
| | LAN | | 1 x SFP Module Female (Black) | | |
| Power | | 1 x DC Jack (Black) | | | |
| Switches | Function | | 1 x Slide Switch (Black) (Auto, RS-232 Config, Local) | | |
| | Reset | | 1 x Semi-recessed Pushbutton | | |
| LEDs | LAN | | 1 (10: Orange / 100: Orange & Green / 1000: Green) | | |
| | Power | | 1 x Blue | | |
| | Local | | 1 x Green | | |
| | Remote | | 1 x Green | | |
| Emulation | Keyboard / Mouse | | USB | | |
| Power Consumption | | DC 5 V, 6.56 W | DC 48 V, 9.02 W (PoE) | | |
| Video Resolution | | Up to 3840 x 2160 @ 60 Hz (4:4:4) | | | |
| Environment | Operating Temp. | | 0 – 50 °C | | |
| | Storage Temp. | | -20 – 60 °C | | |
| | Humidity | | 0–95% RH, Non-condensing | | |
| Physical Properties | Housing | | Metal | | |
| | Weight | | 1.10 kg (2.42 lb) | 1.13 kg (2.49 lb) | |
| | Dimensions (L x W x H) | | 21.50 x 16.29 x 4.18 cm (8.46 x 6.41 x 1.65 in.) | | |

KE8950R / KE8952R

| Function | | KE8950R | KE8952R | |
|---------------------|------------------------|--|-------------------------------------|--|
| Connectors | USB Virtual Media | 2 x USB Type A Female (White) | | |
| | Console Ports | Keyboard | 1 x USB Type A Female (White) | |
| | | Video | 1 x HDMI Female (Silver) | |
| | | Mouse | 1 x USB Type A Female (White) | |
| | | Speaker | 1 x Mini Stereo Jack Female (Green) | |
| | | Mic. | 1 x Mini Stereo Jack Female (Pink) | |
| | RS-232 | 1 x DB-9 Male (Black) | | |
| | LAN | 1 x RJ-45 Female (Black) | 1 x RJ-45 Female (Black; PoE) | |
| | LAN | 1 x SFP Module Female (Black) | | |
| Power | 1 x DC Jack (Black) | | | |
| Switches | OSD | 1 x Pushbutton | | |
| | Video | 1 x Pushbutton | | |
| | Graphics | 1 x Pushbutton | | |
| | Function | 1 x Slide Switch (Black) (Extension, RS-232 Config) | | |
| | Reset | 1 x Semi-recessed Pushbutton | | |
| LEDs | LAN | 1 (10: Orange / 100: Orange & Green / 1000: Green) | | |
| | Power | 1 x Blue | | |
| | Local | 1 x Green | | |
| | Remote | 1 x Green | | |
| Emulation | Keyboard / Mouse | USB | | |
| Power Consumption | | DC 5 V, 5.65 W | DC 48 V, 7.06 W (PoE) | |
| Video Resolution | | Up to 3840 x 2160 @ 60 Hz (4:4:4) | | |
| Environment | Operating Temp. | 0 – 50 °C | | |
| | Storage Temp. | -20 – 60 °C | | |
| | Humidity | 0–95% RH, Non-condensing | | |
| Physical Properties | Housing | Metal | | |
| | Weight | 1.23 kg (2.71 lb) | 1.26 kg (2.78 lb) | |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | | |

KE9900ST

| Function | | KE9900ST |
|---------------------|---------------------------|---|
| Connectors | KVM Ports | 1 x USB Type B Female (White) |
| | | 1 x DisplayPort Female (Black) |
| | | 1 x DB-9 Male (Black) |
| | Power | 1 x DC Jack (Black) |
| | | 1 x 3-Pole Terminal Block Connector (Green) |
| LAN | 1 x RJ-45 (Black) | |
| Switches | Reset | 1 x Semi-recessed Pushbutton |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) |
| | Power | 1 x Blue |
| Emulation | Keyboard / Mouse | USB |
| Power Consumption | | DC 5 V, 4.75 W; DC 48 V, 6.97 W |
| Video Resolution | | Up to 1920 x 1200 @ 60 Hz |
| Environment | Operating Temp. | 0 – 50 °C |
| | Storage Temp. | -20 – 60 °C |
| | Humidity | 0–95% RH, Non-condensing |
| Physical Properties | Housing | Metal |
| | Weight | 0.65 kg (1.43 lb) |
| | Dimensions (L x W x H) | 18.20 x 11.75 x 2.87 cm (7.17 x 4.63 x 1.13 in.) |

KE9950

| Function | | KE9950R | KE9950T |
|-----------------------|-----------------------------------|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | |
| | | 1 x DisplayPort Female (Black) | |
| | | 1 x Mini Stereo Jack (Green) | |
| | | 1 x Mini Stereo Jack (Pink) | |
| | | 1 x DB-9 Male (Black) | |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DisplayPort Female (Black) |
| | | | 1 x Mini Stereo Jack (Green) |
| | | | 1 x Mini Stereo Jack (Pink) |
| 1 x DB-9 Male (Black) | | | |
| Power | 2 x DC Jack (Black) | | |
| LAN | 1 x RJ-45 (Black) 1 x SFP Slot | | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | N/A |
| | Graphics | 1 x Pushbutton | N/A |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |
| Power Consumption | | DC 5 V, 8.03 W | DC 5 V, 9.51 W |
| Video Resolution | | Up to 3840 x 2160 @ 30 Hz | |

| Function | | KE9950R | KE9950T |
|---------------------|------------------------|---|---|
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.24 kg (2.73 lb) | 1.12 kg (2.47 lb) |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | 21.50 x 16.29 x 4.18 cm (8.46 x 6.41 x 1.65 in.) |

KE9952

| Function | | KE9952R | KE9952T |
|------------------------------|---|--|---|
| Connectors | Virtual Media | 2 x USB Type A Female (White) | N/A |
| | Console Ports | 2 x USB Type A Female (White) | |
| | | 1 x DisplayPort Female (Black) | |
| | | 1 x Mini Stereo Jack (Green) | |
| | | 1 x Mini Stereo Jack (Pink) | |
| | | 1 x DB-9 Male (Black) | |
| | KVM Ports | N/A | 1 x USB Type B Female (White) |
| | | | 1 x DisplayPort Female (Black) |
| 1 x Mini Stereo Jack (Green) | | | |
| 1 x Mini Stereo Jack (Pink) | | | |
| 1 x DB-9 Male (Black) | | | |
| Power | 1 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | 1 x DC Jack (Black) 1 x RJ-45 (Black, PoE) | |
| LAN | 1 x RJ-45 (Black, PoE) 1 x SFP Slot | 1 x RJ-45 (Black, PoE) 1 x SFP Slot | |
| Switches | OSD | 1 x Pushbutton | N/A |
| | Video | 1 x Pushbutton | |
| | Graphics | 1 x Pushbutton | |
| | Reset | 1 x Semi-recessed Pushbutton | |
| | Mode Selection | 1 x Slide Switch (Extension, RS-232 Config) | 1 x Slide Switch (Auto, RS-232 Config/ Access Control, Local) |
| LEDs | 10/100/1000 Mbps | 1 (10: Orange / 100: Orange & Green / 1000: Green) | |
| | Power | 1 x Blue | |
| | Local | 1 x Green | |
| | Remote | 1 x Green | |
| Emulation | Keyboard / Mouse | USB | |
| Power Consumption | | DC 48 V / 10.04 W (PoE) | DC 48 V / 11.88 W (PoE) |

| Function | | KE9952R | KE9952T |
|---------------------|------------------------|---|---|
| Video Resolution | | Up to 3840 x 2160 @ 30 Hz | |
| Environment | Operating Temp. | 0 – 50 °C | |
| | Storage Temp. | -20 – 60 °C | |
| | Humidity | 0–95% RH, Non-condensing | |
| Physical Properties | Housing | Metal | |
| | Weight | 1.27 kg (2.8 lb) | 1.15 kg (2.53 lb) |
| | Dimensions (L x W x H) | 22.75 x 17.16 x 5.48 cm (8.96 x 6.76 x 2.16 in.) | 21.50 x 16.29 x 4.18 cm (8.46 x 6.41 x 1.65 in.) |

Optional Rack Mount

Optional rack mount kits are available as shown in the following table:

| Mount Type | Model |
|---|-----------|
| Dual Rack Mount Kit* | 2X-021G |
| Single Rack Mount Kit* | 2X-031G |
| Video Extender Rack Mount Kit** (for KE6900ST, KE8900ST, KE8900SR and KE9900ST) | VE-RMK 1U |

*Supports KE6900/KE6900A/KE6910/KE6912/KE6920/KE6922/KE6940/KE6940A/KE8950/KE8952/KE9950/KE9952.

**Please refer to VE-RMK 1U user manual on how to mount these units.


Dual Rack Mount

The 2X-021G Dual Rack Mount Kit installs two KE6900/KE6900A/KE6910/KE6912/KE6920/KE6922/KE6940/KE6940A/KE8950/KE8952/KE9950/KE9952 units side by side in 1U of server rack space.


Transmitter Dual Rack Mount

KE8950T is the example used here.


1. Remove four screws from the units and then use the same screws to secure the units together with the link bracket provided with the kit.




2. Remove the bottom and side screws from each unit.



3. Use the screws in step 2 to install the left and right mounting brackets.




4. Screw the mounting brackets onto the rack.




Receiver Dual Rack Mount

KE8950R is the example used here.


1. Remove the eight screws and plastic guards from the receiver units.




2. Remove four screws from the units and then use the same screws to secure the units together with the link bracket provided with the kit.




3. Remove the bottom and side screws from each unit.



4. Use the screws in step 3 to install the left and right mounting brackets.




5. Screw the mounting brackets onto the rack.




Single Rack Mount

The 2X-031G Single Rack Mount kit installs one KE6900/KE6940/KE8950/KE8952 unit within a 1U rack space.


1. Remove the eight screws and plastic guards from the unit (receiver units only).




2. Remove the bottom and side screws from the unit.



- Use the screws in step 2 to install the right and left mounting brackets.




- Screw the mounting brackets onto the rack.



IP Installer

From a client computer running Windows, an IP address for a transmitter or receiver can be assigned with the IP Installer utility. The utility can be obtained from the Download area of our website or from the product page on the *Software & Driver* tab. After downloading the utility to your client computer, do the following:

1. Unzip the contents of IPInstaller.zip to a directory on your hard drive.
2. Go to the directory that you unzipped the IPInstaller program to and run IPInstaller.exe. A dialog box similar to the one below appears:



3. Select the Transmitter or Receiver in the Device List.

Note: 1. If the list is empty, or your device doesn't appear, click **Enumerate** to refresh the Device List.

2. If there is more than one device in the list, use the MAC address to pick the one you want. The MAC address is located on the devices bottom panel.

4. Select either *Obtain an IP address automatically (DHCP)*, or *Specify an IP address*. If you chose the latter, fill the IP Address, Subnet Mask, and Gateway fields with the information appropriate to your network.
5. Click **Set IP**.
6. After the IP address shows up in the Device List, click **Exit**.

Trusted Certificates

Overview

When you try to log in to the device from your browser, a Security Alert message appears to inform you that the device's certificate is not trusted, and asks if you want to proceed.



The certificate can be trusted, but the alert is triggered because the certificate's name is not found on the Microsoft list of Trusted Authorities. You can ignore the warning and click **Yes** to go on.

Self-Signed Private Certificates

If you wish to create your own self-signed encryption key and certificate, a free utility – `openssl.exe` – is available for download over the web at www.openssl.org. To create your private key and certificate do the following:

1. Go to the directory where you downloaded and extracted *openssl.exe* to.
2. Run `openssl.exe` with the following parameters:

```
openssl req -new -newkey rsa:1024 -days 3653 -nodes -x509
-keyout CA.key -out CA.cer -config openssl.cnf
```

-
- Note:**
1. The command should be entered all on one line (i.e., do not press [Enter] until all the parameters have been keyed in).
 2. If there are spaces in the input, surround the entry in quotes (e.g., “ATEN International”).
-

To avoid having to input information during key generation the following additional parameters can be used:

```
/C /ST /L /O /OU /CN /emailAddress .
```

Examples

```
openssl req -new -newkey rsa:1024 -days 3653 -nodes -x509
-keyout CA.key -out CA.cer -config openssl.cnf -subj
"/C=yourcountry/ST=yourstateorprovince/L=yourlocationor
city/O=yourorganization/OU=yourorganizationalunit/
CN=yourcommonname/emailAddress=name@yourcompany.com
```

```
openssl req -new -newkey rsa:1024 -days 3653 -nodes -x509
-keyout CA.key -out CA.cer -config openssl.cnf -subj
"/C=CA/ST=BC/L=Richmond/O=ATEN International/OU=ATEN
/CN=ATEN/emailAddress=eservice@aten.com.tw
```


Importing the Files

After the `openssl.exe` program completes, two files – `CA.key` (the private key) and `CA.cer` (the self-signed SSL certificate) – are created in the directory that you ran the program from.

Reset All Information

To reset all information (including passwords) to their default settings, follow the steps below:

1. Power off the unit and remove its housing.
2. Use a jumper cap to short the mainboard pins labeled **DEFAULT PASSWORD**. An example is shown:




3. Power on the unit.
4. After the unit is turned on, power off the unit.
5. Remove the jumper cap from the **Reset** pins and close the housing.
6. Power on the unit again.

After powering on the unit, you can use the default administrator Username and Password (see *Logging In*, page 179) to log in.


Default Password Pins

The **Default Password** pins for different models are shown below.


■ KE6900ST






■ KE6900AR




■ KE6900AT




■ KE6900AiT**■ KE6940AR****■ KE6940AT**


■ KE6940AiT






■ KE6910R / KE6912R




■ KE6910T / KE6912T




■ KE6920R / KE6922R**■ KE6920T / KE6922T****■ KE8900SR**


■ KE8900ST






■ KE8950R / KE8952R



■ KE8950T / KE8952T




■ KE9900ST**■ KE9950R / KE9952R****■ KE9950T / KE9952T**

RS-232 Pin Assignments

Pin assignments for the Transmitter and Receiver's rear RS-232 port that is used for connecting to a serial terminal are given in the table, below:

| Pin | Assignment | |
|-----|------------|---------------------|
| 1 | N/A | None |
| 2 | RXD | Receive Data |
| 3 | TXD | Transmit Data |
| 4 | DTR | Data Terminal Ready |
| 5 | GND | Signal Ground |
| 6 | DSR | Data Set Ready |
| 7 | RTS | Request to Sent |
| 8 | CTS | Clear to Sent |
| 9 | N/A | None |




DB9 Male

Transmitter Front RS-232 Port

Pin assignments for the Transmitter's front RS-232 port that is used for connecting to a computer for serial control are given in the table, below:

| Pin | Assignment | |
|-----|------------|---------------------|
| 1 | N/A | None |
| 2 | TXD | Transmit Data |
| 3 | RXD | Receive Data |
| 4 | DSR | Data Set Ready |
| 5 | GND | Signal Ground |
| 6 | DTR | Data Terminal Ready |
| 7 | CTS | Clear to Sent |
| 8 | RTS | Request to Sent |
| 9 | N/A | None |



DB9 Female

Multicast IP Address

Multicasting helps to broadcast audio and video data from a transmitter to multiple Receivers over a network. To setup up Multicasting on a network switch you must know the Audio and Video Multicast IP address which can be found on the KE Transmitter. To determinate the default Multicast IP address set by the KE device use the instructions below. The Multicast IP addresses can be set manually using Telnet.

KE Multicast Rule

All Audio and Video Multicast IP addresses use the format: 230.X.Y.Z.

X.Y.Z relates to the Transmitter's IP address and **230** is always the first octet of a Multicast IP address. You use the Transmitter's IP address to find **X** and then use it to calculate the Audio and Video Multicast IP address.

Multicast IP Formula

To calculate the Audio and Video Multicast IP address, use the Transmitter's IP address to determine **X** and then use the appropriate table below to calculate the Multicast IP address for each data stream (audio/video).

Example:

Transmitter IP Address: 172.16.27.146; (172.X.Y.Z)

X =16

If X is between 0 ~ 127

| Transmitter IP | X | Video X + 128 | Audio X + 192 | Multicast Video IP Address | Multicast Audio IP Address |
|----------------------------|----|--|--|----------------------------------|----------------------------------|
| 172.16.27.146 (example) | 16 | $\underline{16} + 128 =$ 144 | $\underline{16} + 192 =$ 208 | 230.144.27.146 | 230.208.27.146 |
| | | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |

If X is between 128 ~ 192

| Transmitter IP | X - 128 = A | Video A + 128 | Audio A + 192 | Multicast Video IP Address | Multicast Audio IP Address |
|----------------------------|----------------|----------------|----------------|----------------------------|----------------------------|
| 172.168.27.14 (example) | 168 - 128 = 40 | 40 + 128 = 168 | 40 + 192 = 232 | 230.168.27.14 | 230.232.27.14 |
| | ___ - 128 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | ___ - 128 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | ___ - 128 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |

If X is 192 or higher

| Transmitter IP | X - 192 = A | Video A + 128 | Audio A + 192 | Multicast Video IP Address | Multicast Audio IP Address |
|----------------------------|---------------|---------------|---------------|----------------------------|----------------------------|
| 172.200.27.14 (example) | 200 - 192 = 8 | 8 + 128 = 136 | 8 + 192 = 200 | 230.136.27.14 | 230.200.27.14 |
| | ___ - 192 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | ___ - 192 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |
| | ___ - 192 = | ___ + 128 = | ___ + 192 = | 230.____.____.____ | 230.____.____.____ |

Keys to Network Performance

For optimum performance, KE Series devices requires high amounts of data to be transferred across a network; therefore we recommend the following strategies to setup KE Series devices. Using our suggestions will provide better performance and the highest video resolutions possible. Use each of the keys to ensure the best transmission of data and the highest throughput possible.

Build a Network Diagram

To build an effective KE installation, start by mapping out the layout. Create a diagram with the KE devices, computers and routers along with how they will be connected across the network. It also helps to write out how the devices will interact. Use this diagram as the frame work as you decide what devices to purchase and how to build the network effectively for the best data throughput.

Considerations:

- ◆ If possible, create a private network for the KE devices
- ◆ Use the same switch model throughout
- ◆ Use a flat cascaded layout
- ◆ Avoid a tree or pyramid structure
- ◆ Limit cascades to two levels
- ◆ Install network switches near each other
- ◆ Minimize the distance of connections
- ◆ Install KE Matrix Manager (CCKM) computer and KE devices on the same subnet
- ◆ Check the 3 Other Factors before installation

Other Factors

■ Choose the Right Cable

Always use Cat 5/6e Ethernet cable or higher installed by a professional between any two devices you are installing. We recommend using ATEN Brand Ethernet cable to ensure the quality. It's best when installing KE devices to use brand new Ethernet cabling for each part of the installation to ensure the reliability of the data being transmitted. This is a key to getting the best uninterrupted video resolution across the network.


■ **Determine the Distance**

Distance is an important factor when setting up networks, with a shorter distance and fewer hops through routers, data can be transmitted more efficiently. So whenever possible decrease the distance and direct network traffic effectively between subnets that communicate with each other to increase the data throughput.

■ **Ensure the Bandwidth**

Ensuring the bandwidth ahead of time will guarantee performance before installing KE devices on a network. This will eliminate the primary cause of problems related to video quality and transmission of data. If the speed is right at all ends of your network, then the only other causes are derived from device failure or limits caused by a router, switch or device setting.

Sample Network Diagram



Choose a High Performance Switch

A high performance network switch is the means of a successful KE setup. When choosing a network switch, first select the type:

Layer 2 or Layer 3 Switches

You'll need to determine whether you need a layer 2 or a layer 3 switch for your KE network. Layer 3 switches cost more than layer 2 switches because they are more complex and handle more network traffic. The best way to calculate which type of switch you need is to first determine if you will have a dedicated network for the KE devices or if the KE devices will be on a network that shares throughput with other network equipment such as computers, servers and printers. If they share the network with other devices its best to consider a layer 3 switch and use layer 2 switches exclusively for the KE device connections. For larger installations we recommend using Layer 3 switches. The major differences are:

Layer 3 Switch: IP addresses in packets are examined and intelligent forwarding decisions are made. On a larger network broken into subnets across long distances, a layer 3 switch becomes the best choice as they can improve network efficiency and provide better traffic flow. They are better at directing more traffic to different locations on a larger more complex network, and with layer two switches working below them.

Layer 2 Switch: Packets are examined and forwarded using only the MAC address. If you have a small central network, a layer 2 switch should do the job. If the network is exclusive and will only transmit the bandwidth of KE devices, layer 2 switches with the correct settings can get the job done effectively.

Considerations

Number of ports

Choose a switch that has enough ports to match the number of KE devices you will be installing. Switches typically come in 5, 8, 10, 16, 24, 28, 48, and 52-port configurations. If you are installing 13 KE transmitters and 13 KE receivers, you will need to purchase a switch with at least 28 ports.

Stackable verse Standalone

Stackable switches allow you to easily manage and configure ports spanning across multiple switches that the KE devices are connected through. This provides a centralized method to configure and troubleshoot the initial setup of

KE devices on a network which makes fine tuning the bandwidth, data throughput and video quality easier. Stackable switches can be configured to direct the KE transmissions between many units more specifically and effectively. Standalone switches provide the same configuration features as Stackable switches but they must be set individually.

Stackable switches provide an easy way to manage multiple switches, as one unit. For example, instead of configuring, managing, and troubleshooting 6 28-port switches individually, you can manage the six as if they are a single unit using Stackable Switches. The six switches (168 ports) function as a single switch and are managed from one web or GUI interface.

What Stackable Switches Can do:

1. Create a link aggregation group with one port in one unit of the stack and another port of that group in another switch in the stack.
2. Select a port on one switch in the stack and mirror the traffic to a switch port on another unit of the stack; thus copy the configuration to direct traffic more effectively between KE devices.
3. Apply custom ACL security settings to any port on any switch in the stack.
4. Stackable switches can be setup in a ring configuration, so that if a port or cable fails, the stack automatically routes around the failure, at microsecond speeds. Stackable Switches also allow you to add and remove stack “members” which are automatically updated and recognized as such.

Switch Specifications

The following specifications are recommended when choosing a layer 2 or layer 3 switch:

- ◆ 1000Mbps Gigabit Ethernet switches (1000Mbps or faster Ethernet ports)
- ◆ High bandwidth between switches, if possible using Fibre Channel
- ◆ Layer 3 switches that efficiently processes IGMP queries
- ◆ IGMP Snooping v2 or v3
- ◆ Flow Control Functions
- ◆ Throughput of: Full Duplex, 1Gbps up- and down- stream speeds per port
- ◆ Performance of their most onerous tasks (e.g. IGMP snooping) with multiple dedicated processors (ASICs)
- ◆ Use the same switch make and model throughout each subnet

- ◆ The maximum number of simultaneous ‘snoopable groups’ the switch can handle meets or exceeds the number of KE transmitters that will be used to create Channel groups

Configuring Switches and KE Devices

Configuring the switch correctly will pass data more efficiently, allowing a better stream across the network to each KE device. The following settings will help optimize your network traffic through a switch:

- ◆ Enable IGMP Snooping on L2 switches
- ◆ Enable IGMP Querier on the L3 switch
- ◆ Enable IGMP Fast-Leave on all switches where KE units are directly connected
- ◆ Enable Spanning Tree Protocol (STP) on all switches and enable Portfast exclusively on switch ports that have KE units connected
- ◆ Pick an appropriate forwarding mode on all switches. Use Cut-through if available, or Store and Forward (see *Recommended Network Switches* below)

KE transmitter Settings:

- ◆ Adjust the KE transmitter settings one at a time, in small intervals, and view the images as you do, so that you can adjust to the positive or negative results and achieve the best quality and bandwidth possible
- ◆ If the quality of color is important, set the Color Depth to 24 bits (KE69 Series) or 36 bits (KE89 Series) and manually adjust other settings until you are satisfied with the visual appearance
- ◆ If moving video images are shown frequently, increase the Video Quality setting to the highest level and reduce the Bandwidth Limit and Color Depth setting.
- ◆ When images on the screen are more often static, increase the Background Refresh and/or the Video Quality settings
- ◆ Check that all KE units have been updated with the latest firmware version

Recommended Network Switches

Below are the network switches that have passed ATEN's stress tests using the KE Series extenders. Our tests streamed content over a network with a resolution of 1920 x 1200 @60Hz (KE69 Series, KE8900S, KE9900ST); 24 bit color depth and 3840 x 2160 @30Hz (KE8950 and KE8952); 36 bit color depth.

- ◆ Cisco Catalyst 2960X / Catalyst 2960XR / Catalyst 3750
- ◆ HP Procurve 2920
- ◆ H3C S5120
- ◆ Huawei S5700
- ◆ DLink DGS-1510

Please refer to the FAQ link below on how to select network switches and network switch information collected by ATEN Customer Service Division, where the collected information includes customer's feedback from their actual experience in using and installing the product(s).

<https://eservice.aten.com/eServiceCx/Common/FAQ/view.do?id=6276>


Additional Mouse Synchronization Procedures

If the mouse synchronization procedures mentioned in the manual fail to resolve mouse pointer problems for particular computers, try the following:

Windows:


Note: In order for the local and remote mice to synchronize, you must use the generic mouse driver supplied with the MS operating system. If you have a third party driver installed - such as one supplied by the mouse manufacturer - you must remove it.

1. Windows 2000:
 - a) Open the Mouse Properties dialog box (Control Panel → Mouse → Mouse Properties)
 - b) Click the *Motion* tab
 - c) Bring the mouse speed to the middle position (6 units in from the left)
 - d) Set the mouse acceleration to *None*



2. Windows XP / Windows Server 2003 / Windows 7 / Windows 8 / Windows 10:
 - a) Open the Mouse Properties dialog box (Control Panel → Mouse)
(For Windows 10, click Start → Devices → Mouse → Additional mouse options)

- b) Click the *Pointer Options* tab
- c) Bring the mouse speed to the middle position (6 units in from the left)
- d) Disable *Enhance Pointer Precision*



3. Windows ME:
Set the mouse speed to the middle position; disable mouse acceleration (click **Advanced** to get the dialog box for this).
4. Windows NT / Windows 98 / Windows 95:
Set the mouse speed to the slowest position.

Sun / Linux

Open a terminal session and issue the following command:

```
Sun: xset m 1
```

```
Linux: xset m 0
```

```
or
```

```
xset m 1
```

(If one does not help, try the other.)

Virtual Media Support

WinClient ActiveX Viewer / WinClient AP

- ◆ IDE CDROM/DVD-ROM Drives – Read Only
- ◆ IDE Hard Drives – Read Only
- ◆ USB CDROM/DVD-ROM Drives – Read Only
- ◆ USB Hard Drives – Read/Write*
- ◆ USB Flash Drives – Read/Write*
- ◆ USB Floppy Drives – Read/Write

* These drives can be mounted either as Drives or Removable Disks (see *Virtual Media*, page 295). Mounting them as removable disks allow booting the remote server if the disk contains a bootable OS. In addition, if the disk contains more than one partition, the remote server can access all the partitions.

- ◆ ISO Files – Read Only
- ◆ Folders – Read/Write
- ◆ Smart Card Readers

Java Applet Viewer / Java Client AP

- ◆ ISO Files – Read Only
- ◆ Folders – Read/Write

Note: 1. The Java Client supports Virtual Media in the same way as WinClient does – however, the account should have Administrator level privilege.

2. Folder mapping uses a FAT16 file system, so there is a 2G limitation. Virtual Media only supports ISO files less than 4G.
-

Setup CCKM Server IP address on Windows

1. Select **Network and Sharing Center** and click **Change adapter settings**.
2. Right-click **Local Area Connection** and select **Properties**.
3. In the Local Area Connection Properties window, highlight **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.
4. Select **Use the following IP address** and enter in the IP for the CCKM server (e.g. any IP address not in use, and in between 192.168.0.2 and 192.168.0.253)*, Subnet Mask (e.g. 255.255.255.0), and Default Gateway that corresponds with your network setup.
5. Click **OK** to change the CCKM server's IP address.

Note: Make sure the CCKM server's IP address is not a duplicate to prevent IP address conflict.

To connect to the CCKM server via web browser, enter the CCKM IP address and port number (default: 8443). For example, if the CCKM IP address is 192.168.0.10, then enter <https://192.168.0.10:8443>.

If you have a 2nd NIC, please follow the following steps.

6. Select **Network and Sharing Center** and click **Change adapter settings**.
7. Right-click **Local Area Connection** for the 2nd NIC and select **Properties**.
8. In the Local Area Connection Properties window, highlight **Internet Protocol Version 4 (TCP/IPv4)** then click **Properties**.
9. Select **Use the following IP address** and enter in the IP of the 2nd subnet for the CCKM server (e.g. any IP address not in use, and in between 192.168.1.2 and 192.168.1.253)*, Subnet Mask (e.g. 255.255.255.0), and Default Gateway that corresponds with your network setup.
10. Click **OK** to change the CCKM server's IP address of the 2nd subnet.

Limited Warranty

ATEN warrants its hardware in the country of purchase against flaws in materials and workmanship for a Warranty Period of two [2] years (warranty period may vary in certain regions/countries) commencing on the date of original purchase. This warranty period includes the [LCD panel of ATEN LCD KVM switches](#). Select products are warranted for an additional year (see [A+ Warranty](#) for further details). Cables and accessories are not covered by the Standard Warranty.

What is covered by the Limited Hardware Warranty

ATEN will provide a repair service, without charge, during the Warranty Period. If a product is defective, ATEN will, at its discretion, have the option to (1) repair said product with new or repaired components, or (2) replace the entire product with an identical product or with a similar product which fulfills the same function as the defective product. Replaced products assume the warranty of the original product for the remaining period or a period of 90 days, whichever is longer. When the products or components are replaced, the replacing articles shall become customer property and the replaced articles shall become the property of ATEN.

To learn more about our warranty policies, please visit our website:

<http://www.aten.com/global/en/legal/policies/warranty-policy/>

© Copyright 2021 ATEN® International Co., Ltd.
Released: 2021-09-09

ATEN and the ATEN logo are registered trademarks of ATEN International Co., Ltd. All rights reserved. All other brand names and trademarks are the registered property of their respective owners.