

Dell G3 3590

Service Manual



Identifier	GUID-5B8DE7B7-879F-45A4-88E0-732155904029
Status	Released

Notes, cautions, and warnings

 | **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 | **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 | **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Identifier	GUID-089FFA4B-3A62-4B51-BDE1-309C58A451D9
Status	Released

© 2019 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

1 Safety instructions	6
Before working inside your computer	6
Before you begin	6
Electrostatic discharge—ESD protection	7
ESD field service kit	7
Components of an ESD field service kit	7
ESD protection summary	8
Transporting sensitive components	8
Lifting equipment	8
After working inside your computer	9
2 Removing and installing components	10
Recommended tools	10
Screw list	10
Base cover	11
Removing the base cover	11
Installing the base cover	13
Battery	14
Lithium-ion battery precautions	14
Removing the battery	14
Installing the battery	15
Memory modules	16
Removing the memory module	16
Installing the memory module	17
Coin-cell battery	18
Removing the coin-cell battery	18
Installing the coin-cell battery	19
Solid-state drive/Intel Optane memory module	20
Removing the solid-state drive/Intel Optane memory module	20
Installing the solid-state drive/Intel Optane memory module	22
Hard drive	23
Removing the hard drive	24
Installing the hard drive	26
Heat sink	28
Removing the heat sink	28
Installing the heat sink	29
Fans	30
Removing the left fan	31
Removing the right fan	31
Installing the left fan	32
Installing the right fan	33
Speakers	34
Removing the speakers	34

Installing the speakers.....	35
WLAN card.....	36
Removing the WLAN card.....	36
Installing the WLAN card.....	37
Power-adapter port.....	38
Removing the power-adapter port.....	39
Installing the power-adapter port.....	39
I/O board.....	40
Removing the I/O board.....	40
Installing the I/O board.....	41
Display assembly.....	42
Removing the display assembly.....	43
Installing the display assembly.....	44
System board.....	46
Removing the system board.....	46
Installing the system board.....	48
Touchpad.....	50
Removing the touchpad.....	50
Installing the touchpad.....	51
Palm-rest and keyboard assembly.....	52
Removing the palm-rest and keyboard assembly.....	52
Installing the palm-rest and keyboard assembly.....	53
3 Device drivers.....	55
Intel Chipset Software Installation Utility.....	55
Video drivers.....	55
Intel Serial IO driver.....	55
Intel Trusted Execution Engine Interface.....	55
Intel Virtual Button driver.....	56
Wireless and Bluetooth drivers.....	56
4 System setup.....	57
System setup.....	57
Entering BIOS setup program.....	57
Navigation keys.....	57
Boot Sequence.....	58
System setup options.....	58
Clearing CMOS settings.....	66
Clearing BIOS (System Setup) and System passwords.....	67
5 Troubleshooting.....	68
Enhanced Pre-Boot System Assessment (ePSA) diagnostics.....	68
Running the ePSA diagnostics.....	68
System diagnostic lights.....	69
Enabling Intel Optane memory.....	70
Disabling Intel Optane memory.....	70
Flashing BIOS (USB key).....	70

Flashing the BIOS.....	71
Flea power release.....	71
Wi-Fi power cycle.....	72
Using Game Shift.....	72
Enabling Game Shift.....	72
Disabling Game Shift.....	72
Installing Game Shift after reinstalling the operating system.....	73
Keyboard shortcuts.....	73
6 Getting help and contacting Dell.....	76
Self-help resources.....	76
Contacting Dell.....	76

Identifier	GUID-71128823-CE64-4E17-9439-D
Status	Released

Safety instructions

Use the following safety guidelines to protect your computer from potential damage and ensure your personal safety.

- ⚠ WARNING:** Before working inside your computer, read the safety information that shipped with your computer. For more safety best practices, see the Regulatory Compliance home page at www.dell.com/regulatory_compliance.
- ⚠ WARNING:** Disconnect all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting to the electrical outlet.
- ⚠ CAUTION:** To avoid damaging the computer, ensure that the work surface is flat and clean.
- ⚠ CAUTION:** To avoid damaging the components and cards, handle them by their edges, and avoid touching pins and contacts.
- ⚠ CAUTION:** You should only perform troubleshooting and repairs as authorized or directed by the Dell technical assistance team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that shipped with the product or at www.dell.com/regulatory_compliance.
- ⚠ CAUTION:** Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity, which could harm internal components.
- ⚠ CAUTION:** When you disconnect a cable, pull on its connector or on its pull tab, not on the cable itself. Some cables have connectors with locking tabs or thumb-screws that you must disengage before disconnecting the cable. When disconnecting cables, keep them evenly aligned to avoid bending any connector pins. When connecting cables, ensure that the ports and connectors are correctly oriented and aligned.
- ⚠ CAUTION:** Press and eject any installed card from the media-card reader.

Identifier	GUID-5D3B1051-9384-409A-8D5B-9B53BD496DE8
Status	Released

Before working inside your computer

- ⓘ NOTE:** The images in this document may differ from your computer depending on the configuration you ordered.

Identifier	GUID-B2521C24-A407-4ABB-8022-6D88B53F0B94
Status	Released

Before you begin

- 1 Save and close all open files and exit all open applications.
- 2 Shut down your computer. Click **Start** > **Power** > **Shut down**.

- ⓘ NOTE:** If you are using a different operating system, see the documentation of your operating system for shut-down instructions.

- 3 Disconnect your computer and all attached devices from their electrical outlets.
- 4 Disconnect all attached network devices and peripherals, such as keyboard, mouse, and monitor from your computer.
- 5 Remove any media card and optical disc from your computer, if applicable.

Identifier	GUID-E1EAA29F-F785-45A4-A7F8-3E717B40D541
------------	-------------------------------------------

Status	Released
--------	----------

Electrostatic discharge—ESD protection

ESD is a major concern when you handle electronic components, especially sensitive components such as expansion cards, processors, memory DIMMs, and system boards. Very slight charges can damage circuits in ways that may not be obvious, such as intermittent problems or a shortened product life span. As the industry pushes for lower power requirements and increased density, ESD protection is an increasing concern.

Due to the increased density of semiconductors used in recent Dell products, the sensitivity to static damage is now higher than in previous Dell products. For this reason, some previously approved methods of handling parts are no longer applicable.

Two recognized types of ESD damage are catastrophic and intermittent failures.

- **Catastrophic** – Catastrophic failures represent approximately 20 percent of ESD-related failures. The damage causes an immediate and complete loss of device functionality. An example of catastrophic failure is a memory DIMM that has received a static shock and immediately generates a "No POST/No Video" symptom with a beep code emitted for missing or nonfunctional memory.
- **Intermittent** – Intermittent failures represent approximately 80 percent of ESD-related failures. The high rate of intermittent failures means that most of the time when damage occurs, it is not immediately recognizable. The DIMM receives a static shock, but the tracing is merely weakened and does not immediately produce outward symptoms related to the damage. The weakened trace may take weeks or months to melt, and in the meantime may cause degradation of memory integrity, intermittent memory errors, etc.

The more difficult type of damage to recognize and troubleshoot is the intermittent (also called latent or "walking wounded") failure.

Perform the following steps to prevent ESD damage:

- Use a wired ESD wrist strap that is properly grounded. The use of wireless anti-static straps is no longer allowed; they do not provide adequate protection. Touching the chassis before handling parts does not ensure adequate ESD protection on parts with increased sensitivity to ESD damage.
- Handle all static-sensitive components in a static-safe area. If possible, use anti-static floor pads and workbench pads.
- When unpacking a static-sensitive component from its shipping carton, do not remove the component from the anti-static packing material until you are ready to install the component. Before unwrapping the anti-static packaging, ensure that you discharge static electricity from your body.
- Before transporting a static-sensitive component, place it in an anti-static container or packaging.

Identifier	GUID-A48EDCBD-2D76-4460-B709-223F43658255
------------	-------------------------------------------

Status	Released
--------	----------

ESD field service kit

The unmonitored Field Service kit is the most commonly used service kit. Each Field Service kit includes three main components: anti-static mat, wrist strap, and bonding wire.

Components of an ESD field service kit

The components of an ESD field service kit are:

- **Anti-Static Mat** – The anti-static mat is dissipative and parts can be placed on it during service procedures. When using an anti-static mat, your wrist strap should be snug and the bonding wire should be connected to the mat and to any bare metal on the system being worked on. Once deployed properly, service parts can be removed from the ESD bag and placed directly on the mat. ESD-sensitive items are safe in your hand, on the ESD mat, in the system, or inside a bag.
- **Wrist Strap and Bonding Wire** – The wrist strap and bonding wire can be either directly connected between your wrist and bare metal on the hardware if the ESD mat is not required, or connected to the anti-static mat to protect hardware that is temporarily placed on

the mat. The physical connection of the wrist strap and bonding wire between your skin, the ESD mat, and the hardware is known as bonding. Use only Field Service kits with a wrist strap, mat, and bonding wire. Never use wireless wrist straps. Always be aware that the internal wires of a wrist strap are prone to damage from normal wear and tear, and must be checked regularly with a wrist strap tester in order to avoid accidental ESD hardware damage. It is recommended to test the wrist strap and bonding wire at least once per week.

- **ESD Wrist Strap Tester** – The wires inside of an ESD strap are prone to damage over time. When using an unmonitored kit, it is a best practice to regularly test the strap prior to each service call, and at a minimum, test once per week. A wrist strap tester is the best method for doing this test. If you do not have your own wrist strap tester, check with your regional office to find out if they have one. To perform the test, plug the wrist-strap's bonding-wire into the tester while it is strapped to your wrist and push the button to test. A green LED is lit if the test is successful; a red LED is lit and an alarm sounds if the test fails.
- **Insulator Elements** – It is critical to keep ESD sensitive devices, such as plastic heat sink casings, away from internal parts that are insulators and often highly charged.
- **Working Environment** – Before deploying the ESD Field Service kit, assess the situation at the customer location. For example, deploying the kit for a server environment is different than for a desktop or portable environment. Servers are typically installed in a rack within a data center; desktops or portables are typically placed on office desks or cubicles. Always look for a large open flat work area that is free of clutter and large enough to deploy the ESD kit with additional space to accommodate the type of system that is being repaired. The workspace should also be free of insulators that can cause an ESD event. On the work area, insulators such as Styrofoam and other plastics should always be moved at least 12 inches or 30 centimeters away from sensitive parts before physically handling any hardware components.
- **ESD Packaging** – All ESD-sensitive devices must be shipped and received in static-safe packaging. Metal, static-shielded bags are preferred. However, you should always return the damaged part using the same ESD bag and packaging that the new part arrived in. The ESD bag should be folded over and taped shut and all the same foam packing material should be used in the original box that the new part arrived in. ESD-sensitive devices should be removed from packaging only at an ESD-protected work surface, and parts should never be placed on top of the ESD bag because only the inside of the bag is shielded. Always place parts in your hand, on the ESD mat, in the system, or inside an anti-static bag.
- **Transporting Sensitive Components** – When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

ESD protection summary

It is recommended that all field service technicians use the traditional wired ESD grounding wrist strap and protective anti-static mat at all times when servicing Dell products. In addition, it is critical that technicians keep sensitive parts separate from all insulator parts while performing service and that they use anti-static bags for transporting sensitive components.

Identifier	GUID-0332D293-B3CC-4042-8A0D-795B07BE277E
Status	Released

Transporting sensitive components

When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

Lifting equipment

Adhere to the following guidelines when lifting heavy weight equipment:

⚠ CAUTION: Do not lift greater than 50 pounds. Always obtain additional resources or use a mechanical lifting device.

- 1 Get a firm balanced footing. Keep your feet apart for a stable base, and point your toes out.
- 2 Tighten stomach muscles. Abdominal muscles support your spine when you lift, offsetting the force of the load.
- 3 Lift with your legs, not your back.
- 4 Keep the load close. The closer it is to your spine, the less force it exerts on your back.
- 5 Keep your back upright, whether lifting or setting down the load. Do not add the weight of your body to the load. Avoid twisting your body and back.
- 6 Follow the same techniques in reverse to set the load down.

Identifier	GUID-06588814-2678-4667-9FF9-C009F4BCE185
------------	-------------------------------------------

Status	Released
--------	----------

After working inside your computer

About this task

 **CAUTION:** Leaving stray or loose screws inside your computer may severely damage your computer.

Steps

- 1 Replace all screws and ensure that no stray screws remain inside your computer.
- 2 Connect any external devices, peripherals, or cables you removed before working on your computer.
- 3 Replace any media cards, discs, or any other parts that you removed before working on your computer.
- 4 Connect your computer and all attached devices to their electrical outlets.
- 5 Turn on your computer.

Identifier	GUID-7FBB11D7-9820-47BB-AFAA
Status	Released

Removing and installing components

Identifier	GUID-EA979CC8-84EC-4827-86C4-C80A8C31F4BF
Status	Released

Recommended tools

The procedures in this document may require the following tools:




- Philips screwdriver #1
- Flat-head screwdriver
- Plastic scribe














Identifier	GUID-CC648B28-FBF9-4A6F-BB11-4C6C2FA3D08A
Status	Released

Screw list

- ① **NOTE:** When removing screws from a component, it is recommended to note the screw type, the quantity of screws, and then place them in a screw storage box. This is to ensure that the correct number of screws and correct screw type is restored when the component is replaced.
- ① **NOTE:** Some computers have magnetic surfaces. Ensure that the screws are not left attached to such surface when replacing a component.
- ① **NOTE:** Screw color may vary with the configuration ordered.

Table 1. Screw list

Component	Secured to	Screw type	Quantity	Screw image
Base cover	Palm rest and keyboard assembly	M2x7	6	 <ul style="list-style-type: none"> ① NOTE: Screw color may vary depending on the configuration ordered.
Battery	Palm rest and keyboard assembly	M2x3	2	
Solid-state drive	Solid-state drive bracket	M2x3	1	

Component	Secured to	Screw type	Quantity	Screw image
Hard-drive assembly	Palm rest and keyboard assembly	M2x3	3	
Hard-drive bracket	Hard-drive assembly	M3x3	4	
Left fan	Palm rest and keyboard assembly	M2x3	2	
Right fan	Palm rest and keyboard assembly	M2x3	2	
Wireless-card bracket	System board	M2x3	1	
Touchpad bracket	Palm rest and keyboard assembly	M2L2 Big Head	7	
Power button with fingerprint reader (optional)	Palm rest and keyboard assembly	M2x3	2	
USB 3.1 Type-C port bracket	System board	M2x3	2	
Hinge brackets	Palm rest and keyboard assembly	M2.5x5	4	
Hinge brackets	Display panel	M2.5x2.5 Big Head	12	
Hinge brackets	Display panel	M2x2.5	2	
I/O board	Palm rest and keyboard assembly	M2x3	2	
System board	KB Support	M2L2 Big Head	2	

Identifier GUID-011AA877-0F90-479B-BF50-6CDFB72AD6D8

Status Released

Base cover

Identifier GUID-C6699B8D-6354-42F8-BF7D-B3B9A754F225

Status Released

Removing the base cover

Prerequisite

- 1 Follow the procedure in [Before working inside your computer](#).

About this task

The following image indicates the location of the base cover and provides a visual representation of the removal procedure.



6x
M2x7



Steps

- 1 Loosen the four captive screws on the base cover.
- 2 Remove the six screws (M2x7) that secure the base cover to the palm-rest and keyboard assembly.
- 3 Using a plastic scribe, moving in an anti-clockwise direction beginning from the top left corner, pry the base cover.
- 4 Lift the base cover off the palm-rest and keyboard assembly.

Identifier GUID-058BB0A4-5B2E-48AF-BAD8-351923AD90B5

Status Released


Installing the base cover

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the base cover and provides a visual representation of the installation procedure.



Steps

- 1 Place the base cover on the palm-rest and keyboard assembly, and snap the base cover into place.
- 2 Replace the six screws (M2x7) that secure the base cover to the palm-rest and keyboard assembly.
- 3 Tighten the four captive screws that secure the base cover to the palm-rest and keyboard assembly.

Next step

- 1 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-F65273B2-AF5E-4C69-B895-7CEF2148F79D
Status	Released

Battery

Identifier	GUID-22C7DCB3-8D29-41D7-8D51-D90ABC7C2D63
Status	Released

Lithium-ion battery precautions

⚠ CAUTION:

- Exercise caution when handling Lithium-ion batteries.
- Discharge the battery as much as possible before removing it from the system. This can be done by disconnecting the AC adapter from the system to allow the battery to drain.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any kind to pry on or against the battery.
- Ensure any screws during the servicing of this product are not lost or misplaced, to prevent accidental puncture or damage to the battery and other system components.
- If a battery gets stuck in a device as a result of swelling, do not try to free it as puncturing, bending, or crushing a Lithium-ion battery can be dangerous. In such an instance, the entire system should be replaced. Contact <https://www.dell.com/support> for assistance and further instructions.
- Always purchase genuine batteries from <https://www.dell.com> or authorized Dell partners and resellers.

Identifier	GUID-EAB97C01-EE83-4790-8A4E-CFC47478A0C4
Status	Released



Removing the battery

Prerequisite

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).

About this task

The following image indicates the location of the battery and provides a visual representation of the removal procedure.



Steps

- 1 Disconnect the battery cable from the system board.
- 2 Remove the two screws (M2x3) that secure the battery to the palm-rest and keyboard assembly.
- 3 Lift the battery off the palm-rest and keyboard assembly.

Identifier GUID-63292BF2-6AA9-4B2C-9239-649FCF55BFDF

Status Released


Installing the battery

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the battery and provides a visual representation of the installation procedure.



Steps

- 1 Align the screw holes on the battery with the screw holes on the palm rest and keyboard assembly.
- 2 Replace the two screws (M2x3) that secure the battery to the palm-rest and keyboard assembly.
- 3 Connect the battery cable to the system board.

Next steps

- 1 Install the [base cover](#).
- 2 Follow the procedure in [After working inside your computer](#).

Identifier GUID-2A6DAE1B-1FBE-40F9-8D46-40E8C3FBD267

Status Released

Memory modules

Identifier GUID-D1F7FD84-7CAA-4775-A9B9-B9859B7196DE

Status Released



Removing the memory module

Prerequisite

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).

About this task

The following image indicates the location of the memory module and provides a visual representation of the removal procedure.



Steps

- 1 Turn the mylar to find the memory module.
- 2 Use your fingertips to carefully spread apart the securing-clips on each end of the memory-module slot until the memory module pops-up.
- 3 Remove the memory module from the memory-module slot.

Identifier	GUID-B40EB3A3-365A-4DD9-82C8-68B68AB90B07
Status	Released



Installing the memory module

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the memory module and provides a visual representation of the installation procedure.



Steps

- 1 Turn the mylar to find the memory-module slot.
- 2 Align the notch on the memory module with the tab on the memory-module slot.
- 3 Slide the memory module firmly into the slot at an angle.
- 4 Press the memory module down until it clicks into place.

NOTE: If you do not hear the click, remove the memory module and reinstall it.

Next steps

- 1 Install the [base cover](#).
- 2 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-D99D5F9B-0FF3-406B-A51F-FFA061BB89EA
Status	Released

Coin-cell battery

Identifier	GUID-9767CB19-E8EA-42DD-94FE-0EC35344A5E9
Status	Released

Removing the coin-cell battery

Prerequisite



- 1 Follow the procedure in [Before working inside your computer](#).

CAUTION: Removing the coin-cell battery resets the BIOS setup program's settings to default. It is recommended that you note the BIOS setup program's settings before removing the coin-cell battery.

- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the coin-cell battery and provides a visual representation of the removal procedure.



Steps

- 1 Using a plastic scribe, push the coin-cell battery from the right to release it.
- 2 Gently lift the coin-cell battery out from the system board.

Identifier	GUID-1A7CA395-295B-4956-9D1E-CEC6622607D3
Status	Released



Installing the coin-cell battery

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the coin-cell battery and provides a visual representation of the installation procedure.



Steps

- 1 With the positive-side facing up, align the coin-cell battery to the slot on the palm-rest and keyboard assembly.
- 2 Insert the coin-cell battery at an angle back into the slot on the palm-rest and keyboard assembly.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-1C622BA0-DC4F-4B77-8AD0-153BD9C5F567
Status	Released

Solid-state drive/Intel Optane memory module

Identifier	GUID-D7B9F8BA-CE58-4925-86EC-A91132BE39F0
Status	Released

Removing the solid-state drive/Intel Optane memory module

Prerequisites

If you are removing the Intel Optane memory module (optional) from your computer, disable the Intel Optane memory so that all cached system data are moved from the Intel Optane memory module to the SATA drive. For more information about disabling the Intel Optane memory, see [Disabling Intel Optane memory](#).






- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task


The following image indicates the location of the solid-state drive/Intel Optane memory module and provides a visual representation of the removal procedure.




1x
M2x3



M.2 2280



M.2 2230



Steps

- 1 Locate the solid-state drive/Intel Optane memory module on your computer.
- 2 Remove the screw (M2x3) that secures the solid-state drive/Intel Optane memory module to the system board.
- 3 Slide and lift the solid-state drive/Intel Optane memory module off the solid-state drive/Intel Optane memory module slot on the system board.

Identifier GUID-07E87825-A9FD-42DE-8914-3A7060D7C836

Status Released

Installing the solid-state drive/Intel Optane memory module



Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task



The following image indicates the location of the solid-state drive/Intel Optane memory module and provides a visual representation of the installation procedure.

If you are installing a solid-state drive/Intel Optane memory module that is a different form factor from the original (2280 to 2230), then first remove the solid-state drive screw-mount bracket and rotate it 180 degrees before inserting it in the other solid-state drive screw-mount bracket slot.





1x
M2x3



Steps

- 1 Align the notches on the solid-state drive/Intel Optane memory module with the solid-state drive/Intel Optane memory module slot on the system board.
- 2 Slide the solid-state drive/Intel Optane memory module into the solid-state drive/Intel Optane memory module slot on the system board.
- 3 Install the screw (M2x3) that secures the solid-state drive/Intel Optane memory module to the system board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier GUID-2CFF108D-02DC-40AF-BD5A-C4C22584A457

Status Released

Hard drive

Identifier	GUID-74F7EEC5-C9C5-4253-947E-0749989B6665
Status	Released

Removing the hard drive

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task



The following image indicates the location of the hard drive and provides a visual representation of the removal procedure.



3x
M2x3



4x
M3x3



Steps

- 1 Open the latch and disconnect the hard-drive cable from the system board.
- 2 Remove the three screws (M2x3) that secure the hard-drive assembly to the palm rest and keyboard assembly.
- 3 Lift the hard-drive assembly along with its cable off the palm rest and keyboard assembly.
- 4 Disconnect the interposer from the hard-drive assembly.
- 5 Remove the four screws (M3x3) that secure the hard-drive bracket to the hard drive.
- 6 Remove the hard drive from the hard-drive bracket.

Identifier	GUID-2949E4A7-8CDC-438B-A9DF-00A520DB167B
Status	Released



Installing the hard drive

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the hard drive and provides a visual representation of the installation procedure.



Steps

- 1 Align the screw holes on the hard-drive bracket with the screw holes on the hard drive.
- 2 Replace the four screws (M3x3) that secure the hard-drive bracket to the hard drive.
- 3 Connect the interposer to the hard-drive assembly.
- 4 Align the screw holes on the hard-drive assembly with the screw holes on the palm rest and keyboard assembly.
- 5 Replace the three screws (M2x3) that secure the hard-drive assembly to the palm rest and keyboard assembly.
- 6 Connect the hard-drive cable to the system board and close the latch to secure the cable.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-4DA6FA84-FF63-4D31-A148-125AAD9F4B2B
Status	Released

Heat sink


Identifier	GUID-B2C40BC8-544B-4F8E-9257-1958A7438D14
Status	Released

Removing the heat sink

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).




 **WARNING:** The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.

 **CAUTION:** For maximum cooling of the processor, do not touch the heat transfer areas on the heat sink. The oils in your skin can reduce the heat transfer capability of the thermal grease.

- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the heat sink and provides a visual representation of the removal procedure.



Steps

- 1 In the reverse sequential order (8>7>6>5>4>3>2>1), loosen the eight captive screws that secure the heat sink to the system board.
- 2 Peel the tape that secures the heat sink to the system board.
- 3 Lift the heat sink off the system board.

Identifier GUID-1D068D1E-AE28-46D4-A78E-FD694CD80609

Status Released

Installing the heat sink

Prerequisite




If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the heat sink and provides a visual representation of the installation procedure.

⚠ CAUTION: Incorrect alignment of the heat sink can damage the system board and processor.

NOTE: If either the system board or the heat sink is replaced, use the thermal pad/paste provided in the kit to ensure that thermal conductivity is achieved.



Steps

- 1 Place the heat sink on the system board and align the screw holes on the heat sink with the screw holes on the system board.
- 2 In sequential order (as indicated on the heat sink), tighten the eight captive screws that secure the heat sink to the system board.
- 3 Adhere the tape to the heat sink to secure it to the system board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-E3C0201A-5B16-4C16-BB92-B961F39AE9F4
Status	Released

Fans

Identifier GUID-44E0EF5F-8E7A-4D6B-A395-8F86F3BFF0EA

Status Released

Removing the left fan

Prerequisites




- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the left fan and provides a visual representation of the removal procedure.



2x
M2x3



Steps

- 1 Note the routing of the WLAN cable and remove the WLAN cable from the left fan.
- 2 Peel the tape that secures the left fan to the system board.
- 3 Remove the two (M2x3) screws that secure the left fan to the system board.
- 4 Lift the left fan off the palm-rest and keyboard assembly.

Identifier GUID-14FAC2E2-EFA1-4896-A1E6-BAD13D52B666

Status Released

Removing the right fan

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).



- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the right fan and provides a visual representation of the installation procedure.



2x
M2x3



Steps

- 1 Disconnect the right-fan cable from the system board.
- 2 Peel the tape that secures the right fan to the system board.
- 3 Remove the two (M2x3) screws that secure the right fan to the system board.
- 4 Lift the right fan off the palm-rest and keyboard assembly.

Identifier	GUID-15C9424A-CC0D-4018-86B2-5AB0174B24B7
Status	Released



Installing the left fan

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the left fan and provides a visual representation of the installation procedure.



Steps

- 1 Align and place the left fan on the palm-rest and keyboard assembly.
- 2 Route the WLAN cable through the routing guides on the fan.
- 3 Connect the left-fan cable to the system board.
- 4 Attach the tape to the left fan to secure it to the system board.
- 5 Replace the two (M2x3) screws to secure the left fan to the palm-rest and keyboard assembly.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-08F267F3-A85D-49A6-ABEE-D7F23B995C68
Status	Released

Installing the right fan

Prerequisite




If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the right fan and provides a visual representation of the installation procedure.



2x
M2x3



Steps

- 1 Align and place the right fan on the palm-rest and keyboard assembly.
- 2 Connect the right-fan cable to the system board.
- 3 Attach the tape to the right fan to secure it to the system board.
- 4 Replace the two (M2x3) screws to secure the right fan to the palm-rest and keyboard assembly.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-A6445DA5-405C-4BDA-A929-FE53DC4A83F6
Status	Released

Speakers

Identifier	GUID-6EC19481-56D5-44BB-B938-42C32B80A46A
Status	Released



Removing the speakers

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the speakers and provides a visual representation of the removal procedure.



Steps

- 1 Disconnect the speaker cable from the system board.
- 2 Note the routing of the speaker cable and remove the speaker cable from the routing guides on the palm-rest and keyboard assembly.
① | NOTE: Note the position of the rubber grommets before lifting the speakers.
- 3 Lift the speakers, along with the cable, off the palm-rest and keyboard assembly.

Identifier GUID-72DFF5D1-504F-4A9A-BDDE-73F58B1D0949

Status Released



Installing the speakers

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the speakers and provides a visual representation of the installation procedure.



Steps

- 1 Using the alignment posts and rubber grommets, place the speakers in the slots on the palm-rest and keyboard assembly

NOTE: If the rubber grommets are pushed out of the speakers when removing the speakers, push them back in place before replacing the speakers.

- 2 Route the speaker cable through the routing guides on the palm-rest and keyboard assembly.
- 3 Connect the speaker cable to the system board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-F6A4309E-A10E-4E7F-903C-3FFAE07278CD
------------	-------------------------------------------

Status	Released
--------	----------

WLAN card

Identifier	GUID-D2FFFCCA-CA48-41C2-BE4D-4318BE3C1DAC
------------	-------------------------------------------

Status	Released
--------	----------


Removing the WLAN card

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the WLAN card and provides a visual representation of the removal procedure.



Steps

- 1 Remove the screw (M2x3) that secures the WLAN card to the system board.
- 2 Remove the bracket that secures the WLAN card to the system board.
- 3 Disconnect the antenna cables from the WLAN card.
- 4 Slide and remove the WLAN card from the WLAN card slot.

Identifier	GUID-CC33136C-1B6C-439B-8202-1AAB1DF041DE
Status	Released

Installing the WLAN card

Prerequisite




If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the WLAN card and provides a visual representation of the installation procedure.



1x
M2x3



Steps

- 1 Connect the antenna cables to the WLAN card.

The following table provides the antenna-cable color scheme for the wireless card supported by your computer.

Table 2. Antenna-cable color scheme

Connectors on the wireless card	Antenna-cable color
Main (white triangle)	White
Auxiliary (black triangle)	Black

- 2 Align the notch on the WLAN card with the tab on the WLAN card slot and insert the WLAN card at an angle into the WLAN card slot.
- 3 Align and place the WLAN card bracket on the WLAN card.
- 4 Replace the screw (M2x3) to secure the WLAN card to the system board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-FCFD0001-7CDA-44E5-ACBB-F3DB60FC0CFF
Status	Released

Power-adapter port

Identifier GUID-251632D1-688A-4409-906D-6800BA81A6F7

Status Released

Removing the power-adapter port

Prerequisites



- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).

About this task

The following image indicates the location of the power-adapter port and provides a visual representation of the removal procedure.



2x
M2x3



Steps

- 1 Remove the two screws (M2x3) on the power-adapter port bracket that secure the power-adapter port to the system board.
- 2 Remove the power-adapter port bracket from the system board.
- 3 Peel the power-adapter port cable from the heat sink.
- 4 Disconnect the power-adapter port cable from the system board.
- 5 Lift the power-adapter port, along with its cable, off the palm-rest and keyboard assembly.

Identifier GUID-F8B0AB18-2F1D-433F-9ACD-3B5A34EADE6A

Status Released

Installing the power-adapter port

Prerequisite




If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the power-adaptor port and provides a visual representation of the installation procedure.



2x
M2x3



Steps

- 1 Place the power-adaptor port into the slot and adhere the power-adaptor port cable on the palm rest and keyboard assembly.
- 2 Connect the power-adaptor port cable to the system board.
- 3 Align and place the power-adaptor port bracket over the power-adaptor port.
- 4 Replace the two screws (M2x3) to secure the power-adaptor port bracket to the system board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-A4EB1B18-E790-4DC7-A6B0-85015144D8CE
Status	Released

I/O board

Identifier	GUID-59DA147E-C1D2-4060-8A28-765A287FF639
Status	Released

Removing the I/O board

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).


- 3 Remove the [battery](#).

About this task

The following image indicates the location of the I/O board and provides a visual representation of the removal procedure.



2x
M2x3



Steps

- 1 Lift the latch to disconnect the I/O-board cable from the I/O board.
- 2 Remove the two screws (M2x3) that secure the I/O board to the palm-rest and keyboard assembly.
- 3 Lift the I/O board off the palm-rest and keyboard assembly.

Identifier	GUID-A9CE11EA-716D-4685-BA5C-E0F6BD7B85A1
Status	Released

Installing the I/O board

Prerequisite



If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the I/O board and provides a visual representation of the installation procedure.



2x
M2x3



Steps

- 1 Align and place the I/O board on the palm-rest and keyboard assembly.
- 2 Install the two screws (M2x3) that secure the I/O board to the palm-rest and keyboard assembly.
- 3 Connect the I/O-board cable to the I/O board.

Next step

- 1 Install the [battery](#).
- 2 Install the [base cover](#).
- 3 Follow the procedure in [After working inside your computer](#).

Identifier GUID-E641BD48-9062-46FE-8F5A-723887A0921D

Status Released

Display assembly

Identifier GUID-93FD762A-AEE6-4771-ADFA-B59846B4BE9F

Status Released

Removing the display assembly

Prerequisites


- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).
- 4 Remove the [WLAN card](#).

About this task

The following image indicates the location of the display assembly and provides a visual representation of the removal procedure.



4x
M2.5x5



3



Steps

- 1 Place the computer on a flat surface near the edge with its display assembly perpendicular to the palm-rest and keyboard assembly.
- 2 Using the pull tab, disconnect the display cable from the system board.
- 3 Remove the four screws (M2.5x5) that secure the display hinges to the system board.
- 4 Lift the display assembly upwards to separate it from the palm-rest and keyboard assembly.

Identifier	GUID-B54075E8-1018-43E0-8F29-B8E2B972A5B6
Status	Released

Installing the display assembly

Prerequisite



If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the display assembly and provides a visual representation of the installation procedure.



4x
M2.5x5



Steps

- 1 Place the palm-rest and keyboard assembly on a flat surface near the edge.
- 2 Align and place the display assembly perpendicularly onto the palm-rest and keyboard assembly.
- 3 Install the four screws (M2.5x5) to secure the display hinges to the system board.
- 4 Connect the display cable on to the connector on the system board.
- 5 Close the display.

Next step

- 1 Install the [WLAN card](#).
- 2 Install the [battery](#).
- 3 Install the [base cover](#).
- 4 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-46B53388-5C4F-4861-92E0-6AE357EE9CBF
Status	Released

System board

Identifier	GUID-204C5111-9521-4463-8902-2C2D224FD498
Status	Released

Removing the system board

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).
- 4 Remove the [solid-state drive/Intel Optane memory module](#).
- 5 Remove the [WLAN card](#).
- 6 Remove the [left fan](#).
- 7 Remove the [right fan](#).
- 8 Remove the [heat sink](#).
- 9 Remove the [display assembly](#).
- 10 Remove the [power-adaptor port](#).

About this task




The following image indicates the location of the system board and provides a visual representation of the removal procedure.

NOTE:

The I/O board connector is located underneath the system board. Turn the system board over and disconnect the I/O board cable from the system board.



2x
M2x2



Steps

- 1 Open the latch and disconnect the hard drive cable from the system board.
- 2 Open the latch and disconnect the power-button cable from the system board.
- 3 Open the latch and disconnect the battery cable from the system board.
- 4 Open the latch and disconnect the keyboard cable from the system board.
- 5 Disconnect the speaker cable from the system board.
- 6 Remove the two (M2x2) screws that secure the system board to the palm-rest and keyboard assembly.
- 7 Turn the system board over and disconnect the I/O board cable from the system board.

Identifier GUID-BA27C213-B7F1-41F6-B836-E6C76C377150

Status Released

Installing the system board

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task



The following image indicates the location of the system board and provides a visual representation of the installation procedure.

NOTE:


The I/O board connector is located underneath the system board. Turn the system board over and connect the I/O board cable to the system board.



2x
M2x2



2



Steps

- 1 Connect the I/O board cable to the system board.
- 2 Turn the system board to the front and align and place the system board on the palm-rest and keyboard assembly.
- 3 Connect the speaker cable to the system board.
- 4 Open the latch and connect the keyboard cable to the system board.
- 5 Open the latch and connect the battery cable to the system board.
- 6 Open the latch and connect the power-button cable to the system board.
- 7 Open the latch and connect the hard drive cable to the system board.
- 8 Replace the two (M2x2) screws that secure the system board to the palm-rest and keyboard assembly.

Next step

- 1 Install the [power-adapter port](#).
- 2 Install the [display assembly](#).
- 3 Install the [heat sink](#).
- 4 Install the [left fan](#).
- 5 Install the [right fan](#).
- 6 Install the [WLAN card](#).
- 7 Install the [solid-state drive/Intel Optane memory module](#).
- 8 Install the [battery](#).
- 9 Install the [base cover](#).
- 10 Follow the procedure in [After working inside your computer](#).

Identifier GUID-775EE71A-A503-47AD-AC10-E85111BEF34A

Status Released

Touchpad

Identifier GUID-B12E7002-497F-4B17-AD1D-70B26876034B

Status Released

Removing the touchpad

Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).
- 4 Remove the [solid-state drive/Intel Optane memory module](#).
- 5 Remove the [WLAN card](#).
- 6 Remove the [left fan](#).
- 7 Remove the [right fan](#).
- 8 Remove the [heat sink](#).
- 9 Remove the [display assembly](#).
- 10 Remove the [power-adaptor port](#).
- 11 Remove the [system board](#)




 **NOTE:** The system board can be removed with the heat sink attached.

About this task

The following image indicates the location of the touchpad and provides a visual representation of the removal procedure.



7x
M2.x2



Steps

- 1 Remove the three (M2x2) screws that secure the touchpad bracket to the palm-rest and keyboard assembly.
- 2 Lift the touchpad bracket off the palm-rest and keyboard assembly.
- 3 Peel the tapes from the touchpad.
- 4 Remove the four (M2x2) screws that secure the touchpad to the palm-rest and keyboard assembly.
- 5 Lift the touchpad off the palm-rest and keyboard assembly.

Identifier

GUID-C4F99E84-A8F5-48D2-9937-13BAE339135C

Status

Released

Installing the touchpad

Prerequisite



If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

The following image indicates the location of the touchpad and provides a visual representation of the installation procedure.



7x
M2.x2



Steps

- 1 Align and place the touchpad into the slot on the palm-rest and keyboard assembly.
- 2 Replace the four (M2x2) screws and adhere the tapes that secure the touchpad to the palm-rest and keyboard assembly.
- 3 Align and place the touchpad bracket into the slot on the palm-rest and keyboard assembly.
- 4 Replace the three (M2x2) screws that secure the touchpad bracket to the palm-rest and keyboard assembly.

Next step

- 1 Install the [system board](#).
- 2 Install the [power-adapter port](#).
- 3 Install the [display assembly](#).

- 4 Install the [heat sink](#).
- 5 Install the [left fan](#).
- 6 Install the [right fan](#).
- 7 Install the [WLAN card](#).
- 8 Install the [solid-state drive/Intel Optane memory module](#).
- 9 Install the [battery](#).
- 10 Install the [base cover](#).
- 11 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-4AAEA62D-3F30-4E6E-ADEC-AD46B79B8EA6
Status	Released

Palm-rest and keyboard assembly

Identifier	GUID-31169B40-7319-4910-98EC-40F9D3DD0D09
Status	Released

Removing the palm-rest and keyboard assembly


Prerequisites

- 1 Follow the procedure in [Before working inside your computer](#).
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).
- 4 Remove the [memory modules](#).
- 5 Remove the [WLAN card](#).
- 6 Remove the [left fan](#).
- 7 Remove the [right fan](#).
- 8 Remove the [solid-state drive/Intel Optane memory module](#).
- 9 Remove the [hard drive](#).
- 10 Remove the [I/O board](#).
- 11 Remove the [touchpad](#).
- 12 Remove the [speakers](#).
- 13 Remove the [display assembly](#).
- 14 Remove the [power-adaptor port](#).
- 15 Remove the [system board](#).

 **NOTE:** The system board can be removed with the heat sink attached.

About this task

After performing the steps in the pre-requisites, we are left with the palm-rest and keyboard assembly.



Identifier	GUID-AB00DC65-3DED-482C-B335-DFD57932D3A8
Status	Released


Installing the palm-rest and keyboard assembly

Prerequisite

If you are replacing a component, remove the existing component before performing the installation procedure.

About this task

Place the palm-rest and keyboard assembly on a flat surface.



Next step

- 1 Install the [system board](#).
- 2 Install the [power-adapter port](#).
- 3 Install the [display assembly](#).
- 4 Install the [heat sink](#).
- 5 Install the [speakers](#).

- 6 Install the [touchpad](#).
- 7 Install the [I/O board](#).
- 8 Install the [hard drive](#).
- 9 Install the [solid-state drive/Intel Optane memory module](#).
- 10 Install the [right fan](#).
- 11 Install the [left fan](#).
- 12 Install the [WLAN card](#).
- 13 Install the [memory modules](#).
- 14 Install the [battery](#).
- 15 Install the [base cover](#).
- 16 Follow the procedure in [After working inside your computer](#).

Identifier	GUID-B7285CF1-FC18-4DE7-8A89-
Status	Released

Device drivers

Identifier	GUID-C959B142-CF42-4306-A9EA-A640C509AB98
Status	Released

Intel Chipset Software Installation Utility

In the Device Manager, check if the chipset driver is installed.

Install the Intel chipset updates from www.dell.com/support.

Identifier	GUID-925A39C4-0B26-40F8-9404-94B0BFCC4742
Status	Released

Video drivers

In the Device Manager, check if the video driver is installed.

Install the video driver update from www.dell.com/support.

Identifier	GUID-43531ABB-B77D-45B5-AFBA-B90BDF782CFC
Status	Released

Intel Serial IO driver

In the Device Manager, check if the Intel Serial IO driver is installed.

Install the driver updates from www.dell.com/support.

Identifier	GUID-B021278B-5FB5-429E-B0B5-BF580C34D140
Status	Released

Intel Trusted Execution Engine Interface

In the Device Manager, check if the Intel Trusted Execution Engine Interface driver is installed.

Install the driver update from www.dell.com/support.

Identifier	GUID-E13FC788-9CE7-4370-AFF0-51C6169ADAC3
Status	Released

Intel Virtual Button driver

In the Device Manager, check if the Intel Virtual Button driver is installed.

Install the driver updates from www.dell.com/support.

Identifier	GUID-543661C6-4009-4F1B-BB4F-6CF5FF28149D
Status	Released

Wireless and Bluetooth drivers

In the Device Manager, check if the network card driver is installed.

Install the driver updates from www.dell.com/support.

In the Device Manager, check if the Bluetooth driver is installed.

Install the driver updates from www.dell.com/support.

Identifier	GUID-4D6759B1-4017-4F54-87E6-9
Status	Released

System setup

NOTE: Depending on the computer and its installed devices, the items listed in this section may or may not be displayed.

Identifier	GUID-E8E05C46-BC9D-4CF1-AC84-34B87FDCCFB7
Status	Released

System setup

CAUTION: Unless you are an expert computer user, do not change the settings in the BIOS Setup program. Certain changes can make your computer work incorrectly.

NOTE: Before you change BIOS Setup program, it is recommended that you write down the BIOS Setup program screen information for future reference.

Use the BIOS Setup program for the following purposes:

- Get information about the hardware installed in your computer, such as the amount of RAM and the size of the hard drive.
- Change the system configuration information.
- Set or change a user-selectable option, such as the user password, type of hard drive installed, and enabling or disabling base devices.

Identifier	GUID-1432A924-49E9-4080-961D-2AFBDAF42039
Status	Released

Entering BIOS setup program

- 1 Turn on (or restart) your computer.
- 2 During POST, when the DELL logo is displayed, watch for the F2 prompt to appear, and then press F2 immediately.

NOTE: The F2 prompt indicates that the keyboard is initialized. This prompt can appear very quickly, so you must watch for it, and then press F2. If you press F2 before the F2 prompt, this keystroke is lost. If you wait too long and the operating system logo appears, continue to wait until you see the desktop. Then, turn off your computer and try again.

Identifier	GUID-7A7EB30A-4A48-422B-AE30-B8DC236A1790
Status	Released

Navigation keys

NOTE: For most of the System Setup options, changes that you make are recorded but do not take effect until you restart the system.

Keys	Navigation
Up arrow	Moves to the previous field.

Keys	Navigation
Down arrow	Moves to the next field.
Enter	Selects a value in the selected field (if applicable) or follow the link in the field.
Spacebar	Expands or collapses a drop-down list, if applicable.
Tab	Moves to the next focus area.
Esc	Moves to the previous page until you view the main screen. Pressing Esc in the main screen displays a message that prompts you to save any unsaved changes and restarts the system.

Identifier	GUID-C50BED7F-226B-4768-AB61-9725153DF132
Status	Released

Boot Sequence

Boot Sequence allows you to bypass the System Setup–defined boot device order and boot directly to a specific device (for example: optical drive or hard drive). During the Power-on Self Test (POST), when the Dell logo appears, you can:

- Access System Setup by pressing F2 key
- Bring up the one-time boot menu by pressing F12 key

The one-time boot menu displays the devices that you can boot from including the diagnostic option. The boot menu options are:

- Removable Drive (if available)
- STXXXX Drive

 **NOTE: XXX denotes the SATA drive number.**

- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics

 **NOTE: Choosing Diagnostics, will display the ePSA diagnostics screen.**

The boot sequence screen also displays the option to access the System Setup screen.

Identifier	GUID-BFFA76A3-0626-42E1-9867-8EBFC7BDA0DD
Status	Released

System setup options

 **NOTE: Depending on this computer and its installed devices, the items that are listed in this section may or may not be displayed.**

Table 3. System setup options—System information menu

Overview

BIOS Version	Displays the BIOS version number.
Service Tag	Displays the Service Tag of the computer.
Asset Tag	Displays the Asset Tag of the computer.
Ownership Tag	Displays the ownership tag of the computer.
Manufacture Date	Displays the manufacture date of the computer.

Overview

Ownership Date	Displays the ownership date of the computer.
Express Service Code	Displays the express service code of the computer.
Ownership Tag	Displays the ownership tag of the computer.
Signed Firmware Update	Displays whether the signed firmware update is enabled.
Battery	Displays the battery health information.
Primary	Displays the primary battery.
Battery Level	Displays the battery level.
Battery State	Displays the battery state.
Health	Displays the battery health.
AC Adapter	Displays whether an AC adapter is installed.
Processor Information	
Processor Type	Displays the processor type.
Maximum Clock Speed	Displays the maximum processor clock speed.
Core Count	Displays the number of cores on the processor.
Processor L2 Cache	Displays the processor L2 Cache size.
Processor ID	Displays the processor identification code.
Processor L3 Cache	Displays the processor L3 Cache size.
Current Clock Speed	Displays the current processor clock speed.
Minimum Clock Speed	Displays the minimum processor clock speed.
Microcode Version	Displays the microcode version.
Intel Hyper-Threading Capable	Displays whether the processor is Hyper-Threading (HT) capable.
64-Bit Technology	Displays whether 64-bit technology is used.
Memory Information	
Memory Installed	Displays the total computer memory installed.
Memory Available	Displays the total computer memory available.
Memory Speed	Displays the memory speed.
Memory Channel Mode	Displays single or dual channel mode.
Memory Technology	Displays the technology that is used for the memory.
Device Information	
Video Controller	Displays the integrate graphics information of the computer.
dGPU Video Controller	Displays the discrete graphics information of the computer.
Video BIOS Version	Displays the video BIOS version of the computer.
Video Memory	Displays the video memory information of the computer.
Panel Type	Displays the Panel Type of the computer.
Native Resolution	Displays the native resolution of the computer.
Audio Controller	Displays the audio controller information of the computer.
Wi-Fi Device	Displays the wireless device information of the computer.
Bluetooth Device	Displays the Bluetooth device information of the computer.

Table 4. System setup options—Boot options menu

Boot options

Advanced Boot Options

Enable UEFI Network Stack Enables or disables UEFI Network Stack.
Default: OFF.

Boot Mode

Boot Mode: UEFI only Displays the boot mode of this computer.

Enable Boot Devices Enables or disables boot devices for this computer.

Boot Sequence Displays the boot sequence.

BIOS Setup Advanced Mode

Enables or disables advanced BIOS settings.
Default: ON.

UEFI Boot Path Security

Enables or disables the system to prompt the user to enter the Admin password when booting a UEFI boot path from the F12 boot menu.
Default: Always Except Internal HDD.

Table 5. System setup options—System Configuration menu

System Configuration

Date/Time

Date Sets the computer date in MM/DD/YYYY format. Changes to the date take effect immediately.

Time Sets the computer time in HH/MM/SS 24-hour format. You can switch between 12-hour and 24-hour clock. Changes to the time take effect immediately.

Enable SMART Reporting

Enables or disables SMART (Self-Monitoring, Analysis, and Reporting Technology) during computer startup to report hard drive errors.
Default: OFF.

Enable Audio

Enables or disables all integrated audio controller.
Default: ON.

Enable Microphone

Enables or disables microphone.
Default: ON.

Enable Internal Speaker

Enables or disables internal speaker.
Default: ON.

USB Configuration

Enable Boot Support Enables or disables booting from USB mass storage devices such as external hard drive, optical drive, and USB drive.

Enable External USB Ports Enables or disables USB ports to be functional in an operating system environment.

SATA Operation

Configures operating mode of the integrated SATA hard drive controller.
Default: RAID. SATA is configured to support RAID (Intel Rapid Restore Technology).

Drives

M.2 PCIe SSD-0/SATA-2 Enables or disables various onboard drives.
Default: ON.

SATA-0 Default: ON.

System Configuration


Drive Information	Displays the information of various onboard drives.
Miscellaneous Devices	Enables or disables various onboard devices.
Enable Camera	Enables or disables the camera. Default: ON.
Keyboard Illumination	Configures the operating mode of the keyboard illumination feature. Default: Disabled. The keyboard illumination will always be off.
Keyboard Backlight Timeout on AC	Configures the timeout value for the keyboard when an AC adapter is connected to the computer. The keyboard backlight timeout value is only effect when the backlight is enabled. Default: 10 seconds.
Keyboard Backlight Timeout on Battery	Configures the timeout value for the keyboard when the computer is running on battery. The keyboard backlight timeout value is only effect when the backlight is enabled. Default: 10 seconds.
Touchscreen	Enables or disables the touchscreen for the operating system.  NOTE: Touchscreen will always work in the BIOS setup irrespective of this setting. Default: ON.

Table 6. System setup options—Video menu

Video

LCD Brightness	
Brightness on battery power	Sets the screen brightness when the computer is running on battery power.
Brightness on AC power	Sets the screen brightness when the computer is running on AC power.
EcoPower	Enables or disables EcoPower which increases the battery life by reducing the screen brightness when appropriate. Default: ON.

Table 7. System setup options—Security menu

Security

Enable Admin Setup Lockout	Enables or disables the user from entering BIOS Setup when an Admin Password is set. Default: OFF.
Password Bypass	Bypass the System (Boot) Password and the internal hard drive password prompts during a system restart. Default: Disabled.
Enable Non-Admin Password Changes	Enables or disables the user to change the system and hard drive password without the need for admin password. Default: ON.

Non-Admin Setup Changes

Security



Allow Wireless Switch Changes	Enables or disables changes to the setup option when an Administrator password is set. Default: OFF.
Enable UEFI Capsule Firmware Updates	Enables or disables BIOS updates through UEFI capsule update packages.
Computrace	Enable or disable the BIOS module interface of the optional Computrace(R) Service from Absolute Software.
Intel Platform Trust Technology On	Enables or disables Platform Trust Technology (PTT) visibility to the operating system. Default: ON.
PPI Bypass for Clear Commands	Enables or disables the operating system to skip BIOS Physical Presence Interface (PPI) user prompts when issuing the Clear command. Default: OFF.
Clear	Enables or disables the computer to clear the PTT owner information, and returns the PTT to the default state. Default: OFF.
Intel SGX	Enables or disables the Intel Software Guard Extensions (SGX) to provide a secured environment for running code/storing sensitive information. Default: Software Control
SMM Security Mitigation	Enables or disables additional UEFI SMM Security Mitigation protections. Default: OFF.
	 NOTE: This feature may cause compatibility issues or loss of functionality with some legacy tools and applications.
Enable Strong Passwords	Enables or disables strong passwords. Default: OFF.
Password Configuration	Control the minimum and maximum number of characters that are allowed for Admin and System passwords.
Admin Password	Sets, Changes, or deletes the administrator (admin) password (sometimes called the "setup" password).
System Password	Sets, Changes, or deletes the system password.
Enable Master Password Lockout	Enables or disables the master password support. Default: OFF.

Table 8. System setup options—Secure Boot menu

Secure Boot

Enable Secure Boot	Enables or disables the computer to boot using only validated boot software. Default: OFF.
	 NOTE: For Secure Boot to be enabled, the computer needs to be in UEFI boot mode and the Enable Legacy Option ROMs option needs to be turned off.
Secure Boot Mode	Selects the Secure Boot operation mode. Default: Deployed Mode.

NOTE: Deployed Mode should be selected for normal operation of Secure Boot.

Table 9. System setup options—Expert Key Management menu

Expert Key Management

Enable Custom Mode	Enables or disables the keys in the PK, KEK, db, and dbx security key databases to be modified. Default: OFF.
Custom Mode Key Management	Selects the custom values for expert key management. Default: PK.

Table 10. System setup options—Performance menu

Performance

Intel Hyper-Threading Technology	Enables or disables the Intel Hyper-Threading Technology to use processor resources more efficiently. Default: ON.
Intel SpeedStep	Enables or disables the Intel SpeedStep Technology to dynamically adjust processor voltage and core frequency, decreasing average power consumption and heat production. Default: ON.
Intel TurboBoost Technology	Enabled or disabled the Intel TurboBoost mode of the processor. If enabled, the Intel TurboBoost driver increases the performance of the CPU or graphics processor. Default: ON.
Multi-Core Support	Changes the number of CPU cores available to the operating system. The default value is set to the maximum number of cores. Default: All Cores.
Enable C-State Control	Enables or disables the CPU's ability to enter and exit low-power states. Default: ON.

Table 11. System setup options—Power Management menu

Power Management

Wake on AC	Enables the computer to turn on and go to boot when AC power is supplied to the computer. Default: OFF.
Auto on Time	Enables the computer to automatically power on for defined days and times. Default: Disabled. The system will not automatically power up.
Battery Charge Configuration	Enables the computer to run on battery during power usage hours. Use the below options to prevent AC power usage between certain times of each day. Default: Adaptive. Battery settings are adaptively optimized based on your typical battery usage pattern.

Power Management

Enable Advanced Battery Charge Configuration	Enables Advanced Battery Charge Configuration from the beginning of the day to a specified work period. Advanced Battery Charged maximizes battery health while still supporting heavy use during the work day. Default: OFF.
Block Sleep	Blocks the computer from entering Sleep (S3) mode in the operating system. Default: OFF. i NOTE: If enabled, the computer will not go to sleep, Intel Rapid Start will be disabled automatically, and the operating system power option will be blank if it was set to Sleep.
Enable USB Wake Support	Enables the USB devices to wake the computer from Standby mode. Default: OFF.
Enable Intel Speed Shift Technology	Enables or disables Intel Speed Shift Technology support which enables the operating system to select the appropriate processor performance automatically. Default: ON.
Lid Switch	Enables the computer to power up from the off state whenever the lid is opened. Default: ON.

Table 12. System setup options—Wireless menu

Wireless

Wireless Switch	Determines which wireless devices can be controlled by the Wireless Switch. For Windows 8 systems, this is controlled by an operating system drive directly. As a result, the setting does not affect the Wireless Switch behavior. i NOTE: When both WLAN and WiGig are present, enable/disable controls are tied together. Thus, they cannot be enabled or disabled independently.
WLAN	Default: ON.
Bluetooth	Default: ON.
Wireless Device Enable	Enable or disable internal WLAN/Bluetooth devices.
WLAN	Default: ON.
Bluetooth	Default: ON.

Table 13. System setup options—POST Behavior menu

POST Behavior

Numlock Enable	Enables or disables Numlock when the computer boots. Default: ON.
Enable Adapter Warnings	Enables the computer to display adapter warning messages during boot. Default: ON.
Extend BIOS POST Time	Configures the BIOS POST (Power-On Self-Test) load time. Default: 0 seconds.
Fastboot	Configures the speed of the UEFI boot process.

POST Behavior

	Default: Thorough. Performs complete hardware and configuration initialization during boot.
Fn Lock Options	Enables or disables the Fn lock mode. Default: ON.
Lock Mode	Default: Lock Mode Secondary. Lock Mode Secondary = If this option is selected, the F1-F12 keys scan the code for their secondary functions.
Pull Screen Logo	Enabled or disabled the computer to display full screen logo if the image match screen resolution. Default: OFF.
Warnings and Errors	Selects an action on encountering a warning or error during boot. Default: Prompt on Warnings and Errors. Stop, prompt and wait for user input when warnings or errors are detected.


 **NOTE: Errors deemed critical to the operation of the computer hardware will always halt the computer.**

Table 14. System setup options—Virtualization menu


Virtualization

Intel Virtualization Technology	Enables the computer to run a virtual machine monitor (VMM). Default: ON.
VT for Direct I/O	Enables the computer to perform Virtualization Technology for Direct I/O (VT-d). VT-d is an Intel method that provides virtualization for memory map I/O. Default: ON.


Table 15. System setup options—Maintenance menu

Maintenance

Asset Tag	Creates a system Asset Tag that can be used by an IT administrator to uniquely identify a particular system. Once set in BIOS, the Asset Tag cannot be changed.
Service Tag	Displays the Service Tag of the computer.
BIOS Recovery from Hard Drive	Enables the computer to recover from a bad BIOS image, as long as the Boot Block portion is intact and functioning. Default: ON.

 **NOTE: BIOS recovery is designed to fix the main BIOS block and cannot work if the Boot Block is damaged. In addition, this feature cannot work in the event of EC corruption, ME corruption, or a hardware issue. The recovery image must exist on an unencrypted partition on the drive.**

BIOS Auto-Recovery	Enables the computer to automatically recover the BIOS without user actions. This feature requires BIOS Recovery from Hard Drive to be set to Enabled. Default: OFF.
--------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Start Data Wipe	 CAUTION: This Secure Wipe Operation will delete information in a way that it cannot be reconstructed. If enabled, the BIOS will queue up a data wipe cycle for storage devices that are connected to the motherboard on the next reboot.
-----------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Maintenance

	Default: OFF.
Allow BIOS Downgrade	Controls flashing of the system firmware to previous revisions. Default: ON.

Table 16. System setup options—System Logs menu

System Logs

Power Event Log	Displays Power events. Default: Keep.
BIOS Event Log	Displays BIOS events. Default: Keep.
Thermal Event Log	Displays Thermal events. Default: Keep.

Table 17. System setup options—SupportAssist menu

SupportAssist

Dell Auto operating system Recovery Threshold	Controls the automatic boot flow for SupportAssist System Resolution Console and for Dell operating system Recovery tool. Default: 2.
SupportAssist operating system Recovery	Enables or disables the boot flow for SupportAssist operating system Recovery tool in the even of certain system errors. Default: ON.

Identifier	GUID-52E6F16C-1AA9-4088-98C2-CCFF3BE77302
Status	Released

Clearing CMOS settings

About this task

 **CAUTION:** Clearing CMOS settings will reset the BIOS settings on your computer.

Steps

- 1 Remove the [base cover](#).
- 2 Disconnect the battery cable from the system board.
- 3 Remove the [coin-cell battery](#).
- 4 Wait for one minute.
- 5 Replace the [coin-cell battery](#).
- 6 Connect the battery cable to the system board.
- 7 Replace the [base cover](#).

Identifier	GUID-5941E06E-ABCB-4468-ACE5-D51EF6AAA083
Status	Released

Clearing BIOS (System Setup) and System passwords

To clear the system or BIOS passwords, contact Dell technical support as described at www.dell.com/contactdell.

NOTE: For information on how to reset Windows or application passwords, refer to the documentation accompanying Windows or your application.

Identifier	GUID-F93F7E34-BE30-464B-886E-
Status	Released

Troubleshooting

Identifier	GUID-D75C4F0A-CC06-4C3C-9C4B-7250CA2DCDAC
Status	Released

Enhanced Pre-Boot System Assessment (ePSA) diagnostics

The ePSA diagnostics (also known as system diagnostics) performs a complete check of your hardware. The ePSA is embedded with the BIOS and is launched by the BIOS internally. The embedded system diagnostics provides a set of options for particular devices or device groups allowing you to:

- Run tests automatically or in an interactive mode
- Repeat tests
- Display or save test results
- Run thorough tests to introduce additional test options to provide extra information about the failed device(s)
- View status messages that inform you if tests are completed successfully
- View error messages that inform you of problems encountered during testing

NOTE: Some tests for specific devices require user interaction. Always ensure that you are present at the computer terminal when the diagnostic tests are performed.

For more information, see [Dell ePSA Diagnostic 3.0](#).

Identifier	GUID-0B893EED-EFBC-4831-A9C4-7298A7A9F619
Status	Released

Running the ePSA diagnostics

- 1 Turn on your computer.
- 2 As the computer boots, press the F12 key as the Dell logo appears.
- 3 On the boot menu screen, select the **Diagnostics** option.
- 4 Click the arrow at the bottom left corner.
Diagnostics front page is displayed.
- 5 Click the arrow in the lower-right corner to go to the page listing.
The items detected are listed.
- 6 To run a diagnostic test on a specific device, press Esc and click **Yes** to stop the diagnostic test.
- 7 Select the device from the left pane and click **Run Tests**.
- 8 If there are any issues, error codes are displayed.
Note the error code and validation number and contact Dell.

Identifier GUID-215FECAB-328D-40F9-8731-750BE6594708

Status Released

System diagnostic lights

Battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5 percent charge.

Amber — Computer is running on battery and the battery has less than 5 percent charge.

Off

- Power adapter is connected and the battery is fully charged.
- Computer is running on battery and the battery has more than 5 percent charge.
- Computer is in sleep state, hibernation, or turned off.

The power and battery-status light blinks amber along with beep codes indicating failures.

For example, the power and battery-status light blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off indicating no memory or RAM is detected.

The following table shows different power and battery-status light patterns and associated problems.

Table 18. LED codes

Diagnostic light codes	Problem description
2,1	Processor failure
2,2	System board: BIOS or ROM (Read-Only Memory) failure
2,3	No memory or RAM (Random-Access Memory) detected
2,4	Memory or RAM (Random-Access Memory) failure
2,5	Invalid memory installed
2,6	System board or chipset error
2,7	Display failure
2,8	System board error
3,1	Coin-cell battery failure
3,2	PCI, video card/chip failure
3,3	Recovery image not found
3,4	Recovery image found but invalid
3,5	Power-rail failure
3,6	System BIOS Flash incomplete
3,7	Management Engine (ME) error

Camera status light: Indicates whether the camera is in use.

- Solid white — Camera is in use.
- Off — Camera is not in use.

Caps Lock status light: Indicates whether Caps Lock is enabled or disabled.

- Solid white — Caps Lock enabled.
- Off — Caps Lock disabled.

Identifier	GUID-FE39A314-6129-4A79-A5FA-B69617360582
Status	Released

Enabling Intel Optane memory

- 1 On the taskbar, click the search box, and then type `Intel Rapid Storage Technology`.
- 2 Click **Intel Rapid Storage Technology**.
The **Intel Rapid Storage Technology** window is displayed.
- 3 On the **Status** tab, click **Enable** to enable the Intel Optane memory.
- 4 On the warning screen, select a compatible fast drive, and then click **Yes** to continue enabling Intel Optane memory.
- 5 Click **Intel Optane memory > Reboot** to complete enabling your Intel Optane memory.

NOTE: Applications may take up to three subsequent launches after enablement to see the full performance benefits.

Identifier	GUID-CD2E8B90-160E-43C9-BA9D-F0F6C6BAA458
Status	Released

Disabling Intel Optane memory

About this task

CAUTION: After disabling Intel Optane memory, do not uninstall the driver for Intel Rapid Storage Technology as it will result in a blue screen error. The Intel Rapid Storage Technology user interface can be removed without uninstalling the driver.

NOTE: Disabling Intel Optane memory is required before removing the SATA storage device accelerated by the Intel Optane memory module from the computer.

Steps

- 1 On the taskbar, click the search box, and then type `Intel Rapid Storage Technology`.
- 2 Click **Intel Rapid Storage Technology**.
The **Intel Rapid Storage Technology** window is displayed.
- 3 On the **Intel Optane memory** tab, click **Disable** to disable the Intel Optane memory.

NOTE: For computers in which Intel Optane memory acts as a primary storage, do not disable the Intel Optane memory. The **Disable** option will be grayed out.

- 4 Click **Yes** if you accept the warning.
The disabling progress is displayed.
- 5 Click **Reboot** to complete disabling your Intel Optane memory and restart your computer.

Identifier	GUID-060D210F-C287-462B-AC38-81183D440A9D
Status	Released

Flashing BIOS (USB key)

- 1 Follow the procedure from step 1 to step 7 in "[Flashing the BIOS](#)" to download the latest BIOS setup program file.
- 2 Create a bootable USB drive. For more information see the knowledge base article [SLN143196](#) at www.dell.com/support.

- 3 Copy the BIOS setup program file to the bootable USB drive.
- 4 Connect the bootable USB drive to the computer that needs the BIOS update.
- 5 Restart the computer and press **F12** when the Dell logo is displayed on the screen.
- 6 Boot to the USB drive from the **One Time Boot Menu**.
- 7 Type the BIOS setup program filename and press **Enter**.
- 8 The **BIOS Update Utility** appears. Follow the instructions on the screen to complete the BIOS update.

Identifier	GUID-F5899359-C2E1-41C0-9663-4C79969506EB
Status	Released

Flashing the BIOS

About this task

You may need to flash (update) the BIOS when an update is available or when you replace the system board.

Follow these steps to flash the BIOS:

Steps

- 1 Turn on your computer.
- 2 Go to www.dell.com/support.
- 3 Click **Product support**, enter the Service Tag of your computer, and then click **Submit**.

NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4 Click **Drivers & downloads > Find it myself**.
- 5 Select the operating system installed on your computer.
- 6 Scroll down the page and expand **BIOS**.
- 7 Click **Download** to download the latest version of the BIOS for your computer.
- 8 After the download is complete, navigate to the folder where you saved the BIOS update file.
- 9 Double-click the BIOS update file icon and follow the instructions on the screen.

Identifier	GUID-F5888FED-ECD3-4130-9BE0-7BF759B7ED4A
Status	Released

Flea power release

About this task

Flea power is the residual static electricity that remains on the computer even after it has been powered off and the battery has been removed. The following procedure provides the instructions on how to conduct flea power release:

Steps

- 1 Turn off your computer.
- 2 Remove the [base cover](#).
- 3 Remove the [battery](#).
- 4 Press and hold the power button for 15 seconds to drain the flea power.
- 5 Replace the [battery](#).
- 6 Replace the [base cover](#).
- 7 Turn on your computer.

Identifier	GUID-7D2143EA-2C62-498E-97AF-DCEF3DA56624
Status	Released

Wi-Fi power cycle

About this task

If your computer is unable to access the Internet due to Wi-Fi connectivity issues a Wi-Fi power cycle procedure may be performed. The following procedure provides the instructions on how to conduct a Wi-Fi power cycle:

 **NOTE:** Some ISPs (Internet Service Providers) provide a modem/router combo device.

Steps

- 1 Turn off your computer.
- 2 Turn off the modem.
- 3 Turn off the wireless router.
- 4 Wait for 30 seconds.
- 5 Turn on the wireless router.
- 6 Turn on the modem.
- 7 Turn on your computer.

Identifier	GUID-BB503BA0-303E-41D6-9B1B-06A2EF4C8817
Status	Released

Using Game Shift

Game Shift improves gaming performance by increasing the fan speed for optimal thermal cooling of the processor.

Enabling Game Shift

To enable Game Shift, press **F7** (if **fn** default is enabled; otherwise, press **fn + F7**). For more information, see [Keyboard shortcuts](#).

Alienware Command Center displays a blue G icon, a notification pops up to indicate that Game Shift is enabled.

Disabling Game Shift

When you are not using the computer for gaming, disable Game Shift by pressing **F7** (if **fn** default is enabled; otherwise, press **fn + F7**).

Game Shift is also disabled when:

- You set your computer to a sleep state.
- You restart your computer.
- Game Shift has been active for 24 consecutive hours.
- You start a new game.
- You terminate the game that has been running on Game Shift.
- You change power plans or thermal profiles of the computer.

Installing Game Shift after reinstalling the operating system

Alienware Command Center and Alienware OC Controls are installed at the factory. If you reinstall the operating system, you have to reinstall Alienware Command Center and Alienware OC Controls before you can use Game Shift.

NOTE: Ensure that the Windows operating system and all the compatible drivers are reinstalled in your computer. Windows update is also required.

After you have reinstalled the operating system, Alienware Command Center, and Alienware OC Controls, install Game Shift:

- 1 Go to Dell support site www.dell.com/support.
- 2 Enter Dell G3 3590 and click **Search**.
- 3 Click **Drivers & downloads**.
- 4 Download and install **Alienware Command Center**.
- 5 Download and install **Alienware OC Controls**.
- 6 Restart your computer. You can now enable Game Shift (see [Enabling Game Shift](#)).

Identifier	GUID-7F239B43-4075-42A0-957E-C240FE5516E0
Status	Released

Keyboard shortcuts

NOTE: Keyboard characters may differ depending on the keyboard language configuration. Keys used for shortcuts remain the same across all language configurations.










Some keys on your keyboard have two symbols on them. These keys can be used to type alternate characters or to perform secondary functions. The symbol shown on the lower part of the key refers to the character that is typed out when the key is pressed. If you press **Shift** and the key, the symbol shown on the upper part of the key is typed out. For example, if you press **2**, 2 is typed out; if you press **Shift + 2**, @ is typed out.




























The keys **F1** to **F12** at the top row of the keyboard are function keys for multi-media control, as indicated by the icon at the bottom of the key. Press the function key to invoke the task represented by the icon. For example, pressing **F1** mutes the audio (refer to the table below).

However, if the function keys **F1** to **F12** are needed for specific software applications, multi-media functionality can be disabled by pressing **fn + Esc**. Subsequently, multi-media control can be invoked by pressing **fn** and the respective function key. For example, mute audio by pressing **fn + F1**.

NOTE: You can also define the primary behavior of the function keys (F1 to F12) by changing Function Key Behavior in the BIOS setup program.









Table 19. List of keyboard shortcuts

Function key	Redefined key (for multimedia control)	Behavior
	 + 	Mute audio
	 + 	Decrease volume
	 + 	Increase volume

Function key	Redefined key (for multimedia control)	Behavior
	 + 	Play previous track/chapter
	 + 	Play/Pause
	 + 	Play next track/chapter
	 + 	Enable/disable Game Shift
	 + 	Switch to external display
	 + 	Search
	 + 	Toggle keyboard backlight (optional)
		NOTE: Non-backlight keyboards have the F10 function key without the backlight icon. In this case, the function key does not toggle the keyboard backlight function.
	 + 	Decrease brightness
	 + 	Increase brightness

The **Fn** key is also used with selected keys on the keyboard to invoke other secondary functions.

Table 20. List of keyboard shortcuts

Function key	Behavior
 + 	Turn off/on wireless
 + 	Pause/Break
 + 	Sleep
 + 	Toggle scroll lock

Function key

Behavior



Toggle between power and battery-status light/hard-drive activity light



System request



Open application menu



Toggle fn-key lock



Page up



Page down



Home



End



Identifier	GUID-79104453-0F4A-4408-A5D4-4
Status	Released

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 21. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	www.dell.com
My Dell	
Tips	
Contact Support	In Windows search, type <code>Contact Support</code> , and press Enter.
Online help for operating system	www.dell.com/support/windows www.dell.com/support/linux
Troubleshooting information, user manuals, setup instructions, product specifications, technical help blogs, drivers, software updates, and so on.	www.dell.com/support
Dell knowledge base articles for a variety of computer concerns.	<ol style="list-style-type: none"> 1 Go to www.dell.com/support. 2 Type the subject or keyword in the Search box. 3 Click Search to retrieve the related articles.
Learn and know the following information about your product:	See <i>Me and My Dell</i> at www.dell.com/support/manuals .
<ul style="list-style-type: none"> • Product specifications • Operating system • Setting up and using your product • Data backup • Troubleshooting and diagnostics • Factory and system restore • BIOS information 	<p>To locate the <i>Me and My Dell</i> relevant to your product, identify your product through one of the following:</p> <ul style="list-style-type: none"> • Select Detect Product. • Locate your product through the drop-down menu under View Products. • Enter the Service Tag number or Product ID in the search bar.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

- ① **NOTE:** Availability varies by country/region and product, and some services may not be available in your country/region.
- ① **NOTE:** If you do not have an active internet connection, you can find contact information on your purchase invoice, packing slip, bill, or Dell product catalog.