

SUN2000-(8KTL, 10KTL, 12KTL, 15KTL, 17KTL, 20KTL)-M0

User Manual

Issue 03

Date 2019-07-19



Copyright © Huawei Technologies Co., Ltd. 2019. All rights reserved.

No part of this document may be reproduced or transmitted in any form or by any means without prior written consent of Huawei Technologies Co., Ltd.

Trademarks and Permissions

HUAWEI

HUAWEI and other Huawei trademarks are trademarks of Huawei Technologies Co., Ltd.

All other trademarks and trade names mentioned in this document are the property of their respective holders.

Notice

The purchased products, services and features are stipulated by the contract made between Huawei and the customer. All or part of the products, services and features described in this document may not be within the purchase scope or the usage scope. Unless otherwise specified in the contract, all statements, information, and recommendations in this document are provided "AS IS" without warranties, guarantees or representations of any kind, either express or implied.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information, and recommendations in this document do not constitute a warranty of any kind, express or implied.

Huawei Technologies Co., Ltd.

Address: Huawei Industrial Base

Bantian, Longgang Shenzhen 518129

People's Republic of China

Website: http://e.huawei.com

About This Document

Purpose

This document describes the SUN2000-8KTL-M0, SUN2000-10KTL-M0, SUN2000-12KTL-M0, SUN2000-15KTL-M0, SUN2000-17KTL-M0, and SUN2000-20KTL-M0 (SUN2000 for short) in terms of installation, electrical connections, commissioning, maintenance, and troubleshooting. Read this document through, understand the safety information, and get familiar with the functions and features of the SUN2000 before installing and operating it.

M NOTE

The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

Intended Audience

This document is intended for:

- Installers
- Users

Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description
▲ DANGER	Indicates an imminently hazardous situation which, if not avoided, will result in serious injury or death.
<u>∧</u> WARNING	Indicates a potentially hazardous situation which, if not avoided, could result in serious injury or death.
▲ CAUTION	Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

Symbol	Description
NOTICE	Indicates a potentially hazardous situation which, if not avoided, could result in equipment damage, data loss, performance deterioration, or unanticipated results. NOTICE is used to address practices not related to personal injury.
NOTE	Calls attention to important information, best practices and tips. NOTE is used to address information not related to personal injury, equipment damage, or environment deterioration.

Change History

Changes between document issues are cumulative. The latest document issue contains all updates made in previous issues.

Issue 03 (2019-07-19)

- Added E Starting AFCI Check.
- Added F IPS Test (for Italy CEI0-21 Grid Code only).
- Added SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

Issue 02 (2019-06-30)

- Added C Setting Export Limitation Parameters.
- Added D Setting Voltage Rise Suppression Q-U Curve.

Issue 01 (2019-05-08)

This issue is used for first office application (FOA).

Contents

About This Document	11
1 Safety Precautions	1
2 Overview	4
2.1 Product Introduction	4
2.2 Appearance	7
2.3 Label Description	9
2.3.1 Enclosure Labels	9
2.3.2 Product Nameplate	10
2.4 Working Principles	11
2.4.1 Circuit Diagram	11
2.4.2 Working Modes	11
3 Storage	14
4 Installation	15
4.1 Checking Before Installation	15
4.2 Tools	15
4.3 Determining the Installation Position	17
4.3.1 Environment Requirements	17
4.3.2 Space Requirements	17
4.4 Moving an Inverter	21
4.5 Installing the Mounting Bracket	22
4.5.1 Wall-mounted Installation	23
4.5.2 Support-mounted Installation	25
5 Electrical Connections	29
5.1 Preparing for Installation	30
5.2 Connecting the PE cable	33
5.3 Connecting the AC Output Power Cable	35
5.4 Connecting the DC input power cable	39
5.5 (Optional) Installing the Smart Dongle	44
5.6 (Optional) Installing the Signal Cable	44
5.6.1 Connecting the RS485 Communications Cable (Inverter Cascading)	47
5.6.2 Connecting the RS485 Communications Cable (Smart Power Sensor)	48

5.6.3 Connecting the Power Grid Scheduling Signal Cable	50
6 Commissioning	53
6.1 Check Before Power-On	53
6.2 Powering On the System	54
6.3 Commissioning	55
6.3.1 Scenario 1: Single inverter + Smart Dongle	55
6.3.2 Scenario 2: Multiple Inverters + SmartLogger1000A	58
6.3.3 Other Scenarios	58
6.4 Powering Off the System	61
7 Maintenance	62
7.1 Routine Maintenance	62
7.2 Troubleshooting	63
8 Handling the Inverter	70
8.1 Removing the SUN2000	70
8.2 Packing the SUN2000	70
8.3 Disposing of the SUN2000	70
9 Technical Data	71
A Grid Codes	76
B Setting Dry Contact Scheduling Parameters	80
C Setting Export Limitation Parameters	82
D Setting Voltage Rise Suppression Q-U Curve	85
E Starting AFCI Check	87
F IPS Test (for Italy CEI0-21 Grid Code only)	88
G DRM Configuration Guide for Standard AS NZS4777.2	91
H Acronyms and Abbreviations	92

Safety Precautions

Safety

NOTICE

- Before performing operations, read through this manual and follow all the precautions to
 prevent accidents. The DANGER, WARNING, CAUTION, and NOTICE statements in
 this document do not represent all the safety instructions. They are only supplements to the
 safety instructions.
- Only certified electricians are allowed to install, connect cables for, commission, maintain, and troubleshoot Huawei products, and they must understand basic safety precautions to avoid hazards.

When operating Huawei equipment, in addition to following the general precautions in this document, follow the specific safety instructions given by Huawei. Huawei will not be liable for any consequence caused by the violation of the safety operation regulations and design, production, and usage standards.

Disclaimer

Huawei shall not be liable for any consequence caused by any of the following events:

- Damage during the transportation by the customer
- Storage conditions that do not meet the requirements specified in this document.
- Incorrect storage, installation, or use
- Installation or use by unqualified personnel
- Failure to follow the operation instructions and safety precautions in this document
- Operation in extreme environments which are not covered in this document
- Operation beyond specified ranges.
- Unauthorized modifications to the product or software code or removal of the product
- Device damage due to force majeure (such as earthquake, fire, and storm)
- Warranty expiration without extension of warranty service.
- Installation or use in environments which are not specified in relevant international standards

Personnel Requirements

- Operation personnel should receive professional training.
- Operation personnel should read through this document and follow all the precautions.
- Operation personnel should be familiar with the safety standards relevant to electrical systems.
- Operation personnel should understand the composition and working principles of the grid-tied PV system and be aware of local regulations.
- Operation personnel must wear proper personal protective equipment (PPE).

Protecting Labels

Do not scrawl, damage, or block any warning label on the device.

Installation

A DANGER

Never power on the SUN2000 during installation.

- Ensure that the SUN2000 is not connected to a power supply or powered on before finishing installation.
- Ensure that the SUN2000 is installed in a well-ventilated environment.
- Ensure that the SUN2000 heat sinks are free from blockage.
- Do not open the front panel of the SUN2000.
- Do not remove the terminals and ports at the bottom of the SUN2000.

Grounding

- When installing the device, always make the ground connection first and disconnect it in the end.
- Do not damage the ground conductor.

Electrical Connections

A DANGER

Before connecting cables, ensure that the SUN2000 is secured in position and not damaged in any way. Otherwise, electric shock or fire may occur.

- Ensure that all electrical connections comply with local electrical standards.
- Obtain approval from the local utility company before using the SUN2000 to generate electricity in grid-tied mode.
- Ensure that the cables used in a grid-tied PV system are properly connected and insulated and meet all specification requirements.

Operation

A DANGER

High voltage may cause an electric shock, which results in serious property damage, serious injury, or death from the SUN2000 in operation. Strictly comply with the safety precautions in this document and associated documents when operating the SUN2000.

- Before operating a device, ensure that it is properly grounded.
- Do not touch an energized SUN2000 because the heat sink reaches a high temperature.
- Follow local laws and regulations when operating the equipment.

Commissioning

When the SUN2000 is powered on for the first time, only qualified personnel are allowed to set the parameters on **Quick Setting**. Incorrect settings may cause the SUN2000 to conflict with the local certification, which affects the normal operation of the SUN2000.

Maintenance and Replacement

A DANGER

High voltage may cause an electric shock, which results in serious property damage, serious injury, or death, or serious property damage from the SUN2000 in operation. Prior to maintenance, power off the SUN2000 and strictly comply with the safety precautions in this document and associated documents when operating the SUN2000.

- A faulty SUN2000 requires overall maintenance. Contact your dealer if the SUN2000 is faulty.
- Maintain the SUN2000 with sufficient knowledge of this document, proper tools, and testing equipment.
- Before maintaining the SUN2000, power it off and follow the instructions on the delay discharge label. Wait for a proper time to operate the SUN2000.
- Place temporary warning signs or erect fences to prevent unauthorized access to the maintenance site.
- Rectify any fault that may compromise the SUN2000 security performance before powering it on again.
- Observe ESD precautions during maintenance.

2 Overview

2.1 Product Introduction

Function

The SUN2000 is a three-phase grid-tied PV string inverter that converts the DC power generated by PV strings into AC power and feeds the power into the power grid.

Models

This document involves the following product models:

- SUN2000-8KTL-M0
- SUN2000-10KTL-M0
- SUN2000-12KTL-M0
- SUN2000-15KTL-M0
- SUN2000-17KTL-M0
- SUN2000-20KTL-M0

∭ NOTE

The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

Figure 2-1 Model description (SUN2000-20KTL-M0 is used as an example)




Table 2-1 Model description


Icon	Meaning	Description
1	Product	SUN2000: three-phase grid-tied PV string inverter

Icon	Meaning	Description	
2	Power level	 8K: The rated power is 8 kW. 10K: The rated power is 10 kW. 12K: The rated power is 12 kW. 15K: The rated power is 15 kW. 17K: The rated power is 17 kW. 20K: The rated power is 20 kW. 	
3	Topology	TL: transformerless	
4	Product code	M0: the product series with the 1100 V DC input voltage	

Network Application

The SUN2000 applies to grid-tied PV systems for residential rooftops and small ground plants. Typically, a grid-tied system consists of the PV string, SUN2000, AC switch, and alternating current distribution unit (ACDU).

Figure 2-2 Networking application (optional in dashed boxes)



■ NOTE

indicates a power cable, indicates a signal cable, indicates wireless communication.


• If the inverter is connected to the FusionSolar app over its built-in WiFi network, only local commissioning can be performed.

(A) PV string	(B) DC switch	(C) SUN2000
(D) AC switch	(E) ACDU	(F) Smart Power Sensor
(G) Power grid	(H) 4G Smart Dongle	(I) WLAN Smart Dongle
(J) Router	(K) FusionSolar management system	(L) FusionSolar APP
(M) Load	(N) Ripple Control Device	

Supported Power Grids

Power grid types supported by the SUN2000 include TN-S, TN-C, TN-C-S, TT, and IT.

Figure 2-3 Supported power grids




IS01S10001

MOTE

- In a TT power grid, the N-PE voltage should be lower than 30 V.
- In an IT power grid, you need to set isolation settings to input not grounded, with a transformer.

2.2 Appearance

Figure 2-4 Appearance



- (1) LED indicator
- (3) Mounting plate
- (5) Ventilation valve
- (7) AC output port (AC)
- (9) Smart Dongle port (GPRS/4G/WLAN)
- (11) DC input terminals (PV3+/PV3-)
- (13) DC input terminals (PV1+/PV1-)

- (2) Front panel
- (4) Heat sink
- (6) Ground screw
- (8) Communication port (COM)
- (10) DC input terminals (PV4+/PV4-)
-
- (12) DC input terminals (PV2+/PV2-)
- (14) DC switch (DC SWITCH)

M NOTE

Two M6 screw holes are reserved on the sides of the enclosure for installing an awning.

Table 2-2 LED indicator description

Category	Status		Meaning
Running	LED1	LED2	N/A
indication	Steady green	Steady green	The SUN2000 is operating in gridtied mode.

Category	Status		Meaning	
□ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □ □	Blinking green at long intervals (on for 1s and then off for 1s)	Off	The DC is on and the AC is off.	
	Blinking green at long intervals (on for 1s and then off for 1s)	Blinking green at long intervals (on for 1s and then off for 1s)	The DC is on, the AC is on, and the SUN2000 is not exporting power to the power grid.	
	Off	Off	The DC is off. ^a	
	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	N/A	DC environmental alarm	
	N/A	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	AC environmental alarm	
	Steady red	Steady red	Fault	
Communicatio	LED3		N/A	
n indication	Blinking green at short intervals (on for 0.2s and then off for 0.2s)		Communication is in progress. (When a mobile phone is connected to the SUN2000, the indicator first indicates that the phone is connected to the SUN2000): blinks green at long intervals.)	
	Blinking green at long intervals (on for 1s and then off for 1s)		The mobile phone is connected to the SUN2000.	
Off		There is no communication.		
Note a: The AC may be on. Check whether the external AC switch is OFF.				

2.3 Label Description


2.3.1 Enclosure Labels

Symbol	Name	Meaning
Danger: High Voltage! 高压危险! Start maintaining the SUN2000 at least 5 minutes after the SUN2000 disconnects from all external power supplies. 逆变器与外部所有电源断开后需要等待至少5分钟,才可以进行维护。	Delayed discharge	Residual voltage exists after the SUN2000 is powered off. It takes 5 minutes for the SUN2000 to discharge to the safe voltage.
Warning: High Temperaturel 高温危险! Never touch the enclosure of an operating SUN2000. 逆变器工作时严禁触摸外壳。	Burn warning	Do not touch an operating SUN2000 because it generates high temperatures on the shell.
Danger, Electrical Hazard! 有电危险! Only certified professionals are allowed to install and operate the SUN2000. 仅有资质的专业人员才可进行 逆变器的安装和操作。 High touch current, earth connection essential before connecting supply. 大接触电流!接通电源前须先接地。	Electric shock warning label	High voltage exists after the SUN2000 is powered on. Only qualified and trained electrical technicians are allowed to perform operations on the SUN2000.
		High touch current exists after the SUN2000 is powered on. Ensure that the SUN2000 has been grounded before powering on it.
CAUTION Read instructions carefully before performing any operation on the SUN2000. 对逆变器进行任何操作前,请 仔细阅读说明书!	Refer to documentation	Reminds operators to refer to the documents shipped with the SUN2000.
	Grounding	Indicates the position for connecting the protective earthing (PE) cable.
Do not disconnect under load! 禁止带负荷断开连接!	Operation warning	Do not remove the DC input connector or the AC output connector when the SUN2000 is running.
(1P)PN/ITEM:XXXXXXXX (32P)Model: SUN2000-XKTL-M0 (S)SN:XXXXXXXXXXXXXX MADE IN CHINA	SUN2000 serial number (SN) label	Indicates the SUN2000 SN.

Symbol	Name	Meaning
MAC: xxxxxxxxxxx	SUN2000 MAC address label	Indicates the MAC address.
	QR code label for SUN2000 WiFi connection	Scan the QR code to connect to Huawei SUN2000 WiFi network.

2.3.2 Product Nameplate

Figure 2-5 Nameplate (SUN2000-20KTL-M0 as an example)



- (1) Trademark and product model
- (2) Important technical specifications
- (3) Compliance symbols
- (4) Company name and country of manufacture

MOTE

The nameplate figure is for reference only.

Symbol	Name	Meaning
	Australia RCM certification mark	This product complies with Australia RCM certification standards.
CE	Conformité Européenne (CE) certification mark	This product complies with CE certification standards.


Symbol	Name	Meaning
50)	Environmentally friendly use period (EFUP) mark	The product does not pollute the environment during the specified period.
X	EU waste electrical and electronic equipment (WEEE) mark	Do not dispose of the product as household garbage.

2.4 Working Principles

2.4.1 Circuit Diagram

Four PV strings connect to the SUN2000, and their maximum power points are tracked by two maximum power point tracking (MPPT) circuits. The SUN2000 converts DC power into three-phase AC power through an inverter circuit. Surge protection is supported on both the DC and AC sides.


Figure 2-6 SUN2000 conceptual diagram



2.4.2 Working Modes

The SUN2000 can work in Standby, Operating, or Shutdown mode.

Figure 2-7 Working modes



IS07S00001

Table 2-3 Working mode description

Working Mode	Description
Standby	The SUN2000 enters Standby mode when the external environment does not meet the operating requirements. In Standby mode:
	The SUN2000 continuously performs status check and enters the Operating mode once the operating requirements are met.
	The SUN2000 enters Shutdown mode after detecting a shutdown command or a fault after startup.
Operating	In Operating mode:
	The SUN2000 converts DC power from PV strings into AC power and feeds the power to the power grid.
	The SUN2000 tracks the maximum power point to maximize the PV string output.
	• If the SUN2000 detects a fault or a shutdown command, it enters the Shutdown mode.
	The SUN2000 enters Standby mode after detecting that the PV string output power is not suitable for connecting to the power grid for generating power.

Working Mode	Description
Shutdown	In Standby or Operating mode, the SUN2000 enters Shutdown mode after detecting a fault or shutdown command.
	• In Shutdown mode, the SUN2000 enters Standby mode after detecting a startup command or that the fault is rectified.

3 Storage

The following requirements should be met if the SUN2000 is not put into use directly:

- Do not unpack the SUN2000.
- Keep the storage temperature at -40°C to +70°C and the humidity at 5%-95% RH (non-condensing).
- The SUN2000 should be stored in a clean and dry place and be protected from dust and water vapor corrosion.
- A maximum of six SUN2000s can be stacked. To avoid personal injury or device damage, stack SUN2000s with caution to prevent them from falling over.
- Periodic inspections are required during the storage. Replace the packing materials if necessary.
- If the SUN2000 has been long-term stored, inspections and tests should be conducted by qualified personnel before it is put into use.

4 Installation

4.1 Checking Before Installation

Outer Packing Materials

Before unpacking the inverter, check the outer packing materials for damage, such as holes and cracks, and check the inverter model. If any damage is found or the inverter model is not what you requested, do not unpack the package and contact your supplier as soon as possible.

M NOTE

You are advised to remove the packing materials within 24 hours before installing the inverter.


Package Contents

After unpacking the inverter, check that the contents are intact and complete. If any damage is found or any component is missing, contact your supplier.

M NOTE

For details about the number of contents, see the *Packing List* in the packing case.

4.2 Tools



Type	Tool			
	Wire stripper	Removal wrench Model: H4TW0001; manufacturer: Amphenol	Rubber mallet	Utility knife
	Cable cutter	Crimping tool Model: H4TC0003; manufacturer: Amphenol	Multimeter DC voltage measurement range ≥ 1100 V DC	Vacuum cleaner
	A			
	Marker	Measuring tape	Bubble or digital level	OT terminal crimping tool
				N/A
	Heat shrink tubing	Heat gun	Cable tie	
PPE				C. C
	Safety gloves	Safety goggles	Anti-dust respirator	Safety shoes

4.3 Determining the Installation Position

4.3.1 Environment Requirements

Basic Requirements

- The SUN2000 is protected to IP65 and can be installed indoors or outdoors.
- Do not install the SUN2000 in a place where personnel are easy to come into contact with its enclosure and heat sinks, because these parts are extremely hot during operation.
- Do not install the SUN2000 in areas with flammable or explosive materials.
- Do not install the SUN2000 at a place within children's reach.
- Do not install the SUN2000 outdoors in salt areas because it will be corroded there and
 may cause fire. A salt area refers to the region within 500 meters from the coast or prone
 to sea breeze. The regions prone to sea breeze vary depending on weather conditions
 (such as typhoons and monsoons) or terrains (such as dams and hills).
- The SUN2000 must be installed in a well-ventilated environment to ensure good heat dissipation.
- Recommended: Install the SUN2000 in a sheltered place or a place with an awning.

Mounting Structure Requirements

- The mounting structure where the SUN2000 is installed must be fireproof.
- Do not install the SUN2000 on flammable building materials.
- The SUN2000 is heavy. Ensure that the installation surface is solid enough to bear the weight load.
- In residential areas, do not install the SUN2000 on drywalls or walls made of similar materials which have a weak sound insulation performance because the noise generated by the SUN2000 is noticeable.


4.3.2 Space Requirements

Installation Angle Requirements

The SUN2000 can be wall-mounted or pole-mounted. The installation angle requirements are as follows:

- Install the SUN2000 vertically or at a maximum back tilt of 15 degrees to facilitate heat dissipation.
- Do not install the SUN2000 at forward tilted, excessive back tilted, side tilted, horizontal, or upside down positions.


Figure 4-1 Installation tilts



Installation Space Requirements


• Reserve enough space around the SUN2000 to ensure sufficient space for installation and heat dissipation.

Figure 4-2 Installation space



• When installing multiple SUN2000s, install them in horizontal mode if sufficient space is available and install them in triangle mode if no sufficient space is available. Stacked installation is not recommended.

Figure 4-3 Horizontal installation (recommended)



≥ 500 mm ≥ 200 mm IS05W00017

Figure 4-4 Staggered installation (recommended)




Figure 4-5 Stacked installation (not recommended)

4.4 Moving an Inverter


Procedure

Step 1 Two persons are required to move the inverter and one person on both sides. Lift the inverter from the packing case and move it to the specified installation position.

⚠ CAUTION

- To prevent personal injury and damage to the device, take care to keep your balance when moving the SUN2000.
- Do not use the wiring terminals and ports at the bottom to support any weight of the SUN2000.
- When you need to temporally place the SUN2000 on the ground, use foam, paper or other protective materials to prevent damage to its enclosure.

Figure 4-6 Moving an inverter




----End

4.5 Installing the Mounting Bracket

Installation Precautions

Figure 4-7 shows the dimensions of installation holes on the SUN2000.

Figure 4-7 Mounting bracket dimensions



4.5.1 Wall-mounted Installation


Procedure

- **Step 1** Determine the installation positions for drilling holes, and mark the positions using a marker.
- **Step 2** Secure the mounting brackets.

M NOTE

- M6x60 expansion bolts are delivered with the SUN2000. If the length and amount of the bolts do not meet installation requirements, prepare M6 stainless steel expansion bolts by yourself.
- The expansion bolts delivered with the inverter are used for solid concrete walls. For other types of
 walls, prepare bolts by yourself and ensure that the wall meets the load bearing requirements of the
 inverter.

Figure 4-8 Expansion bolt composition




A DANGER

Avoid drilling holes in the utility pipes or cables attached to the back of the wall.

NOTICE


- To prevent dust inhalation or contact with eyes, wear safety goggles and an anti-dust respirator when drilling holes.
- Clean up any dust in and around the holes using a vacuum cleaner and measure the distance between holes. If large hole tolerance exists, position and drill holes again.
- After removing the bolt, spring washer, and flat washer, level the front of the expansion tube with the concrete wall. Otherwise, the mounting brackets will not stay steady on the concrete wall.
- Partially loosen the nut, flat washer and spring washer of the two expansion bolts below.

Figure 4-9 Installing the Mounting Bracket



- **Step 3** Install the SUN2000 onto the mounting bracket.
- Step 4 Tighten nuts.

Figure 4-10 Installing the SUN2000




Step 5 (Optional) Install the anti-theft lock.

NOTICE

- Prepare an anti-theft lock suitable for the lock hole diameter (Φ8 mm) by yourself.
- An outdoor waterproof lock is recommended.
- Keep the key to the anti-theft lock safe.

Figure 4-11 Installing the anti-theft lock



----End

4.5.2 Support-mounted Installation


Prerequisites

Prepare M6 stainless bolt assemblies (including flat washers, spring washers, and M6 bolts) with appropriate lengths as well as matched flat washers and nuts based on the support specifications.

Procedure

Step 1 Determine the hole positions based on the marking-off template, and then mark the hole positions using a marker.

Figure 4-12 Determining hole positions




Step 2 Drill holes using a hammer drill.

 \square NOTE


You are advised to apply anti-rust paint on the hole positions for protection.

Figure 4-13 Drilling holes




Step 3 Secure the mounting bracket.

Figure 4-14 Securing the mounting bracket



- **Step 4** Install the SUN2000 onto the mounting bracket.
- **Step 5** Tighten the bolt assembly.

Figure 4-15 Installing the SUN2000




Step 6 (Optional) Install the anti-theft lock.

NOTICE

- Prepare an anti-theft lock suitable for the lock hole diameter ($\Phi 8$ mm) by yourself.
- An outdoor waterproof lock is recommended.
- Keep the key to the anti-theft lock safe.

Figure 4-16 Installing the anti-theft lock



----End

5 Electrical Connections

Precautions

A DANGER

Before connecting cables, ensure that the DC switch on the SUN2000 and all the switches connecting to the SUN2000 are OFF. Otherwise, the high voltage of the SUN2000 may result in electric shocks.

MARNING


- The equipment damage caused by incorrect cable connections is beyond the warranty scope.
- Only certified electricians are allowed to connect cables.
- Operation personnel must wear proper PPE when connecting cables.

Ⅲ NOTE

The cable colors shown in the electrical connection diagrams provided in this chapter are for reference only. Select cables in accordance with local cable specifications (green-and-yellow cables are only used for PE).

5.1 Preparing for Installation

Figure 5-1 SUN2000 cable connections (optional in dashed boxes)



NOTICE

If the Smart Dongle is configured, you are advised to install the Smart Dongle before connecting the signal cable.

Table 5-1 Component description

No.	Component	Description	Source
A	PV module	 A PV string is composed of the PV modules connected in series. The SUN2000 supports the input from four PV strings. 	Prepared by the customer
В	DC switch	Recommended: a PV circuit breaker with a rated voltage greater than or equal to 1,100 V DC and a rated current of 15 A.	Prepared by the customer

No.	Component	Description	Source
С	Smart Dongle ^a	 WLAN Smart Dongle: SDongleA-01. 4G Smart Dongle: SDongleA- 03. 	Purchased from Huawei
D	SUN2000	Select a proper model based on requirements.	Purchased from Huawei
Е	SmartLogger10 00A	Select a proper model based on requirements.	Purchased from Huawei
F	Smart Power Sensor	The recommended electricity meter model is DTSU666-H.	Purchased from Huawei
G	Ripple Control Device	Select the devices that meet the power grid scheduling requirements.	Provided by local power grid companies
Н	AC switch ^b	Recommended: a three-phase AC circuit breaker with a rated voltage greater than or equal to 415 V AC and a rated current of: • 25 A (SUN2000-8KTL-M0, SUN2000-10KTL-M0, SUN2000-12KTL-M0) • 40 A (SUN2000-15KTL-M0, SUN2000-17KTL-M0, SUN2000-20KTL-M0)	Prepared by the customer

- Note a: WLAN Smart Dongle: For details about the SDongleA-01 operation, see SDongleA-01 Quick Guide (WLAN); 4G Smart Dongle: For details about the SDongleA-03 operation, see SDongleA-03 Quick Guide (4G). You can obtain the quick guide at https://support.huawei.com/enterprise by searching for the Smart Dongle model.
- Note b: The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

Table 5-2 Cable description

No.	Name	Туре	Specifications
1	DC input power cable	Standard PV cable in the industry	• Conductor cross- sectional area: 4–6 mm²
			• Cable outer diameter: 4.5–7.8 mm

No.	Name	Туре	Specifications
2	(Optional) RS485 communications cable (used to cascade inverters or connect to the RS485 signal port on the SmartLogger)	Two-core outdoor shielded twisted pair cable	 Conductor cross-sectional area: 0.2–1 mm² Cable outer diameter: 4–11 mm
3	(Optional) RS485 communications cable (used to connect to the RS485 signal port on a Smart Power Sensor for export limitation)	Two-core outdoor shielded twisted pair cable	 Conductor cross-sectional area: 0.2–1 mm² Cable outer diameter: 4–11 mm
4	(Optional) Grid scheduling signal cable	Five-core outdoor cable	 Conductor cross-sectional area: 0.2–1 mm² Cable outer diameter: 4–11 mm
5	AC output power cable	Outdoor copper cable ^a	SUN2000-8KTL-M0, SUN2000-10KTL-M0, SUN2000-12KTL-M0: Conductor cross-sectional area: 6–16 mm² Cable outer diameter: 11–26 mm SUN2000-15KTL-M0, SUN2000-17KTL-M0, SUN2000-20KTL-M0: Conductor cross-sectional area: 10–16 mm² Cable outer diameter: 11–26 mm
6	PE cable	Single-core outdoor copper cable ^b	$SUN2000-8KTL-M0, \\ SUN2000-10KTL-M0, \\ SUN2000-12KTL-M0: \\ Conductor cross-sectional \\ area \geq 6 \text{ mm}^2 \\ \\ SUN2000-15KTL-M0, \\ SUN2000-17KTL-M0, \\ SUN2000-20KTL-M0: \\ Conductor cross-sectional \\ area \geq 10 \text{ mm}^2 \\ \\$

- Note a: The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.
- Note b: The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

5.2 Connecting the PE cable

Precautions

A DANGER

- Ensure that the PE cable is properly connected. If it is disconnected or loose, electric shocks may occur.
- Do not connect the neutral wire to the enclosure as a PE cable. Otherwise, electric shocks may occur.

M NOTE

- The PE point at the AC output port is used only as a PE equipotential point, and cannot substitute for the PE point on the enclosure.
- After the ground cable is installed, it is recommended that the silica gel or paint be applied to the ground terminal for protection.

Additional Information

The SUN2000 has the grounding detection function. This function detects whether the SUN2000 is grounded properly before its startup, or whether the ground cable is disconnected when the SUN2000 is running. This function works under limited conditions. To ensure the safe operation of the SUN2000, ground the SUN2000 properly according to the connection requirements of the PGND cable. For some power grid types, if the output side of the inverter is connected to an isolation transformer, ensure that the inverter is properly grounded and set **isolation settings** to **Input not grounded, with a transformer** to enable the inverter to run properly.

- According to IEC62109, to ensure safe application in case of the ground cable is damaged or disconnected, connect the PE cable properly before the grounding detection function is disabled. Ensure that the PE cable meets at least one of the following requirements.
 - The PE cable is a single-core outdoor copper cable with a conductor cross-sectional area of at least 10 mm².
 - Use cables that have the same diameter as the AC output cable, and ground the PE terminal on the AC connector and the ground screw on the enclosure respectively.
- In some countries and regions, additional ground cables are required for the SUN2000. In this case, use cables that have the same diameter as the AC output cable, and ground the PE terminal on the AC connector and the ground screw on the enclosure respectively.


Procedure

Step 1 Crimp the OT terminal.

NOTICE

- Pay attention not to damage the core wire when stripping a cable.
- The cavity formed after crimping the conductor strip of the OT terminal needs to wrap the core wire completely. The core wire needs to contact the OT terminal closely.
- Wrap the wire crimping area with the heat shrink tubing or the PVC insulation tape. The following figure uses the heat shrink tubing as an example.
- When using the heat gun, protect devices from being scorched.

Figure 5-2 Crimping an OT terminal



Step 2 Connect the PE cable.

Figure 5-3 Connecting the PE cable

----End

5.3 Connecting the AC Output Power Cable

Precautions

A three-phase AC switch needs to be installed on the AC side of the SUN2000. To ensure that the SUN2000 can safely disconnect itself from the power grid when an exception occurs, select a proper overcurrent protection device in compliance with local power distribution regulations.




Do not connect loads between the SUN2000 and the AC switch directly connected to it.

The SUN2000 is integrated with a comprehensive residual current monitoring unit. Once detecting that the residual current exceeds the threshold, the SUN2000 immediately disconnects itself from the power grid.

NOTICE

- If the external AC switch can perform earth leakage protection, the rated leakage action current should be greater than or equal to 100 mA.
- If multiple SUN2000s connect to the general residual current device (RCD) through their respective external AC switches, the rated leakage action current of the general RCD should be greater than or equal to the number of SUN2000s multiplied by 100 mA.
- A knife switch cannot be used as an AC switch.
- The hex key is delivered with the inverter and bound to the hanging kit at the bottom of the inverter.


Figure 5-4 Hex key



Procedure

Step 1 Connect the AC output power cable to the AC connector.

Figure 5-5 Stripping requirements



IS06I20048

NOTICE

- Ensure that the cable jacket is inside the connector.
- Ensure that the exposed core wire is totally inserted into the cable hole.
- Ensure that AC terminations provide firm and solid electrical connections. Failing to do so may cause SUN2000 malfunction and damage to its AC connectors.
- Ensure that the cable is not twisted.

Figure 5-6 Three-core cable (L1, L2, and L3)





Figure 5-7 Four-core cable (L1, L2, L3, and PE)




IS10I20015

Figure 5-8 Four-core cable (L1, L2, L3, and N)

IS10I20014

Figure 5-9 Five-core cable (L1, L2, L3, N, and PE)



IS10I20013

∭ NOTE

The cable colors shown in the figures are for reference only. Select an appropriate cable according to local standards.

Step 2 Connect the AC connector to the AC output port.

NOTICE

Ensure that the AC connector is connected securely.


3 M3 (3) (3) (4) (3) (4) (4) (5) (5) Nm

Figure 5-10 Securing the AC connector

IS10H20001

Step 3 Check the route of the AC output power cable.

Figure 5-11 Cable route



----End

Disconnection

Disconnection can be performed in reverse order.

5.4 Connecting the DC input power cable

Precautions

↑ DANGER

- Before connecting the DC input power cable, ensure that the DC voltage is within the safe range (lower than 60 V DC), and that the **DC SWITCH** is set to the **OFF** position. Failure to do so could generate high voltage, which may cause electric shocks.
- When the SUN2000 is operating, it is not allowed to operate the DC input power cable, such as connecting or disconnecting a PV string or a PV module in a PV string. Failing to do so may cause electric shocks.
- If no PV string is connected to a DC input terminal of the SUN2000, do not remove the
 watertight cap from the terminal. Otherwise, the IP rating of the SUN2000 will be
 affected.

MARNING

Ensure that the following conditions are met. Otherwise, the SUN2000 may be damaged, or even a fire could happen.


- PV modules connected in series in each PV string are of the same specifications.
- The open-circuit voltage of each PV string is always lower than or equal to 1080 V DC.
- The maximum short-circuit current of each PV string must be lower than or equal to 15 A.
- The DC input power cable is correctly connected. The positive and negative terminals of a PV module are connected to corresponding positive and negative DC input terminals of the SUN2000.
- If the DC input power cable is reversely connected, do not operate the DC switch and positive and negative connectors. Wait until the solar irradiance declines at night and the PV string current reduces to below 0.5 A, and then turn off the DC switch. Remove the positive and negative connectors to correct the polarity.

NOTICE

- Because the output of the PV string connected to the SUN2000 cannot be grounded, ensure that the PV module output is insulated to ground.
- The PV strings connecting to the same MPPT circuit should contain PV modules of the same model and quantity.
- During the installation of PV strings and the SUN2000, the positive or negative terminals
 of PV strings may be short-circuited to ground if power cables are not properly installed or
 routed. An AC or DC short circuit may occur and damage the device when the SUN2000
 is operating. The caused device damage is not covered under any warranty.

Terminal Description

Figure 5-12 Terminals



- (1) Terminals of DC input 1
- (2) Terminals of DC input 2
- (3) Terminals of DC input 3
- (4) Terminals of DC input 4



It is recommended that the number of PV modules connected to PV1 and PV2 be the same, and that the number of PV modules connected to PV3 and PV4 be the same.

Procedure

Step 1 Connect the DC input power cable.

MWARNING

Before inserting the positive and negative connectors into the positive and negative DC input terminals of the SUN2000, check that the **DC SWITCH** is **OFF**.


⚠ CAUTION

Use the Amphenol Helios H4 PV connectors supplied with the SUN2000. If the PV connectors are lost or damaged, purchase the connectors of the same model. The device damage caused by incompatible PV connectors is not covered under any warranty.

NOTICE

- Cables with high rigidity, such as armored cables, are not recommended as DC input power cables, because poor contact may be caused by the bending of the cables.
- Before assembling DC connectors, label the cable polarities correctly to ensure correct cable connections.
- After crimping the positive and negative metal contacts, pull the DC input power cables back to ensure that they are connected securely.
- Insert the crimped metal contacts of the positive and negative power cables into the appropriate positive and negative connectors. Then pull back the DC input power cables to ensure that they are connected securely.
- Crimp the metal stamping forming contacts using crimping tool H4TC0003 (Amphenol, recommended), H4TC0002 (Amphenol), PV-CZM-22100 (Staubli), or PV-CZM-19100 (Staubli). When choosing PV-CZM-22100 or PV-CZM-19100, do not use the locator. Otherwise metal contacts would be damaged.

Figure 5-13 Crimping tool (H4TC0003)



(1) Locator

\square NOTE

- The DC voltage measurement range of the multimeter must be at least 1100 V.
- If the voltage is a negative value, the DC input polarity is incorrect and needs correction.
- If the voltage is greater than 1080 V, too many PV modules configured in the same string. Remove some PV modules.

Positive connector Positive metal terminal ₩ H4TC0003 (Amphenol) Negative connector Ensure that the cable will 8±10 mm not be extracted after Negative metal terminal crimped. 6 6 Ensure that the locking nut is secured. (Amphenol)

Figure 5-14 Connecting the DC input power cable

IS10I30003

NOTICE

If the DC input power cable is reversely connected and the **DC SWITCH** is set to the **ON** position, do not operate the **DC SWITCH** and positive and negative connectors. Otherwise, the device may be damaged. The caused device damage is not covered under any warranty. Wait until the solar irradiance declines and the PV string current drops to below 0.5 A. Then set the two **DC SWITCH** to the **OFF** position, remove the positive and negative connectors, and rectify the connection of the DC input power cable.

----End


Removing a DC connector

<u>∧</u> WARNING

Before removing the positive and negative connectors, ensure that the **DC SWITCH** is **OFF**.

To remove the positive and negative connectors from the SUN2000, insert an open-end wrench into the notch and press hard to remove the DC connector.

Figure 5-15 Removing a DC connector



5.5 (Optional) Installing the Smart Dongle

Procedure

NOTE


- If the 4G Smart Dongle you purchase is configured with a SIM card, skip this step.
- If it is not configured with a SIM card, prepare a standard one (dimensions: 25 mm x 15 mm, capacity ≥ 64 KB.
- When installing a SIM card, you can determine the SIM card installation direction based on the silk screen and arrow mark on the slot.
- When being pressed into place, the SIM card will be locked, which means that the card is installed correctly.
- To remove the SIM card, push it inwards. Then the SIM card springs out automatically.
- When reinstalling the 4G Smart Dongle, ensure that the buckle springs back in place.

Step 1 Install the Smart Dongle.

Figure 5-16 Installing the Smart Dongle.











IS10H00016

----End

5.6 (Optional) Installing the Signal Cable

Communication port signal definitions

NOTICE

- When routing the signal cable, ensure that it is separate from the power cable and away from interfering sources to prevent communication from being affected.
- The protection layer of the cable is in the connector. Cut off surplus core wires from the protection layer. Ensure that the core wires are completely inserted into the cable holes, and that the cable is securely connected.

Figure 5-17 Signal definitions




Table 5-3 Signal definitions


Pin	Definiti on	Functio n	Descrip tion	Pin	Definiti on	Functio n	Descrip tion
1	485A1-1	RS485 different ial signal+	Used to connect to the RS485	2	485A1-2	RS485 different ial signal+	Used to connect to the RS485
3	485B1-1	RS485 different ial signal—	signal port on the SUN200 0 or SmartLo gger100 0A	4	485B1-2	RS485 different ial signal—	signal port on the SUN200 0 or SmartLo gger100 0A
5	PE	Shieldin g ground	N/A	6	PE	Shieldin g ground	N/A
7	485A2	RS485 different ial signal+	Used to connect to an RS485	8	DIN1	Dry contact interface for grid	Connect s to the Ripple Control

Pin	Definiti on	Functio n	Descrip tion	Pin	Definiti on	Functio n	Descrip tion
9	485B2	RS485 different ial signal—	signal port on a Smart Power Sensor for export limitatio n	10	DIN2	scheduli ng	Device.
11	N/A	N/A	N/A	12	DIN3		
13	GND	Signal ground	N/A	14	DIN4		
15	N/A	N/A	N/A	16	GND		

Communication Networking

• Single Inverter+Smart Dongle Networking


Figure 5-18 Smart Dongle networking



◯ NOTE

- In the Smart Dongle networking scenario, the SmartLogger1000A cannot be connected.
- The Smart Power Sensor is necessary for export limitation. Only the DTSU666-H Smart Power Sensor (provided by Huawei) can be used.
- Multiple Inverters+SmartLogger1000A Networking

Figure 5-19 SmartLogger networking



M NOTE


- In the SmartLogger1000A networking scenario, the Smart Dongle cannot be connected.
- A maximum of 80 devices can connect to a single SmartLogger1000A, such as inverters, Smart Power sensor, and EMI. You are advised to connect fewer than 30 devices to each RS485 route.
- The Smart Power Sensor is a necessary export limitation. Select the Smart Power Sensor according to the actual project.
- To ensure the system response speed, the Smart Power Sensor is recommended to be connected to a COM port separately from inverter COM port.

5.6.1 Connecting the RS485 Communications Cable (Inverter Cascading)

Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-20 Installing the cable



Step 2 Connect the signal cable connector to the COM port.

Figure 5-21 Securing the signal cable connector



IS10I20007

----End

5.6.2 Connecting the RS485 Communications Cable (Smart Power Sensor)

Cable Connection

The following figure shows the cable connections between the inverter and the Smart Power Sensor.

L3 L2 L1 (3) (9) 10 (6) IA* IΑ IB* DTSU666-H ΙB IC* 13 14 16 17 19 21 24 25 IC [2]

Figure 5-22 Cable connection


(1) Shielding layer of the signal cable

Procedure

Step 1 Connect the signal cable to the signal cable connector.


IH05N00001

Figure 5-23 Installing the cable



Step 2 Connect the signal cable to the COM port.

Figure 5-24 Securing the signal cable connector




----End

5.6.3 Connecting the Power Grid Scheduling Signal Cable

Cable Connection

The following figure shows the cable connections between the inverter and the Ripple Control Device.


Figure 5-25 Cable connection



Procedure


Step 1 Connect the signal cable to the signal cable connector.

Figure 5-26 Installing the cable



Step 2 Connect the signal cable to the COM port.

Figure 5-27 Securing the signal cable connector



IS10I20007

----End

6 Commissioning

6.1 Check Before Power-On

Table 6-1 Installation checklist

No.	Check Item	Acceptance Criteria		
1	SUN2000 installation	The SUN2000 is installed correctly, securely, and reliably.		
2	Smart Dongle	The Smart Dongle is installed correctly and securely.		
3	Cable layout	Cables are routed properly as required by the customer.		
4	Cable tie	Cable ties are secured evenly and no burr exists.		
5	Grounding	The ground cable is connected correctly, securely, and reliably.		
6	Turn off the switches	The DC SWITCH and all the switches connected to the SUN2000 are set to OFF .		
7	Cable connections	The AC output power cable and DC input power cable are connected correctly, securely, and reliably.		
8	Unused terminals and ports	Unused terminals and ports are locked by watertight caps.		
9	Installation environment	The installation space is proper, and the installation environment is clean and tidy, without foreign matter.		

6.2 Powering On the System

Precautions

NOTICE

Before turning on the AC switch between the SUN2000 and the power grid, use a multimeter set to the AC position to check that the AC voltage is within the specified range.

Procedure

Step 1 Turn on the AC switch between the SUN2000 and the power grid.

NOTICE

If the DC is on and the AC is off, the SUN2000 reports a **Grid Failure** alarm. The SUN2000 starts normally only after the fault is automatically rectified.

- Step 2 If there is a DC switch between the PV string and the inverter, turn on the DC switch.
- **Step 3** Set the **DC SWITCH** at the bottom of the SUN2000 to the **ON** position.
- **Step 4** Wait for about 1 minute, and then observe the LED indicators of the inverter to check the running status.

Table 6-2 LED indicator description

Category	Status		Meaning
Running indication	LED1	LED2	N/A
	Steady green	Steady green	The SUN2000 is operating in gridtied mode.
LED1 LED2	Blinking green at long intervals (on for 1s and then off for 1s)	Off	The DC is on and the AC is off.
	Blinking green at long intervals (on for 1s and then off for 1s)	Blinking green at long intervals (on for 1s and then off for 1s)	The DC is on, the AC is on, and the SUN2000 is not exporting power to the power grid.
	Off	Off	The DC is off. ^a
	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	N/A	DC environmental alarm

Category	Status		Meaning			
	N/A	Blinking red at short intervals (on for 0.2s and then off for 0.2s)	AC environmental alarm			
	Steady red	Steady red	Fault			
Communica	LED3		N/A			
tion indication S[]~ (p) O O O	Blinking green at short intervals (on for 0.2s and then off for 0.2s)		Communication is in progress. (When a mobile phone is connected to the SUN2000, the indicator first indicates that the phone is connected to the SUN2000): blinks green at long intervals.)			
	Blinking green at long intervals (on for 1s and then off for 1s)		The mobile phone is connected to the SUN2000.			
	Off		There is no communication.			
Note a: The A	C may be on. Che	Note a: The AC may be on. Check whether the external AC switch is OFF.				

----End

6.3 Commissioning

6.3.1 Scenario 1: Single inverter + Smart Dongle

Downloading the App

Search for "FusionSolar" from the following app stores or scan the corresponding QR code, download the installation package, and install the FusionSolar app by following the instructions.

- Google Play (Android)
- App Store (iOS)

Figure 6-1 FusionSolar QR code



M NOTE

The screenshots shown in the document are from FusionSolar 2.3.0. Data in the screenshots is for reference only. The actual screens prevail.

In Britain, only the FusionHome app can be used for commissioning. This document uses the FusionSolar app as an example to describe the commissioning method. For the FusionHome app, perform operations as required.

Search for "FusionHome" from the following app stores or scan the corresponding QR code, download the installation package, and install the FusionHome app by following the instructions.

- Google Play (Android)
- App Store (iOS)

Figure 6-2 FusionHome QR code



M NOTE

- The initial password for connecting the inverter WiFi is Changeme
- Log in to the FusionHome app as installer. The initial password is 00000a.
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.


(Optional) Installer Account Registration

Creating the first installer account will generate a domain named after the company.

NOTE

If you have an installer account, skip this step.


Figure 6-3 Creating the first installer account



NOTICE


To create multiple installer accounts for the same company, log in to the FusionSolar app and tap **New User**.

Figure 6-4 Creating multiple installer accounts for the same company



Creating a PV Plant and an Account for User

Figure 6-5 Creating a PV Plant and an Account for User



NOTE

For details, see the FusionSolar App Quick Guide.

You can scan the QR code to obtain it.



6.3.2 Scenario 2: Multiple Inverters + SmartLogger1000A

See the Distributed PV Plants Connecting to Huawei Hosting Cloud Quick Guide (Distributed Inverters + SmartLogger1000A + RS485 Networking).

You can scan the QR code to obtain it.



6.3.3 Other Scenarios

1. Access **Inverter commissioning**.

Figure 6-6 Method 1: before login



Figure 6-7 Method 2: after login




2. Connect to the inverter WiFi. Log in as **installer**, and perform **Quick settings**.

M NOTE

- When the inverter is directly connected to the mobile phone using the built-in antenna, the distance between the inverter and mobile phone must be less than 5 m without obstructions in between to ensure the communication quality between the FusionSolar app and inverter. The distance is for reference only and may vary depending on mobile phones and whether there are obstructions between the inverter and the mobile phone.
- When connecting the SUN2000L to the FusionSolar app over a router, ensure that the mobile phone and inverter are in the WiFi coverage of the router and the SUN2000L is connected to the router.
- $\bullet \quad \text{The router supports WiFi (IEEE 802.11 b/g/n, 2.4 GHz) and the WiFi signal reaches the inverter.} \\$

The WPA, WPA2, or WPA/WPA2 encryption mode is recommended for routers. Enterprise-level
encryption is not supported (for example, public hotspots requiring authentication such as airport
WiFi). WEP and WPA TKIP are not recommended because these two encryption modes have serious
security defects. If the inverter cannot be connected using WEP, log in to the router and change the
encryption mode to WPA2 or WPA/WPA2.


Figure 6-8 Quick settings



☐ NOTE

- The initial password for connecting the inverter WiFi is Changeme
- The initial password of the installer is 00000a
- Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.
- To set more parameters, tap **Parameter configuration**.
- 3. (Optional) When multiple inverters are connected to a third-party data collector, set RS485 parameters.

Figure 6-9 RS485 Settings



M NOTE

The RS485 addresses of different inverters must be different.

6.4 Powering Off the System

Precautions

⚠ WARNING

After the SUN2000 is powered off, the remaining electricity and heat may still cause electric shocks or body burns. Therefore, put on protective gloves and operate the SUN2000 five minutes after the power-off.

Procedure

- **Step 1** Send a shutdown command from the app.
- Step 2 Turn off the AC switch between the SUN2000 and the power grid.
- **Step 3** Set the **DC SWITCH** at the bottom of the SUN2000 to the **OFF** position.
- **Step 4** Turn off the DC switch between the PV string and the SUN2000 if there is one.

----End

7 Maintenance

7.1 Routine Maintenance

To ensure that the SUN2000 can operate properly for a long term, you are advised to perform routine maintenance on it as described in this chapter.

⚠ CAUTION

Before cleaning the system, connecting cables, and maintaining the grounding reliability, power off the system.

Table 7-1 Maintenance list

Check Detail	Check Method	Maintenance Interval
System cleanliness	Check the heat sink for foreign matter or the overall health of the SUN2000.	Annual or every time an abnormality is detected
System running status	Check the SUN2000 for damage or deformation.	Annual
Electrical connections	 Cables are securely connected. Cables are intact, in particular, the parts touching the metallic surface are not scratched. 	The first inspection is 6 months after the initial commissioning. From then on, the interval can be 6 to 12 months.
Grounding reliability	Check whether the ground terminal and ground cable are securely connected.	Annual
Sealing	Check whether all terminals and ports are properly sealed.	Annual

7.2 Troubleshooting

Alarm severities are defined as follows:

- Major: The inverter is faulty. As a result, the output power decreases or the grid-tied power generation is stopped.
- Minor: Some components are faulty without affecting the grid-tied power generation.
- Warning: The inverter works properly. The output power decreases or some authorization functions fail due to external factors.

Table 7-2 Common alarms and troubleshooting measures

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2001	High String Input Voltage	Major	Excessive PV modules are connected in series in the PV array. Therefore, the open-circuit voltage exceeds the maximum input voltage of the SUN2000. Cause ID 1 = PV1 and PV2 Cause ID 2 = PV3 and PV4	Check the number of PV modules connected in series in the PV string, and ensure that the PV string open-circuit voltage is no greater than the maximum operating voltage of the SUN2000. After you correctly configure the PV array, the inverter alarm disappears automatically.
2002	DC Arc Fault	Major	The PV string power cable arcs or is in poor contact. Cause ID 1 = PV1 and PV2 Cause ID 2 = PV3 and PV4	Check whether the string cables arc or are in poor contact.
2011	String Reversed	Major	The PV string is reversely connected. Cause ID 1 = PV1 Cause ID 2 = PV2 Cause ID 3 = PV3 Cause ID 4 = PV4	Check whether the PV string is reversely connected to the SUN2000. If so, wait until the solar irradiance declines at night and the PV string current drops to below 0.5 A. Then, set the DC SWITCH to the OFF position, and correct the string polarity.
2012	String Current Backfeed	Warning	Only a few PV modules are connected in series in the PV string. Therefore, the end voltage is lower than that of other PV strings. Cause ID 1 = PV1 Cause ID 2 = PV2 Cause ID 3 = PV3 Cause ID 4 = PV4	1. Check whether the number of PV modules connected in series to this PV string is less than the number of PV modules connected in series to the other PV strings connected in parallel with this PV string. If yes, wait until the PV string current drops below 0.5 A, set DC SWITCH to OFF, and adjust the number of PV modules in the PV string. 2. Check whether the PV string is shaded. 3. Check whether the open-circuit voltage of the PV string is normal.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2031	Power grid phase wire short- circuit to PE	Major	Cause ID = 1 The impedance of the output phase wire is low or short-circuited to PE.	Check the impedance of the output phase wire to PE, locate the position with lower impedance and restore that.
2032	Grid Failure	Major	 Cause ID = 1 The power grid experiences an outage. The AC circuit is disconnected or the AC switch is off. 	 Check the AC voltage. Check whether the AC circuit is disconnected or whether the AC switch is off.
2033	Grid Undervolt age	Major	Cause ID = 1 The power grid voltage is below the lower threshold or the undervoltage duration exceeds the value specified by LVRT.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If no, contact the local power operator. If yes, log in to the mobile phone app, SmartLogger, or NMS to modify the grid undervoltage protection threshold with the consent of the local power operator. If the fault persists for a long time, check the connection between the AC switch and the output power cable.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2034	Grid Overvolta ge	Major	Cause ID = 1 The power grid voltage is beyond the upper threshold or the overvoltage duration exceeds the value specified by HVRT.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If no, contact the local power operator. If yes, log in to the mobile phone app, SmartLogger, or NMS to modify the grid overvoltage protection threshold with the consent of the local power operator. Check whether the peak voltage of the power grid is too high. If the fault persists and cannot be rectified for a long time, contact the power operator.
2035	Unbalance d Grid Voltage	Major	Cause ID = 1 The difference between grid phase voltages exceeds the upper threshold.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the grid voltage is within the acceptable range. If no, contact the local power operator. If the fault persists for a long time, check the connection between the AC switch and the output power cable.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2036	Grid Overfrequ ency	Major	Cause ID = 1 Power grid exception: The actual power grid frequency is higher than the standard requirement for the local power grid.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the grid frequency is within the acceptable range. If no, contact the local power operator. If yes, log in to the mobile phone app, SmartLogger, or NMS to modify the grid overfrequency protection threshold with the consent of the local power operator.
2037	Grid Underfreq uency	Major	Cause ID = 1 Power grid exception: The actual power grid frequency is lower than the standard requirement for the local power grid.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the grid frequency is within the acceptable range. If no, contact the local power operator. If yes, log in to the mobile phone app, SmartLogger, or NMS to modify the grid underfrequency protection threshold with the consent of the local power operator.
2038	Unstable Grid Frequency	Major	Cause ID = 1 Power grid exception: The actual grid frequency change rate does not comply with the local power grid standard.	 If the alarm occurs occasionally, the power grid may be abnormal temporarily. The SUN2000 automatically recovers after detecting that the power grid becomes normal. If the alarm occurs frequently, check whether the power grid frequency is within the acceptable range. If not, contact the local power operator.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2039	Output Overcurre nt	Major	Cause ID = 1 The power grid voltage drops dramatically or the power grid is short-circuited. As a result, the SUN2000 transient output current exceeds the upper threshold and therefore the protection is triggered.	 The SUN2000 detects its external working conditions in real time. After the fault is rectified, it automatically recovers. If the alarm occurs frequently and affects the power production of the PV plant, check whether the output is short-circuited. If the fault persists, contact your dealer or Huawei technical support.
2040	Output DC Compone nt Overhigh	Major	Cause ID = 1 The DC component of the SUN2000 output current exceeds the specified upper threshold.	 The SUN2000 detects its external working conditions in real time. After the fault is rectified, it automatically recovers. If the alarm occurs frequently, contact your dealer or Huawei technical support.
2051	Abnormal Residual Current	Major	Cause ID = 1 The insulation impedance of the input side to PE decreases when the SUN2000 is operating.	 If the alarm occurs occasionally, the external power cable may be abnormal temporarily. The SUN2000 automatically recovers after the fault is rectified. If the alarm occurs frequently or persists, check whether the impedance of the PV string to ground is excessively low.
2061	Abnormal Groundin g	Major	 Cause ID = 1 The N cable or ground cable is not connected. When a PV array is grounded, the inverter output is not connected to an isolation transformer. 	Power off the inverter and check the following items: 1. Check whether the PE cable of the SUN2000 is connected properly. 2. If the inverter is connected to the TN power grid, check whether the N cable is properly connected and whether the voltage of the N cable to ground is normal. 3. Check whether the output is connected to an isolation transformer. If yes, set Grounding inspection to Disable through the mobile phone app, SmartLogger, or NMS.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2062	Low Insulation Resistance	Major	 Cause ID = 1 PV arrays are short-circuited with PE. The ambient air of the PV array is damp and the insulation between the PV array and the ground is poor. 	 Check the output resistance of the PV array to ground. If there is a short circuit or lack of insulation, rectify it. Check that the PE cable of the SUN2000 is correctly connected. If you are sure that the impedance is less than the default value in a cloudy or rainy environment, log in to the mobile phone app, SmartLogger, or NMS and reset the insulation impedance protection threshold.
2063	Overtemp	Minor	 Cause ID = 1 The SUN2000 is installed in a place with poor ventilation. The ambient temperature is too high. The SUN2000 is not working properly. 	 Check the ventilation and ambient temperature of the SUN2000 installation position. If the ventilation is poor or the ambient temperature exceeds the upper threshold, improve the ventilation and heat dissipation. If the ventilation and ambient temperature both meet requirements, contact your dealer or Huawei technical support.
2064	Device Fault	Major	Cause ID = 1–12 An unrecoverable fault has occurred on a circuit inside the SUN2000.	Turn off the AC output switch and DC input switch, and then turn them on after 5 minutes. If the fault persists, contact your dealer or Huawei technical support. Note: If the cause ID is ID 1, perform the preceding operation when the PV string current is less than 1 A.
2065	Upgrade Failed or Software Version Unmatch	Minor	Cause ID = 1, 2 and 4 The upgrade does not end normally. NOTE Upgrade the inverter again if it is stuck in initialization state without generating any alarms and cannot be restored to the normal state during the upgrade when the PV inputs are disconnected and reconnected next time.	Perform the upgrade again. If the upgrade fails several times, contact your dealer or Huawei technical support.

Alarm ID	Alarm Name	Alarm Severity	Possible Cause	Troubleshooting Suggestion
2066	License Expired	Minor	 Cause ID = 1 The privilege certificate has entered the grace period. The privilege feature will be invalid soon. 	 Apply for a new certificate. Load the new certificate.
61440	Monitorin g Unit Faulty	Minor	 Cause ID = 1 1. The flash memory is insufficient. 2. The flash memory has bad sectors. 	Turn off the AC output switch and then the DC input switch. After 5 minutes, turn on the AC output switch and then the DC input switch. If the fault persists, replace the board, If the upgrade fails several times, contact your dealer or Huawei technical support.
2067	Faulty Power Collector	Major	Cause ID = 1 The power meter communication is interrupted.	 Check that the power meter settings are based on the actual model. Check that the communications parameters for the power meter are the same as the SUN2000 RS485 parameter settings. Check that the power meter is powered on, and the RS485 cable is connected correctly.
2072	Transient AC Overvolta ge	Major	Cause ID = 1 The inverter detects that the phase voltage exceeds the transient AC overvoltage protection threshold.	 Check whether the grid connection voltage exceeds the upper threshold. If yes, contact the local power operator. If you have confirmed that the grid-tied voltage exceeds the upper threshold and have obtained the consent of the local power operator, modify the overvoltage protection threshold through the mobile phone app, SmartLogger, or NMS. Check whether the peak power grid voltage exceeds the upper threshold.

$\begin{picture}(10,0) \put(0,0){\line(0,0){100}} \put(0,0){\line(0,0){100$

Contact your dealer or Huawei technical support if the measures listed in the **Troubleshooting Suggestion** column have been taken but the fault persists.

8 Handling the Inverter

8.1 Removing the SUN2000

NOTICE

Before removing the SUN2000, disconnect both the AC and DC power supplies. After powering off the SUN2000, wait at least 5 minutes before performing operations on the SUN2000.

Perform the following operations to remove the SUN2000:

- 1. Disconnect all cables from the SUN2000, including RS485 communications cables, DC input power cables, AC output power cables, and PGND cables.
- 2. Remove the SUN2000 from the mounting bracket.
- 3. Remove the mounting bracket.

8.2 Packing the SUN2000

- If the original packing materials are available, put the SUN2000 inside them and then seal them by using adhesive tape.
- If the original packing materials are not available, put the SUN2000 inside a suitable cardboard box and seal it properly.

8.3 Disposing of the SUN2000

If the SUN2000 service life expires, dispose of it according to the local disposal rules for electrical equipment waste.

9 Technical Data

NOTICE

The SUN2000-8KTL-M0 and SUN2000-10KTL-M0 inverters are applicable only to Australia.

Efficiency

Technical Specificati ons	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL-M0	SUN2000- 20KTL-M0
Maximum efficiency	98.5%	98.5%	98.5%	98.65%	98.65%	98.65%
European efficiency	98.0%	98.0%	98.0%	98.3%	98.3%	98.3%

Input

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0
Maximum input voltage ^a	1080 V					
Maximum input current (per MPPT)	22 A					
Maximum short-circuit current (per MPPT)	30 A					

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0
Maximum inverter backfeed current to the PV array	0 A					
Minimum startup voltage	200 V					
Operating voltage range ^b	160–950 V					
Full-load MPPT voltage range	320–850 V	320–850 V	380–850 V	380–850 V	400–850 V	480–850 V
Rated input voltage	600 V					
Number of input routes	4					
Number of MPP trackers	2					

Note a: The maximum input voltage is the upper threshold of the DC voltage. If the input voltage exceeds the threshold, the solar inverter may be damaged.

Note b: If the input voltage is beyond the operating voltage range, the solar inverter cannot work properly.

Output

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0	
Rated active power	8000 W	10000 W	12000 W	15000 W	17000 W	20000 W	
Maximum apparent power	8800 VA	11000 VA	13200 VA	16500 VA	18700 VA	22000 VA	
Maximum active power (cosφ = 1)	8800 W	11000 W	13200 W	16500 W	18700 W	22000 W	
Rated output voltage	220/380 V, 2	220/380 V, 230/400 V, 3W+(N)+PE					

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0	
Rated output current	12.8 A (380 V)/11.6 A (400 V)	15.9 A (380 V)/14.5 A (400 V)	18.2 A (380 V)/17.3 A (400 V)	22.8 A (380 V)/21.7 A (400 V)	25.8 A (380 V)/24.6 A (400 V)	30.4 A (380 V)/28.9 A (400 V)	
Maximum output current	13.4 A	17 A	20 A	25.2 A	28.5 A	33.5 A	
Adapted power grid frequency	50/60 Hz						
Power factor	0.8 leading	0.8 lagging					
Maximum total harmonic distortion (rated power)	< 3%						
Inrush current	153 A (peak	current, duration	ı < 33 μ s)				
Maximum output fault current	237 A (peak	237 A (peak current, duration < 1ms)					
Maximum output overcurrent protection	13.45 A	13.45 A					

Protection and Feature

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0
AFCI	Yes					
Input DC switch	Yes					
Anti- islanding protection	Yes					
Output overcurrent protection	Yes					

User Manual 9 Technical Data

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0
Output short- circuit protection	Yes					
Output overvoltage protection	Yes					
Input reverse connection protection	Yes					
PV string fault detection	Yes					
DC surge protection	Yes					
AC surge protection	Yes					
Insulation resistance detection	Yes					
Residual current monitoring unit (RCMU)	Yes					

Display and Communication

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000 -17KTL- M0	SUN2000- 20KTL-M0	
Display	LED indicato	ors; WLAN+app					
RS485	Yes						
Communicati ons expansion module	(Optional) W	(Optional) WLAN/4G					
Remote dry contact scheduling	Yes						

Common Parameters

Technical Specificatio ns	SUN2000- 8KTL-M0	SUN2000- 10KTL-M0	SUN2000- 12KTL-M0	SUN2000- 15KTL-M0	SUN2000- 17KTL- M0	SUN2000- 20KTL-M0	
Dimensions (W x H x D)	525mm×470r	nm×262mm					
Net weight	25 kg						
Operating temperature	-25°C to +60	°C (derated at +	45°C or higher)				
Cooling mode	Natural conve	Natural convection					
Highest operating altitude	0–4000 m (de	0-4000 m (derated above 2000 m)					
Relative humidity	0%-100% RI	H					
Input terminal	Amphenol He	elios H4					
Output terminal	Waterproof q	Waterproof quick-connect terminal					
IP rating	IP65	IP65					
Topology	No transform	er					



■ NOTE

The grid codes are subject to change. The listed codes are for your reference only.

Table A-1 Grid Codes

No.	Grid Codes	Description
1	VDE-AR-N-4105	Germany low-voltage power grid
2	UTE C 15-712-1 (A)	France mainland low-voltage power grid
3	UTE C 15-712-1 (B)	France island power grid (230 V 50 Hz)
4	UTE C 15-712-1 (C)	France island power grid (230 V 60 Hz)
5	VDE 0126-1-1-BU	Bulgaria low-voltage power grid
6	VDE 0126-1-1-GR (A)	Greece mainland low-voltage power grid
7	VDE 0126-1-1-GR (B)	Greece island low-voltage power grid
8	BDEW-MV	Germany medium-voltage power grid
9	G59-England	England 230 V power grid (I > 16 A)
10	G59-Scotland	Scotland 240 V power grid (I > 16 A)
11	G83-England	England 230 V power grid (I < 16 A)
12	G83-Scotland	England 240 V power grid (I < 16 A)
13	CEI0-21	Italy low-voltage power grid
14	EN50438-CZ	Czech Republic low-voltage power grid
15	RD1699/661	Spain low-voltage power grid
16	EN50438-NL	Netherlands low-voltage power grid

No.	Grid Codes	Description	
17	C10/11	Belgium low-voltage power grid	
18	AS4777	Australia low-voltage power grid	
19	IEC61727	IEC61727 low-voltage power grid (50 Hz)	
20	User-defined (50 Hz)	Reserved	
21	User-defined (60 Hz)	Reserved	
22	CEI0-16	Italy low-voltage power grid	
23	TAI-PEA	Thailand low-voltage power grid (PEA)	
24	TAI-MEA	Thailand low-voltage power grid (MEA)	
25	EN50438-TR	Turkey low-voltage power grid	
26	Philippines	Philippines low-voltage power grid	
27	NRS-097-2-1	South Africa low-voltage power grid	
28	KOREA	South Korea low-voltage power grid	
29	IEC61727-60Hz	IEC61727 low-voltage power grid (60 Hz)	
30	ANRE	Romania low-voltage power grid	
31	EN50438_IE	Ireland low-voltage power grid	
32	PO12.3	Spain low-voltage power grid	
33	Egypt ETEC	Egypt medium-voltage power grid	
34	CLC/TS50549_IE	Ireland low-voltage power grid	
35	Jordan-Transmission	Jordan low-voltage power grid	
36	NAMIBIA	Namibia low-voltage power grid	
37	ABNT NBR 16149	Brazil low-voltage power grid	
38	SA_RPPs	South Africa low-voltage power grid	
39	INDIA	India low-voltage power grid	
40	ZAMBIA	Zambia low-voltage power grid	
41	Chile	Chile low-voltage power grid	
42	Malaysian	Malaysia low-voltage power grid	
43	KENYA_ETHIOPIA	Kenya low-voltage power grid and Ethiopia low-voltage power grid	
44	NIGERIA	Nigeria low-voltage power grid	

No.	Grid Codes	Description	
45	DUBAI	Dubai low-voltage power grid	
46	Northern Ireland	Northern Ireland low-voltage power grid	
47	Cameroon	Cameroon low-voltage power grid	
48	Jordan-Distribution	Jordan power distribution network low-voltage power grid	
49	LEBANON	Lebanon low-voltage power grid	
50	TUNISIA	Tunisia low-voltage power grid	
51	AUSTRALIA-NER	Australia NER standard low-voltage power grid	
52	SAUDI	Saudi Arabia low-voltage power grid	
53	Israel	Israel low-voltage power grid	
54	Chile-PMGD	Chile PMGD low-voltage power grid	
55	VDE-AR-N4120_HV	VDE41200 standard low-voltage power grid	
56	Vietnam	Vietnam low-voltage power grid	
57	TAIPOWER	Taiwan low-voltage power grid	
58	OMAN	Oman low-voltage power grid	
59	KUWAIT	Kuwait low-voltage power grid	
60	BANGLADESH	Bangladesh low-voltage power grid	
61	CHILE_NET_BILLING	Chile Net Billing low-voltage power grid	
62	BAHRAIN	Bahrain low-voltage power grid	
63	Fuel-Engine-Grid	DG hybrid low-voltage power grid (50 Hz)	
64	Fuel-Engine-Grid-60Hz	DG hybrid low-voltage power grid (60 Hz)	
65	ARGENTINA	Argentina low-voltage power grid	
66	Mauritius	Mauritius low-voltage power grid	
67	EN50438-SE	Sweden low-voltage power grid	
68	Austria	Austria	
69	G99-TYPEA-LV	United Kingdom	
70	G99-TYPEB-LV	United Kingdom	
71	G99-TYPEB-HV	United Kingdom	

A Grid Codes

No.	Grid Codes	Description
72	G99-TYPEA-HV	United Kingdom


B Setting Dry Contact Scheduling Parameters

Scenario 1: Single inverter + Smart Dongle

Prerequisites

You have logged in to the app as **installer**. The initial password is **00000a**. Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

Procedure



Hz

Hz

Hz

>




Figure B-1 Setting dry contact scheduling parameters

----End

Scenario 2: Multiple Inverters + SmartLogger1000A

See the SmartLogger1000A User Manual.



Scenario 1: Single inverter + Smart Dongle

Prerequisites

You have logged in to the app as **installer**. The initial password is **00000a**. Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

Procedure

Step 1 Set export limitation parameters.

6 .d 3 Grid-tied point control > > + Add/Delete device 1 Upgrade device (II) Performance data > Device information Energy control (2) Alarm > (b) Inverter ON/OFF Quick settings Parameter configuration Restore defaults Clear data Adjust total energy yield Restart Communication configuration Log management Energy control Grid-tied point control Grid-tied point control Grid connected with zero power Control mode Please re-enter the password to confirm : Closed-loop controller External controller 🗸 6 4 Cancel

Figure C-1 Setting export limitation parameters

Table C-1 Setting export limitation parameters

Parameter	Value Range	Description
Control mode	Not restricted Grid connected with zero power Power-limited grid connected	 If this parameter is set to Not restricted, the SUN2000 output power is not limited. The SUN2000 can export its rated power to the power grid. If this parameter is set to Grid connection with zero power and the SUN2000 is connected to a power meter, the output power of the SUN2000 is supplied only to the local load, but not the power grid. If this parameter is set to Power-limited grid connection and the SUN2000 is connected to a Smart power sensor, the SUN2000 supplies power limited based on the setting of Grid-tied Point Power to the power grid.
Closed-loop controller	External controllerInverter	 Set this parameter to External controller when the SmartLogger1000A is connected. If multiple inverters are cascaded, set this parameter to External controller. If a single inverter is used, set this parameter to Inverter.

----End

Scenario 2: Multiple Inverters + SmartLogger1000A

See the SmartLogger1000A User Manual.



Scenario 1: Single inverter + Smart Dongle

Prerequisites

You have logged in to the app as **installer**. The initial password is **00000a**. Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

Procedure

Step 1 Set voltage rise suppression Q-U curve parameters.




Figure D-1 Setting voltage rise suppression Q-U curveparameters

----End

Scenario 2: Multiple Inverters + SmartLogger1000A

See the SmartLogger1000A User Manual.

E Starting AFCI Check


Prerequisites

You have logged in to the app as **installer**. The initial password is **00000a**. Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.

Procedure

Step 1 On the **Home** screen, choose **Device maintenance** > **Start AFCI check** and perform the required operation.

Figure E-1 Start AFCI check



----End

F IPS Test (for Italy CEI0-21 Grid Code only)

Prerequisites

You have logged in to the app as **installer**. The initial password is **00000a**. Use the initial password upon first power-on and change it immediately after login. To ensure account security, change the password periodically and keep the new password in mind. Not changing the initial password may cause password disclosure. A password left unchanged for a long period of time may be stolen or cracked. If a password is lost, devices cannot be accessed. In these cases, the user is liable for any loss caused to the PV plant.


Context

The Italy CEI0-21 grid code requires an IPS test for the SUN2000. During the IPS test process, the SUN2000 consecutively tests the protection thresholds and time for 10-min overvoltage, level 1 overvoltage, level 1 overfrequency, and level 1 underfrequency. The SUN2000 shuts down after the IPS test starts, and it restarts after the IPS test is successful.

Procedure

Step 1 On the Home screen, choose Device maintenance > IPS test to access the IPS test screen.

Figure F-1 IPS test



Step 2 Choose to start the S1 or S2 check as required. The default check type is S2. To start the S2 check, you need to set **External Signal** or **Local Command**.

Table F-1 IPS test type description

IPS Test Type	Description	External Signal Setting	Local Command Setting
S1	The level 1 overfrequency protection threshold is 50.5 Hz and the level 1 underfrequency protection threshold is 49.5 Hz.		•
S2	The level 1 overfrequency protection threshold is 51.5 Hz and the level 1 underfrequency protection threshold is 47.5 Hz.	•	

IPS Test Type	Description	External Signal Setting	Local Command Setting
S2 (default)	The level 1 overfrequency protection threshold is 51.5 Hz and the level 1 underfrequency protection threshold is 47.5 Hz.		
S2	The level 1 overfrequency protection threshold is 51.5 Hz and the level 1 underfrequency protection threshold is 47.5 Hz.		

Step 3 Tap Start to start the IPS test. After the IPS test is complete, IPS State is displayed as IPS state success. Tap Reports in the upper right corner of the IPS test screen to view IPS Self-Check Report.

----End

G DRM Configuration Guide for Standard AS NZS4777.2

If Demand Response Modes are required, then the installer will need to connect the Huawei SmartLogger1000A. Refer to the Huawei document SmartLogger1000A User Manual for Standard AS NZS4777.2 of how to connect the DRED and how to configure the inverter and Smart Logger for use with the DRED.

H Acronyms and Abbreviations

A

ACDU alternating current distribution unit

AFCI arc-fault circuit interrupter

 \mathbf{L}

LED light emitting diode

M

MPP maximum power point

MPPT maximum power point tracking

P

PV photovoltaic

R

RCD residual current device

W

WEEE waste electrical and electronic equipment