



Micro Hi-Fi System

MCM108
MCM108B
MCM108C

User manual

使用説明





Controls on the system and remote control

① BAND

- for Tuner (on the set only) selects waveband.

② SOURCE (CD/TUNER/AUX)

- switches on the system.
- selects the respective sound source for CD/FM/ MW/ AUX.

③ STANDBY-ON / ⏻

- switches the system to standby/on.

④ PROG/CLOCK

for CD programs tracks and reviews the program.

for clock sets the clock function.

⑤ OPEN•CLOSE

- opens/closes the CD door.

⑥ VOLUME – / +

- adjusts volume level.

⑦ TUNING ●

- tunes to radio stations.

⑧ IR SENSOR

- infrared sensor for remote control.

⑨ 🎧

- connect headphones.

⑩ ▶ II

for CD starts or pauses CD playback.

⑪ ⏮ / ⏭

- skips to the beginning of a current track/previous/ next track.
- fast searches back and forward within a track/ CD.

⑫ STOP ■

- stops CD playback or erase a CD program.

⑬ AUX IN

- connects to external audio source.

⑭ MUTE

- switches playback sound off and on.

⑮ REPEAT

- repeats a track/ disc/ all programmed tracks.

⑯ SHUFF (SHUFFLE)

- plays CD/MP3 tracks in random order.

⑰ SLEEP

- activates/deactivates or selects the sleeper time.

⑱ TIMER

- activates/deactivates or sets the timer function.

⑲ ALBUM ▼ ▲


for MP3 disc.....selects an album.

⑳ DBB

- (Dynamic Bass Boost) enhances the bass.

㉑ DSC

- (Digital Sound Control) selects sound characteristics: JAZZ/POP/CLASSIC/ROCK.



Notes for remote control:

- First select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- Then select the desired function (for example ▶, ⏮, ⏭).

General Information

Supplied accessories

- 2 speaker boxes
- remote control with 1 x CR2032 battery
- MW loop antenna

Environmental Information


All unnecessary packaging has been omitted. We have tried to make the packaging easy to separate into three materials: cardboard (box), polystyrene foam (buffer) and polyethylene (bags, protective foam sheet).

Your system consists of materials which can be recycled and reused if disassembled by a specialized company. Please observe the local regulations regarding the disposal of packaging materials, exhausted batteries and old equipment.

Safety Information

- Before operating the system, check that the operating voltage indicated on the typeplate (or the voltage indication beside the voltage selector) of your system is identical with the voltage of your local power supply. If not, please consult your dealer.
- Place the system on a flat, hard and stable surface.
- Where the MAINS plug or an appliance coupler is used as the disconnct device, the disconnct device shall remain readily operable.
- Install the unit near the AC outlet and where the AC power plug can be easily reached.
- The apparatus shall not be exposed to dripping or splashing.
- Place the system in a location with adequate ventilation to prevent internal heat build-up in your system. Allow at least 10 cm (4 inches) clearance from the rear and the top of the unit and 5 cm (2 inches) from each side.
- The ventilation should not be impeded by covering the ventilation openings with items, such as newspapers, table-cloths, curtains, etc.
- Do not expose the system, batteries or discs to excessive moisture, rain, sand or heat sources caused by heating equipment or direct sunlight.
- No naked flame sources, such as lighted candles, should be placed on the apparatus.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.
- If the system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens of the disc unit inside the system. Should this occur, the CD player would not operate normally. Leave the power on for about one hour with no disc in the system until normal playback is possible.
- The mechanical parts of the set contain self-lubricating bearings and must not be oiled or lubricated.
- **When the system is switched to Standby mode, it is still consuming some power. To disconnect the system from the power supply completely, remove the AC power plug from the wall socket.**

Preparations



Rear connections

The type plate is located at the rear of the system.

A Power

– Before connecting the AC power cord to the wall outlet, ensure that all other connections have been made.


WARNING!

- **For optimal performance, use only the original power cable.**
- **Never make or change any connections with the power switched on.**

B Antennas Connection

MW antenna

- 1 Unfold the loop antenna and if necessary, use screws (not supplied) to fix it to a flat, hard and stable place:



- 2 Fit the plug of the loop antenna to MW ANTENNA as shown above.
- 3 Adjust the antenna for optimal reception

FM Antenna

It is unnecessary to connect the FM pigtail antenna since it is fixed to the main unit.


- Position the antenna as far as possible from a TV, VCR or other radiation source.

Preparations

C Speakers Connection

Front Speakers

Connect the speaker wires to the SPEAKERS terminals, right speaker to "RIGHT" and left speaker to "LEFT", the wire (marked red) to "+" and the wire (marked black) to "-".




- Fully insert the stripped portion of the speaker wire into the terminal as shown.

Notes:

- For optimal sound performance, use the supplied speakers.
- Do not connect more than one speaker to any one pair of + / - speaker terminals.
- Do not connect speakers with an impedance lower than the speakers supplied. Please refer to the SPECIFICATIONS section of this manual.


Before using the remote control

- 1 Pull out the plastic protective sheet.
- 2 Select the source you wish to control by pressing one of the source select keys on the remote control (for example CD, TUNER).
- 3 Then select the desired function (for example ►, ◀, ▶).



Replacing battery (lithium CR2032) into the remote control


- 1 Pull out the knob (A) slightly to the left.
- 2 Pull out the battery compartment (B).
- 3 Replace a new battery and fully insert the battery compartment back to the original position.



CAUTION!

Batteries contain chemical substances, so they should be disposed off properly.

Basic Functions



IMPORTANT:

Before you operate the system, complete the preparation procedures.

Switching the system on

- Press **STANDBY-ON** (⏻ on the remote control).
→ The system will switch to the last selected source.
- Press **SOURCE** (CD, TUNER or AUX on the remote control).
→ The system will switch to the selected source.


To switch the system to standby mode


- Press **STANDBY-ON** (⏻ on the remote control).
→ The clock is displayed.

Power-saving automatic standby

The power-saving feature automatically switches to standby 15 minutes after a CD playback has ended and no control is operated.


Adjusting volume and sound

- 1 Press **VOLUME - / +** to increase or decrease volume.
→ Display shows the volume level  and a number from 0-32.
- 2 Press **DSC** repeatedly to select the desired sound effect: **JAZZ / POP / CLASSIC / ROCK**.
- 3 Press **DBB** (on the remote control) to switch bass enhancement on or off.
→ Display shows: **DBB** if the DBB is activated.
- 4 Press **MUTE** on the remote control to stop sound play-back instantly.
→ Playback will continue without sound and the display shows **MUTE**.




- To start sound playback you can:
 - press **MUTE** again;
 - adjust the volume controls;
 - change source.

CD/MP3 Operation



IMPORTANT:

The lens of the CD player should never be touched.




Loading a disc

This CD player plays Audio Discs including CD-Recordables, CD-Rewritables and MP3 CD.

- CD-ROM, CD-I, CDV, VCD, DVD or computer CDs, however, are not possible.

- 1 Select **CD** source.
- 2 Press **OPEN/CLOSE** on the top of the system to open the CD compartment.
→ **OPEN** is displayed when you open the CD compartment.



- 3 Insert a disc with the printed side facing up and press down on **OPEN/CLOSE** to close the CD door:
→ **READY** is displayed as the CD player scans the contents of a disc, and then the total number of tracks and playing time (or the total number of albums and tracks for MP3 disc) are shown.

Basic playback controls

To play a disc

- Press **▶||** to start playback.
→ The current track number and elapsed playing time of the track are displayed during disc playback.

To select a different track

- Press **◀◀ ▶▶** once or repeatedly until the desired track number appears in the display.

To find a passage within a track

- 1 Press and hold down on **◀◀ ▶▶**.
→ The disc is played at high speed and low volume.
- 2 When you recognise the passage you want, release **◀◀ ▶▶**.
→ Normal playback continues.

To interrupt playback

- Press **▶||** during playback.
→ The display freezes and the elapsed playing time flashes when playback is interrupted.
→ To resume, press **▶||** again.

To stop playback

- Press **■**.

Notes: CD play will also stop when;

- the CD door is opened.
- the disc has reached the end.
- you select another source: **TUNER** or **AUX**.
- you select standby

Playing an MP3 disc

- 1 Load an MP3 disc.
→ The disc reading time may exceed 10 seconds due to the large number of songs compiled into one disc.
→ "XXX XXX" is displayed. XXX is the current track number and XXX is the current album number.
- 2 Press **ALBUM ▼ ▲** to select a desired album..

CD/MP3 Operation

- 3 Press **⏮** **⏭** to select a desired track.
→ The album number will change accordingly as you reach the first track of an album by pressing **⏮** or the last track of an album by pressing **⏭**.
- 4 Press **▶** to start playback.
- During playback, press once **ALBUM ▼ ▲** to show the current album number.

Supported MP3 disc formats:

- ISO9660, Joliet, UDF 1.5
- Maximum title number: 512 (depending on filename length)
- Maximum album number: 99
- Supported sampling frequencies: 32 kHz, 44.1kHz, 48 kHz
- Supported Bit-rates: 32~256 (kbps), variable bitrates

Different play modes: SHUFFLE and REPEAT

You can select and change the various play modes before or during playback. The REPEAT modes can also be combined with PROGRAMME.

SHUFFLEtracks of the entire disc are played in random order

REPEAT ALL ...repeats the entire disc/ programme

REPEATplays the current track continuously

REPEAT ALBrepeats all tracks in the current (for MP3 only) album

- 1 To select your play mode, press the **SHUFF** or **REPEAT** on the remote control before or during playback until the display shows the desired function.
- 2 Press **▶** to start playback if in the STOP position.
→ If you have selected SHUFFLE, playback starts automatically.
- 3 To return to normal playback, press **SHUFF** or **REPEAT** on the remote control until the various SHUFFLE/ REPEAT modes are no longer displayed.
- You can also press **■** to cancel your play mode.

Notes:

- The **SHUFFLE** and **REPEAT** functions cannot be used simultaneously.
- **SHUFFLE** play is not available in the programme mode.

Programming track numbers

Programme in the STOP position to select and store your disc tracks in the desired sequence. If you like, store any track more than once. Up to 20 (10 for MP3 disc) tracks can be stored in the memory.

- 1 In the stop position, use the **⏮** **⏭** to select your desired track number.
- For MP3, you may press **ALBUM ▼ ▲** to select a desired album, then press **⏮** **⏭** to select your desired track.
- 2 Press **PROG** (or **PROG/CLOCK** on the set) to store.
→ Display: **PROG** flashes, and **⏮** **⏭** is displayed briefly, then the selected track number (and the selected album number for MP3).
- 3 Repeat **steps 1-2** to select and store all desired tracks.
→ **FULL** is displayed if you attempt to programme more than 20 (10 for MP3 disc) tracks.
- 4 To start playback of your disc programme, press **▶**.

Reviewing the programme

- Stop playback and press **PROG** (or **PROG/CLOCK** on the set) repeatedly.
→ Display first shows a programme sequence, then the stored track number (and the album number for MP3).
- To exit review mode, press **■**.


Erasing the programme

You can erase the programme by:

- pressing **■** once in the STOP mode;
- pressing **■** twice during playback;
- opening the CD compartment;
- Select another sound source.
→ **PROG** disappears from the display.

Radio Reception

Other Connection



Helpful hints:

To improve radio reception:

- For **FM**, extend coil antenna at the back of the unit fully for optimum reception.

Listening to an external source

You can listen to the sound of the connected external device through your system's speakers.

- 1 Select **AUX** source.
- 2 Use a line-in cable (not supplied) to connect MCM 108's AUX-IN jack (3.5 mm) to an AUDIO OUT or headphone jack on an external equipment (such as CD player; or VCR).

Tuning to radio stations

- 1 Select **TUNER** source.
→ **TUNER** is displayed.
- 2 Press **BAND** (**TUNER** on the remote control) once or more to select your waveband.
- 3 Turn **TUNING** ● to tune to a station.
→ Display shows: the frequency of the tuned station.


Maintenance

Cleaning the Cabinet

- Use a soft cloth slightly moistened with a mild detergent solution. Do not use a solution containing alcohol, spirits, ammonia or abrasives.

Cleaning Discs


- When a disc becomes dirty, clean it with a cleaning cloth. Wipe the disc from the centre out.
- Do not use solvents such as benzene, thinner; commercially available cleaners, or antistatic spray intended for analogue records.



Cleaning the disc lens

- After prolonged use, dirt or dust may accumulate at the disc lens. To ensure good playback quality, clean the disc lens with Philips CD Lens Cleaner or any commercially available cleaner. Follow the instructions supplied with cleaner.

Clock/Timer



Setting the clock

- 1 In Standby mode, press **PROG/CLOCK** button.
→ The clock digits for the hours flash.
- 2 Press **◀◀ / ▶▶** to set the hours.
- 3 Press **PROG/CLOCK** again.
→ The clock digits for the minutes flash.
- 4 Press **◀◀ / ▶▶** to set the minutes.
- 5 Press **PROG/CLOCK** to confirm the time.

Note:

– If the clock has not been set, – --:-- will be displayed.

Setting the timer


- The system can be used as an alarm clock. CD or TUNER can be set to switch on at a preset time. The clock time needs to be set first before the timer can be used.
 - If no button is pressed within 90 seconds during timer setup, the system will exit timer setting mode automatically.
- 1 In any mode, press **TIMER** on the remote control for more than 2 seconds.
 - 2 Press **◀◀ / ▶▶** (or **CD / TUNER** on the remote control) to select sound source.
 - 3 Press **TIMER** to confirm your desired source.
→ The clock digits for the hours flash.

- 4 Press **◀◀ / ▶▶** to set the hours.
- 5 Press **TIMER** again.
→ The clock digits for the minutes flash.
- 6 Press **◀◀ / ▶▶** to set the minutes.
- 7 Press **TIMER** to confirm the time.
→ The timer is now set and actiated.

Note:


- If source CD is selected and no disc is in the CD tray or the disc has an error, TUNER will be selected automatically.

To activate and deactivate timer

- In standby or during playback, press **TIMER** once.
→ Display shows  if activated, and disappears if deactivated.

Activating and deactivating SLEEP

The sleep timer enables the system to switch off by itself after a set period of time. The clock time needs to be set first before the sleep timer can be used.

- Press **SLEEP** on the remote control repeatedly to select desired time before system shuts off.
→ Display shows **SLEEP** and series of time options for selection: 60, 45, 30, 15, 0, 60...
- To deactivate, press **SLEEP** on the remote control once or more until "0" is shown, or press **STANDBY ON**  on the system or remote control.



Troubleshooting

WARNING

Under no circumstances should you try to repair the system yourself, as this will invalidate the warranty. Do not open the system as there is a risk of electric shock.

If a fault occurs, first check the points listed below before taking the system for repair. If you are unable to remedy a problem by following these hints, consult your dealer or service centre.

Problem	Solution
CD OPERATION	
"NO CD" is displayed.	<ul style="list-style-type: none">– Insert a disc.– Check if the disc is inserted upside down.– Wait until the moisture condensation at the lens has cleared.– Replace or clean the disc, see "Maintenance".– Use a finalised CD-RW or CD-R, or a correct MP3-CD format disc.
RADIO RECEPTION	
Radio reception is poor.	<ul style="list-style-type: none">– If the signal is too weak, adjust the antenna or connect an external antenna for better reception.– Increase the distance between the Micro HiFi System and your TV or VCR.
GENERAL	
The system does not react when buttons are pressed.	<ul style="list-style-type: none">– Remove and reconnect the AC power plug and switch on the system again.
Sound cannot be heard or is of poor quality.	<ul style="list-style-type: none">– Adjust the volume.– Disconnect the headphones.– Check that the speakers are connected correctly.– Check if the stripped speaker wire is clamped.– Make sure the MP3-CD was recorded within 32-256 kbps bit rate with sampling frequencies at 48 kHz, 44.1 kHz or 32 kHz.
The left and right sound outputs are reversed.	<ul style="list-style-type: none">– Check the speaker connections and location.
The remote control does not function properly.	<ul style="list-style-type: none">– Select the source (CD or TUNER, for example) before pressing the function button (▶, ◀, ⏮, ⏭).– Reduce the distance between the remote control and the system.– Insert the batteries with their polarities (+/- signs) aligned as indicated.– Replace the batteries.– Point the remote control directly toward IR sensor on the front of the system.
The timer is not working.	<ul style="list-style-type: none">– Set the clock correctly.– Press TIMER to switch on the timer.
The Clock/Timer setting is erased.	<ul style="list-style-type: none">– Power has been interrupted or the power cord has been disconnected. Reset the clock/timer.

Specifications

AMPLIFIER

Output power 2 x 2W RMS
Signal-to-noise ratio ≥ 62 dBA (IEC)
Frequency response 60 – 16000 Hz, ± 3 dB
Impedance loudspeakers 8 Ω
Impedance headphones 32 Ω – 1000 Ω

CD PLAYER

Frequency range 20 – 20000 Hz
Signal-to-noise ratio 75 dBA

TUNER

FM wave range 87.5 – 108 MHz
MW wave range 531 – 1602 kHz
Sensitivity at 75 Ω
– mono, 26 dB signal-to-noise ratio 2.8 μ V
– stereo, 46 dB signal-to-noise ratio 61.4 μ V
Selectivity ≥ 28 dB
Total harmonic distortion $\leq 5\%$
Frequency response 63 – 12500 Hz (± 3 dB)
Signal-to-noise-ratio ≥ 50 dB

SPEAKERS

Bass reflex system
Dimensions (w x h x d) .. 150 x 150 x 200 (mm)

GENERAL INFORMATION


AC Power.....220V-240V 50Hz,
Dimensions (w x h x d) .. 150 x 150 x 220 (mm)
Weight (with/without speakers)
..... approx. 4.9 / 2.3 kg
Standby power consumption < 3 W

Subject to modification

Meet Philips at the Internet
<http://www.philips.com>

English

中文



MCM108
MCM108B
MCM108C

**CLASS 1
LASER PRODUCT**



Printed in China

PDCC-JH-J.W.Wang-0716

