Inspiron 7306 2-in-1 Silver

Service Manual



Regulatory Model: P124G Regulatory Type: P124G002 September 2020 Rev. A00

Notes, cautions, and warnings

(i) NOTE: A NOTE indicates important information that helps you make better use of your product.

CAUTION: A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

MARNING: A WARNING indicates a potential for property damage, personal injury, or death.

© 2020 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

Contents

hapter 1: Working inside your computer	5
Before working inside your computer	5
Safety instructions	5
Electrostatic discharge—ESD protection	6
ESD field service kit	6
Transporting sensitive components	7
After working inside your computer	7
hapter 2: Removing and installing components	8
Recommended tools	
Screw list	8
Major components of Inspiron 7306 2-in-1 Silver	9
Base cover	
Removing the base cover	11
Installing the base cover	13
Battery	15
Lithium-ion battery precautions	
Removing the battery	
Installing the battery	16
Solid-state drive/Intel Optane	
Removing the M.2 2230 solid-state drive	17
Installing the M.2 2230 solid-state drive	
Removing the M.2 2280 solid-state drive/Intel Optane H10	
Installing the M.2 2280 solid-state drive/Intel Optane H10	20
Display assembly	21
Removing the display assembly	
Installing the display assembly	23
Fans	
Removing the fan	
Installing the fan	
Power-adapter port	
Removing the power-adapter port	27
Installing the power-adapter port	
Coin-cell battery	
Removing the coin-cell battery	
Installing the coin-cell battery	
I/O board	
Removing the I/O board	
Installing the I/O board	
Touchpad	
Removing the touchpad	
Installing the touchpad	
Speakers	
Removing the speakers	35

Installing the speakers	
Heat sink	
Removing the heat sink	
Installing the heat sink	
Power button with fingerprint reader	
Removing the power-button with fingerprint reader	
Installing the power-button with fingerprint reader	
System board	
Removing the system board	41
Installing the system board	
Palm-rest and keyboard assembly	46
Removing the palm-rest and keyboard assembly	
Installing the palm-rest and keyboard assembly	47
Chapter 3: Drivers and downloads	49

Chapter 4: System setup	50
Entering BIOS setup program	
Navigation keys	
Boot Sequence	
One time boot menu	
System setup options	
Clearing CMOS settings	60
Clearing BIOS (System Setup) and System passwords	

Chapter 5: Troubleshooting	61
SupportAssist diagnostics	
Locate the Service Tag or Express Service Code of your Dell computer	61
System diagnostic lights	61
Recovering the operating system	
Flashing the BIOS	62
Flashing BIOS (USB key)	63
Backup media and recovery options	63
WiFi power cycle	
Flea power release	

Chapter 6: Getting help and contacting	J Dell65
--	----------

Working inside your computer

Before working inside your computer

About this task

(i) NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Steps

- 1. Save and close all open files and exit all open applications.
- 2. Shut down your computer. Click Start > **U** Power > Shut down.
 - **NOTE:** If you are using a different operating system, see the documentation of your operating system for shut-down instructions.
- 3. Disconnect your computer and all attached devices from their electrical outlets.
- 4. Disconnect all attached network devices and peripherals, such as keyboard, mouse, and monitor from your computer.
 - CAUTION: To disconnect a network cable, first unplug the cable from your computer and then unplug the cable from the network device.
- 5. Remove any media card and optical disc from your computer, if applicable.

Safety instructions

Use the following safety guidelines to protect your computer from potential damage and to ensure your personal safety. Unless otherwise noted, each procedure included in this document assumes that you have read the safety information that shipped with your computer.

- WARNING: Before working inside your computer, read the safety information that is shipped with your computer. For more safety best practices, see the Regulatory Compliance home page at www.dell.com/ regulatory_compliance.
- WARNING: Disconnect your computer from all power sources before opening the computer cover or panels. After you finish working inside the computer, replace all covers, panels, and screws before connecting your computer to an electrical outlet.

 \wedge CAUTION: To avoid damaging the computer, ensure that the work surface is flat, dry, and clean.

- CAUTION: To avoid damaging the components and cards, handle them by their edges, and avoid touching the pins and the contacts.
- CAUTION: You should only perform troubleshooting and repairs as authorized or directed by the Dell technical assistance team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. See the safety instructions that is shipped with the product or at www.dell.com/regulatory_compliance.
- CAUTION: Before touching anything inside your computer, ground yourself by touching an unpainted metal surface, such as the metal at the back of the computer. While you work, periodically touch an unpainted metal surface to dissipate static electricity which could harm internal components.

CAUTION: When you disconnect a cable, pull it by its connector or its pull tab, not the cable itself. Some cables have connectors with locking tabs or thumbscrews that you must disengage before disconnecting the cable. When disconnecting cables, keep them evenly aligned to avoid bending the connector pins. When connecting cables, ensure that the ports and the connectors are correctly oriented and aligned.

CAUTION: Press and eject any installed card from the media-card reader.

(i) NOTE: The color of your computer and certain components may appear differently than shown in this document.

Electrostatic discharge—ESD protection

ESD is a major concern when you handle electronic components, especially sensitive components such as expansion cards, processors, memory DIMMs, and system boards. Very slight charges can damage circuits in ways that may not be obvious, such as intermittent problems or a shortened product life span. As the industry pushes for lower power requirements and increased density, ESD protection is an increasing concern.

Due to the increased density of semiconductors used in recent Dell products, the sensitivity to static damage is now higher than in previous Dell products. For this reason, some previously approved methods of handling parts are no longer applicable.

Two recognized types of ESD damage are catastrophic and intermittent failures.

- Catastrophic Catastrophic failures represent approximately 20 percent of ESD-related failures. The damage causes an
 immediate and complete loss of device functionality. An example of catastrophic failure is a memory DIMM that has received
 a static shock and immediately generates a "No POST/No Video" symptom with a beep code emitted for missing or
 nonfunctional memory.
- Intermittent Intermittent failures represent approximately 80 percent of ESD-related failures. The high rate of
 intermittent failures means that most of the time when damage occurs, it is not immediately recognizable. The DIMM
 receives a static shock, but the tracing is merely weakened and does not immediately produce outward symptoms related to
 the damage. The weakened trace may take weeks or months to melt, and in the meantime may cause degradation of memory
 integrity, intermittent memory errors, etc.

The more difficult type of damage to recognize and troubleshoot is the intermittent (also called latent or "walking wounded") failure.

Perform the following steps to prevent ESD damage:

- Use a wired ESD wrist strap that is properly grounded. The use of wireless anti-static straps is no longer allowed; they do not provide adequate protection. Touching the chassis before handling parts does not ensure adequate ESD protection on parts with increased sensitivity to ESD damage.
- Handle all static-sensitive components in a static-safe area. If possible, use anti-static floor pads and workbench pads.
- When unpacking a static-sensitive component from its shipping carton, do not remove the component from the anti-static
 packing material until you are ready to install the component. Before unwrapping the anti-static packaging, ensure that you
 discharge static electricity from your body.
- Before transporting a static-sensitive component, place it in an anti-static container or packaging.

ESD field service kit

The unmonitored Field Service kit is the most commonly used service kit. Each Field Service kit includes three main components: anti-static mat, wrist strap, and bonding wire.

Components of an ESD field service kit

The components of an ESD field service kit are:

- Anti-Static Mat The anti-static mat is dissipative and parts can be placed on it during service procedures. When using an anti-static mat, your wrist strap should be snug and the bonding wire should be connected to the mat and to any bare metal on the system being worked on. Once deployed properly, service parts can be removed from the ESD bag and placed directly on the mat. ESD-sensitive items are safe in your hand, on the ESD mat, in the system, or inside a bag.
- Wrist Strap and Bonding Wire The wrist strap and bonding wire can be either directly connected between your wrist and bare metal on the hardware if the ESD mat is not required, or connected to the anti-static mat to protect hardware that is temporarily placed on the mat. The physical connection of the wrist strap and bonding wire between your skin, the ESD

mat, and the hardware is known as bonding. Use only Field Service kits with a wrist strap, mat, and bonding wire. Never use wireless wrist straps. Always be aware that the internal wires of a wrist strap are prone to damage from normal wear and tear, and must be checked regularly with a wrist strap tester in order to avoid accidental ESD hardware damage. It is recommended to test the wrist strap and bonding wire at least once per week.

- ESD Wrist Strap Tester The wires inside of an ESD strap are prone to damage over time. When using an unmonitored kit, it is a best practice to regularly test the strap prior to each service call, and at a minimum, test once per week. A wrist strap tester is the best method for doing this test. If you do not have your own wrist strap tester, check with your regional office to find out if they have one. To perform the test, plug the wrist-strap's bonding-wire into the tester while it is strapped to your wrist and push the button to test. A green LED is lit if the test is successful; a red LED is lit and an alarm sounds if the test fails.
- Insulator Elements It is critical to keep ESD sensitive devices, such as plastic heat sink casings, away from internal parts that are insulators and often highly charged.
- Working Environment Before deploying the ESD Field Service kit, assess the situation at the customer location. For example, deploying the kit for a server environment is different than for a desktop or portable environment. Servers are typically installed in a rack within a data center; desktops or portables are typically placed on office desks or cubicles. Always look for a large open flat work area that is free of clutter and large enough to deploy the ESD kit with additional space to accommodate the type of system that is being repaired. The workspace should also be free of insulators that can cause an ESD event. On the work area, insulators such as Styrofoam and other plastics should always be moved at least 12 inches or 30 centimeters away from sensitive parts before physically handling any hardware components
- ESD Packaging All ESD-sensitive devices must be shipped and received in static-safe packaging. Metal, static-shielded bags are preferred. However, you should always return the damaged part using the same ESD bag and packaging that the new part arrived in. The ESD bag should be folded over and taped shut and all the same foam packing material should be used in the original box that the new part arrived in. ESD-sensitive devices should be removed from packaging only at an ESD-protected work surface, and parts should never be placed on top of the ESD bag because only the inside of the bag is shielded. Always place parts in your hand, on the ESD mat, in the system, or inside an anti-static bag.
- **Transporting Sensitive Components** When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

ESD protection summary

It is recommended that all field service technicians use the traditional wired ESD grounding wrist strap and protective anti-static mat at all times when servicing Dell products. In addition, it is critical that technicians keep sensitive parts separate from all insulator parts while performing service and that they use anti-static bags for transporting sensitive components.

Transporting sensitive components

When transporting ESD sensitive components such as replacement parts or parts to be returned to Dell, it is critical to place these parts in anti-static bags for safe transport.

After working inside your computer

About this task

CAUTION: Leaving stray or loose screws inside your computer may severely damage your computer.

Steps

- 1. Replace all screws and ensure that no stray screws remain inside your computer.
- 2. Connect any external devices, peripherals, or cables you removed before working on your computer.
- 3. Replace any media cards, discs, or any other parts that you removed before working on your computer.
- 4. Connect your computer and all attached devices to their electrical outlets.
- 5. Turn on your computer.

Removing and installing components

(i) NOTE: The images in this document may differ from your computer depending on the configuration you ordered.

Recommended tools

The procedures in this document may require the following tools:

- Philips screwdriver #0
- Philips screwdriver #1
- Plastic scribe

Screw list

- () **NOTE:** When removing screws from a component, it is recommended to note the screw type, the quantity of screws, and then place them in a screw storage box. This is to ensure that the correct number of screws and correct screw type is restored when the component is replaced.
- **NOTE:** Some computers have magnetic surfaces. Ensure that the screws are not left attached to such surfaces when replacing a component.

(i) NOTE: Screw color may vary with the configuration ordered.

Table 1. Screw list


Component	Secured to	Screw type	Quantity	Screw image
Base cover	Palm-rest assembly	M2x4	4	Ŷ
Battery	Palm-rest assembly	M2x3	4	9
M.2 2230 mounting bracket	System board	M2x2	1	@
M.2 2280 solid-state drive/Intel Optane H10	System board	M2x2	1	
Display assembly	Palm-rest assembly	M2×5	Left hinge: 1Right hinge: 1	Ŷ
Display assembly	Palm-rest assembly	M2x3.5	Left hinge: 1Right hinge: 1	
Fan	Palm-rest assembly	M2x3	2	Ŷ
Power-adapter port	Palm-rest assembly	M2x3	1	9
I/O board	Palm-rest assembly	M2x2	1	•

Table 1. Screw list (continued)

Component	Secured to	Screw type	Quantity	Screw image
Touchpad	Palm-rest assembly	M2x2	2	38
Touchpad bracket	Palm-rest assembly	M1.6x2	3	
Power-button with fingerprint reader	Palm-rest assembly	M2x3	1	9
Power-button bracket	Palm-rest assembly	M2x3	1	9
Wireless-card bracket	Palm-rest assembly	M2x3	1	9
System board	Palm-rest assembly	M2x2	3	57

Major components of Inspiron 7306 2-in-1 Silver

The following image shows the major components of Inspiron 7306 2-in-1 Silver.



- 1. Base cover
- 2. Battery
- 3. Heat sink
- 4. Left speaker
- 5. Touchpad
- 6. Touchpad bracket
- 7. Power-adapter port
- 8. Palm-rest assembly
- 9. Display assembly
- **10.** I/O board
- 11. Right speaker
- 12. System board
- 13. I/O-board cable
- 14. Coin-cell battery
- 15. M.2 2280 solid-state drive (if applicable)
- **16.** Power-button with fingerprint reader
- 17. Power-button bracket

18. Fan

() NOTE: Dell provides a list of components and their part numbers for the original system configuration purchased. These parts are available according to warranty coverages purchased by the customer. Contact your Dell sales representative for purchase options.

(i) NOTE: Depending on the configuration ordered, some components may not installed in your computer.

Base cover

Removing the base cover


Prerequisites

1. Follow the procedure in Before working inside your computer.

About this task

The following image(s) indicate the location of the base cover and provides a visual representation of the removal procedure.





4

ex. d*n d*n d*n b*n *n *n *n #n <	prin hore ng hoge hoge (*) - + hoge hoge 9 0 - + hoge
tao Q W E R T Y U	
svit Z X C V B N M	shite
ctri fn 📲 ait	

Steps

- 1. Loosen the three captive screws that secure the base cover to the palm-rest assembly.
- 2. Remove the four screws (M2x4) that secure the base cover to the palm-rest assembly.
- **3.** Using a plastic scribe, pry the base cover from the tabs at the hinges and continue to work on the sides to release the base cover from the palm-rest assembly.
- 4. Lift the base cover off the palm-rest assembly.
- 5. Using the pull tab, disconnect the battery cable from the system board.
- 6. Turn your computer over and press the power button for 15 seconds to drain the flea power.

Installing the base cover

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the base cover and provides a visual representation of the installation procedure.







1. Connect the battery cable to the system board.

- 2. Align the tabs on the base cover with the slots on the palm-rest assembly and snap the base cover to the palm-rest assembly.
- **3.** Replace the four screws (M2x4) that secure the base cover to the palm-rest assembly.
- 4. Tighten the three captive screws that secure the base cover to the palm-rest assembly.

Next steps

1. Follow the procedure in After working inside your computer.

Battery

Lithium-ion battery precautions

- Exercise caution when handling Lithium-ion batteries.
- Discharge the battery completely before removing it. Disconnect the AC power adapter from the system and operate the computer solely on battery power—the battery is fully discharged when the computer no longer turns on when the power button is pressed.
- Do not crush, drop, mutilate, or penetrate the battery with foreign objects.
- Do not expose the battery to high temperatures, or disassemble battery packs and cells.
- Do not apply pressure to the surface of the battery.
- Do not bend the battery.
- Do not use tools of any kind to pry on or against the battery.
- Ensure any screws during the servicing of this product are not lost or misplaced, to prevent accidental puncture or damage to the battery and other system components.
- If the battery gets stuck inside your computer as a result of swelling, do not try to release it as puncturing, bending, or crushing a lithium-ion battery can be dangerous. In such an instance, contact Dell technical support for assistance. See www.dell.com/contactdell.
- Always purchase genuine batteries from www.dell.com or authorized Dell partners and resellers.


Removing the battery

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

The following image(s) indicate the location of the battery and provides a visual representation of the removal procedure.



- 1. Remove the four screws (M2x3) that secure the battery to the palm-rest assembly.
- 2. Peel off the tapes that secure the battery to the palm-rest assembly.
- 3. Lift the battery off the palm-rest assembly.


Installing the battery

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the battery and provides a visual representation of the installation procedure.



1. Place the battery on the palm-rest assembly.

NOTE: Ensure that the battery cable is not under the battery when placing the battery on the palm-rest assembly to avoid damage to your computer.

- 2. Align the screw holes on the battery to the screw holes on the palm-rest assembly.
- 3. Replace the four screws (M2x3) that secure the battery to the palm-rest assembly.
- 4. Adhere the tapes that secure the battery to the palm-rest assembly.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Solid-state drive/Intel Optane

Removing the M.2 2230 solid-state drive

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.


About this task

(i) NOTE: This procedure applies only to computers shipped with a M.2 2230 solid-state drive installed.

NOTE: The M.2 card installed on your computer will depend on the configuration ordered. Supported card configurations on the M.2 card slot:

- M.2 2230 solid-state drive + 2230 mounting bracket
- M.2 2280 solid-state drive
- M.2 2280 Intel Optane Memory H10

The following image(s) indicate the location of the M.2 2230 solid-state drive and provides a visual representation of the removal procedure.



Steps

- 1. Remove the screw (M2x2) that secures the M.2 2230 mounting bracket to the system board.
- 2. Slide and remove the M.2 2230 mounting bracket off the system board.
- 3. Slide and remove the M.2 2230 solid-state drive off the system board.

Installing the M.2 2230 solid-state drive

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.


About this task

(i) NOTE: This procedure applies if you are installing a M.2 2230 solid-state drive.

NOTE: The M.2 card installed on your computer will depend on the configuration ordered. Supported card configurations on the M.2 card slot:

- M.2 2230 solid-state drive + 2230 mounting bracket
- M.2 2280 solid-state drive
- M.2 2280 Intel Optane Memory H10

The following image(s) indicate the location of the $M.2\ 2230$ solid-state drive and provides a visual representation of the installation procedure.



- 1. Align the notch on the M.2 2230 solid-state drive with the tab on the M.2 card slot on the system board.
- 2. Slide the M.2 2230 solid-state drive into the M.2 card slot on the system board.
- **3.** Slide the M.2 2230 mounting bracket into place, aligning the peg on the bracket with the notch on the M.2 2230 solid-state drive.
- $\textbf{4.} \hspace{0.1in} \text{Align the screw hole on the M.2 2230 mounting bracket to the screw hole on the system board.}$
- 5. Replace the screw (M2x2) that secures the M.2 2230 mounting bracket to the system board.

Next steps

1. Follow the procedure in After working inside your computer.

Removing the M.2 2280 solid-state drive/Intel Optane H10

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.


About this task

NOTE: This procedure applies only to computers shipped with a M.2 2280 solid-state drive or a M.2 2280 Intel Optane H10 installed.

NOTE: The M.2 card installed on your computer will depend on the configuration ordered. Supported card configurations on the M.2 card slot:

- M.2 2230 solid-state drive + 2230 mounting bracket
- M.2 2280 solid-state drive
- M.2 2280 Intel Optane Memory H10

The following image(s) indicate the location of the M.2 2280 solid-state drive/Intel Optane H10 and provides a visual representation of the removal procedure.



- 1. Remove the screw (M2x2) that secures the M.2 2280 solid-state drive/Intel Optane to the system board.
- 2. Slide and remove the M.2 2280 solid-state drive/Intel Optane from the M.2 card slot on the system board.

Installing the M.2 2280 solid-state drive/Intel Optane H10

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.


About this task

(i) NOTE: This procedure applies if you are installing a M.2 2280 solid-state drive or M.2 2280 Intel Optane H10.

NOTE: The M.2 card installed on your computer will depend on the configuration ordered. Supported card configurations on the M.2 card slot:

- M.2 2230 solid-state drive + 2230 mounting bracket
- M.2 2280 solid-state drive
- M.2 2280 Intel Optane Memory H10

The following image(s) indicate the location of the M.2 2280 solid-state drive/Intel Optane H10 and provides a visual representation of the installation procedure.



- 1. Align the notch on the M.2 2280 solid-state drive/Intel Optane with the tab on the M.2 card slot on the system board.
- 2. Slide the M.2 2280 solid-state drive/Intel Optane into the M.2 card slot on the system board.
- 3. Replace the screw (M2x2) that secures the M.2 2280 solid-state drive/Intel Optane to the system board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Display assembly

Removing the display assembly

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.


About this task


The following image(s) indicate the location of the display assembly and provides a visual representation of the removal procedure.













- 1. Open the latch and disconnect the touchscreen cable from the system board.
- 2. Peel the tape that secures the display-cable latch to the system board.
- 3. Open the latch and disconnect the display cable from the system board.
- 4. Remove the touchscreen cable and display cable from the routing guide on the palm-rest assembly.
- 5. Remove the screw (M2x5) that secures the left display-hinge to the palm-rest assembly.
- 6. Remove the screw (M2x3.5) that secures the left display-hinge to the I/O board and palm-rest assembly.
- 7. Pry open the left display-hinge.
- 8. Remove the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 9. Remove the screw (M2x3.5) that secures the right display-hinge to the palm-rest assembly and system board.
- **10.** Pry open the right display-hinge.
- 11. Lift and remove the palm-rest assembly from the display assembly.


Installing the display assembly


Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the display assembly and provides a visual representation of the installation procedure.





- 1. Align the hinges on the display assembly with the slots on the palm-rest assembly.
- 2. Place the palm-rest assembly on the display assembly at an angle.

(i) NOTE: To avoid damaging your system do not slide the palm-rest assembly on the display assembly.

- **3.** Close the left display-hinge.
 - **NOTE:** Ensure that the screw holes on the left display-hinge are aligned with the screw holes on the system board and palm-rest assembly
- 4. Replace the screw (M2x5) that secures the left display-hinge to the palm-rest assembly.
- 5. Replace the screw (M2x3.5) that secures the left display-hinge to the I/O-board and palm-rest assembly.
- 6. Close the right display-hinge.

NOTE: Ensure that the screw holes on the right display-hinge are aligned with the screw holes on the I/O board and palm-rest assembly

- 7. Replace the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 8. Replace the screw (M2x3.5) that secures the right display-hinge to the system board and palm-rest assembly.
- 9. Route the touchscreen cable and display cable through the routing guide on the palm-rest assembly.
- **10.** Connect the touchscreen cable to the system board and close the latch.

- 11. Connect the display cable to the system board and close the latch.
- **12.** Adhere the tape that secures the display-cable latch to the system board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Fans


Removing the fan

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

The following image(s) indicate the location of the fan and provides a visual representation of the removal procedure.



Steps

- 1. Remove the antenna cables from the routing guides on the fan.
- 2. Disconnect the fan cable from the system board.
- 3. Remove the two screws (M2x3) that secure the fan to the palm-rest assembly.
- 4. Lift the fan off the palm-rest assembly.


Installing the fan

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the fan and provides a visual representation of the installation procedure.



Steps

- 1. Using the alignment posts, place the fan on the palm-rest assembly.
- 2. Replace the two screws (M2x3) that secure the fan to the palm-rest assembly.
- **3.** Connect the fan cable to the system board.
- 4. Route the antenna cables through the routing guides on the fan.

Next steps

- **1.** Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Power-adapter port


Removing the power-adapter port

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

The following image(s) indicate the location of the power-adapter port and provides a visual representation of the removal procedure.



- 1. Remove the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 2. Remove the screw (M2x3.5) that secures the right display-hinge to the system board and palm-rest assembly.
- **3.** Pry open the right display-hinge.
- 4. Peel off the tape the secures the power-adapter port cable to the system board.
- 5. Disconnect the power-adapter port cable from the system board.
- 6. Remove the screw (M2x3) that secures the power-adapter port to the palm-rest assembly.
- 7. Remove the power-adapter port cable from the routing guide on the palm-rest assembly.
- 8. Lift the power-adapter port along with its cable off the palm-rest assembly.


Installing the power-adapter port

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the power-adapter port and provides a visual representation of the installation procedure.



Steps

- 1. Place the power-adapter port into the slot on the palm-rest assembly.
- 2. Replace the screw (M2x3) that secures the power-adapter port to the palm-rest assembly.
- **3.** Route the power-adapter port cable through the routing guide on the palm-rest assembly.
- 4. Connect the power-adapter port cable to the system board.
- 5. Adhere the tape that secures the power-adapter port cable to the system board.
- 6. Close the right display-hinge.

NOTE: Ensure that the screw holes on the left display-hinge are aligned with the screw holes on the system board and palm-rest assembly

- 7. Replace the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 8. Replace the screw (M2x3.5) that secures the right display-hinge to the system board and palm-rest assembly.

Next steps

1. Install the base cover.

2. Follow the procedure in After working inside your computer.

Coin-cell battery

Removing the coin-cell battery


Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

() NOTE: Removing the coin-cell battery resets the BIOS setup program's settings to default. It is recommended that you note the BIOS setup program's settings before removing the coin-cell battery.

The following image(s) indicate the location of the coin-cell battery and provides a visual representation of the removal procedure.



Steps

- 1. Peel the tape that secures the I/O-board cable-latch to the I/O board.
- 2. Open the latch and disconnect the I/O-board cable from the I/O board.
- 3. Disconnect the coin-cell battery cable from the I/O board.
- 4. Peel and lift the coin-cell battery off the palm-rest assembly.


Installing the coin-cell battery

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the coin-cell battery and provides a visual representation of the installation procedure.



Steps

- 1. Connect the coin-cell battery cable to the I/O board.
- 2. Adhere the coin-cell battery to the palm-rest assembly.
- 3. Connect the I/O-board cable to the I/O board and close the latch.
- 4. Adhere the tape that secures the I/O-board cable-latch to the I/O board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

I/O board


Removing the I/O board

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

The following image(s) indicate the location of the I/O board and provides a visual representation of the removal procedure.



- 1. Remove the screw (M2x3.5) that secures the left display-hinge to the I/O board and palm-rest assembly.
- 2. Remove the screw (M2x5) that secures the left display-hinge to the palm-rest assembly.
- **3.** Pry open the left display-hinge.
- 4. Peel the tape that secures the I/O-board cable-latch to the I/O board.
- 5. Open the latch and disconnect the I/O-board cable from the I/O board.
- 6. Disconnect the coin-cell battery from the I/O board.
- 7. Remove the screw (M2x2) that secures the I/O board to the palm-rest assembly.
- 8. Lift the I/O-board from the palm-rest assembly.


Installing the I/O board

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the I/O board and provides a visual representation of the installation procedure.



- 1. Using the alignment posts, place the I/O board on the palm-rest assembly.
- 2. Replace the screw (M2x2) that secures the I/O board to the palm-rest assembly.
- 3. Close the left display-hinge.
- 4. Replace the screw (M2x5) that secures the left display-hinge to the palm-rest assembly.
- 5. Replace the screw (M2x3.5) that secures the left display-hinge to the I/O board and palm-rest assembly.
- 6. Connect the I/O-board cable to the I/O board and close the latch.
- 7. Adhere the tape that secures the I/O-board cable-latch to the I/O-board.
- 8. Connect the coin-cell battery cable to the I/O board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Touchpad


Removing the touchpad

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.
- **3.** Remove the battery.

About this task

The following image(s) indicate the location of the touchpad and provides a visual representation of the removal procedure.



- 1. Remove the three screws (M1.6x2) that secure the touchpad bracket to the palm-rest assembly.
- 2. Peel the mylar that covers the tape that secures the touchpad to the palm-rest assembly.
- 3. Lift the touchpad bracket off the palm-rest assembly.
- 4. Open the latch and disconnect the touchpad cable from the system board.
- 5. Remove the two screws (M2x2) that secure the touchpad to the palm-rest assembly.
- 6. Peel the tapes that secure the touchpad to the palm-rest assembly.
- 7. Lift the touchpad from the palm-rest assembly.


Installing the touchpad

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the touchpad and provides a visual representation of the installation procedure.



- 1. Slide the touchpad into the slot on the palm-rest assembly.
- 2. Replace the two screws (M2x2) that secure the touchpad to the palm-rest assembly.
- **3.** Adhere the tapes that secure the touchpad to the palm-rest assembly.
- 4. Connect the touchpad cable to the system board and close the latch.
- 5. Align the screw holes on the touchpad bracket with the screw holes on the palm-rest assembly.
- 6. Replace the three screws (M1.6x2) that secure the touchpad bracket to the palm-rest assembly.
- 7. Adhere the mylar that covers the tape that secures the touchpad to the palm-rest assembly.

Next steps

- 1. Install the battery.
- 2. Install the base cover.
- 3. Follow the procedure in After working inside your computer.

Speakers


Removing the speakers

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.
- 3. Remove the battery.

About this task

The following image(s) indicate the location of the speakers and provides a visual representation of the removal procedure.



- 1. Disconnect the speaker cable from the system board.
- 2. Remove the speaker cable from the routing guide on the fan.
- 3. Lift the left speaker from the palm-rest assembly.
- 4. Remove the speaker cable from the routing guide on the palm-rest assembly.
- 5. Lift both the speakers along with the speaker cable off the palm-rest assembly.


Installing the speakers

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the speakers and provides a visual representation of the installation procedure.



1. Using the alignment posts, place the right speaker on the palm-rest assembly.

(i) NOTE: Ensure that the alignment posts are threaded through the rubber grommets on the speaker.

- 2. Route the speaker cable through the routing guides on the palm-rest assembly.
- 3. Using the alignment posts, place the left speaker on the palm-rest assembly.

(i) NOTE: Ensure that the alignment posts are threaded through the rubber grommets on the speaker.

- **4.** Route the speaker cable through the routing guides on the fan.
- 5. Connect the speaker cable to the system board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Heat sink

Removing the heat sink


Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.

About this task

- () NOTE: The heat sink may become hot during normal operation. Allow sufficient time for the heat sink to cool before you touch it.
- **NOTE:** For maximum cooling of the processor, do not touch the heat transfer areas on the heat sink. The oils in your skin can reduce the heat transfer capability of the thermal grease.

The following image(s) indicate the location of the heat sink and provides a visual representation of the removal procedure.



Steps

- 1. In reverse sequential order (4>3>2>1) loosen the four captive screws that secure the heat sink to the system board.
- 2. Lift the heat sink from the system board.

Installing the heat sink


Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

NOTE: If either the system board or the heat sink is replaced, use the thermal grease provided in the kit to ensure that thermal conductivity is achieved.

The following image(s) indicate the location of the heat sink and provides a visual representation of the installation procedure.



- 1. Place the heat sink on the system board.
- 2. In sequential order (1>2>3>4) tighten the four captive screws that secure the heat sink to the system board.

Next steps

- 1. Install the base cover.
- 2. Follow the procedure in After working inside your computer.

Power button with fingerprint reader


Removing the power-button with fingerprint reader

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.
- **3.** Remove the fan.
- **4.** Remove the I/O board.

About this task

The following image(s) indicate the location of the power-button with fingerprint reader and provides a visual representation of the removal procedure.



- 1. Remove the screw (M2x3) that secures the power-button bracket to the palm-rest assembly.
- 2. Lift the power-button bracket off the palm-rest assembly.
- **3.** Open the latch and disconnect the power-button with fingerprint reader cable from the power-button board.
- 4. Remove the screw (M2x3) that secures the power-button with fingerprint reader to the palm-rest assembly.
- 5. Peel the tape that secures the power-button with fingerprint reader cable to the palm-rest assembly.
- 6. Lift the power-button and fingerprint reader and its cable off the palm-rest assembly.

Installing the power-button with fingerprint reader

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the power-button with fingerprint reader and provides a visual representation of the installation procedure.



- 1. Place the power-button with fingerprint reader into the slot on the palm-rest assembly.
- 2. Replace the screw (M2x3) that secures the power-button with fingerprint reader to the palm-rest assembly.
- 3. Adhere the tape that secures the power-button with fingerprint reader cable to the palm-rest assembly.
- 4. Connect the power-button with fingerprint-reader cable to the power-button board and close the latch.
- 5. Adhere the tape that secures the power-button with fingerprint reader cable to the palm-rest assembly.
- 6. Place the power-button bracket on the power-button with fingerprint reader.
- 7. Replace the screw (M2x3) that secures the power-button bracket to the palm-rest assembly.

Next steps

- 1. Install the I/O board.
- 2. Install the fan.
- **3.** Install the base cover.
- 4. Follow the procedure in After working inside your computer.

System board


Removing the system board

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.
- 3. Remove the M.2 2230 solid-state drive. (if applicable)
- 4. Remove the M.2 2280 solid-state drive/Intel Optane H10. (if applicable)
- 5. Remove the battery.
- 6. Remove the fan.
- 7. Remove the heat sink.

About this task

The following image(s) indicate the location of the system board and provides a visual representation of the removal procedure.







- 1. Remove the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 2. Remove the screw (M2x3.5) that secures the right display-hinge to the system board and palm-rest assembly.
- **3.** Pry open the right display-hinge.
- 4. Remove the screw (M2x3) that secures the wireless-card bracket to the palm-rest assembly.
- 5. Lift the wireless-card bracket off the system board.
- 6. Disconnect the power-adapter port cable from the system board.
- 7. Peel the tape that secures the display-cable latch to the system board.
- 8. Open the latch and disconnect the display cable from the system board.
- 9. Open the latch and disconnect the touchscreen cable from the system board.
- **10.** Open the latch and disconnect the power-button board cable from the system board.
- 11. Disconnect the antenna cables from the wireless card on the system board.
- 12. Peel the tape that secures the I/O-board cable-latch to the system board.
- 13. Open the latch and disconnect the I/O-board cable from the system board.
- 14. Disconnect the speaker cable from the system board.
- 15. Open the latch and disconnect the touchpad cable from the system board.
- 16. Open the latch and disconnect the keyboard-backlight cable from the system board.
- 17. Peel the Mylar that secures the keyboard-cable latch to the system board.
- **18.** Open the latch and disconnect the keyboard cable from the system board.
- 19. Remove the three screws (M2x2) that secure the system board to the palm-rest assembly.

20. Lift the system board off the palm-rest assembly.


Installing the system board

Prerequisites


If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the system board and provides a visual representation of the installation procedure.







- 1. Place the system board on the palm-rest assembly.
- 2. Replace the three screws (M2x2) that secure the system board to the palm-rest assembly.
- **3.** Connect the power-adapter port cable to the system board.
- 4. Connect the display cable to the system board and close the latch.
- 5. Adhere the tape that secures the display-cable latch to the system board.
- 6. Connect the touchscreen cable to the system board and close the latch.
- 7. Connect the power-button board cable to the system board and close the latch.
- 8. Connect the antenna cables to the wireless card on the system board.

The following table provides the antenna-cable color scheme for the wireless card supported by your computer.

Table 2. Antenna-cable color scheme

Connectors on the wireless card	Antenna-cable color	Silkscreen marking	
Main	White	MAIN	riangle (white triangle)
Auxiliary	Black	AUX	▲ (black triangle)

9. Connect the I/O-board cable to the system board and close the latch.

- 10. Adhere the tape that secures the I/O-board cable-latch to the system board.
- 11. Connect the speaker cable to the system board.
- 12. Connect the touchpad cable to the system board and close the latch.
- **13.** Connect the keyboard-backlight cable from the system board and close the latch.
- 14. Connect the keyboard cable to the system board and close the latch.
- 15. Adhere the Mylar that secures the keyboard-cable latch to the system board.
- 16. Place the wireless-card bracket on the wireless card.
- 17. Replace the screw (M2x3) that secures the wireless-card bracket to the palm-rest assembly.
- **18.** Close the right display-hinge.
 - (i) **NOTE:** Ensure that the screw holes on the left display-hinge are aligned with the screw holes on the system board and palm-rest assembly
- 19. Replace the screw (M2x5) that secures the right display-hinge to the palm-rest assembly.
- 20. Replace the screw (M2x3.5) that secures the right display-hinge to the system board and palm-rest assembly.

Next steps

- 1. Install the heat sink.
- 2. Install the fan.
- **3.** Install the battery.
- 4. Install the M.2 2230 solid-state drive. (if applicable)
- 5. Install the M.2 2280 solid-state drive/Intel Optane H10. (if applicable)
- 6. Install the base cover.
- 7. Follow the procedure in After working inside your computer.

Palm-rest and keyboard assembly


Removing the palm-rest and keyboard assembly

Prerequisites

- 1. Follow the procedure in Before working inside your computer.
- 2. Remove the base cover.
- **3.** Remove the battery.
- 4. Remove the display assembly.
- 5. Remove the fan.
- 6. Remove the power-adapter port.
- 7. Remove the coin-cell battery.
- 8. Remove the I/O board.
- 9. Remove the touchpad.
- **10.** Remove the speakers.
- **11.** Remove the power-button with fingerprint reader.
- **12.** Remove the system board.
 - **INOTE:** The system board can be removed along with the heat sink.

About this task

The following image(s) indicate the location of the palm-rest and keyboard assembly and provides a visual representation of the removal procedure.



After performing the pre-requisites, you are left with the palm-rest and keyboard assembly.


Installing the palm-rest and keyboard assembly

Prerequisites

If you are replacing a component, remove the existing component before performing the installation process.

About this task

The following image(s) indicate the location of the palm-rest and keyboard assembly and provides a visual representation of the installation procedure.



To install the palm-rest and keyboard assembly perform the post-requisites.

Next steps

- 1. Install the system board.
- 2. Install the power-button with fingerprint reader.
- **3.** Install the speakers.
- 4. Install the touchpad.
- 5. Install the I/O board.
- 6. Install the coin-cell battery.
- 7. Install the power-adapter port.
- 8. Install the fan.
- 9. Install the display assembly.
- **10.** Install the battery.
- **11.** Install the base cover.
- **12.** Follow the procedure in After working inside your computer.

Drivers and downloads

When troubleshooting, downloading or installing drivers it is recommended that you read the Dell Knowledge Based article, Drivers and Downloads FAQ SLN128938.

CAUTION: Unless you are an expert computer user, do not change the settings in the BIOS Setup program. Certain changes can make your computer work incorrectly.

(i) NOTE: Depending on the computer and its installed devices, the items listed in this section may or may not be displayed.

NOTE: Before you change BIOS Setup program, it is recommended that you write down the BIOS Setup program screen information for future reference.

Use the BIOS Setup program for the following purposes:

- Get information about the hardware installed in your computer, such as the amount of RAM and the size of the hard drive.
- Change the system configuration information.
- Set or change a user-selectable option, such as the user password, type of hard drive installed, and enabling or disabling base devices.

Entering BIOS setup program

About this task

Turn on (or restart) your computer and press F2 immediately.

Navigation keys

NOTE: For most of the System Setup options, changes that you make are recorded but do not take effect until you restart the system.

Table 3. Navigation keys

Keys	Navigation
Up arrow	Moves to the previous field.
Down arrow	Moves to the next field.
Enter	Selects a value in the selected field (if applicable) or follow the link in the field.
Spacebar	Expands or collapses a drop-down list, if applicable.
Tab	Moves to the next focus area. NOTE: For the standard graphics browser only.
Esc	Moves to the previous page until you view the main screen. Pressing Esc in the main screen displays a message that prompts you to save any unsaved changes and restarts the system.

Boot Sequence

Boot Sequence allows you to bypass the System Setup-defined boot device order and boot directly to a specific device (for example: optical drive or hard drive). During the Power-on Self Test (POST), when the Dell logo appears, you can:

Access System Setup by pressing F2 key

• Bring up the one-time boot menu by pressing F12 key

The one-time boot menu displays the devices that you can boot from including the diagnostic option. The boot menu options are:

- Removable Drive (if available)
- STXXXX Drive (if available)
 NOTE: XXX denotes the SATA drive number.
- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics

The boot sequence screen also displays the option to access the System Setup screen.

One time boot menu

To enter one time boot menu, turn on your computer, and then press F2 immediately.

(i) NOTE: It is recommended to shutdown the computer if it is on.

The one-time boot menu displays the devices that you can boot from including the diagnostic option. The boot menu options are:

- Removable Drive (if available)
- STXXXX Drive (if available)
 NOTE: XXX denotes the SATA drive number.
- Optical Drive (if available)
- SATA Hard Drive (if available)
- Diagnostics

The boot sequence screen also displays the option to access the System Setup screen.

System setup options

NOTE: Depending on this computer and its installed devices, the items that are listed in this section may or may not be displayed.

Table 4. System setup options—System information menu

Overview		
Inspiron 7306 2-in-1		
BIOS Version	Displays the BIOS version number.	
Service Tag	Displays the Service Tag of the computer.	
Asset Tag	Displays the Asset Tag of the computer.	
Manufacture Date	Displays the manufacture date of the computer.	
Ownership Date	Displays the ownership date of the computer.	
Express Service Code	Displays the express service code of the computer.	
Ownership Tag	Displays the ownership tag of the computer.	
Signed Firmware Update	Displays whether the signed firmware update is enabled.	
	Default: Enabled	
Battery	Displays the battery health information.	
Primary	Displays the primary battery.	
Battery Level	Displays the battery level.	
Battery State	Displays the battery state.	

Table 4. System setup options—System information menu (continued)

Health	Displays the battery health.
AC Adapter	Displays whether an AC adapter is connected. If connected, the AC adapter type.
PROCESSOR	
Processor Type	Displays the processor type.
Maximum Clock Speed	Displays the maximum processor clock speed.
Minimum Clock Speed	Displays the minimum processor clock speed.
Current Clock Speed	Displays the current processor clock speed.
Core Count	Displays the number of cores on the processor.
Processor ID	Displays the processor identification code.
Processor L2 Cache	Displays the processor L2 Cache size.
Processor L3 Cache	Displays the processor L3 Cache size.
Microcode Version	Displays the microcode version.
Intel Hyper-Threading Capable	Displays whether the processor is Hyper-Threading (HT) capable.
64-Bit Technology	Displays whether 64-bit technology is used.
MEMORY	
Memory Installed	Displays the total computer memory installed.
Memory Available	Displays the total computer memory available.
Memory Speed	Displays the memory speed.
Memory Channel Mode	Displays single or dual channel mode.
Memory Technology	Displays the technology that is used for the memory.
DEVICES	
Panel Type	Displays the Panel Type of the computer.
Video Controller	Displays the integrate graphics information of the computer.
Video Memory	Displays the video memory information of the computer.
Wi-Fi Device	Displays the Wi-Fi device installed in the computer.
Native Resolution	Displays the native resolution of the computer.
Video BIOS Version	Displays the video BIOS version of the computer.
Audio Controller	Displays the audio controller information of the computer.
Bluetooth Device	Displays whether a Bluetooth device is installed in the computer.

Table 5. System setup options—Boot Configuration menu

Boot Configuration	
Boot Sequence	
Boot Mode: UEFI only	Displays the boot mode of this computer.
Boot Sequence	Enables or disables Windows Boot Manager and UEFI Hard Drive.
	By default, Windows Boot Manager is selected
	By default, UEFI Hard Drive is selected
Secure Boot	
Enable Secure Boot	Enables secure boot using only validated boot software.

Table 5. System setup options—Boot Configuration menu (continued)

Boot Configuration		
	Default: OFF	
Secure Boot Mode	Changes to the Secure Boot operation mode. Allows to switch between Deployed Mode and Audit Mode.	
	Default: Deployed Mode	
Expert Key Management		
Enable Custom Mode	Allows the PK, KEK, db, and dbx security key databases to be modified.	
Custom Mode Key Management	Allows for selection of key database.	

Table 6. System setup options—Integrated Devices menu

Date/Time	
Date	Sets the computer date in MM/DD/YYYY format. Changes to the date take effect immediately.
Time	Sets the computer time in HH/MM/SS 24-hour format. You can switch between 12-hour and 24-hour clock. Changes to the time take effect immediately.
Camera	
Enable Camera	Enables or disables the camera.
	By default, Enable Camera is selected.
Audio	
Enable Audio	Enables or disables all integrated audio controller.
	Default: ON
Enable Microphone	Enables or disables microphone.
	By default, Enable Microphone is selected.
Enable Internal Speaker	Enables or disables internal speaker.
	By default, Enable Internal Speaker is selected.
USB/Thunderbolt Configuration	
Enable External USB Ports	Enables or disables all external USB ports in an OS environment.
	By default, Enable External USB Ports is selected.
Enable USB Boot Support	Enables or disables booting from USB mass storage devices such as external hard drive, optical drive, and USB drive.
	By default, Enable USB Boot Support is selected.
Enable Thunderbolt Boot Support	Enables or disables Thunderbolt Boot Support.
	Default: OFF
Enable Thunderbolt (and PCIe behind TBT) pre-boot modules	Enables or disables to allow or disallow PCIe devices to be connected throug a Thunderbolt adapter during pre-boot.
	Default: OFF

Table 7. System setup options—Storage menu

Storage	
SATA/NVMe Operation	

Table 7. System setup options—Storage menu (continued)

Storage	
SATA/NVMe Operation	Configures operating mode of the integrated storage device controller.
	Default: RAID On. Storage device is configured to support RAID functions. When enabled, all NVMe and SATA devices will be mapped under VMD controller. Windows RST (Intel Rapid Restore Technology) driver, or Linux kernel VMD driver must be loaded in order to boot the OS.
Storage Interface	
Port Enablement	Enables or disables the onboard drives.
	Default: ON
SMART Reporting	
Enable SMART Reporting	Enables or disables Self-Monitoring, Analysis, and Reporting Technology (SMART).
	Default: OFF
Drive Information	Displays the information of various onboard drives.

Table 8. System setup options—Display menu

Display	
Display Brightness	
Brightness on battery power	Sets the screen brightness when the computer is running on battery power. Default: 50
Brightness on AC power	Sets the screen brightness when the computer is running on AC power. Default: 100
Full Screen Logo	When turned on, the full screen logo is displayed if the image matches the screen resolution. Default: OFF

Table 9. System setup options—Connection menu

Connection	
Enable or disable internal WLAN devices.	
By default, WLAN is selected.	
Enable or disable internal Bluetooth devices.	
By default, Bluetooth is selected.	
Enables or disables UEFI networking protocols, if they are installed and available.	
Default: ON	
:	

Table 10. System setup options—Power menu

Power

Battery Configuration	Enables the computer to run on battery during power usage hours. Use the below options to prevent AC power usage between certain times of each day.
	Default: Adaptive. Battery settings are adaptively optimized based on your typical battery usage pattern.
Advanced Configuration	

Table 10. System setup options—Power menu (continued)

Power	
Enable Advanced Battery Charge Configuration	Enables Advanced Battery Charge Configuration from the beginning of the day to a specified work period. Advanced Battery Charged maximizes battery health while still supporting heavy use during the work day.
	Default: OFF
Thermal Management	Enables the cooling fan and processor heat management to adjust system performance, noise, and temperature.
	Default: Optimized. Standard settings for cooling fan and processor heat management. This setting is a balance of performance, noise, and temperature.
USB Wake Support	
Wake on Dell USB-C Dock	Enables connecting a Dell USB-C Dock to wake the computer from Standby.
	Default: ON
Block Sleep	Blocks the computer from entering Sleep (S3) mode in the operating system.
	Default: OFF
	(i) NOTE: If enabled, the computer will not go to sleep, Intel Rapid Start will be disabled automatically, and the operating system power option will be blank if it was set to Sleep.
Lid Switch	
Enable Lid Switch	Enable or disable the lid switch.
	Default: ON
Power On Lid Open	Enables the computer to power up from the off state whenever the lid is opened.
	Default: ON
Intel Speed Shift Technology	Enables or disables the Intel Speed Shift Technology support. Setting this option to enable allows the operating system to select the appropriate processor performance automatically.
	Default: ON

Table 11. System setup options—Security menu

Security	
Intel Platform Trust Technology	
Intel Platform Trust Technology On	Enable or disable the Intel Platform Trust Technology (PPT) feature in the OS
	Default: ON
PPI Bypass for Clear Commands	Enables or disables the Trusted Platform Model (TPM) Physical Presence Interface (PPI). When enabled, the OS will skip BIOS Physical Presence Interface (PPI) user prompts when issuing the Clear command.
	Default: OFF
Clear	Enables or disables the computer to clear the PTT owner information, and returns the PTT to the default state.
	Default: OFF
SMM Security Mitigation	Enables or disables additional UEFI SMM Security Mitigation protections.
	Default: OFF
	() NOTE: This feature may cause compatibility issues or loss of functionality with some legacy tools and applications.

Table 11. System setup options—Security menu (continued)

curity	
Data Wipe on Next Boot	When enabled, the BIOS will schedule a data wipe cycle for all storage device connected to the system board on the next reboot.
	Default: OFF
Absolute	Enables, disables or permanently disable the BIOS module interface of the optional Absolute Persistence Module service from Absolute Software.
	Default: Enabled
UEFI Boot Path Security	Determines if the system will prompt the user to enter the admin password (in set) when booting to a UEFI boot path device frim the F12 boot menu.
	Default: Always Except Internal HDD.

Table 12. System setup options—Passwords menu

sswords	
Admin Password	Enables the user to set, change, or delete the administrator (admin) passwor The admin password enables several security features
System Password	Enables the user to set, change, or delete the system password.
Password Configuration	
Upper Case Letter	Enforces password restriction that the password must contain at least one upper case letter.
	Default: OFF
Lower Case Letter	Enforces password restriction that the password must contain at least one lower case letter.
	Default: OFF
Digit	Enforces password restriction that the password must contain at least one digit.
	Default: OFF
Special Character	Enforces password restriction that the password must contain at least one special character.
	Default: OFF
Minimum Characters	Controls the minimum number of characters allowed for password.
	Default: 04
Password Bypass	Bypass the System (Boot) Password and the internal hard drive password prompts during a system restart.
	Default: Disabled
Password Changes	
Enable Non-Admin Password Changes	Enables or disables the user to change the system and hard drive password without the need for admin password.
	Default: ON
Admin Setup Lockout	
Enable Admin Setup Lockout	Enables or disables the user from entering BIOS Setup when an Admin Password is set.
	Default: OFF

Table 12. System setup options—Passwords menu (continued)

Passwords	
Enable Master Password Lockout	Enables or disables master password support.
	Default: OFF
	() NOTE: Hard drive passwords must be cleared before the setting can be changed.

Table 13. System setup options—Update, Recovery menu

Update, Recovery	
UEFI Capsule Firmware Updates	Enable or disable internal WLAN/Bluetooth devices.
	By default, WLAN is selected.
	By default, Bluetooth is selected.
Enable UEFI Capsule Firmware Updates	Enables or disables BIOS updates through UEFI capsule update packages.
	Default: ON
BIOS Recovery from Hard Drive	Enables the computer to recover from a bad BIOS image, as long as the Boot Block portion is intact and functioning.
	Default: ON
	(i) NOTE: BIOS recovery is designed to fix the main BIOS block and cannot work if the Boot Block is damaged. In addition, this feature cannot work in the event of EC corruption, ME corruption, or a hardware issue. The recovery image must exist on an unencrypted partition on the drive.
BIOS Downgrade	
Allow BIOS Downgrade	Controls flashing of the system firmware to previous revisions.
	Default: ON
SupportAssist OS Recovery	Enables or disables the boot flow for SupportAssist OS Recovery tool, in the event of certain system error.
	Default: ON
BIOSConnect	Enables or disables cloud Service OS recovery if the main OS fails to boot within the number of failures equal or greater than the value specified by Dell Auto OS Recovery Threshold, and local Service does not boot, or is not installed.
	Default: ON
Dell Auto OS Recovery Threshold	Controls the automatic boot flow for SupportAssist System Resolution Conso and for Dell operating system Recovery tool.
	Default: 2

Table 14. System setup options—System Management menu

ystem Management	
Service Tag	Displays the Service Tag of the computer.
Asset Tag	Creates a system Asset Tag that can be used by an IT administrator to uniquely identify a particular system. Once set in BIOS, the Asset Tag cannot be changed.
AC Behavior	
Wake on AC	Enables or disables basic checks when AC power is applied to the device. The checks include determining how the AC Recovery option is set. The system w

Table 14. System setup options—System Management menu (continued)

System Management	
	boot up if Wake on AC is enabled, the system will power off, if Wake on AC is disabled.
	Default: OFF
Auto On Time	Controls automatic powering up of system for defined days and times.
	Default: Disabled

Table 15. System setup options—Keyboard menu

eyboard	
Numlock Enable	
Enable Numlock	Enables or disables Numlock when the computer boots.
	Default: ON
Fn Lock Options	Enables or disables the Fn lock mode.
	Default: ON
Lock Mode	Controls operation of function keys F1-F12.
	Default: Lock Mode Secondary
Keyboard Illumination	Enables the user to change the keyboard illumination settings.
	Default: Bright
Keyboard Backlight Timeout on AC	Enables the user to define the timeout value for the keyboard backlight when an AC adapter is plugged into the system.
	Default: 1 minute
Keyboard Backlight Timeout on Battery	Enables the user to define the timeout value for the keyboard backlight when the system is operating only on battery power.
	Default: 1 minute

Table 16. System setup options—Pre-boot Behavior menu

re-boot Behavior	
Adapter warnings	
Enable Adapter warnings	Enables or disables the computer to display adapter warning messages when adapters with too little power capacity are detected.
	Default: ON
— Warnings and Errors	Selects an action on encountering a warning or error during boot.
	Default: Prompt on Warnings and Errors. Stop, prompt, and wait for user input when warnings or errors are detected.
	(i) NOTE: Errors deemed critical to the operation of the computer hardware will always halt the computer.
USB-C Warnings	Specify the maximum number of characters allowed for Admin password.
	Default: 32
– Enable Dock Warning Messages	Enable or disable dock warning messages.
	Default: ON
 Fastboot	Configures the speed of the UEFI boot process.

Table 16. System setup options—Pre-boot Behavior menu (continued)

Pre-boot Behavior	
	Default: Thorough. Performs complete hardware and configuration initialization during boot.
Extend BIOS POST Time	Configures the BIOS POST (Power-On Self-Test) load time. Default: 0 seconds

Table 17. System setup options—Virtualization menu

Virtualization	
Intel Virtualization Technology	
Enable Intel Virtualization Technology (VT)	Enables the computer to run a virtual machine monitor (VMM).
	Default: ON
VT for Direct I/O	
Enable Intel VT for Direct I/O	Enables the computer to perform Virtualization Technology for Direct I/O (VT-d). VT-d is an Intel method that provides virtualization for memory map I/O.
	Default: ON

Table 18. System setup options—Performance menu

Performance

Multi-Core Support	
Active Cores	Changes the number of CPU cores available to the operating system. The default value is set to the maximum number of cores.
	Default: All Cores
Intel SpeedStep	
Enable Intel SpeedStep Technology	Enables or disables the Intel SpeedStep Technology to dynamically adjust processor voltage and core frequency, decreasing average power consumption and heat production.
	Default: ON
C-State Control	
Enable C-State Control	Enables or disables the CPU's ability to enter and exit low-power states.
	Default: ON
Intel Turbo Boost Technology	
Enable Intel Turbo Boost Technology	Enabled or disabled the Intel TurboBoost mode of the processor. If enabled, the Intel TurboBoost driver increases the performance of the CPU or graphics processor.
	Default: ON
Intel Hyper-Threading Technology	
Enable Intel Hyper-Threading Technology	Enabled or disabled the Intel Hyper-Threading mode of the processor. If enabled, the Intel Hyper-Threading increases the efficiency of the processor resources when multiple threads run on each core.
	Default: ON

able 10 S

Table 19. System setup options—System Logs menu	
System Logs	
BIOS Event Log	

Table 19. System setup options—System Logs menu (continued)

System Logs		
Clear Bios Event Log	Select keep or clear BIOS events.	
	Default: Keep	
Thermal Event Log		
Clear Thermal Event Log	Select keep or clear Thermal events.	
	Default: Keep	
Power Event Log		
Clear POWER Event Log	Select keep or clear Power events.	
	Default: Keep	

Clearing CMOS settings

About this task

CAUTION: Clearing CMOS settings will reset the BIOS settings on your computer.

Steps

- **1.** Turn off your computer.
- 2. Follow the steps in Removing the base cover.

(i) NOTE: Ensure that the battery cable is disconnected from the system board.

- **3.** Press and hold the power button for 15 seconds to drain the flea power.
- 4. Before you turn on your computer, follow the steps in Installing the base cover.
- 5. Turn on your computer.

Clearing BIOS (System Setup) and System passwords

About this task

To clear the system or BIOS passwords, contact Dell technical support as described at www.dell.com/contactdell.

NOTE: For information on how to reset Windows or application passwords, refer to the documentation accompanying Windows or your application.

5

Troubleshooting

SupportAssist diagnostics

About this task

The SupportAssist diagnostics (previously known as ePSA diagnostics) performs a complete check of your hardware. The SupportAssist diagnostics is embedded in the BIOS and is launched by it internally. The SupportAssist diagnostics provides a set of options for particular devices or device groups. It allows you to:

- Run tests automatically or in an interactive mode.
- Repeat tests
- Display or save test results
- Run thorough tests to introduce additional test options and provide extra information about the failed device(s)
- View status messages that indicate if the tests are completed successfully
- View error messages that indicate if problems were encountered during the test

NOTE: Some tests are meant for specific devices and require user interaction. Ensure that you are present in front of the computer when the diagnostic tests are performed.

For more information, see SupportAssist Pre-Boot System Performance Check.

Locate the Service Tag or Express Service Code of your Dell computer

Your Dell computer is uniquely identified by a Service Tag or Express Service Code. To view relevant support resources for your Dell computer, we recommend entering the Service Tag or Express Service Code at www.dell.com/support.

For more information on how to find the Service Tag for your computer, see Locate the Service Tag for your Dell Laptop.

System diagnostic lights

Battery-status light

Indicates the power and battery-charge status.

Solid white — Power adapter is connected and the battery has more than 5 percent charge.

Amber — Computer is running on battery and the battery has less than 5 percent charge.

Off

- Power adapter is connected, and the battery is fully charged.
- Computer is running on battery, and the battery has more than 5 percent charge.
- Computer is in sleep state, hibernation, or turned off.

The battery-status light blinks amber along with beep codes indicating failures.

For example, the battery-status light blinks amber two times followed by a pause, and then blinks white three times followed by a pause. This 2,3 pattern continues until the computer is turned off indicating no memory or RAM is detected.

The following table shows different power and battery-status light patterns and associated problems.

Table 20. LED codes

Diagnostic light codes	Problem description
2,1	Processor failure
2,2	System board: BIOS or ROM (Read-Only Memory) failure
2,3	No memory or RAM (Random-Access Memory) detected
2,4	Memory or RAM (Random-Access Memory) failure
2,5	Invalid memory installed
2,6	System-board or chipset error
2,7	Display failure
3,1	Coin-cell battery failure
3,2	PCI, video card/chip failure
3,3	Recovery image not found
3,4	Recovery image found but invalid

Camera status light: Indicates whether the camera is in use.

- Solid white Camera is in use.
- Off Camera is not in use.

Caps Lock status light: Indicates whether Caps Lock is enabled or disabled.

- Solid white Caps Lock enabled.
- Off Caps Lock disabled.

Recovering the operating system

When your computer is unable to boot to the operating system even after repeated attempts, it automatically starts Dell SupportAssist OS Recovery.

Dell SupportAssist OS Recovery is a standalone tool that is preinstalled in all Dell computers installed with Windows 10 operating system. It consists of tools to diagnose and troubleshoot issues that may occur before your computer boots to the operating system. It enables you to diagnose hardware issues, repair your computer, back up your files, or restore your computer to its factory state.

You can also download it from the Dell Support website to troubleshoot and fix your computer when it fails to boot into their primary operating system due to software or hardware failures.

For more information about the Dell SupportAssist OS Recovery, see *Dell SupportAssist OS Recovery User's Guide* at www.dell.com/support.

Flashing the BIOS

About this task

You may need to flash (update) the BIOS when an update is available or when you replace the system board. Follow these steps to flash the BIOS:

Steps

- 1. Turn on your computer.
- 2. Go to www.dell.com/support.
- 3. Click Product support, enter the Service Tag of your computer, and then click Submit.

(i) NOTE: If you do not have the Service Tag, use the auto-detect feature or manually browse for your computer model.

- 4. Click Drivers & downloads > Find it myself.
- 5. Select the operating system installed on your computer.
- 6. Scroll down the page and expand BIOS.
- 7. Click **Download** to download the latest version of the BIOS for your computer.
- 8. After the download is complete, navigate to the folder where you saved the BIOS update file.
- 9. Double-click the BIOS update file icon and follow the instructions on the screen.

Flashing BIOS (USB key)

Steps

- 1. Follow the procedure from step 1 to step 7 in "Flashing the BIOS" to download the latest BIOS setup program file.
- 2. Create a bootable USB drive. For more information see the knowledge base article SLN143196 at www.dell.com/support.
- 3. Copy the BIOS setup program file to the bootable USB drive.
- 4. Connect the bootable USB drive to the computer that needs the BIOS update.
- 5. Restart the computer and press F12 when the Dell logo is displayed on the screen.
- 6. Boot to the USB drive from the One Time Boot Menu.
- 7. Type the BIOS setup program filename and press Enter.
- 8. The BIOS Update Utility appears. Follow the instructions on the screen to complete the BIOS update.

Backup media and recovery options

It is recommended to create a recovery drive to troubleshoot and fix problems that may occur with Windows. Dell proposes multiple options for recovering Windows operating system on your Dell PC. For more information. see Dell Windows Backup Media and Recovery Options.

WiFi power cycle

About this task

If your computer is unable to access the Internet due to WiFi connectivity issues, a WiFi power cycle procedure may be performed. The following procedure provides the instructions on how to conduct a WiFi power cycle:

(i) NOTE: Some ISPs (Internet Service Providers) provide a modem/router combo device.

Steps

- 1. Turn off your computer.
- 2. Turn off the modem.
- 3. Turn off the wireless router.
- 4. Wait for 30 seconds.
- 5. Turn on the wireless router.
- 6. Turn on the modem.
- 7. Turn on your computer.

Flea power release

About this task

Flea power is the residual static electricity that remains on the computer even after it has been powered off and the battery has been disconnected from the system board. The following procedure provides the instructions on how to release the flea power:

- 1. Turn off your computer.
- **2.** Follow the steps in Removing the base cover.

(i) NOTE: Ensure that the battery is disconnected from the system board.

- **3.** Press and hold the power button for 15 seconds to drain the flea power.
- **4.** Follow the steps in Installing the base cover.
- 5. Turn on your computer.

6

Getting help and contacting Dell

Self-help resources

You can get information and help on Dell products and services using these self-help resources:

Table 21. Self-help resources

Self-help resources	Resource location
Information about Dell products and services	www.dell.com
My Dell	Deell
Tips	· •
Contact Support	In Windows search, type Contact Support, and press Enter.
Online help for operating system	www.dell.com/support/windows www.dell.com/support/linux
Troubleshooting information, user manuals, set up instructions, product specifications, technical help blogs, drivers, software updates, and so on.	www.dell.com/support
Dell knowledge base articles for a variety of computer concerns	 Go to www.dell.com/support. On the menu bar at the top of the Support page, select Support > Knowledge Base. In the Search field on the Knowledge Base page, type the keyword, topic, or model number, and then click or tap the search icon to view the related articles.
 Learn and know the following information about your product: Product specifications Operating system Setting up and using your product Data backup Troubleshooting and diagnostics Factory and system restore BIOS information 	 See Me and My Dell at www.dell.com/support/manuals. To locate the Me and My Dell relevant to your product, identify your product through one of the following: Select Detect Product. Locate your product through the drop-down menu under View Products. Enter the Service Tag number or Product ID in the search bar.

Contacting Dell

To contact Dell for sales, technical support, or customer service issues, see www.dell.com/contactdell.

(i) NOTE: Availability varies by country/region and product, and some services may not be available in your country/region.

NOTE: If you do not have an active Internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell product catalog.