# User Guide

Quality, Design and Innovation

home.liebherr.com/fridge-manuals

LIEBHERR

# Contents


**1 Appliance at a glance..... 3**
1.1 Scope of delivery..... 3
1.2 Overview of appliances and equipment..... 3
1.3 SmartDevice..... 3
1.4 Appliance range of use..... 4
1.5 Conformity..... 4
1.6 SVHC substances according to REACH regulation. 4
1.7 EPREL database..... 4

**2 General safety instructions..... 4**

**3 Functionality of the Touch & Swipe display..... 6**
3.1 Navigation and symbol explanation..... 6
3.2 Menus..... 6
3.3 Sleep mode..... 7

**4 Putting into operation..... 7**
4.1 Switching on appliance (first use)..... 7

**5 Storage..... 7**
5.1 Information regarding storage..... 7
5.2 Fridge compartment..... 8
5.3 BioFresh..... 8
5.4 ****-freezer compartment*..... 8
5.5 Storage times..... 8

**6 Saving energy..... 9**

**7 Controls..... 9**
7.1 Controls and displays..... 9
7.1.1 Status display..... 9
7.1.2 Display symbols..... 9
7.2 Appliance functions..... 10
7.2.1 Notes on the appliance functions..... 10
Turn off appliance..... 10
WiFi..... 10
Temperature..... 11
Temperature unit..... 11
BioFresh B-Value..... 11
C-Value*..... 12
D-Value..... 12
SuperCool..... 12
PartyMode..... 12
HolidayMode..... 13
SabbathMode..... 13
EnergySaver..... 13
CleaningMode..... 14
Display brightness..... 14
Door alarm..... 14
Input lock..... 14
Language..... 15
Info..... 15
Reminder..... 15
Demo mode..... 15
Reset..... 16
7.3 Fault messages..... 16
7.3.1 Warnings..... 16

**8 Features..... 17**
8.1 4-star freezer compartment*..... 17
8.2 Door rack..... 17
8.3 Shelves..... 18
8.4 Dividing shelf..... 18
8.5 VarioSafe*..... 19
8.6 Space for baking tray..... 21
8.7 Adjustable bottle shelf..... 21
8.8 Drawers..... 22
8.9 Fruit & Vegetable safe cover..... 22
8.10 Adjusting the moisture levels..... 23
8.11 Butter dish..... 23
8.12 Egg rack..... 23
8.13 Bottle holder..... 24
8.14 FlexSystem..... 24
8.15 Ice cube tray with cover*..... 25

**9 Maintenance..... 25**
9.1 FreshAir carbon filter..... 25
9.2 Disassembling / assembling pull-out systems..... 25
9.3 Defrosting the appliance..... 26
9.4 Defrosting the freezer compartment manually*..... 26
9.5 Cleaning the appliance..... 26


**10 Customer help..... 27**
10.1 Technical specifications..... 27
10.2 Operating noises..... 27
10.3 Technical fault..... 27
10.4 Customer Service..... 28
10.5 Model plate..... 29

**11 Shutting down..... 29**

**12 Disposal..... 29**
12.1 Preparing appliance for disposal..... 29
12.2 Disposing of the appliance in an environmentally friendly manner..... 29


The manufacturer is continually working on the further development of all types and models. Please be aware that we reserve the right to make changes to the shape, equipment and technology.

| Symbol | Explanation |
|---|---|
|  | **Read instructions**<br>Please read the information in these instructions carefully to understand all of the benefits of your new appliance. |

| Symbol | Explanation |
|---|---|
| | **Full instructions on the internet**<br>You can find detailed instructions on the internet using the QR code on the front of these instruction or by entering the service number at **home.liebherr.com/fridge-manuals**.<br>The service number can be found on the serial tag:<br><br>*Fig.* Example illustration |
| | **Check appliance**<br>Check all parts for transport damage. If you have any complaints, please contact your agent or customer service. |
| | **Differences**<br>These instructions apply to a range of models, so differences are possible. Sections that apply to certain models only are marked with an asterisk (*). |
| | **Instructions and results**<br>Instructions are marked with a ▶.<br>Results are marked with a ▷. |
| | **Videos**<br>Videos about the appliances are available on the YouTube channels of Liebherr-Hausgeräte. |

These operating instructions apply to:

| | |
|---|---|
| IRB..i | 40.. / 41.. / 45.. / 48.. / 51.. |
| IKB 51Vc50i | |
| IKB 51Vc51i | |

# 1 Appliance at a glance

## 1.1 Scope of delivery

Check all parts for transport damage. Contact your dealer or customer service in the event of complaints. (see 10.4 Customer Service)

Your new appliance comes with the following parts:

- Built-in appliance
- Features (depending on the model)
- Installation materials (depending on the model)
- “Quick Start Guide”
- “Installation Guide”
- Service Brochure

## 1.2 Overview of appliances and equipment





*Fig. 1 Example illustration*

**Temperature range**

**(A)** Fridge compartment
**(B)** BioFresh
**(C)** Coldest zone

**Equipment**

**(1)** Controls
**(2)** 4-star freezer compartment*
**(3)** Fan with FreshAir activated charcoal filter
**(4)** Dry rear panel
**(5)** Divisible storage shelf
**(6)** Storage shelf
**(7)** VarioSafe*
**(8)** Space for baking tray
**(9)** Variable bottle shelf
**(10)** Lid for Fruit & Vegetable safe
**(11)** Fruit & Vegetable safe
**(12)** Drain hole
**(13)** Meat & Dairy safe
**(14)** Type plate
**(15)** Door shelf
**(16)** Bottle holder
**(17)** VarioBoxes*
**(18)** Soft-closing mechanism
**(19)** Adjusting feet

**Note**

▶ Shelves, drawers and baskets are arranged for optimum energy efficiency when the appliance is delivered. Changing how the shelves, for example, are inserted in the fridge compartment does not have any impact on energy consumption.

## 1.3 SmartDevice

SmartDevice is the networking solution for your refrigerator.

If your appliance SmartDevice-enabled or compatible, you can quickly and easily connect your appliance to your WiFi. With the SmartDevice app, you can operate your appliance from a mobile device. Additional functions and setting options are available in the SmartDevice SmartDevice app.

| | |
|---|---|
| SmartDevice-enabled appliance: | Your appliance is capable of being a SmartDevice. To be able to connect your device to WiFi, you need to download the SmartDevice app. |
| More information about SmartDevice: | **smartdevice.liebherr.com** |
| Downloading the SmartDevice app: | After installing and configuring the SmartDevice, you can connect your appliance to the WiFi using the SmartDevice app and the WiFi appliance function (see WiFi) . |

**Note**
The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

## 1.4 Appliance range of use

### Intended use

The appliance is only suitable for cooling food products in a domestic or household-like environment. This includes, for example, use:

- in staff kitchens, bed and breakfast establishments,
- by guests in country houses, hotels, motels and other accommodation,
- for catering and similar services in the wholesale trade.

The appliance is not suitable for freezing food;*

All other types of use are not permitted.

### Foreseeable misuse

The following applications are expressly forbidden:

- Storing and refrigerating medicines, blood plasma, laboratory preparations or similar substances and products based on the Medical Device Directive 2007/47/EC
- Use in areas at risk of explosions

Misusing the appliance may lead to damage to the goods stored or they may spoil.

### Climate classifications

Depending on the climate classification the appliance is designed to operate in restricted ambient temperatures. The climate classification applying to your appliance is printed on the rating plate.

**Note**
▶ Keep to the specified ambient temperatures in order to guarantee that the appliance works properly.

| Climate classification | for ambient temperatures of |
|---|---|
| SN | 10 °C to 32 °C |
| N | 16 °C to 32 °C |
| ST | 16 °C to 38 °C |
| T | 16 °C to 43 °C |
| SN-ST | 10 °C to 38 °C |
| SN-T | 10 °C to 43 °C |

## 1.5 Conformity

The refrigerant circuit has been tested for leaks. When installed, the appliance complies with the applicable safety regulations and with the corresponding directives.

| | | |
|---|---|---|
| For the market: | EU | The appliance complies with directive 2014/53/EU. |
| For the market: | GB | The appliance complies with Radio Equipment Regulations 2017 SI 2017 No. 1206. |

The full text of the EU Declaration of Conformity is available on the following website: www.Liebherr.com

The BioFresh compartment meets the requirements of a cold storage compartment as set out in DIN EN 62552:2020.

## 1.6 SVHC substances according to REACH regulation

You can check whether your appliance contains SVHC substances according to REACH regulation at the following link: home.liebherr.com/de/deu/de/liebherr-erleben/nachhaltigkeit/umwelt/scip/scip.html

## 1.7 EPREL database

Details about energy labelling and ecodesign requirements will be available on the European product database (EPREL) from 1st March 2021. You can access the product database at the following link: https://eprel.ec.europa.eu/ You will be asked to enter the model ID. You can find the model ID on the nameplate.

# 2 General safety instructions

Please keep these operating instructions in a safe place so you can refer back to them at any time.

If you pass the appliance on, please hand these operating instructions to the next user.

Read these operating instructions carefully before use to ensure safe and correct use of the appliance. Follow the instructions, safety instructions and warning messages included



* Depending on model and options

at all times. They are important for ensuring you can operate and install the appliance safely and without any problems.

**Danger for the user:**

- This device can be used by children and people with impaired physical, sensory or mental abilities or with a lack of experience and knowledge provided that they are supervised or have received instruction in the safe use of this device, and about the resulting hazards. Children must not play with this appliance. Cleaning and user maintenance work must not be carried out by children without adult supervision. Children aged between 3 and 8 are allowed to load and unload the appliance. Children below the age of 3 must be kept away from the appliance unless they are under continuous adult supervision.
- The socket must be easily accessible so that the appliance can be disconnected quickly from the electricity in an emergency. It must not be located in the area behind the appliance.
- When disconnecting the appliance from the supply, always take hold of the plug. Do not pull the cable.
- In the event of a fault pull out the mains plug or deactivate the fuse.
- Do not damage the mains power cable. Do not operate the appliance with a defective mains power cable.
- Only customer service or other specially trained staff may repair or perform other operations on the appliance.
- Only install, connect and dispose of the appliance according to the instructions.
- Only use the appliance when is installed.

**Fire hazard:**

- The coolant used (information on the model plate) is ecofriendly but also flammable. Any leaking coolant may ignite.
  - Do not damage the refrigerant circuit pipes.
  - Do not handle ignition sources inside the appliance.
  - Do not use electrical appliances inside the appliance (e.g. steam cleaners, heaters, ice cream makers, etc.).
  - If the refrigerant leaks: remove any naked flames or ignition sources from the vicinity of the leakage point. Properly air the room. Inform customer services.
- Do not store explosives or sprays using combustible propellants such as butane, propane, pentane, etc. in the appliance. To identify these spray cans, look for the list of contents printed on the can, or a flame symbol. Gases possibly escaping may ignite due to electrical components.
- Keep burning candles, lamps and other items with naked flames away from the appliance so that they do not set the appliance on fire.
- Please be sure to store alcoholic drinks or other packaging containing alcohol in tightly closed containers. Any alcohol that leaks out may be ignited by electrical components.

**Danger of tipping and falling:**

- Do not misuse the plinth, drawers, doors etc. as a step or for support. This applies particularly to children.

**Danger of food poisoning:**

- Do not consume food which has been stored too long.

**Danger of frostbite, numbness and pain:**

- Avoid prolonged skin contact with cold surfaces or refrigerated/frozen goods or take protective measures, e.g wear gloves.

**Danger of injury and damage:**

- Hot steam can lead to injury. Do not use electrical heating or steam cleaning equipment, open flames or defrosting sprays to defrost.
- Do not use sharp implements to remove the ice.

**Risk of crushing:**

- Do not hold the hinge when opening and closing the door. Fingers may get caught.

**Symbols on the appliance:**



This symbol may be located on the compressor. It relates to the oil in the compressor and makes reference to the risk that: Swallowing or inhaling can be fatal. This advice is only relevant to recycling. There is no danger in normal operation.



This symbol is located on the compressor and indicates the danger of flammable materials. Do not remove the sticker.



This or a similar sticker may be located on the rear of the appliance. This sticker indicates that there are vacuum insulation panels (VIP) or perlite panels in the door and/or housing. This advice is only relevant to recycling. Do not remove the sticker.

**Please note the warning messages and other specific advice in the other chapters:**




| | | |
|---|---|---|
| ⚠ | DANGER | indicates an immediately hazardous situation which will lead to death or serious injuries if it is not avoided. |
| ⚠ | WARNING | indicates a hazardous situation which may lead to death or serious injuries if it is not avoided. |
| ⚠ | CAUTION | indicates a hazardous situation which may lead to minor or moderate injuries if it is not avoided. |
| | NOTICE | indicates a hazardous situation which may lead to damage to property if it is not avoided. |
| | Note | indicates useful instructions and tips. |

# 3 Functionality of the Touch & Swipe display

You operate your appliance using the Touch & Swipe display. You select appliance functions in the Touch & Swipe display (hereafter referred to as display) by tapping them. If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display.

## 3.1 Navigation and symbol explanation


In the illustrations, different symbols are used to navigate the display. The following table describes these symbols.

| Symbol | Description |
|---|---|
|  | **Briefly touch the display:**<br>Activates/deactivates function.<br>Confirms selection.<br>Opens submenu. |
|   | **Touch the display for a specified time (e.g. 3 seconds):**<br>Activates/deactivates function or value. |
|  | **Swipe left or right:**<br>Navigate in the menu. |
|   | **Briefly touch the Back symbol:**<br>Jumps back one menu level. |
|   | **Press and hold the Back symbol for 3 seconds:**<br>Jumps back to the status display. |
| ➡<br>🕒 | **Arrow with clock:**<br>It takes more than 10 seconds for the following message to appear in the display. |
| ➡ ➡ ➡<br>2s 5s 10s | **Arrow with a time indication:**<br>It takes the specified amount of time until the following message appears in the display. |
|  | **"Open Settings menu" symbol:**<br>Navigates to the Settings menu and opens the settings menu.<br>If necessary: Navigate to the desired function in the Settings menu.<br>(see 3.2.1 Opening the Settings menu) |
|  | **"Open Advanced menu" symbol:**<br>Navigates to the Advanced menu and opens the advanced menu.<br>If necessary: Navigate to the desired function in the Advanced menu.<br>(see 3.2.2 Opening the expanded menu) |
| No action for 10 seconds | If you do not perform any action on the display for 10 seconds, the display either jumps back to the higher-level menu or directly to the status display. |
| Open door and close it again. | If you open the door and immediately close it again, the display jumps directly back to the status display. |

*Note: Illustrations of the display are shown in the English version.*

## 3.2 Menus

The appliance functions are distributed over various menus:

| Menu | Description |
|---|---|
| Main menu | When you switch the appliance on, you are automatically in the main menu.<br>From here you can navigate to the most important appliance functions, to the Settings menu and to the Advanced menu. |
|  <br>Settings menu | The Settings menu contains additional appliance functions for setting up your appliance. |
| Advanced menu | The advanced menu contains special appliance functions for setting up your appliance. Access to the Advanced menu is protected by the numerical code **1 5 1**. |

### 3.2.1 Opening the Settings menu





*Fig. 2 Example illustration*



*** Depending on model and options**

▶ Carry out action steps according to the illustration.
▷ Settings menu is open.
▶ If necessary: Navigate to the desired function.

### 3.2.2 Opening the expanded menu



*Fig. 3*





*Fig. 4 Example illustration, access with numerical code **151***

▶ Carry out action steps according to the illustration.
▷ The expanded menu is open.
▶ If necessary: Navigate to the desired function.

## 3.3 Sleep mode

If you do not touch the display for 1 minute, the display switches to sleep mode. In sleep mode, the display brightness is dimmed.

### 3.3.1 Ending sleep mode

▶ Touch the display briefly with your finger.
▷ Sleep mode is ended.

# 4 Putting into operation

## 4.1 Switching on appliance (first use)

Make sure that the following requirements are fulfilled:

❑ The appliance is properly installed and connected according to the installation instructions.
❑ All adhesive strips, adhesive and protective films and transport locks are removed from inside and on the appliance.
❑ All marketing leaflets are removed from the drawers.
❑ You are familiar with the functionality of the Touch & Swipe display. (see 3 Functionality of the Touch & Swipe display)

**Switch on the appliance using the Touch & Swipe display:**

▶ If the display is in sleep mode: Briefly touch the display.
▶ Carry out action steps according to the illustration.





*Fig. 5 Example illustration*

▷ The status display appears.
▷ The appliance cools to the temperature set at the factory.
▷ The appliance starts in demo mode (status display with DEMO appears): If the appliance starts in demo mode, you can deactivate demo mode within the next 5 minutes. (see Demo mode)

**More information:**

- Start the SmartDevice for the first time. (see 1.3 SmartDevice) and (see WiFi)

**Note**
The manufacturer recommends:

▶ Stock with food: Wait for around 6 hours until the set temperature is reached.
▶ **Store frozen foods** at -18 °C or colder.*
▶ Observe the notes on storing food. (see 5.1 Information regarding storage)

**Note**
Accessories can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

# 5 Storage

## 5.1 Information regarding storage

**WARNING**
Risk of fire

▶ Do not use any electrical appliances in the food area of the appliance unless recommended by the manufacturer.

**Note**
The energy consumption increases and the cooling power goes down if ventilation is not sufficient.

▶ Always keep air slots clear.

Observe the following specifications for storage:

- Keep the air vents on the inside of the rear wall free.
- Keep the air vents on the fan free.
- In the freezer compartment: Package food properly.*
- Package or cover foods that readily take on or give off odours or taste in closed containers.
- Package raw meat or fish in clean, closed containers. This will prevent meat or fish from touching or dripping onto other food.
- Keep liquids in closed containers.
- Leave space between goods to ensure good air circulation.

- Store food according to the instructions on the packaging.
- Always observe the best-before date indicated on the packaging.

**Note**
Failure to follow these guidelines can lead to foodstuffs spoiling.

## 5.2 Fridge compartment

The air circulation in the appliance creates different temperature zones. You will find the different temperature zones in the appliance and equipment overview. (see 1.2 Overview of appliances and equipment)

### 5.2.1 Arranging your food properly

▶ Upper area and door: Store butter, cheese, tinned food and tubes.
▶ Coldest temperature zone: Store perishable foods such as pre-cooked meals.

## 5.3 BioFresh

BioFresh will extend the storage time for some fresh foods compared to traditional refrigeration.

**Note**
If the temperature drops below 0 °C foods may freeze.
▶ Store cold-sensitive produce such as cucumbers, aubergines, courgettes and tropical fruit in the fridge compartment.

### 5.3.1 Fruit & Vegetable safe

This safe creates a storage climate of close to 0 °C. The tight lid ensures constant levels of humidity. This storage climate is suitable for storing unpackaged food with high intrinsic moisture (for example, lettuce, vegetables, fruit).

The humidity in the compartment depends on the moisture content of the chilled goods placed in it, and also depends on how often the compartment is opened. You can regulate the humidity level. (see 8.10 Adjusting the moisture levels)

**Arranging your food properly**

▶ Store unpackaged fruit and vegetables.
If the humidity is too high:
▶ Regulate the humidity. (see 8.10 Adjusting the moisture levels)

### 5.3.2 Meat & Dairy safe

This safe creates a storage climate of close to 0 °C. This storage climate is suitable for more sensitive foods (e.g. dairy products, meat, fish, sausage).

**Arranging your food properly**

▶ Store dry or packaged food.

## 5.4 ****-freezer compartment*

Here, a dry, frosty storage climate is created at -18 °C. The frosty storage climate is suitable for storing frozen food for several months, for making ice cubes or freezing fresh food.

The air temperature in the freezer compartment, measured with a thermometer or other measuring device, may fluctuate. Temperature fluctuations are greater in a half-full or empty freezer and it is possible to attain temperatures warmer than -18 °C.

### 5.4.1 Freezing food

The maximum amount of fresh food that you can freeze within 24 hours is specified on the type plate (see 10.5 Model plate) under “Freezing capacity ... kg/24h”.

To ensure that food quickly freezes through, adhere to the following quantities per package:

- Fruit and vegetables up to 1 kg
- Meat up to 2.5 kg

**Arranging your food properly**

**CAUTION**
Risk of injury due to broken glass!
Bottles and cans containing drinks may burst when being frozen. This applies particularly to sparkling drinks.
▶ Do not freeze bottles and cans containing drinks!

▶ For maximum freezing performance: Remove glass plate before freezing.*
▶ Place packaged food in the freezer compartment in such a way that it is in contact with the bottom or sides.

**Defrosting food**

**WARNING**
Risk of food poisoning!
▶ Do not re-freeze thawed food.
▶ Use defrosted foodstuff as soon as possible.

You can defrost food in several ways:

- In the fridge compartment
- In the microwave
- In the oven/fan-assisted oven
- At room temperature

▶ Take out only as much food as necessary.

## 5.5 Storage times

Refer to the specified storage times as a guide.

In the case of foods with a minimum shelf life, the date indicated on the packaging still applies.

### 5.5.1 Fridge section

Always follow the best-before date stated on the packaging.

### 5.5.2 BioFresh

| Recommended storage periods in the Meat & Dairy-Safe | | |
|---|---|---|
| Butter | at 1 °C | up to 90 days |
| Hard cheese | at 1 °C | up to 110 days |
| Milk | at 1 °C | up to 12 days |
| Sausage, cold meats | at 1 °C | up to 8 days |
| Poultry | at 1 °C | up to 6 days |
| Pork | at 1 °C | up to 6 days |
| Beef | at 1 °C | up to 6 days |
| Game | at 1 °C | up to 6 days |

**Note**
▶ Remember that high-protein foods perish quicker; shellfish and crustaceans do not last as long as fish, and fish does not last as long as meat.


* Depending on model and options

| Recommended storage periods in the Fruit & Vegetable-Safe | | |
|---|---|---|
| **Vegetables, salads** | | |
| Artichokes | at 1 °C | up to 14 days |
| Celery | at 1 °C | up to 28 days |
| Cauliflower | at 1 °C | up to 21 days |
| Broccoli | at 1 °C | up to 13 days |
| Chicory | at 1 °C | up to 27 days |
| Lettuce | at 1 °C | up to 19 days |
| Peas | at 1 °C | up to 14 days |
| Kale | at 1 °C | up to 14 days |
| Carrots | at 1 °C | up to 80 days |
| Garlic | at 1 °C | up to 160 days |
| Turnip | at 1 °C | up to 14 days |
| Lettuce | at 1 °C | up to 13 days |
| Herbs | at 1 °C | up to 13 days |
| Leeks | at 1 °C | up to 29 days |
| Mushrooms | at 1 °C | up to 7 days |
| Radishes | at 1 °C | up to 10 days |
| Brussels sprouts | at 1 °C | up to 20 days |
| Asparagus | at 1 °C | up to 18 days |
| Spinach | at 1 °C | up to 13 days |
| Savoy | at 1 °C | up to 20 days |
| **Fruit** | | |
| Apricots | at 1 °C | up to 13 days |
| Apples | at 1 °C | up to 80 days |
| Pears | at 1 °C | up to 55 days |
| Blackberries | at 1 °C | up to 3 days |
| Dates | at 1 °C | up to 180 days |
| Strawberries | at 1 °C | up to 7 days |
| Figs | at 1 °C | up to 7 days |
| Blueberries | at 1 °C | up to 9 days |
| Raspberries | at 1 °C | up to 3 days |
| Currants | at 1 °C | up to 7 days |
| Sweet cherries | at 1 °C | up to 14 days |
| Kiwis | at 1 °C | up to 80 days |
| Peaches | at 1 °C | up to 13 days |
| Plums | at 1 °C | up to 20 days |
| Cranberries | at 1 °C | up to 60 days |
| Rhubarb | at 1 °C | up to 13 days |
| Gooseberries | at 1 °C | up to 13 days |
| Grapes | at 1 °C | up to 29 days |

### 5.5.3 Freezer compartment*

| Recommended shelf-lives for various types of food | | |
|---|---|---|
| Ice cream | at -18 °C | 2 to 6 months |
| Cold cuts, ham | at -18 °C | 2 to 3 months |
| Bread, baked goods | at -18 °C | 2 to 6 months |
| Game, pork | at -18 °C | 6 to 9 months |
| Fatty fish | at -18 °C | 2 to 6 months |
| Lean fish | at -18 °C | 6 to 8 months |
| Cheese | at -18 °C | 2 to 6 months |
| Poultry, beef | at -18 °C | 6 to 12 months |
| Vegetables, fruit | at -18 °C | 6 to 12 months |

# 6 Saving energy

- Pay attention to good ventilation. Do not cover ventilation holes or grids.
- Always keep the fan air slits clear.
- Do not install the appliance in direct sunlight, next to an oven, radiator or similar.
- Energy consumption depends on the installation conditions, e.g. the ambient temperature (see 1.4 Appliance range of use) . A warmer ambient temperature can increase the energy consumption.
- Open the appliance for as short a time as possible.
- The lower the temperature is set the higher the energy consumption.
- Sort your food: home.liebherr.com/food.
- Keep all food properly packed and covered. This prevents frost from forming.
- Only take food out for as long as necessary so that it doesn't warm up too much.
- Inserting warm food: allow to cool down to room temperature first.
- Thaw frozen food in the refrigerator.*
- If there is a thick layer of frost in the appliance: defrost the appliance.*
- For longer periods of absence, use HolidayMode (see HolidayMode) .

# 7 Controls

## 7.1 Controls and displays

### 7.1.1 Status display




*Fig. 6*

**(1)** Temperature display of the fridge section

**(2)** Temperature display BioFresh

The Status display shows the set temperatures and is the home display. From there, you can navigate to the options and settings.

### 7.1.2 Display symbols

Display symbols provide information on the current appliance status:

| Symbol | Appliance status |
|---|---|
|  | **Standby**<br>The appliance or temperature zone is switched off. |
| <br> | **Flashing number**<br>Appliance is working. Temperature flashes until the set temperature is reached. |
| <br> | **Flashing symbol**<br>Appliance is working. Setting is made. |

## 7.2 Appliance functions

### 7.2.1 Notes on the appliance functions

The appliance functions are set at the factory so that your appliance is fully functional.

Before you alter, activate or deactivate the device functions, make sure that the following requirements are met:

❑ You have read and understood the descriptions of how the display works.
❑ You have familiarised yourself with the operating and display elements of your appliance.

### Turn off appliance

This setting turns off the whole appliance.

**Switching off the entire appliance**



*Fig. 7*





*Fig. 8*

▷ Off: Display goes black.

### WiFi

Use this function to connect your appliance to WiFi. You can then operate it via the SmartDevice app on a mobile device. You can also use this function to disconnect or reset the WiFi connection.

More information on the SmartDevice: (see 1.3 SmartDevice)

**Note**
The SmartDevice function is not available in the following countries: Russia, Belarus, Kazakhstan.

**Establishing the WiFi connection for the first time**

Make sure that the following requirements are fulfilled:

❑ You have installed the SmartDevice app (see apps.home.liebherr.com).
❑ Registration in the SmartDevice app is completed.



*Fig. 9*





*Fig. 10*

▶ Carry out action steps according to the illustration.
▷ Connection is established.

**Disconnecting from the WiFi**



*Fig. 11*





*Fig. 12*

▶ Carry out action steps according to the illustration.
▷ There is no connection.

**Resetting the WiFi connection**



*Fig. 13*





*Fig. 14*

▶ Carry out action steps according to the illustration.
▷ WiFi connection and other WiFi settings are reset to factory settings.

**Showing information about the WiFi connection**



*Fig. 15*





*Fig. 16 **

▶ Carry out action steps according to the illustration.

## 5 °C Temperature

Use this function to set the temperature.

The temperature depends on the following factors:

- How often the door is opened
- How long the door is open for
- The room temperature of the installation site
- The type, temperature and amount of food

| Temperature zone | Recommended setting |
|---|---|
| 5 °C Fridge compartment | 5 °C |
| 0 °C BioFresh | (see Setting the temperature in the BioFresh) |

**Setting the temperature in the fridge compartment**





*Fig. 17*

▶ Carry out action steps according to the illustration.
▷ Temperature is set.

**Setting the temperature in the BioFresh**

You can set the temperature using the **BioFresh B-Value** in the customer menu.

## °C/°F Temperature unit

Use this function to set the temperature unit. You can set degrees Celsius or degrees Fahrenheit as the temperature unit.

**Setting the temperature unit**



*Fig. 18*





*Fig. 19 Example illustration: Switch from degrees Celsius to degrees Fahrenheit.*

▶ Carry out action steps according to the illustration.
▷ The temperature unit is set.

## B5 BioFresh B-Value

When delivered, the temperature in the BioFresh compartment is set to **B5**. The status indicator on the display shows the target temperature in the BioFresh.

You can change this value slightly if a higher or lower ambient temperature makes it necessary. When setting the value, note:

| Value | Description |
|---|---|
| B1 | Lowest temperature |

| Value | Description |
|---|---|
| B1-B4 | The temperature can drop below 0 °C which means foods can easily freeze. |
| B5 | Pre-set temperature |
| B9 | Highest temperature |

*BioFresh B-Value*

**Selecting the setting**

▶ Set value in customer menu .

## C5 C-Value*

Use this function to set the C-Value. You can use the C-Value to make the **** freezer compartment slightly warmer or colder. The C-Value is pre-set to value C5 as delivered.

| Value | Description |
|---|---|
| C1 to C4 | **** freezer compartment gets colder. |
| C5 | Pre-set value |
| C6 to C9 | **** freezer compartment gets warmer. |

**Setting the C-Value**



*Fig. 20*





*Fig. 21 Example illustration: Switch from C5 to C6.*

▶ Carry out action steps according to the illustration.
▷ The C-Value is set.

## D1 D-Value

The D-Value is pre-set for your appliance and is not permitted to be changed.

## SuperCool

This function selects the lowest cooling temperature. This gives you colder storage temperatures.

This function is relevant to the fridge section *Fig. 1 (A)*

You can also reach lower temperatures in the 4-star freezer.*

Use:

- Cool large amounts of food quickly.
- Freeze food.*

**Activating/deactivating the function**

▶ Using the 4-star freezer: activate the function 3 hours beforehand.*
▶ Using the fridge section: activate the function when you add the goods.
▶ Activating/deactivating.

**-or-**

▶ Activate/deactivate using the SmartDevice app.

The function automatically turns off. The appliance goes back to normal mode. The temperature adjusts itself to the set level.

## PartyMode

You can use this function to activate or deactivate Party-Mode. PartyMode activates various functions that are useful for a party.

PartyMode activates the following functions:

- SuperCool (see SuperCool)

You can adjust all listed functions individually and flexibly. When you deactivate PartyMode, all changes are discarded.

**Activating PartyMode**




*Fig. 22*





*Fig. 23*

▶ Carry out action steps according to the illustration.
▷ PartyMode and the associated functions are activated.
▷ The temperature display turns blue.
▷ The current temperature flashes until the target temperature is reached.

**Deactivating PartyMode**

The PartyMode is automatically deactivated after 24 seconds. However, you can also deactivate PartyMode manually at any time:



*Fig. 24*





*Fig. 25*

▶ Carry out action steps according to the illustration.
▷ PartyMode is deactivated.
▷ The appliance cools to the temperature set previously: The current temperature flashes until the target temperature is reached.

## HolidayMode

This function minimises the energy consumption during an extended absence. The temperature of the refrigerator compartment is set to 15 °C and this is displayed on the status screen when the temperature has been reached.

Use:

- Save energy if you plan to be away for a while.
- Avoid coming home to bad smells and mould.

### Activating/deactivating the function

▶ Empty everything from the fridge section.
▶ Activating/deactivating .
▷ On: Fridge temperature is raised.
▷ Off: the previously set temperature is restored.

## SabbathMode

You can use this function to activate or deactivate SabbathMode. If you activate this function, some electronic functions are switched off. As a result, your device meets the religious requirements for Jewish holidays such as Sabbath and complies with STAR-K Kosher certification.

| Device status when SabbathMode is active |
|---|
| The status display shows SabbathMode permanently. |
| All functions on the display are locked except for the **Deactivate SabbathMode function**. |
| Active functions remain active. |
| The display remains bright when you close the door. |
| The interior lighting is deactivated. |
| Reminders are not implemented. The set time interval stops. |
| Reminders and warnings are not displayed. |
| There is no door alarm. |
| There is no temperature alarm. |
| The defrosting cycle operates only for the specified time, without considering the device consumption. |
| After a power failure, the device returns to SabbathMode. |

*Device status*

**Note**
This appliance has certification from the “Institute for Science and Halacha”. (www.machonhalacha.co.il)

You can find a list of STAR-K-certified appliances at www.star-k.org/appliances.

### Activating SabbathMode

**WARNING**
Danger of food poisoning from spoiled food!
If you have SabbathMode activated and a power failure occurs, no message appears in the status display about the power failure. Once the power is restored, the appliance continues to operate in SabbathMode. The power failure may mean that food spoils and the consumption of this food could lead to food poisoning.
After a power failure:
▶ Do not consume food that was frozen and has thawed out.



*Fig. 26*




*Fig. 27*

▶ Carry out action steps according to the illustration.
▷ SabbathMode is activated.
▷ The status display shows SabbathMode permanently.

### Deactivating SabbathMode

The SabbathMode is automatically deactivated after 80 hours. However, you can also deactivate SabbathMode manually at any time:





*Fig. 28*

▶ Carry out action steps according to the illustration.
▷ SabbathMode is deactivated.

## EnergySaver

This function activates or deactivates the energy-saving mode. When you activate this function, the energy consumption decreases and the temperature increases by 2 °C in the appliance. The food remains fresh, but the shelf life is shortened.

| Temperature zone | Recommended setting | Temperature when EnergySaver activated |
|---|---|---|
| 5 °C Fridge compartment | 5 °C | 7 °C |

*Temperatures*

### Activating EnergySaver



*Fig. 29*





*Fig. 30*

▶ Carry out action steps according to the illustration.
▷ Energy-saving mode is activated.

### Deactivating EnergySaver



*Fig. 31*





*Fig. 32*

▶ Carry out action steps according to the illustration.
▷ Energy-saving mode is deactivated.

## CleaningMode

You can use this function to activate or deactivate CleaningMode. CleaningMode enables the appliance to be cleaned conveniently.

This setting applies to the fridge section.

Application:

- Clean the fridge section. (see 9.5 Cleaning the appliance)

| Device status when CleaningMode is active |
|---|
| The status display shows CleaningMode permanently. |
| The fridge section is switched off. |
| Interior lighting is activated. |
| The reminders and warnings are not displayed. No signal tone sounds. |

*Device status*

### Activating CleaningMode



*Fig. 33*





*Fig. 34*

▶ Carry out action steps according to the illustration.
▷ CleaningMode is activated.
▷ The status display shows CleaningMode permanently.

### Deactivating CleaningMode

CleaningMode is deactivated automatically after 60 minutes. However, you can also deactivate CleaningMode manually at any time:





*Fig. 35*

▶ Carry out action steps according to the illustration.
▷ CleaningMode is deactivated.
▷ The appliance cools to the temperature set previously.

## Display brightness

Use this function to set the display brightness in stages.

You can select the following brightness levels:

- 40 %
- 60 %
- 80 %
- 100 %

### Setting the display brightness



*Fig. 36*





*Fig. 37 Example illustration: Switch from 80 % to 60 %.*

▶ Carry out action steps according to the illustration.
▷ The display brightness is set.

## Door alarm

Set the time before the door alarm (see Close the door) sounds.

The options are as follows:

- 1 min
- 2 min
- 3 min
- Off

### Choose the setting

▶ Set the time (see 7.3 Fault messages) .

## Input lock

You can use this function to activate or deactivate the input lock. The input lock prevents the appliance being operated accidentally, e.g. by children.

Application:

- Avoid unintentional modification of functions.
- Avoid unintentional switching off of the device.
- Avoid unintentional temperature setting.

### Activating the input lock

If you activate the input lock, you can continue to navigate in the menus but you cannot select or change other functions.



*Fig. 38*





*Fig. 39*

▶ Carry out action steps according to the illustration.
▷ Input lock is activated.

**Deactivating the input lock**



*Fig. 40*





*Fig. 41*

▶ Carry out action steps according to the illustration.
▷ Input lock is deactivated.

## Language

Use this function to set the display language.

You can select the following languages:

- Deutsch
- English
- Français
- Español
- Italiano
- Nederlands
- Čeština
- Polski
- Português
- Русский
- 温度单位

**Setting the language**



*Fig. 42*





*Fig. 43 Example illustration depending on the language and temperature*

▶ Carry out action steps according to the illustration.
▷ The language is set.
▷ The display returns to the status display.

## Info

This setting allows the appliance information to be read out as well as access to the customer menu.

It provides the following information:

- Model name
- Index
- Serial number
- Service number

**Show appliance data**

▶ Swipe in the display until Settings appears.
▶ Confirm the display.
▶ Swipe in the display until About appears.
▶ Read the appliance info.

## Reminder

Reminders are given out acoustically by a beep and visually by a symbol in the display. The signal gets louder until the alert stops.

**Replace FreshAir active carbon filter**

This message appears when the air filter needs replacing.

▶ Change the air filter every six months.
▶ Confirm the message with OK.
▷ The service interval resets.
▷ The air filter guarantees the air quality in the fridge.

**Activating the setting**

▶ Activating/deactivating .

## Demo mode

Demo mode is a special feature for dealers who want to demonstrate appliance features. If you activate demo mode, all refrigeration functions are deactivated.

If you switch on your appliance and “Demo” appears in the status display, then demo mode is already activated.

If you activate and then deactivate demo mode, the appliance will be reset to factory defaults. (see Reset)

**Activating demo mode**



*Fig. 44*





*Fig. 45*

▶ Carry out action steps according to the illustration.
▷ Demo mode is activated.
▷ Appliance is switched off.
▶ Switch on the appliance. (see 4.1 Switching on appliance (first use))
▷ “DEMO” appears in the status display.

**Deactivating demo mode**



*Fig. 46*





*Fig. 47*

▶ Carry out action steps according to the illustration.
▷ Demo mode is deactivated.
▷ Appliance is switched off.
▶ Switch on the appliance. (see 4.1 Switching on appliance (first use))
▷ Appliance is reset to factory settings.

### Reset

This function resets all settings to the factory settings. All settings that you have made thus far will be reset to their original values.

**Activating the setting**

▶ Activate .

## 7.3 Fault messages

Fault messages appear in the display. There are two categories of fault message:

| Category | Meaning |
|---|---|
| Message | Reminder of general procedures. You can carry out these procedures to eliminate the message. |
| Warning | Appears when there are malfunctions. A signal sounds in addition to the display. The signal becomes louder until you acknowledge by tapping the display. You can eliminate simple defects yourself. For more serious defects, you must contact customer service. |

### 7.3.1 Warnings

**Close the door**

This message appears if the door is open for too long.

You can set how long it takes for this message to appear .

▶ Stop alarm: Confirm the message.

**-or-**

▶ Close the door.

**Error**

This message appears if there is a fault with the appliance. An appliance component indicates a fault.
▶ Open the door.
▶ Note down the fault code.
▶ Confirm the message.
▷ The signal tone stops.
▷ The status display appears.
▶ Close the door.
▶ Contact customer service. (see 10.4 Customer Service)

# 8 Features

## 8.1 4-star freezer compartment*

### 8.1.1 Opening/closing the freezer compartment




*Fig. 48*

Opening the freezer compartment:
▶ Reach into the handle area from below.
▶ Push the handle plate while pulling the door towards you.

Closing the freezer compartment:
▶ Close the door while pushing from the front.
▷ Door is engaged.

## 8.2 Door rack

### 8.2.1 Move/remove the door rack




*Fig. 49*

▶ Slide the rack upwards.
▶ Pull forwards.
▶ Re-insert it in reverse order.




*Fig. 50 **

You can use just one or both VarioBoxes. To store oversized bottles, just suspend one box over the bottle rack.*

**Move the VarioBox shelf:***




*Fig. 51 **
▶ Pull it up and out.*
▶ Put it back in at any position.*
▷ In front of 4-star freezer: Optimum air flow in the appliance is no longer guaranteed. Condensate may form on the freezer compartment.*

**Note**
Liebherr recommends the following:*
▶ Put the VarioBox shelf in its default position, anywhere below the 4-star freezer. This will provide the best air flow in the fridge section.*

**Moving the VarioBoxes:***




*Fig. 52 **
If the door rack is removed:*
▶ Remove containers.*




*Fig. 53 **
▶ Place the shelf on the table.*





*Fig. 54* *

▶ Pull off the middle holder *Fig. 54 (1)*.*
▶ Insert the middle holder in the second position *Fig. 54 (2)*.*




*Fig. 55* *

▶ Replace containers.*

### 8.2.2 Disassembling the door rack

The door rack can be taken apart for cleaning.




*Fig. 56*





*Fig. 57* *

▶ Disassemble the door rack.

## 8.3 Shelves

### 8.3.1 Adjusting/removing the shelves

The shelves are prevented from being pulled out accidentally by pull out stops.





*Fig. 58*

▶ Lift the shelf and pull forward.
▷ Line up the side runner.
▶ Adjust the height of the shelf: Lift or lower it to the desired height and slide it in.

**-or-**





*Fig. 59*

▶ Remove the shelf completely: Pull it out to the front.

▶ Easier removal: Set the shelf at an angle.
▶ Insert the shelf again: Slide it in all the way.
▷ The pull-out stoppers point downwards.
▷ The pull-out stoppers are behind the front support.

## 8.4 Dividing shelf

### 8.4.1 Using the dividing shelf

The shelves are prevented from being pulled out accidentally by pull out stops.




*Fig. 60*

▶ Push the dividing shelf underneath as shown.





*Fig. 61*



* Depending on model and options

**Adjusting the height:**
- ▶ Pull the glass panels out *Fig. 61 (1)* from the front, one at a time.
- ▶ Release the support rails and click in at the height you want.
- ▶ Slide in the glass panels one at a time.
- ▷ Flat pull-out stoppers at the front, right behind the support rails.
- ▷ High pull-out stoppers at the back.

**Using both shelves:**
- ▶ Hold the glass panel with one hand and pull it to the front.
- ▷ The glass panel *Fig. 61 (1)* and trim strip are at the front.
- ▷ The stops *Fig. 61 (3)* point down.

Appliances with freezer compartment:*
- ▶ Do not place the support rails and dividing shelf in front of the fan.*

## 8.5 VarioSafe*

The VarioSafe offers space in the refrigerator compartment for small groceries, packages, tubes and jars, for example.





*Fig. 62*

**(1)** VarioSafe drawer

**(2)** Side panels with ribs for VarioSafe drawer

**(3)** Recesses on the left and right side panel

### 8.5.1 Inserting the VarioSafe





*Fig. 63*

- ▶ Insert the VarioSafe into the refrigerator compartment at an angle *Fig. 63 (1)* until the recesses in the side *Fig. 63 (2)* of the VarioSafe are at the level of the support rib in the refrigerator compartment.





*Fig. 64*

- ▶ Set VarioSafe straight. *Fig. 64 (1)*
- ▶ Lift VarioSafe at the front. *Fig. 64 (2)*




*Fig. 65*

- ▶ Lift VarioSafe up toward the front.
- ▶ Push VarioSafe in to the rear.
- ▶ Lower VarioSafe.
- ▷ VarioSafe audibly engages.
- ▷ VarioSafe is inserted.

### 8.5.2 Repositioning the VarioSafe

You can move the VarioSafe as a whole in the refrigerator compartment.




*Fig. 66*

- ▶ Lift VarioSafe at the front.





*Fig. 67*

- ▶ Pull VarioSafe forwards until the recesses in the side of the VarioSafe are at the level of the support rib in the refrigerator compartment. *Fig. 67 (1)*
- ▶ Move VarioSafe up or down in the refrigerator compartment until the desired height is reached. *Fig. 67 (2)*




*Fig. 68*

- ▶ Lift VarioSafe at the front.
- ▶ Push VarioSafe in to the rear.
- ▷ VarioSafe audibly engages.
- ▷ VarioSafe is offset in height.

### 8.5.3 Moving the VarioSafe drawer

You can use the VarioSafe drawer at two different heights. If you would like to store taller foodstuffs in the VarioSafe drawer, slide the VarioSafe drawer in on the bottom rib. If you would like to store smaller foodstuffs in the VarioSafe drawer, slide the VarioSafe drawer in on the top rib.




*Fig. 69*

- ▶ Pull out the VarioSafe drawer as far as it will go.
- ▶ Lift the VarioSafe drawer up at the front.
- ▶ Remove the VarioSafe drawer to the front.





*Fig. 70*

- ▶ Lift the VarioSafe drawer up at the front.
- ▶ Place the VarioSafe drawer behind the stoppers on desired rib *Fig. 70 (1)* or *Fig. 70 (2)*.
- ▷ VarioSafe drawer is offset in height.

### 8.5.4 Removing the VarioSafe

You can remove the VarioSafe as a whole.




*Fig. 71*

- ▶ Lift VarioSafe at the front.





*Fig. 72*

- ▶ Pull VarioSafe forwards *Fig. 72 (1)* until the recesses in the side of the VarioSafe are at the level of the support rib in the refrigerator compartment. *Fig. 72 (2)*



*** Depending on model and options**





*Fig. 73*

▶ Set VarioSafe in refrigerator compartment at an angle. *Fig. 73 (1)*
▶ Take VarioSafe out to the front. *Fig. 73 (2)*
▷ VarioSafe is removed.

### 8.5.5 Disassembling the VarioSafe

You can disassemble the VarioSafe into its individual parts if you want to clean the VarioSafe or if you need to install or remove parts.





*Fig. 74*

▶ Remove VarioSafe as a whole. (see 8.5.4 Removing the VarioSafe)
▶ Disassemble VarioSafe according to the illustration.

## 8.6 Space for baking tray

There is space for a baking tray *Fig. 1 (8)* above the drawers.




*Fig. 75*

Ensure that the following conditions are met:

❑ Max. baking tray dimensions are adhered to (see 10.1 Technical specifications) .
❑ Baking tray is cooled to room temperature.
❑ The lowest door rack is set at least one position higher.

With the door open to 90°:

▶ Slide the baking tray onto the lower side runners.

**-or-**

If baking tray is uneven:

▶ Use the supplied support rails.





*Fig. 76*

▶ Snap support rails into the lowest runners.
With the door open to 90°:
▶ Slide the baking tray in on the support rails.

## 8.7 Adjustable bottle shelf

### 8.7.1 Using the bottle shelf

In the bottom of the fridge section you can either use the variable bottle shelf or the glass panel.




*Fig. 77*

▶ Remove the glass panel and store in a safe place.
▶ Lay bottles with their base towards the rear wall.

**Note**
If the bottles are protruding over the front of the bottle shelf:
▶ Move the lower door rack up a place.

### 8.7.2 Removing the bottle shelf

You can remove the bottle shelf for cleaning.
▶ Remove the glass panel above the bottle shelf.




*Fig. 78*

▶ Lift the bottle shelf at the front and pull out.

**Note**
Liebherr recommends the following:
Do not place any goods on the drawer cover below.

### 8.7.3 Inserting the bottle shelf




*Fig. 79*

▶ Slide in the bottle shelf until it engages and push down.
▷ The lugs at the back of the bottle shelf are connected automatically.
▷ LED comes on.

## 8.8 Drawers

You can remove the drawers for cleaning.

The way to remove/insert the drawers varies depending on the pull-out system. Your appliance can contain various pull-out systems.

**Note**
The energy consumption increases and the cooling power goes down if ventilation is not sufficient.
▶ Always leave the fan air vents clear on the back wall!

### 8.8.1 Drawer on telescopic rails

The drawer runs on extendible rails (telescopic rails). There are fully extendible telescopic rails and telescopic rails with partial pull-out. Drawers which are fully extendible can be pulled out fully from the appliance. Drawers with partial pull-out cannot be removed fully from the appliance. The system in your appliance depends on the type of appliance.

**Fully extendible***

If you have fully extendible rails, there is a clamp located at the back on the left and right of the rail.

**Removing drawer**





*Fig. 80*

▶ Pull out drawer as far as it will go.
▶ Lift left clamp and simultaneously pull drawer forwards on the left. *Fig. 80 (1)*
▶ Lift right clamp and simultaneously pull drawer forwards on the right. *Fig. 80 (2)*
▶ Remove drawer to the front. *Fig. 80 (3)*
▶ Slide rails in.

**Inserting drawer**




*Fig. 81*

▶ Slide rails in.
▶ Place drawer on rails.
▶ Slide in drawer to the back.
▷ Drawer latches in audibly at the back.

**Partial pull-out fridge compartment***

**Removing drawer**





*Fig. 82*

▶ Pull out drawer half-way. *Fig. 82 (1)*
▶ Push the drawer down at the front. *Fig. 82 (2)*
▶ Push the left rail in by about 2 cm. *Fig. 82 (3)*
▶ Push the right rail in by about 2 cm. *Fig. 82 (4)*
▶ Remove drawer to the front. *Fig. 82 (5)*




*Fig. 83*

If the rails are not yet fully inserted after removing the drawer:
▶ Push rails in completely.

**Inserting drawer**




*Fig. 84*

▶ Slide rails in.
▶ Place drawer on rails.
▶ Slide in drawer to the back.

## 8.9 Fruit & Vegetable safe cover

You can remove the compartment cover for cleaning.

### 8.9.1 Removing the compartment cover

Ensure that the following conditions are met:
❑ Bottle shelf is removed (see 8.7 Adjustable bottle shelf) .





*Fig. 85*

When the drawers are removed:
▶ Pull the lid up at the front to the opening in the retaining parts *Fig. 85 (1)*.
▶ Lift from the back and pull it up and out *Fig. 85 (2)*.

### 8.9.2 Inserting the compartment cover





*Fig. 86*

If the text THIS SIDE UP points upwards:
▶ Insert the lip of the cover over the opening of the rear bracket *Fig. 86 (1)* and click into place *Fig. 86 (2)*.
▶ Position the cover where you want it (see 8.10 Adjusting the moisture levels) .

## 8.10 Adjusting the moisture levels

You can adjust the moisture in the drawer yourself by adjusting the compartment cover.

The compartment lid is attached to the drawer and can be hidden by a shelf or additional drawers.




*Fig. 87*

**Low air humidity**
▶ Open the drawer.
▶ Slide the compartment cover forwards.
▷ With the drawer closed: Gap between the cover and the compartment.
▷ The air moisture in the Safe decreases.

**High air moisture**
▶ Open the drawer.
▶ Slide the cover back.
▷ With the drawer closed: The cover seals the compartment.
▷ The air moisture in the Safe increases.
If there is too much moisture in the compartment:
▶ Choose the setting “low air moisture”.

**-or-**

▶ Remove any excess moisture with a cloth.

**Note**
You can apply the “low air moisture” setting to the Fruit & Vegetable-Safe and the Meat & Dairy-Safe.
▶ Set the “low air moisture” option.

## 8.11 Butter dish

### 8.11.1 Opening/closing the butter dish





*Fig. 88*

### 8.11.2 Dismantling the butter dish

You can take the butter dish apart for cleaning.





*Fig. 89*

▶ Disassembling the butter dish.

## 8.12 Egg rack

You can pull out and turn the egg rack. You can use both sides of the egg rack so you can label specifics like the purchase date.

### 8.12.1 Using the egg rack




*Fig. 90*

▶ Top layer: for storing hen eggs.
▶ Bottom layer: for storing quail eggs.

## 8.13 Bottle holder

### 8.13.1 Using the bottle holder




*Fig. 91*

▶ Push the bottle holder onto the bottles.
▷ The bottles are prevented from falling over.

### 8.13.2 Removing the bottle holder




*Fig. 92*

▶ Move the bottle holder all the way to the right.
▶ Push the bottle holder to the back to remove.

## 8.14 FlexSystem

### 8.14.1 Using the FlexSystem

The FlexSystem helps you store and organise your food in a clear and flexible way. It lets you clearly divide your food into fruit, vegetables or by use-by dates, for example.




*Fig. 93*

▶ Move the inner shell.

### 8.14.2 Removing the FlexSystem




*Fig. 94*

▶ Lift the FlexSystem from the back.
▶ Pull up and out.

### 8.14.3 Inserting the FlexSystem




*Fig. 95*

▶ Insert the FlexSystem front-first.
▶ Lower the rear part.

### 8.14.4 Disassembling the FlexSystem

You can take the FlexSystem apart for cleaning.




*Fig. 96*

▶ Disassembling the FlexSystem

## 8.15 Ice cube tray with cover*

### 8.15.1 Using the ice cube tray





*Fig. 97*

When the water is frozen:

▶ Hold ice cube tray under hot water for a short time.
▶ Remove the lid.
▶ Gently turn the ends of the ice cube tray in opposite directions.
▶ Release the ice cubes.

### 8.15.2 Dismantling the ice cube tray

You can take the ice cube tray apart for cleaning.





*Fig. 98*

▶ Disassembling the ice cube tray.

# 9 Maintenance

## 9.1 FreshAir carbon filter

The FreshAir carbon filter is in the compartment above the fan.

It guarantees the best air quality.

❑ Replace the carbon filter every 6 months.
When the reminder is set, a message on the display prompts you to change it.
❑ The carbon filter can be disposed of with the regular household waste.

**Note**
FreshAir activated charcoal filters can be purchased from the Liebherr-Hausgeräte store at home.liebherr.com/shop/de/deu/zubehor.html.

### 9.1.1 Removing the FreshAir carbon filter





*Fig. 99*

▶ Pull out the compartment *Fig. 99 (1)*.
▶ Remove the carbon filter *Fig. 99 (2)*.

### 9.1.2 Inserting the FreshAir carbon filter





*Fig. 100*

▶ Insert the carbon filter as shown in the diagram *Fig. 100 (1)*.
▷ The carbon filter clicks into place.
If the carbon filter is pointing downwards:
▶ Push the compartment in *Fig. 100 (2)*.
▷ The carbon filter is now ready for use.

## 9.2 Disassembling / assembling pull-out systems

### 9.2.1 Notes on disassembly

You can disassemble some of the pull-out systems for cleaning. Your appliance can contain a variety of pull-out systems.

The following pull-out systems can be disassembled or cannot be disassembled:

| Pull-out system | can be disassembled / cannot be disassembled |
|---|---|
| Fully extendible* | cannot be disassembled* |
| Partial pull-out fridge compartment* | cannot be disassembled* |

## 9.3 Defrosting the appliance

**WARNING**
Improper defrosting of the appliance!
Injuries and damage.
- ▶ Do not use mechanical equipment or other methods to speed up the defrosting process other than those recommended by the manufacturer.
- ▶ Do not use electrical heating or steam-cleaning appliances, naked flames or defroster sprays to defrost.
- ▶ Do not use sharp objects to remove ice.


Defrosting is performed automatically. The water from the thawing process drains through the outlet and evaporates.
- ▶ Clean the drain opening regularly (see 9.5 Cleaning the appliance) .

## 9.4 Defrosting the freezer compartment manually*

A layer of frost or ice forms after prolonged use.

The following factors promote the formation of frost or ice:
- The appliance is opened frequently.
- Hot food is put in.

▶ Switch off the appliance .
▶ Pull out the mains plug or switch off the fuse.
▶ Wrap the frozen produce in newspaper or blankets and store in a cool place.



▶ Place a pan of hot water (not boiling) on the middle shelf.
▷ This speeds up the defrosting process.
▶ Leave the compartment and appliance door open during defrosting.
▶ Remove loosened pieces of ice.
▶ Make sure that there is no melted ice water in the cabinet.
▶ Soak up the melted ice water with a sponge or cloth several times as necessary.
▶ Clean the appliance (see 9.5 Cleaning the appliance) .

## 9.5 Cleaning the appliance

### 9.5.1 Ready

**WARNING**
Danger of electric shock!
- ▶ Remove the refrigerator connector or interrupt the power supply.

**WARNING**
Risk of fire
- ▶ Do not damage the refrigeration circuit.

▶ Empty the appliance.
▶ Remove mains connector.
**-or-**
▶ Activate CleaningMode.

### 9.5.2 Cleaning the interior

**NOTICE**
Improper cleaning!
Damage to the appliance.
- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not uses abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.

▶ Plastic surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
▶ Metal surfaces: clean by hand with a soft clean cloth, lukewarm water and a little detergent.
▶ Drain hole: remove deposits using a thin item (for example a cotton bud).

### 9.5.3 Clean the components

**NOTICE**
Improper cleaning!
Damage to the appliance.
- ▶ Only use soft cleaning cloths and ph-neutral all-purpose cleaners.
- ▶ Do not uses abrasive sponges or steel wool which may cause scratches.
- ▶ Do not use any sharp or abrasive cleaning agents, nor any that contain sand, chloride or acid.

**Clean with a soft, clean cloth, lukewarm water and some detergent:**
- VarioSafe*
- Fruit & Vegetable safe cover
- Drawer
- Adjustable bottle shelf
- FlexSystem

**Clean with a damp cloth:**
- Retractable rails
  Please note: The grease in the tracks is used for lubrication and must not be removed!

**Wash in the dishwasher up to 60 °C:**
- Door rack
- VarioBox*
- Bottle rack
- Shelf
- Dividing shelf
- Holder of the dividing shelf
- Egg rack
- Butter dish
- Ice cube tray*

▶ To disassemble components: see the relevant section.
▶ Clean the components.

### 9.5.4 After cleaning

▶ Wipe the appliance and the components dry.
▶ Connect and switch on the appliance.
The temperature is cold enough:
▶ Place the food inside.
▶ Repeat cleaning regularly.

# 10 Customer help

## 10.1 Technical specifications

| Temperature range | |
|---|---|
| Cooling | 3 °C to 9 °C |
| BioFresh | 0 °C to 3 °C |

| Maximum freezing quantity/24 h | |
|---|---|
| Freezer compartment* | See “Freezing capacity .../24 h” on the type plate* |

| Maximum size baking tray | |
|---|---|
| Width | 466 mm |
| Depth | 386 mm |
| Height | 50 mm |

| Lighting | |
|---|---|
| Class[1] | Light source |
| This product contains one or more energy efficiency class G light sources. | LED |

[1] *The appliance may contain light sources with different energy efficiency classes. The lowest energy efficiency class is indicated.*

For appliances with a WiFi connection:

| Frequency specification | |
|---|---|
| Frequency band | 2.4 GHz |
| Maximum radiated power | < 100 mW |
| Purpose of the wireless equipment | Integration in the local WiFi network for data communication |

## 10.2 Operating noises

The appliance makes different noises when it is on.

- At **higher temperatures** the appliance uses less energy but works for longer. It is **quieter**.
- At **lower temperatures** the food is cooled faster. It is **louder**.

  Examples:
  - Functions on (see 7.2 Appliance functions)
  - Fan running
  - Food recently added
  - High ambient temperature
  - Door open for a while

| Noise | Possible cause | Type of noise |
|---|---|---|
| Bubbling and splashing | Coolant flowing into the cooling circuit. | Normal operating noise |
| Hissing | Coolant sprays into the cooling circuit. | Normal operating noise |
| Humming | The appliance is cooling. The volume depends on the cooling output. | Normal operating noise |
| Suction noises | Soft-closing door is being opened and closed. | Normal operating noise |
| Humming and rustling | The fan is running. | Normal operating noise |
| Clicking | Components are switched on and off. | Normal switching noise |
| Rattling or humming | Valves or flaps are working. | Normal switching noise |

| Noise | Possible cause | Type of noise | Lifting |
|---|---|---|---|
| Vibration | Improper installation | Defective noise | Check the installation.<br>Level the appliance. |
| Rattling | Components, items inside the appliance | Defective noise | Secure components.<br>Leave enough space between the items. |

## 10.3 Technical fault

Your appliance is designed and built to ensure it works reliably and has a long service life. In the unlikely event that a fault occurs during operation, please check whether it is due to an operating error. If so, you will be charged for the callout and repair costs even if it falls within the warranty period.

You can fix the following faults yourself.

### 10.3.1 Appliance function

| Defect | Cause | Remedy |
|---|---|---|
| **The appliance is not working.** | → The appliance is not switched on. | ▶ Switch the appliance on. |
| | → The power plug is not properly plugged into the socket. | ▶ Check the power plug. |
| | → There is something wrong with the power outlet fuse. | ▶ Check the fuse. |
| | → Power cut | ▶ Keep the appliance closed. |

| Defect | Cause | Remedy |
|---|---|---|
| | | ▶ Protecting food: Lay freezer packs on top of the food or use another freezer if the power is off for a prolonged period.<br>▶ Do not re-freeze defrosted food, |
| | → The appliance plug does not fit the appliance properly. | ▶ Check the appliance plug. |
| **Temperature is not cold enough.** | → The appliance door is not closed properly. | ▶ Close the appliance door. |
| | → Not enough ventilation. | ▶ Keep ventilation grille clear, and clean it. |
| | → The ambient temperature is too high. | ▶ Solution: (see 1.4 Appliance range of use) . |
| | → The appliance was opened too many times or for too long. | ▶ Wait to see if the required temperature corrects itself. If not, contact Customer Service. (see 10.4 Customer Service) |
| | → The temperature is set incorrectly. | ▶ Turn down the temperature and check after 24 hours. |
| | → The appliance is too close to a heat source (oven, radiator, etc). | ▶ Move the appliance or the heat source. |
| | → The appliance was not correctly installed in the recess. | ▶ Check if the appliance was installed correctly and that the door closes properly. |
| **The door seal is defective or needs to be replaced for another reason.** | → The door seal can be replaced. It can be replaced without the need for special tools. | ▶ Contact Customer Service. (see 10.4 Customer Service) |
| **The appliance builds up too much ice or condensation.** | → The door seal may have slipped out of its groove. | ▶ Check that the door seal is well fitted in the groove. |

### 10.3.2 Features

| Defect | Cause | Remedy |
|---|---|---|
| **The internal light does not come on.** | → The appliance is not switched on. | ▶ Switch the appliance on. |
| | → The door was open for longer than 15 minutes. | ▶ Interior lighting turns off automatically after approx. 15 min. with the door open. |
| | → The LED interior light is faulty or the lid is damaged. | ▶ Contact Customer Service. (see 10.4 Customer Service) |
| **The freezer compartment cannot be closed.*** | → The lock is on when the door is open. | ▶ Use the handle again. |

## 10.4 Customer Service

First check whether you can rectify the fault yourself (see 10 Customer help) . If you cannot rectify the problem, contact Customer Service.

You can find the address in the enclosed brochure “Liebherr-Service” or at home.liebherr.com/service.

**WARNING**
Unprofessional repair!
Injuries.
- ▶ Have any repairs and action - not expressly specified - on the appliance and mains cable carried out by service personnel only. (see 9 Maintenance)
- ▶ A damaged mains cable may only be replaced by the manufacturer, the manufacturer’s Customer Service or a similarly qualified person.
- ▶ In the case of appliances with an IEC connector, the change may be made by the customer.



* Depending on model and options

### 10.4.1 Contacting Customer Service

Make sure that the following appliance information is available:

- ❑ Appliance name (model and index)
- ❑ Service no. (Service)
- ❑ Serial no. (S no.)

▶ Call up the appliance information via the display. (see Info)

**-or-**

▶ Refer to the type plate for appliance information. (see 10.5 Model plate)

▶ Note down the appliance information.
▶ Notify customer service: Report errors and the appliance information.
▷ This will help us to provide you with a faster, more accurate service.
▶ Follow further instructions from Customer Service.

## 10.5 Model plate

The model plate is behind the drawers on the inside of the appliance.





*Fig. 101*

**(1)** Appliance description **(3)** Serial no.
**(2)** Service no.

▶ Note the data on the model plate.

# 11 Shutting down

▶ Empty the appliance.
▶ Switch off appliance. (see Turn off appliance)
▶ Remove mains connector.
▶ Remove appliance connector if required: Remove and move from left to right at the same time.
▶ Clean appliance. (see 9.5 Cleaning the appliance)
▶ Leave the door open to avoid bad smells building up.

# 12 Disposal

## 12.1 Preparing appliance for disposal




Liebherr uses batteries in some of its appliances. In the EU, for environmental reasons, legislation obliges the end user to remove these batteries before disposing of old appliances. If your appliance contains batteries, a corresponding notice is attached.

Lamps — If you can remove the lamps yourself without destroying them, also remove these before disposal.

▶ Take the appliance out of operation.
▶ Appliances with batteries: remove the batteries. For description, see **Maintenance** chapter.
▶ If possible: remove lamps without destroying them.

## 12.2 Disposing of the appliance in an environmentally friendly manner



The appliance still contains valuable materials and must be disposed of separately from unsorted municipal waste.







Dispose of batteries separately from the old appliance. To do this, you can return the batteries free of charge to retailers as well as recycling centres and collection centres for recyclable materials.

Lamps — Dispose of removed lamps via the respective collection systems.

For Germany: — You can dispose of the appliance free of charge via the class 1 collection containers at the local recycling and recyclable material collection centres. When purchasing a new fridge/freezer, if the sales area > 400 $m^2$, retailers will also take back the old appliance free of charge.

**WARNING**
Leaking coolant and oil!
Fire. The coolant contained in the appliance is eco-friendly, but also flammable. The oil contained in the appliance is flammable. Escaping coolant and oil can ignite if the concentration is high enough and in contact with an external heat source.

▶ Do not damage the pipelines of the coolant circuit and the compressor.

▶ Transport the appliance without damaging it.
▶ Dispose of batteries, lamps and the appliance according to the above specifications.



home.liebherr.com/fridge-manuals

EN integrated fridge with BioFresh

Issue date: 20231212

**Part number index: 7088424-00**

Liebherr-Hausgeräte GmbH
Memminger Straße 77-79
88416 Ochsenhausen
Deutschland