

# Always there to help you

Register your product and get support at  
[www.philips.com/welcome](http://www.philips.com/welcome)



HR2100  
HR2101  
HR2102  
HR2103  
HR2104  
HR2108



## EN Important information leaflet

## DA Brochure med vigtige oplysninger

## DE Wichtiges Informationsmerkblatt

## EL Φυλλάδιο σημαντικών διδύμων

## ES Folleto de información importante

## FI Tärkeää-lehtinen

## FR Brochure « Informations importantes »

## IT Brochure informativa importante

## NL Folder met belangrijke informatie

## NO Viktig informasjonshefte

## PT Folheto de informações importantes

## SV Broschyr med viktig information

## TR Önemli bilgi broşürü

شارة تضمن معلومات مهمة AR

فاتحه اطلاعات ملحوظة FA



Specifications are subject to change without notice  
© 2014 Koninklijke Philips N.V.  
All rights reserved.

WEU\_Safety\_V2.0

3140 035 30142

## English

### 1 Important

Read this Important Information leaflet carefully before you use the blender and save it for future reference.

#### General

Danger  
• Never immerse the motor unit in water or any other liquid, nor rinse it under the tap. Use only a moist cloth to clean the motor unit.

Warning  
• Check if the voltage indicated on the appliance corresponds to the local mains voltage before you connect the appliance.

• If the mains cord is damaged, you must have it replaced by Philips, a service centre authorised by Philips or similarly qualified persons in order to avoid a hazard.

• Do not use the blade jar, mill beaker (specific types only) or chopper bowl (specific types only) to switch the appliance on and off.

• Never let the appliance run unattended.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

• Do not touch the blades, especially when the appliance is plugged in. The blades are very sharp.

Caution  
• Always unplug the appliance before you assemble, disassemble or make adjustments to any of the parts.

• Never use any accessories or parts from other manufacturers or that Philips does not specifically recommend. If you use such accessories or parts, your guarantee becomes invalid.

• Do not exceed the maximum indication on the blender jar or the beaker (specific types only).

• The appliance can only be switched on if the blender jar or the beaker (specific types only) is assembled on the motor unit correctly.

#### Blender

##### Warning

• Never reach into the blender jar with your fingers or an object while the appliance is running. Do not touch the cutting edges of the blender blade unit when you handle or clean it. They are very sharp and you could easily cut your fingers on them.

• Make sure the blade unit is securely fastened to the blender jar before you assemble the blender jar onto the motor unit.

• If the blade unit gets stuck, unplug the appliance before you remove the ingredients that block the blades.

Caution  
• Never fill the blender jar with ingredients hotter than 80°C.

• To prevent spillage, do not put more than 1.25 litres of liquid in the blender jar, especially when you process at a high speed. Do not put more than 1 litre in the blender jar when you process hot liquids or ingredients that tend to foam.

• Do not let the appliance run for more than 2 minutes at a time. Let the appliance cool down to room temperature before you continue processing.

• Always make sure the lid is properly closed/assembled on the jar and the measuring cup is inserted properly in the lid before you switch on the appliance.

#### Mini chopper and mill

##### Warning

• Make sure the blade unit is securely fastened to the chopper/mill beaker before you assemble the beaker onto the motor unit.

• Do not touch the cutting edges of the chopper/mill blade unit when you handle or clean it. They are very sharp and you could easily cut your fingers on them.

• If the blade unit gets stuck, unplug the appliance before you remove the ingredients that block the blades.

• Never use the mill to grind very hard ingredients such as nutmeg, Chinese rock sugar and ice cubes.

Caution  
• Never use the mini chopper or mill for more than 30 seconds without interruption. Let it cool down to room temperature between processing cycles.

• Never forget to place the sealing ring in the blade unit before you assemble the mini chopper or mill.

• Always process cloves, cinnamon and anise together with other ingredients. If processed separately, these ingredients may attack the plastic materials of the appliance.

• The mill beaker may become discoloured when you use the mill to process ingredients such as cloves, anise and cinnamon.

• The mill is not suitable for chopping raw meat. Use the blender instead.

• Do not use the mill to process liquids such as fruit juice.

#### Filter

##### Caution

• Never use the filter to process ingredients hotter than 80°C.

• Never overload the filter. Do not fill the filter beyond its metal part.

• Always make sure the lid of the blender jar is assembled properly and the measuring cup is inserted properly in the lid before you switch on the appliance.

• Cut fruit into smaller pieces before you put it in the filter.

• Soak dried ingredients, such as soy beans, before you put them in the filter.

#### Safety Feature

This blender is fitted with a safety feature which safeguards against excessive loads. In case of overloading, the blender automatically activates the protection and operation will stop. If this occurs, set the rotary knob to OFF, unplug the appliance and allow it to cool down for 15 minutes. Remove the ingredients and clear up the blender jar before starting operation.

#### Electromagnetic fields (EMF)

This Philips appliance complies with all standards regarding electromagnetic fields (EMF). If handled properly and according to the instructions in this user manual, the appliance is safe to use based on scientific evidence available today.

## Recycling

Your product is designed and manufactured with high quality materials and components, which can be recycled and reused.  
When you see the crossed-out wheel bin symbol attached to a product, it means the product is covered by the European Directive 2002/96/EC.

Never dispose of your product with other household waste. Please inform yourself about the local rules on the separate collection of electrical and electronic products. The correct disposal of your old product helps prevent potentially negative consequences on the environment and human health.

## Built-in safety lock

This feature ensures that you can only switch on the appliance if the blender jar, the mill or chopper beaker is assembled on the motor unit properly. If the blender jar, the mill or chopper beaker is correctly assembled, the built-in safety lock will be unlocked.

## 2 Guarantee & service

If you need service or information or if you have a problem, please visit the Philips website at [www.philips.com](http://www.philips.com) or contact the Philips Consumer Care Centre in your country (you find its phone number in the worldwide guarantee leaflet). If there is no Consumer Care Centre in your country, go to your local Philips dealer.

## Dansk

### 1 Vigtigt

Denne folder med vigtige oplysninger omhygget igennem, inden blenderen tages i brug, gen til eventuel senere brug.

#### Generelt

Fare  
• Motorheden må aldrig kommes ned i vand eller andre væsker eller skyldes under vandhuden. Motorheden må kun rengøres med en fugtig klud.

Advarsel  
• Kontroller, om den angivne netspænding på apparatet svarer til den lokale netspænding, før du slutter strøm til apparatet.

• Hvis netledningens beskadiges, må den kun udskiftes af Philips, et autoriseret Philips-servicecenter eller en tilsvarende kvalificeret fagmand for at undgå enhver risiko.

• Brug ikke apparat, hvis støt, nedfald eller andre dele er beskadigede.

• Anvend ikke bladet i denne bladmaskine sammen med andre maskiner (kun bestemte typer).

• Lad aldrig apparatet køre uden oversigt.

• Dette apparat er ikke beregnet til at blive bragt af personer (herunder børn) med neddette fysiske og mentale evner, nedfald føles eller manglende erfaring og viden, medmindre de er blevet vejledt eller instrueret i apparatets anvendelse af en person, der er ansvarlig for dens sikkerhed.

• Apparatet bør holdes uden for børns rekkevidde for at sikre, at de ikke kan komme til at lege med det.

• Undgå at røre ved kniven, når apparatet er sluttet til strømmen. Kniven er meget skarpe.

NB!  
• Tag aldrig stikket ud, før du samler, skiller eller justerer tilbehør.

• Brug aldri tilbehør eller dele fra andre fabrikanter eller tilbehør/dele, som ikke specifikt er anbefalet af Philips. Hvis du anvender en sådan type tilbehør eller dele, annulleres garantien.

• Overskrid ikke den angivne maksimumsmærking på bladmaskinens bægeret (kun bestemte typer).

• Undgå at berøre de angivne mængder og tilberedningstider, der er angivet i den relevante tabel.

• Apparatet kan tændes, hvis bladmaskinet eller bægeret (kun bestemte typer) er sat på motoren.

• Lad aldrig apparatet være i stand til at starte ved at slukke af.

• Sørg for, at knivenen sætter sig fast, skal du tage apparatet ud af stikkontakten, for du prøver at fjerne de ingredienser, der blokerer kniven.

• Hvis knivenen sætter sig fast, skal du tage apparatet ud af bladmaskinet, før du prøver at fjerne de ingredienser, der blokerer kniven.

• Hvis knivenen sætter sig fast, skal du tage apparatet ud af stikkontakten, for du prøver at fjerne de ingredienser, der blokerer kniven.

• Brug aldri bladmaskinet til at male grøntsager med.

• Lad aldrig apparatet inde i fortærten, inden du fortsætter.

• Sørg altid for, at låget er ordentligt lukket og sat på glæsset, og at målebægeret er sat rigtigt på plads i låget, inden du tænder for apparatet.

• Sørg altid for, at knivenen sætter sig fast, skal du tage apparatet ud af bladmaskinet, før du prøver at fjerne de ingredienser, der blokerer kniven.

Minihacker og mollekværn

Advarsel  
• Sørg for, at knivenen er sat rigtigt fast i hakkeskæren/mollekværmens bægeret, før bægeret sættes på motoren.

• Undgå at berøre de skrærende sider af hakkeskæren/mollekværmens kniven, når denne håndteres eller rengøres. De er meget skarpe, og du kan derfor nemt komme til at skære dig i fingrene.

• Hvis knivenen sætter sig fast, skal du tage apparatet ud af stikkontakten, for du prøver at fjerne de ingredienser, der blokerer kniven.

• Brug aldri hakkeskæren/mollekværmens bægeret til at male meget hårde ingredienser som f.eks. muskatnød, kardusnød og istemer.

NB!  
• Lad aldrig minihackeren eller mollekværmens kiler i mere end 30 sekunder ved gangen. Lad den køre med til støttepunktet mellem tilberedningstiden.

• Husk altid at sætte tætningsringen på knivenen, inden den sættes sammen med minihackeren eller mollekværmens kiler, eller kan for eksempel lekkage.

• Næller, stemejern og anisfrø skal altid bæres sammen med andre ingredienser. Hvis de tilberedes hver for sig, kan de bedøvelige apparater plaskide.

• Ingredienser som nellier, anis og kanel kan misfælde målebægeret.

• Mollekværmen er ikke beregnet til at halve et kød. Brug i stedet blenderen.

• Mollekværmen bør ikke anvendes til tilbereding af flydende mad/drøge, eksemplvis frugtjuice.

Filter

NB!  
• Filteret må ikke bruges til tilberedning af ingredienser, der er varmere end 80°C.

• Overfyld ikke filteret. Fyld aldrig filteret op over dets metaldele.

• Sørg altid for, at bladmaskinens låg er korrekt samlet, og at målebægeret er sat rigtigt på plads i låget, inden du tænder for apparatet.

• Skær frugten i mindre stykker, inden den kommer op i filteret.

• Læg tærre ingredienser, som f.eks. sojabønner, i blid, inden de kommer i filteret.

Sikkerhedsfunktion

Denne Mølle er udstyret med en sikkerhedsfunktion, der garanterer, at den ikke kan arbejde, hvis den ikke er korrekt monteret.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne starte.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne stoppe.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne starte.

Integrierte Sicherheitssperre

Denne Mølle vedligeholder, så den ikke kan starte, hvis den ikke er korrekt monteret.

• Denne Mølle er udstyret med en sikkerhedsfunktion, der garanterer, at den ikke kan arbejde, hvis den ikke er korrekt monteret.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne starte.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne stoppe.

• Hvis møllen ikke er korrekt monteret, vil den ikke kunne starte.

• Hvis møllen ikke er korrekt monteret,

