EN

PRODUCT DESCRIPTION

Maxisense Plancha Grill is a high-quality product made of aluminium with a durable non-stick coating.
Its flat base makes it suitable for use on glass ceramic induction hobs.

WARNING!
Do not use it on gas rings! hot gases can escape as a result of the size of the cookware and damage or set light to nearby items (e.g., work surfaces, surrounds etc.).

BEFORE FIRST USE

Clean the cookware with warm water and a cleaning agent before first use.

DAILY USE

- Place the cookware on the cook top. It is recommended to use the both heating zones on one side. The cookware can be for used perfectly on MaxiSense / Infinite cook tops.
- Set the highest setting for one or both zones for heat up the cookware fast.
- Lower the setting to continue cooking.

Safety during operation

- Remove all packaging, stickers and layers from the cookware before the first use.
- Make sure that the cookware is not damaged because of transportation. Do not use if it is damaged
- Do not use the cookware when the handles are damaged. Risk of injury if handles broken
- The Risk of burns! The cookware can be hot during operation also on the edges.

CAUTION!
Hot handles! If, the cookware is in operation, the handles can be hot. Use the oven cloth when you move the hot cookware

WARNING!
Risk of fire ! Too hot fats and oils can occur with ignition very quickly.

Correct operation

- Do not use sharp cutlery or scrapers made of sharp or hard materials (Stainless steel, Aluminium, Ceramic) to turn or remove the cooked item! We recommend wooden cooking utensils. This will protect the non-stick coating.
- Do not use the cookware as a work or a storage surface.
- Only use for induction heating systems. Do not use on radiant heated appliances. Hot surfaces of radiant heaters will damage the coating!

- Do not overheat the cookware! This can damage the non-stick coating and any oils or fats can ignite.

CARE AND CLEANING

Clean the cookware after each use.
Always use cookware with clean bottom.
To clean use hot soapy water and a soft brush or sponge.
Sharp objects and abrasive cleaning agents will damage the cookware.
We not recommend to use a dishwasher.

WARNING!
For your safety, do **not** clean the cookware with steam blasters or high-pressure cleaners.

www.aeg.com/shop



892933370-C-252013

CE