



mounting arm must forward lean in the same direction as the two arrows.

B1

3

Using the hole template (see step A or B), mark the hole positions specific to your chosen fixing method.



270°. Insert 2x limit screws.

Mark 'A' positions for "Fixing from above" (Ø2.5mm drillbit). Mark 'C' for the cable hole. (Ø20.0mm Holesaw).

A1



Mark 'B' positions for "Fixing from above" (Ø5.0mm drillbit). Mark 'C' for routing the cable hole. (Ø20.0mm Holesaw).



