



the same direction as the two arrows.

B1

270°. Insert 2x limit screws.



Mark 'A' positions for "Fixing from above" (Ø2.5mm drillbit). Mark 'C' for the cable hole. (Ø20.0mm Holesaw).

A1



Mark 'B' positions for "Fixing from above" (Ø5.0mm drillbit). Mark 'C' for routing the cable hole. (Ø20.0mm Holesaw).



to your chosen fixing method.

