ALT

ACT Pre-terminated cables: Dismantle Protective Tubes Manual ACT connectivity



WARNING: Install the cable before doing steps in the manual

STEP 1

Cut the tip of the protective tube





STEP 2

Cut and remove the heat shrink tube





FINISHED

Cut the Kevlar

Do **NOT** cut off the Fiber Cords

