



SLB-8630 HANGER BRACKET FOR 3M MP8630

Unpack carton and check contents:

(1)	SLB-8630 Plate	(2)	U-Form Rod
(4)	10-24 Lock Nuts	(4)	#10 Flatwashers
(8)	Felt Squares	(6)	Thumb Nuts

INSTALLATION INSTRUCTIONS

1. Turn projector upside down.
2. Place the SLB-8630 Plate onto the projector bottom.
3. Attach the U-Form rods around the projector and up through the two holes in the SLB-8630 plate using the #10 flatwashers and 10-24 nylock nuts. **NOTE: The U-Form rods MUST be attached for mount to properly support projector. This is a correct fit. DO NOT OVERTIGHTEN U-Form rod to projector. Only tightened until a secure fit is achieved. Felt squares are provided to protect projector shell, if desired. They can be attached to the projector or wrapped around the U-Form rod.**
4. See RPA and/or Smart-Lift™ Instructions.