




Lock & unlock Switch Knob Helps to lock/release display out of the wall plate



Lateral shift

Allows screens to slide left/ right to simplify installation and also can be fixed to protect screens from potential collisions



Kickstand Design Provides 12° of tilt for easy cable management and maintenance



Optional Security

Anti-theft design for additional security (require for a padlock)