

Trust




MUTA | WIRELESS


SUITABLE FOR:
PC LAPTOP SWITCH™

www.trust.com/23579/faq


1.



2.



b




3.

c




HOME + B

d




4.

a




b



HOME + X

5.



6.

Controller key	Switch	PC XInput
Y	Y	X
B	B	A
A	A	B
X	X	Y
+	+	Start
-	-	Back
L-Stick	L-Stick	L-Stick
R-Stick	R-Stick	R-Stick
L	L	LB
R	R	RB
LZ	LZ	LT
RZ	RZ	RT
L3	L3	L3
R3	R3	R3
T	Turbo	Turbo
O	Screenshot	N/A
Up	Up	Up
Down	Down	Down
Left	Left	Left
Right	Right	Right
Home	Home	Guide