



Sheet Code: BP-IM-075\_REV3

Release Date: 22/06/2022

Copyright 2022 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.






In the Box



Fixings List



\* Due to the modular nature of our product range you may receive additional fixings in the fixings kit



**1** Complete the steps for your chosen Stand up until the point of attaching the Case. Then turn to this Manual.


**2** Remove the backing from the Spacer. Align with the screw holes on the Case and firmly stick down.

**3** Route the Payment Device Charger Cable through the Self-Service Mount.




**4** Remove the backing from Adhesive Strips. With the cable resting in the bend, centre your Payment Device and firmly press down. Plug in the USB cable


**5** Depending on the size of your tablet/case, note the mounting location.



**6** Feed your charge cables through the Mounting Arm.



**7** Attach the Case and Self-Service Mount to the Mounting arm with the 20mm M4 Machine Screws (supplied with Self Service Mount).



**8** Return to the Main Product Manual to complete the assembly.