Acer LCD Monitor Quick Start Guide (QSG)

Important safety instructions

Please read the following instructions carefully.

- . To clean the LCD monitor screen:
 - Turn off the LCD monitor and unplug the power cord.
 - · Spray a non-solvent cleaning solution onto a rag and clean the screen gently.
- 2. Do not place the LCD monitor near a window. Exposing the monitor to rain, moisture or sunlight can severely damage
- 3. Do not apply pressure to the LCD screen. Excessive pressure may cause permanent damage to the display.
- Do not remove the cover or attempt to service this unit yourself. An authorized technician should perform servicing of any nature.
- Store the LCD monitor in a room with a temperature of -20° to 60° C (-4° to140° F). Storing the LCD monitor outside this range may result in permanent damage.
- 6. Immediately unplug your monitor and call an authorized technician if any of the following circumstances occur:
 - Monitor-to-PC signal cable is frayed or damaged.
 - Liquid spills onto the LCD monitor or the monitor is exposed to rain.
 - The LCD monitor or case is damaged.

Attaching the monitor to the base

- 1. Remove the monitor from the packaging.
- 2. Attach the footstand to the base. (for selected models).
- 3. Turn clockwise to lock. Ensure that the base in locked onto the stand. (for selected models)
- 4. Secure the base to the stand by turning the screw using the intergrated tab or a suitable coin. (for selected models)

Connecting your monitor to a computer

- 1. Turn off your computer and unplug your computer's power cord.
- Connect the signal cable to the DP (optional) and/or HDMI (optional) input socket of the monitor, and the DP(optional) and/or HDMI (optional) output socket of the graphics card on the computer.
- USB Type C Cable (Optional, USB Type C input models only) Connect one end of the USB type C cable (optional) to your computer and connect the other end to your electric devices.
- Connect the USB Cable(Optional) Connect the USB cable to port for fast charge. Connect the USB cable to port.
- Insert the monitor power cable into the power port at the back of the monitor.
- Connect the power adapter and power cord to the monitor, then to a properly grounded AC outlet.

```
Set ------
```


Note: Audio output is only for audio output model. Please check user manual for more instruction.

Transmitting the 2K 300Hz signal via one HDMI 2.1/ DP 1.4 port requires DSC (Display Stream Compression) functionality.

AMD FreeSync Premium:

It can allow a AMD FreeSync Premium supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.

• — 1
 • — 2
 • — 3
 • — 4
 Ø — 5
External controls



1 Power button Turns the monitor on/off.Blue indicates power on. Amber indicates standby/ power saving modee/OSD locked.

2	Function key	a. b.	Press to view Main page. Press again to enter hotkey1 function. When the Function Menu is active, press this key to view the basic information for your monitor and current input or reset the custom color settings to the factory defaults.	
3	b. V		Press to view Main page.Press again to enter hotkey2 function. When the Function Menu is active, press this button to select select scenario mode or game mode.	
4	Function key	a. b.	Press to view Main page.Press again to enter Input select function. When the Function Menu is active, this button will quit the OSD.	
5	Function key	a. b.	Press to view Main page.Press again to enter next function in the Function Menu. The single toggle button on the backside of the Display bezel operates like a joystick. To move the cursor, simply toggle the button in four directions. Press the button to select desired option.	

Note: Acer monitor is purposed for video and visual display of information obtained from electronic devices.

Regulations and safety notices

FCC notices

This device has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- · Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/television technician for help.

CE declaration of conformity

Hereby, Acer Inc., declares that this LCD monitor is in compliance with the essential requirements and other relevant provisions of EMC Directive 2014/30/EU, Low Voltage Directive 2014/35/EU, and RoHS Directive 2011/65/EU and Directive 2009/125/EC with regard to establishing a framework for the setting of ecodesign requirements for energy-related product.

Notice: Shielded cables

All connections to other computing devices must be made using shielded cables to maintain compliance with EMC regulations.

Notice: Peripheral devices

Only peripherals (input/output devices, terminals, printers, etc.) certified to comply with the Class B limits may be attached to this equipment. Operation with non-certified peripherals is likely to result in interference to radio and TV reception.

Caution

Changes or modifications not expressly approved by the manufacturer could void the user authority, which is granted by the Federal Communications Commission, to operate this product.

In order to prevent damage to the monitor, do not lift the monitor by its base.

Operation conditions

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Notice: Canadian users

CAN ICES-003(B)/ NMB-003(B)

Disposal of waste equipment by user in private household in the European Union



This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

SPECIFICATION

	Driving system	Driving system TFT Color LCD				
	Size	27"W (69cm)	27"W (69cm)			
	Pixel pitch	0.233mm(H) x 0.233mm(V)				
	Brightness	Native: 350nits				
		HDR600 mode: Peak 600nits				
	Contrast	100,000,000:1Max. (ACM) 178° (H) 178° (V) (CR=10) (Typical)				
	Viewable angle					
LCD Panel	Response time	1ms (G to G) 0.5ms (G to G, Min.)				
	Panel Type	In-Plane Switching				
		HDMI (2.1):30-470KHz				
	H-Frequency	DP (1.4) :470-470KHz				
		Type-C :470-470KHz HDMI (2.1): 48-300Hz				
	V-Frequency	DP (1.4) : 48-300Hz				
		Type-C : 48-300Hz				
Display Colors		1.07B Colors	1.07B Colors			
Dot Clock		1250MHz	1250MHz			
Max. Resolution		2560x1440 @300Hz	2560x1440 @300Hz			
Plug & Play		VESA DDCCI/DDC2B				
	ON Mode	25W				
Power consumption	Standby mode		0.5W			
	Off Mode		0.3W			
		DP 1.4(Only DP Model)(Optio HDMI 2.1(Only HDMI Model)	DP 1.4(Only DP Model)(Optional)			
Input Connector			USB Type C (Only USB Type C model)			
		USB Hub / USB3.0 x 4 (Only	USB Hub / USB3.0 x 4 (Only USB Hub Model)			
			DP (Only DP Model)(Optional)			
Input Video Signal		HDMI signal (Only HDMI-Inpu	HDMI signal (Only HDMI-Input Model) USB Type C (Only USB Type C model)			
Speakers		2W x 2				
Audio			*			
		Horizontal:597mm	Audio-Output (Only Audio-Output Model)			
Maximum Screen Size		Vertical:336mm				
Power Source		100-240V~, 50/60Hz	100-240V~, 50/60Hz			
Environmental		Operating Temp: 0° to 40°C	Operating Temp: 0° to 40°C			
Considerations		Operating Humidity: 20% to 8	Storage Temp: -20° to 60°C			
Dimensions		614.1(W) x 400.2~520.2(H) x				
Weight (N. W.)		6.27kg Unit (net)				
roight (it. th.)		Tilt: -5° to 25°				
		Swivel: 360°	Swivel: 360°			
Mechanism spec			Height adjustment: 120mm			
		Detachable foot stand: Yes	Pivot:Yes Detachable foot stand: Yes			
		Brightness	VRB			
		Contrast	Aim Point			
		Black Boost Low Blue Light	Language OSD Timeout			
		ACM	Transparency			
		HDR LightSense	OSD Lock Input			
		Super Sharpness	Auto Source			
		Max Brightness	Wide Mode			
		Gamma Color Temp.	Hot Key Assignment DDC/CI			
External	Functions	Modes	ProxiSense			
Controls:		Color Space ColorSense	Rest Reminder HDMI Black Level			
		Grayscale Mode	Quick Start Mode			
		6-axis Hue 6-axis Saturate	USB Port Select USB 3.0			
		Volume	HDMI 2.1			
		Mute	Power-off USB Charge Save Setting to			
		Over Drive AMD FreeSync Premium	Information			
		Refresh Rate Num				
*Specifications may vary	depending on model, sku	and/or region.				

Find manuals and other documents for your Acer product on the official Acer support website.