


Jabra[®]
YOU'RE ON

JABRA SOLEMATE MINI



User Manual

jabra.com/solematemini

A BRAND BY

GN Netcom

© 2013 GN Netcom A/S. All rights reserved. Jabra® is a registered trademark of GN Netcom A/S. All other trademarks included herein are the property of their respective owners. The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by GN Netcom A/S is under license. (Design and specifications subject to change without notice).

MADE IN CHINA
MODEL: HFS210
FCC ID: BCE-HFS210A
IC: 2386C-HFS210A



Declaration of Conformity can be found on
www.jabra.com/CP/US/declarations-of-conformity

CONTENTS

1. WELCOME	4
2. SPEAKER OVERVIEW	5
2.1 POSITIONING THE SPEAKER	
2.2 TURNING ON THE SPEAKER	
3. HOW TO CHARGE THE BATTERY.....	7
3.1 BATTERY STATUS	
4. HOW TO CONNECT.....	9
4.1 CONNECT USING BLUETOOTH	
4.2 CONNECT USING 3.5 MM JACK CONNECTOR	
4.3 CONNECT USING NFC	
5. PLAY MUSIC & CHAT	12
5.1 PLAY MUSIC	
5.2 CHAT USING MOBILE PHONE	
6. VOICE GUIDANCE	14
6.1 TURN VOICE GUIDANCE ON	
6.2 TURN VOICE GUIDANCE OFF	
6.3 LISTEN TO VOICE GUIDANCE	
7. UPDATE FIRMWARE	16
8. SUPPORT	17
8.1 FAQ	
8.2 HOW TO CARE FOR THE JABRA SOLEMATE MINI	
9. TECHNICAL SPECIFICATIONS	19


1. WELCOME

Thank you for using the Jabra Solemate Mini. We hope you will enjoy it!

JABRA SOLEMATE MINI FEATURES

- Built in rechargeable battery for on-the-go music
- Ultra portable design
- Dual speakers for powerful Sound
- Vibration dampening sole
- NFC for easy pairing

2. SPEAKER OVERVIEW




3.5 mm audio cable
(under the sole)



Micro-USB cable


2.1 POSITIONING THE SPEAKER

The Jabra Solemate Mini functions best when placed flat on any surface, and with the Jabra logo facing forward.




2.2 TURNING ON THE SPEAKER

Slide the **On/off** switch up to turn the Jabra Solemate Mini on.




3. HOW TO CHARGE THE BATTERY

Connect the Jabra Solemate Mini to any available USB slot on your PC using the USB cable to charge the Jabra Solemate Mini.







Alternatively, charge using your mobile device's micro-USB charger (phone charger dependent).



Note: A USB connection can only be used for charging, and not for playing music or call handling on the PC.

3.1 BATTERY STATUS

WHAT YOU SEE	WHAT IT MEANS
	The battery is full
	The battery is half full
	The battery is low
	The battery is critically low and requires immediate charging


The battery takes approx. 3 hours to fully charge. The Jabra Solemate Mini can be used during charging.

4. HOW TO CONNECT

The Jabra Solemate Mini can connect wirelessly to any Bluetooth device, or via 3.5 mm audio cable to any audio device, or via NFC to an NFC-enabled device.

4.1 CONNECT USING BLUETOOTH


1. Press and hold (4 secs) the **Answer/end** button until pairing mode is announced, and the Bluetooth light flashes. Release the button.
2. Follow the voice-guided pairing instructions.



Note: If connection is lost (e.g. out of range) tap the Answer/end button when the Jabra Solemate Mini is in range and powered on to reconnect.

4.2 CONNECT USING 3.5 MM JACK CONNECTOR


Connect the Jabra Solemate Mini to any audio device with a 3.5 mm Jack Connector, using the supplied audio cable. The microphone and speaker volume are disabled on the Jabra Solemate Mini when connected via the 3.5 mm Jack Connector (the volume can still be adjusted using the connected device).



NOTE: When a device is connected to the 3.5 mm Jack Connector, Bluetooth is disabled and wireless devices will not be able to play music.

4.3 CONNECT USING NFC

1. Ensure that the Jabra Solemate Mini is turned on, and NFC is enabled on your mobile device.
2. Locate and gently tap the **NFC zone** on the mobile device against the **NFC zone** on the Jabra Solemate Mini.



5. PLAY MUSIC & CHAT

5.1 PLAY MUSIC


Music played on your connected device will automatically transfer to the Jabra Solemate Mini. If you cannot hear audio, ensure the device is connected to the Jabra Solemate Mini via 3.5 mm Jack Connector or Bluetooth, or turn up the speaker volume. The volume can be adjusted on the speaker, or on the connected device.



To control the music (skip tracks, pause music etc) use the connected device.

5.2 CHAT USING MOBILE PHONE

When the Jabra Solemate Mini is Bluetooth connected to your mobile device, calls will automatically transfer to the Jabra Solemate, which will function as a speakerphone.

Note: Music will automatically pause during a call, and will resume when the call is ended.



	FUNCTION	ACTION
+/-	Adjust speaker volume	Tap the Volume up or Volume down button
	Answer/end call	Tap the Answer/end button
	Reject call	Double-tap the Answer/end button
	Redial last number	Double-tap the Answer/end button when not on a call
	Battery status	Tap the Answer/end button when not on a call
	Mute/un-mute microphone	Tap both Volume up and Volume down buttons at the same time

6. VOICE GUIDANCE

6.1 TURN VOICE GUIDANCE ON

1. Turn off the Jabra Solemate Mini.
2. Press and hold the **Volume up** button while turning on the Jabra Solemate Mini. Release the **Volume up** button when you hear 'Sound prompts on'.

6.2 TURN VOICE GUIDANCE OFF

1. Turn off the Jabra Solemate Mini.
2. Press and hold the **Volume down** button while turning on the Jabra Solemate Mini. Release the **Volume down** button when you hear 'Sound prompts off'.

6.3 LISTEN TO VOICE GUIDANCE

CLICK TO LISTEN	WHAT YOU HEAR
	Go ahead and connect me. Use the Bluetooth setting on your phone
	Connected
	Bluetooth off
	Battery full
	Battery medium
	Battery low
	Recharge battery
	Muted
	un-muted
	Redialing
	Sound prompts off
	Sound prompts on
	Connection cancelled

7. UPDATE FIRMWARE

To update the Jabra Solemate Mini firmware visit jabra.com/solematemini and download the latest firmware in the support section. Follow the on-screen instructions.

8. SUPPORT

8.1 FAQ

View the full FAQ on Jabra.com/solematemini.

Q Why do I hear crackling noises?

A Bluetooth is a radio technology that is sensitive to objects between the speaker and the connected device. Ensure the speaker and the connected device are within range (up to 10 meters or 33 feet).

Q What is the range of the speaker?

A The Jabra Solemate Mini supports the following maximum ranges: 10m/33ft.

Q I am having Bluetooth connecting problems

A You may have deleted your Jabra Solemate pairing connection in Bluetooth device. Reconnect by holding the Answer/end button for 4 seconds to put the Jabra Solemate into pairing mode, and then connect to your Bluetooth device.

Q Why can I not use Reject call or redial?

A These features are dependent on the ability of your phone to support a hands-free profile. Even if the hands-free profile is implemented, reject call and redialing are optional features that are not supported by all devices. Please consult your device manual for details.

8.2 HOW TO CARE FOR THE JABRA SOLEMATE MINI

- Always store the speaker with the power off.
- Avoid storage at extreme temperatures (above -20°C/-68°F or below 65°C/149°F). This can shorten battery life and may affect speaker operation.
- Do not expose the speaker to rain or other liquids.

9. TECHNICAL SPECIFICATIONS

JABRA SOLEMATE MINI	SPECIFICATION
Weight:	330g
Dimensions:	H 60.5mm x W 53mm x D 126mm
Microphones:	Omni directional microphone
Speaker:	40mm x 25mm 4 Ohm 3W Nd-Fe-B Type Round
Operating range:	10m/33ft (phone dependent)
Bluetooth version:	3.0
Paired devices:	Up to 8 paired devices, One active device connected at a time
Supported Bluetooth profiles:	A2DP(v1.2), Hands Free Profile (v1.6), Headset profile(v1.2)
Talk time:	Up to 8 hours
Standby time:	Up to 90 days
Operating temperature:	-10°C to 55°C (-50°F to 131°F)
Storage temperature:	-20°C to 65°C (-68°F to 149°F)
Pairing passkey or PIN:	0000

