



www.bestwaycorp.com

©2023 Bestway Inflatables & Material Corp.

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten/Tutti i diritti riservati

Trademarks used in some countries under license from/

Marques utilisées dans certains pays sous la licence de/

Marcas comerciales utilizadas en algunos países bajo la licencia de/

Die Warenzeichen werden in einigen Ländern verwendet unter Lizenz der/

Marchi utilizzati in alcuni paesi concessi in licenza a

Bestway Inflatables & Material Corp., Shanghai, China

Manufactured, distributed and represented in the European Union by/

Fabriqués, distribués et représentés dans l'Union Européenne par/Fabricado, distribuido y representado en la Unión Europea por/

Hergestellt, vertrieben und in der Europäischen Union vertreten von/Prodotto, distribuito e rappresentato nell'Unione Europea da

Bestway Europe S.p.a., Via Resistenza, 5, 20098 San Giuliano Milanese (Milano), Italy

Distributed in Latin America by/Distribué en Amérique latine par/Distribuido en Latinoamérica por/Distribuido na América Latina por

Bestway Central & South America Ltda, Salar Ascotan 1282, Parque Enea, Pudahuel, Santiago, Chile

Distributed in Australia & New Zealand by **Bestway Australia Pty Ltd, Unit 2/98-104 Carnarvon St Silverwater, NSW 2128, Australia**

Tel: Australia: +61 2 9037 1388; New Zealand: 0800 142 101

Distributed in United Kingdom by **Bestway Corp UK Ltd, 8 Wentworth Road, Heathfield Industrial Estate, Newton Abbot, Devon, TQ12 6TL**

Exported by/Exporté par/Exportado por/Exportiert von/Esportato da

Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

www.bestwaycorp.com

OWNER'S MANUAL

WARNING

1. Batteries should not be exposed to excessive heat such as outdoor sun, fire or similar.
2. Dispose of the product before the battery runs out or is scrapped. Batteries contain hazardous substances and are to be disposed of properly. Do not dispose of batteries with general household waste.
3. Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
4. The electric toy is to be operated in water only when fully assembled.
5. This toy contains batteries that are non-replaceable.

Only to be used in water in which the child is within its depth and under adult supervision.
No protection against drowning.

Always seat in the boat when using it.

Be careful when landing or dragging on the shore. Sharp and rough objects such as rocks, cement, shells, glass, etc. may puncture the product.

Do not use your boat if you suspect a puncture or leak.

Proper inflation and use are critical to insure safety. Pay attention to ensure safety valve is tightly closed each time in use. Check seams regularly for tears.



Keep the batteries away from children.

The battery can cause serious injuries if it is swallowed or placed inside any part of the body.

Medical attention should be sought immediately if it is suspected the battery has been swallowed or placed inside any part of the body.

INFLATION

Open the safety valve and inflate the boat. Fill the chamber until it is firm to the touch but not hard.

Insert the stopper into the valve and press down firmly on it.

Never over-inflate or use high pressure air to inflate.

DEFLATION

Pull stopper out and squeeze the valve at its base until deflated.

CLEAN AND STORAGE

After deflation, use a damp cloth to clean. Store in a cool, dry place and out of children's reach.

Check the product for damage at the beginning of each season and at regular interval when in use.



DISPOSAL

Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.