



58770

©2023 Bestway Inflatables & Material Corp.

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten/Tutti i diritti riservati

Trademarks used in some countries under license from/

Marques utilisées dans certains pays sous la licence de/

Marcas comerciales utilizadas en algunos países bajo la licencia de/

Die Warenzeichen werden in einigen Ländern verwendet unter Lizenz der/

Marchi utilizzati in alcuni paesi concessi in licenza a

Bestway Inflatables & Material Corp., Shanghai, China

Manufactured, distributed and represented in the European Union by/

Fabriqués, distribués et représentés dans l'Union Européenne par/Fabricado, distribuido y representado en la Unión Europea por/

Hergestellt, vertrieben und in der Europäischen Union vertreten von/Prodotto, distribuito e rappresentato nell'Unione Europea da

Bestway Europe S.p.a., Via Resistenza, 5, 20098 San Giuliano Milanese (Milano), Italy

Distributed in Latin America by/Distribué en Amérique latine par/Distribuido en Latinoamérica por/Distribuido na América Latina por

Bestway Central & South America Ltda, Salar Ascotan 1282, Parque Enea, Pudahuel, Santiago, Chile

Distributed in Australia & New Zealand by **Bestway Australia Pty Ltd, Unit 2/98-104 Camarvon St Silverwater, NSW 2128, Australia**

Tel: Australia: (+61) 2 9037 1388; New Zealand: 0800 142 101

Distributed in United Kingdom by **Bestway Corp UK Ltd, 8 Wentworth Road, Heathfield Industrial Estate, Newton Abbot, Devon, TQ12 6TL**

Exported by/Exporté par/Exportado por/Exportiert von/Esportato da

Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

www.bestwaycorp.com

OWNER'S MANUAL

Model No.58770

WARNING

- Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.
- Pumps without indication that they are protected against the effect of freezing shall not be left outside during freezing weather conditions.
- Children shall not play with the appliance.
- This appliance shall not be used by children.
- Cleaning and User maintenance shall not be carried out by children.

BATTERY PRECAUTION

- Do not mix old and new batteries.
- Do not mix the different types of batteries. Do not mix alkaline, standard (Carbon - Zinc), or rechargeable (Nickel - Cadmium) batteries.
- Ensure batteries are installed correctly with regard to polarity (+ and -).
- Do not short-circuit the battery.
- Never attempt to recharge primary batteries as this may cause leakage, fire, or explosion.
- Rechargeable batteries are to be removed from this product before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Never attempt to disassemble or open batteries as this can lead to electrolyte burns.
- Remove batteries from equipment which is not to be used for an extended period of time.
- Exhausted batteries are to be removed from this product.
- Do not burn the product or batteries. Check your local regulations for proper disposal instructions.
- Batteries shall not be exposed to excessive heat such as sunshine, fire or the similar.
- Only use AA batteries (not included).

DISPOSAL



Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

TECHNICAL SAFETY INSTRUCTIONS

- The vacuum is designed to clean pools and spas.
- Make sure the battery cap is tightly closed before turning it on to avoid water leaking inside and damaging the product.
- Don't use sharp objects on the filter bag to avoid damage.
- To avoid damaging the motor, do not switch it on when out of water.
- Do not close to the vacuum head when it is on to avoid overheating the motor and to extend the life of the product.
- Do not disassemble the motor without authorization from the manufacturer.
- Working conditions:
 - Water Depth: 35 cm to 120 cm
 - Water Temperature: 4°C (39.2°F) to 35°C (95°F)
- The warnings are not intended to incorporate all possible instances for risks and/or severe injury. Pool/ spa owners should always exercise intensive caution and common sense when operating the cleaner. Batteryoperated appliances shall also be marked with the 8 PCS AA Battery.
- The instructions for battery-operated appliances shall contain the substance of the following, as applicable:
 - 8 PCS AA Battery;
 - Remove and insert the batteries - refer to the manual;
 - Non-rechargeable batteries are not to be recharged;
 - Different types of batteries or new and used batteries are not to be mixed;
 - Batteries are to be inserted with the correct polarity;
 - Exhausted batteries are to be removed from the appliance and safely disposed of;
 - If the appliance is to be stored unused for a long period, the batteries should be removed;
 - The supply terminals are not to be short-circuited.

TROUBLESHOOTING

Problems	Probable Causes	Solutions
Machine does not work	Battery level is too low	Replace the batteries
	Batteries are installed incorrectly	Insert the batteries correctly
Too little suction	Battery level is too low	Replace the batteries
	Debris bag is full	Remove and empty the debris bag
Abnormal noise	Debris in the motor impeller	Unscrew the suction head to clean the debris out of the impeller
	Motor impeller is broken	Return to the shop to get assistance



