

Philips Air Steam Cooker
Series 7000
Bottom Tray



CP1832/01

To replace your current Bottom Tray

This is a replacement part for your Air Steam Cooker

Ease of using Philips spare parts

- Easily renew your product with original Philips parts

PHILIPS

Specifications

replaceable part

- fits to product type: NX0960

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.



Issue date 2023-12-10

Version: 5.5.1

© 2023 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com