




ThinkPad E14 Gen 6 / ThinkPad E16 Gen 2




Get started




* For selected models

Overview

ThinkPad E14 Gen 6




* Press to log in to the computer*

 Navigate as a traditional mouse

Overview

ThinkPad E16 Gen 2




Press to log in to the computer*



Navigate as a traditional mouse


Overview











Read the statement on USB transfer rate in the *User Guide*. To access the *User Guide*, refer to methods mentioned on the back cover.

Lenovo Vantage

Access Lenovo Vantage to adjust device settings, check for system updates, and have your device warranty status.



Lenovo Smart Meeting



¹ The initial version doesn't have these functions. Functions will be available by software update soon.

[English]

Specific absorption rate (SAR)

YOUR DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES.

Refer to the following for 10g SAR limit and maximum reported SAR values:

10g SAR limit: 2 W/kg (body-worn SAR); 4 W/kg (limb SAR)

Maximum SAR with 0 mm separation distance:

| Product name | Body-worn SAR value | Limb SAR value |
|--------------------|---------------------|----------------|
| ThinkPad E14 Gen 6 | 0.308 W/kg | 0.308 W/kg |
| ThinkPad E16 Gen 2 | 0.441 W/kg | 0.441 W/kg |

For more information about SAR, refer to the *Safety and Warranty Guide* that came with your device.


European Union (EU) / United Kingdom (UK) — radio frequency and power

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

| Technology | Frequency [MHz] | Maximum transmit power |
|--|--------------------------|------------------------|
| WLAN 802.11b/g/n/ax Bluetooth BR/EDR/LE | 2400 - 2483.5 | < 20 dBm |
| WLAN 802.11a/n/ac/ax | 5150 - 5350; 5470 - 5725 | < 23 dBm |
| WLAN 802.11a/n/ac/ax | 5725 - 5875 | < 13.98 dBm |
| WLAN 802.11ax | 5945 - 6425 | < 23 dBm |

Note: Not all wireless bands may be enabled depending on your product configuration. Usage of this device is limited to indoor locations in the bands 5150 - 5350 MHz and 5945 - 6425 MHz.

Access User Guide



First Edition (April 2024)

© Copyright Lenovo 2024.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Lenovo, Lenovo logo, ThinkPad, and ThinkPad logo are trademarks of Lenovo. Intel and Thunderbolt are trademarks of Intel Corporation or its subsidiaries in the U.S. and/or other countries. The terms HDMI and HDMI High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries. USB-C is a registered trademark of USB Implementers Forum. All other trademarks are the property of their respective owners.



Reduce
Reuse
Recycle