
ThinkPad T14 Gen 5 / ThinkPad P14s Gen 5 AMD




Get started



^{*} For selected models I For selected models I For selected models I For selected models


Overview



ტ் ு Press to log in to the computer*

Navigate as a traditional mouse


Overview



Read the statement on USB transfer rate in the User Guide. To access the User Guide, refer to methods mentioned on the back cover.


TrackPoint Quick Menu

Launch TrackPoint Quick Menu by double tapping¹ for quick configuration of some device settings.




Lenovo Commercial Vantage*

Access Commercial Vantage to adjust device settings and check for system updates.



Lock on leave²



Protect your privacy and improve battery life.


Note: The initial BIOS disabled this function. It will be enabled by software update soon. Refer to README file for BIOS on system support site.

² For infrared camera models only I Fo

Lenovo View*




Video Enhancer






Background Removal*






Privacy Guard





) Posture Warning



[English]

Specific absorption rate (SAR)

YOUR DEVICE MEETS INTERNATIONAL GUIDELINES FOR EXPOSURE TO RADIO WAVES.

Refer to the following for 10g SAR limit and maximum reported SAR values: 10g SAR limit: 2 W/kg (body-worn SAR); 4 W/kg (limb SAR)

Maximum SAR with 0 mm separation distance:

Product name	Body-worn SAR value	Limb SAR value
ThinkPad T14 Gen 5	1.600 W/kg	1.929 W/kg
ThinkPad P14s Gen 5 AMD	1.600 W/kg	1.929 W/kg

For more information about SAR, refer to the Safety and Warranty Guide that came with your device.

European Union (EU) / United Kingdom (UK) — radio frequency and power

This radio equipment operates with the following frequency bands and maximum radio-frequency power:


Technology	Frequency [MHz] / band	Maximum transmit power
WLAN 802.11b/g/n/ax/be Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac/ax/be	5150 - 5350; 5470 - 5725	< 23 dBm
WLAN 802.11a/n/ac/ax/be	5725 - 5875	< 13.98 dBm
WLAN 802.11ax/be	5945 - 6425	< 23 dBm
WWAN UMTS	1/3/8	< 25.2 dBm
WWAN LTE	1/3/7/8/20/28/34/38/40/41/42/43	< 25 dBm
WWAN LTE HPUE	41	< 27 dBm
WWAN 5G NR	1/3/7/8/20/28/38/40/41/77/78	< 25 dBm
WWAN 5G NR HPUE	41/77/78	< 27.5 dBm
NFC	13.56	< -5.31 dBµA/m@10m

Note: Not all wireless bands may be enabled depending on your product configuration. Usage of this device is limited to indoor locations in the bands 5150 - 5350 MHz and 5945 - 6425 MHz.

Access User Guide

Access User Guide | Access









First Edition (May 2024)

© Copyright Lenovo 2024.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Lenovo, Lenovo logo, ThinkPad, and ThinkPad logo are trademarks of Lenovo. The terms HDMI and HDMI High-Definition Multimedia Interface are trademarks or recipistered trademarks or HDMI Liconsing LLC in the United States and other countries. USB-C[®] is a registered trademark of USB Implementers Forum. All other trademarks are the property of their respective owners.

