






Monitor Portatile Dell Pro 14 Plus
P1425







USB-C


USB-C



























Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P1425