








Monitor przenośny Dell Pro 14 Plus
P1425






























Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P1425