








צג נייד של Dell Pro 14 Plus
P1425





























Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P1425