


Lenovo IdeaPad L340 Series SETUP GUIDE

Initial Setup





Overview



- 1. Camera
- 2. Shutter
 - 3. Camera indicator
- 4. Wireless LAN/Bluetooth antennas
- 5. Microphones
- 6. Mini security-lock slot
- 7. CD/DVD drive
- 8. Screen
- 9. Ventilation slots
- 10. Touchpad

- 11. Speakers
- 12. Power LED
- 13. Novo button
- 14. USB-C™ connector
- 15. Audio connector
- 16. USB 3.0 connector
- 17. HDMI™ connector
- 18. Ethernet connector
- 19. Battery/Charging status indicator
- 20.ac power connector

Note:

Read the statement on USB transfer rate in the User Guide. Refer to the Safety and Warranty Guide for accessing the User Guide.

Additional information

European Union — compliance with the Radio Equipment Directive

Hereby, Lenovo (Singapore) Pte. Ltd., declares that the radio equipment type(s) IdeaPad L340-15IWL, IdeaPad L340-15IWLTouch, and IdeaPad L340-17IWL are in compliance with Directive 2014/53/EU.

The full text of the system EU declaration of conformity and the EU wireless module declarations are available at the following Internet addresses:

- For notebook computers:
- https://www.lenovo.com/eu-doc-notebooks
- For tablets:

https://www.lenovo.com/eu-doc-tablets

This radio equipment operates with the following frequency bands and maximum radio-frequency power:

· · · · · · ·		
Technology	Frequency band [MHz]	Maximum transmit power
WLAN 802.11b/g/n	2400 - 2483.5	< 20 dBm
WLAN 802.11a/n/ac	5150 - 5725	< 23 dBm
WLAN 802.11a/n/ac	5725 - 5875	< 13.98 dBm
Bluetooth BR/EDR/LE	2400 - 2483.5	< 20 dBm

First Edition (February 2019) © Copyright Lenovo 2019.

LIMITED AND RESTRICTED RIGHTS NOTICE: If data or software is delivered pursuant to a General Services Administration "GSA" contract, use, reproduction, or disclosure is subject to restrictions set forth in Contract No. GS-35F-05925.

Reduce I Reuse I Recycle

