










Dell Pro 24 Plus QHD USB-C-hubb bildskärm
P2425DE








2




3





4


1



















1



150 mm



2




21°




3






Dell Display and Peripheral Manager
Dell.com/support/ddpm



Daisy Chain



Dell.com/support/P2425DE