












Dell Pro 27 Plus QHD-skärm
P2725D








* Endast för utvalda länder























1







2




3







Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/P2725D