














Dell Pro 32 Plus QHD USB-C
P3225DE מוניטור































1




2




3






Dell Display and Peripheral Manager
Dell.com/support/ddpm



שרשור



Dell.com/support/P3225DE