RM-SW-T11

VENDORSonicwall

SUPPORTED MODELS

TZ270

TZ270W

TZ370

TZ370W

TZ470

TZ470W

COLOR

BLACK

DIMENSIONS

HxWxD)

44 x 483 x 217 mm 1.73 x 19.00 x 8.54 inch





MOUNTING INSTRUCTIONS

- 1. Place your appliance on the rack.
- 2. Secure your appliance with one screws from the side.
- 3. Place your power supply on the rack and secure it with two zip ties.
- 4. Plug in the power supply.
- 5. Tie down the excess length of the power cable to the rack with a zip tie.
- 6. Connect the appliance to the couplers using the supplied cables.

Optional

- 7. Connect a fiber cable and lead the cable through the opening in the front of the rack.
- 8. To connect antenna cables at the front, remove the pre-cut sections using a screwdriver and hammer. (Antenna cables not included.)

Please ensure proper ventilation according to the network appliance manufacturer's guidelines.

PACKAGE CONTENTS

- 1 Rackmount
- 1 Screw
- 3 Zip ties
- 2 Velcro
- 9 Cat 6 cables

Appliance not included.



QUESTIONS

