












Moniteur Dell 27 Plus 4K
S2725QS










1








2















1










1





2




3





Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/S2725QS

