

PHILIPS



Refurbished Wet or
Dry electric shaver

Shaver series 3000

5D Pivot and Flex Heads

PowerCut Blades

Travel pouch

Charging stand



S3333/54R1

Clean shave, more comfort

Philips Shaver Series 3000 gives you a convenient and comfortable shave. Its 5D Pivot and Flex heads, PowerCut blade system and wet-or-dry function provide a clean and comfortable result.

Easy to use

- 60 minutes of cordless shaving from a 1 hour charge
- One-touch open for easy cleaning
- Keep your charge in check
- Anti-slip handle for a secure shave
- Charging stand keeps the shaver stored, charged and ready
- Convenient storage at home or on the go

A comfortable shave

- Choose a convenient dry or refreshing wet shave
- Follows the contours of your face for a comfortable shave
- Glides over skin for a comfortable, even shave
- Glides over your skin for a smooth and even finish

Get the most out of your shaver

- A 5 minute power boost for short-notice shaving

Eco-friendly choice


Shaver series 3000

Refurbished Wet or Dry electric shaver

S3333/54R1

Highlights

Use less. Re-use more.



At Philips, we renew products returned by our customers to give them a second life. With our refurbished products we always strive for the highest quality, and we can offer you a more sustainable alternative while saving you money. Your refurbished shaver comes with a 2-year warranty and full customer support.

5D Pivot and Flex Heads



The Philips Shaver 3000 features a 5-directional pivot that meets every angle and curve of your face and neck. This beard shaver cuts each hair right above skin level to give you a smooth and even finish.

PowerCut Blades



The Philips shaver glides over your skin for a clean and comfortable finish. Its 27 PowerCut blades cut each hair right above skin level, giving you a smooth and even shave, every time.

Shave wet or dry



A wet and dry shaver that adapts to your preferences. Choose a convenient dry shave or pair with your favourite foam or gel for a refreshing wet shave.

60 minutes of cordless shaving



A shaver for use at home or on the go. Get 60 minutes of shaving time from a 1 hour charge or plug it in for instant and continuous power.

One-touch open



Clean your electric shaver with the touch of a button. Simply flip open the shaver head and rinse with water.

3 level battery indicator



See how much power your shaver has left. The 3-level battery indicator shows when the battery is full, running low or if it's charging.

5 minute quick charge




In a hurry? Just plug in your shaver for 5 minutes and get enough power for 1 full shave.

27 self-sharpening blades



The 27 self-sharpening blades on this electric shaver have been precision-engineered for a consistently clean shave.

Pop-up trimmer



Refine and define your moustache and sideburns with the pop-up trimmer—and complete your look with ease.

Shaver series 3000

Refurbished Wet or Dry electric shaver

S3333/54R1

Highlights

Rubber grip



Ergonomically designed for precision and ease, the handle on this wet and dry electric shaver provides extra grip in the shower or at the sink.

Travel pouch



The convenient travel pouch provides safe and compact storage at home or on the go.

Charging stand



Keep the shaver stored, charged and ready to go with the included charging stand.

Shaver series 3000

Refurbished Wet or Dry electric shaver

S3333/54R1

Specifications

Accessories

Stand: Charging stand

Maintenance: Protective cap

Pouch: Travel pouch

Power

Charging: 1 hour full charge

Battery type: Lithium-ion

Run time: 60 minutes

Automatic voltage: 100-240 V

Design

Handle: Ergonomic grip and handling, Non-slip rubber handle

Colour: Noir Gold

Service

Replacement head: Replace every 2 yrs with SH30

2 year warranty

Shaving Performance

Shaving system: PowerCut blade system

Contour following: 5D Pivot and Flex Heads

Ease of use

Cleaning: One-touch open, Fully washable

Display: 3 level battery indicator

Wet & Dry: Shave wet or dry

Operation: Unplug before use, Cordless use only

