bouncepad®

Original Elevate


Assembly Instructions

Tools Required:

- Socket Driver
- 10mm Spanner *or adjustable spanne

Sheet Code: BP-IM-111_REV0
Release Date: 10/02/2025

Copyright 2025 SpotSpot Ltd. (T/A
Bouncepad) all rights reserved.
Confidential, no part of this publication
may be reproduced or transmitted in any
form without the written permission of the
copyright holder.













Fixings List


* Due to the modular nature of our product range
you may receive additional fixings in the fixings kit












Orientate, locate & secure the Elevate Pole to the Base as shown. Ensure that all fixings are installed correctly.

2 Loosen & remove the Clamp.

Peel the Protective Stickers off the Elevate Pole.


Attach the Cover as Shown.



Reattach the Clamp without tightening.

6


5




Locate & secure the Case onto the Elevate Pole as shown. Tighten by hand.





7 Unlock & remove the Faceplate from the Bouncepad Case.




Feed the Power Cable through the Case, Elevate Pole & Height Limiter Cap.








Install the Tablet Setup 10 Kit. Each kit is specific per device & case.




Install the Tablet into the 11 Case & connect to Power Cable.




Locate & lock the 12 Faceplate to the Case.




Adjust the Elevate Pole to your 13 desired height & tighten the Clamp.



Connect the Power 14.1 Cable to its mains power source.






Approximate maximum Battery Pack dimensions: 91mm (length) x 56mm (width) x 25mm (Height).


14.2

If installing a Battery Pack,


connect the Power Cable & locate into the Base.



With the Cover on the 15 ground, locate & fit the Rubber Collar.



Use a Kensington® Microsaver product to tether to a secure object. (refer to your Kensington® instructions for full details)



Installation is now complete.

bouncepad


Branding Mount

Assembly Instructions

Follow these instructions for the successful assembly of your Branding board to your Floorstanding.


Sheet Code: BP-OR-IM-011_REV2
Release Date: 01/04/2019

Copyright 2016 Spotspot Ltd. (T/A Bouncepad) all rights reserved. Confidential, no part of this publication may be reproduced or transmitted in any form without the written permission of the copyright holder.




1 Tools required


ols required | **()** | Branding Mount - In the Box




A1 Follow 'A' steps if installing a Placard board



A2 Locate the top Bracket Mount & Mount Bolt to Floorstanding pole.




A3 Ensure that the Bracket Mount & Mount Bolt are positioned correctly as shown.




A4


Secure the Bracket Mount & Mount Bolt to the Floorstanding Pole with the supplied Nuts. Tighten evenly.




A5 Locate the Placard Board to the Bracket Mount. Secure with the supplied Plastic Screws & Nuts.




A6 Locate & secure the bottom Bracket
Mount & Mount Bolt. Tighten the nuts




A7 Secure the bottom section of the Placard Board with the Plastic Screws & Nuts. Installation now complete.




B1 Follow 'B' if installing a Front Board




B2 Locate the top Bracket Mount & Mount Bolt to the Floorstanding pole.




B3 Ensure the Bracket Mount & Mount Bolt are positioned correctly as shown.



B4
Secure the Bracket Mount & Mount Bolt to the Floorstanding Pole with the supplied Nuts. Tighten evenly.




B5 Locate the Front Board to the Bracket Mount. Secure with the supplied Plastic Screws & Nuts.



Locate & secure the bottom Bracket Mount & Mount Bolt. Tighten the nuts evenly.

B6



Secure the bottom section of the Front Board with the Plastic Screws & Nuts. Installation now complete.

B7