



52647

©2023 Bestway Inflatables & Material Corp.

All rights reserved/Tous droits réservés/Todos los derechos reservados/Alle Rechte vorbehalten/Tutti i diritti riservati

Trademarks used in some countries under license from/

Marques utilisées dans certains pays sous la licence de/

Marcas comerciales utilizadas en algunos países bajo la licencia de/

Die Warenzeichen werden in einigen Ländern verwendet unter Lizenz der/

Marchi utilizzati in alcuni paesi concessi in licenza a

Bestway Inflatables & Material Corp., Shanghai, China

Manufactured, distributed and represented in the European Union by/

Fabriqués, distribués et représentés dans l'Union Européenne par/Fabricado, distribuido y representado en la Unión Europea por/

Hergestellt, vertrieben und in der Europäischen Union vertreten von/Prodotto, distribuito e rappresentato nell'Unione Europea da

Bestway Europe S.p.a., Via Resistenza, 5, 20098 San Giuliano Milanese (Milano), Italy

Distributed in Latin America by/Distribué en Amérique latine par/Distribuido en Latinoamérica por/Distribuido na América Latina por

Bestway Central & South America Ltda, Salar Ascotan 1282, Parque Enea, Pudahuel, Santiago, Chile

Distributed in Australia & New Zealand by **Bestway Australia Pty Ltd, Unit 2/98-104 Carnarvon St Silverwater, NSW 2128, Australia**

Tel: Australia: +61 2 9037 1388; New Zealand: +0800 142 101

Distributed in United Kingdom by **Bestway Corp UK Ltd, 8 Wentworth Road, Heathfield Industrial Estate, Newton Abbot, Devon, TQ12 6TL**

Exported by/Exporté par/Exportado por/Exportiert von/Esportato da

Bestway (Hong Kong) International Ltd./Bestway Enterprise Company Limited

Suite 713, 7/Floor, East Wing, Tsim Sha Tsui Centre, 66 Mody Road, Kowloon, Hong Kong

www.bestwaycorp.com

OWNER'S MANUAL

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT.

WARNING

- Before using the product, carefully check if there are any leaks or broken parts.
- This toy is not safe in outdoors if the anchorage system is not used, it is recommended to use the anchorage system when the product used in outdoors. Always check all anchors before and during use.
- Avoid damaging the product by clearing your setup area of hard, sharp or dangerous objects.
- Do not use the product if it is leaking or damaged.
- Do not over-inflate.
- Do not use as a jumping device in water.
- Adult assembly required.
- Place the product on a level surface at least 2 m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires.
- The product shall not be installed over concrete, asphalt or any other hard surface.
- Recommend back towards the sun when playing.
- Only for domestic use. For outdoor or indoor use.
- Always keep the entrance free from obstruction.
- Keep assembly and installation instructions for further reference.
- Children should be supervised at all times.
- Children must remove helmets, loose clothing, scarves, headgear, shoes and glasses, as well as any sharp or hard objects from their pockets, as they may puncture the bounding surface.
- Do not allow users to climb or hang on containing walls.
- Do not allow users to do somersaults or rough play.
- Do not allow food, drink or gum inside unit.

PRODUCT DESCRIPTION

Item	For children aged	Number of users	Weight capacity
93542; 93553; 52647	3+	3	85 kg / 188 lbs
52345	3+	1	27 kg / 60 lbs

Refer to the item name or number stated on the packaging. Packaging must be read carefully and kept for future reference.

INFLATION AND ASSEMBLY

WARNING: Adult assembly required.

WARNING: Do not use the product during inflation and deflation.

1. Spread out the product.
2. Open the safety valves and inflate according to the following steps: first, the base of trampoline; second, other accessories (such as pillars, door or fences and so on) if equipped. Be sure to close the safety valves after inflation.
3. Tie the accessories with the provided ropes to the relevant grommets if necessary.
4. Place the product on level ground and firm grass or soil to allow proper use of stakes.
5. Stakes should be placed at an angle for better anchorage, should be driven under the ground to reduce tripping and tipping hazards.

NOTE: Please insert the stakes vertically into the ground.

6. Anchor points: 4.

DEFLATION

Open and pinch the bottom of the safety valves to deflate.

CLEANING AND STORAGE

1. After use, use a damp cloth to gently clean all surfaces.

NOTE: Never use solvents or other chemicals that may damage the product.

2. Store in a dry place, with a temperature higher than 15 °C/59 °F, out of reach of children.

