





SP325's button behavior on communication application

*Microsoft Teams work as intended with SP325's buttons, table below has behavior of speakerphone buttons in most of the popular communication software.

Button						
Function	Mute/ Unmute	Accept call	End call	Reject call	Volume up	Volume down
Communication application						
Microsoft Teams	OK	OK	OK	OK	OK	OK
Zoom	OK	OK	OK**	OK	OK	OK
Google Meet	OK	X	OK	X	OK	OK
Slack	OK*	X	X	X	OK	OK
Amazon Chime	OK*	X	X	X	OK	OK
Cisco Webex	OK*	X	X	X	OK	OK
Rainbow (Alcatel Lucent)	OK*	X	X	X	OK	OK
GoToMeeting	OK*	X	X	X	OK	OK
Cisco Jabber	OK*	X	X	X	OK	OK

NOTE: OK* indicates Mute/ Unmute button works as intended, but for these apps the status may not sync with the app interface.

NOTE: OK** indicates Answer/ End/ Reject Call button has 2 different states.

1. Reject call - Can be done via long press Answer/ End Call button for one second on speakerphone.
2. End an ongoing call - Can be done ONLY from Zoom app.