









Moniteur Dell 27 Plus QHD
S2725DSM

Guide de démarrage rapide















1






2





















1




2




3





Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/S2725DSM