











Dell 24/27 Plus-monitor  
S2425HSM/S2725HSM  
Snelstartgids






























1




2




3





Beeldscherm- en randapparatuurbeheer  
[Dell.com/support/ddpm](https://Dell.com/support/ddpm)



[Dell.com/support/S2425HSM](https://Dell.com/support/S2425HSM)  
[Dell.com/support/S2725HSM](https://Dell.com/support/S2725HSM)