











Dell 24/27 Plus Monitor
S2425HSM/S2725HSM
Schnellstartanleitung






























1




2




3





Display- und Peripheriegeräte-Manager
[Dell.com/support/ddpm](https://dell.com/support/ddpm)



[Dell.com/support/S2425HSM](https://dell.com/support/S2425HSM)
[Dell.com/support/S2725HSM](https://dell.com/support/S2725HSM)