











Dell 24/27 Plus-monitor
S2425HSM/S2725HSM
Snelstartgids






























1




2




3





Beeldscherm- en randapparatuurbeheer
Dell.com/support/ddpm



Dell.com/support/S2425HSM
Dell.com/support/S2725HSM