











Monitor Dell 24/27 Plus
S2425HSM/S2725HSM
Guía de inicio rápido






























1




2




3





Gestor de pantallas y periféricos de Dell
Dell.com/support/ddpm



Dell.com/support/S2425HSM
Dell.com/support/S2725HSM