









Monitor Dell 27 Plus QHD USB-C
S2725DC

Guía de inicio rápido















1





2


























Dell Display and Peripheral Manager
Dell.com/support/ddpm



Dell.com/support/S2725DC