

```
Philips
Remote control
```

CRP614

To operate your device from a distance

Check compatibility data

For fast and easy control of your device. Is your old remote control lost or broken? Order a new one here! Delivered without batteries.

Ease of using Philips spare parts

• Easily renew your product with original Philips parts



Specifications

Replaceable part

 Fits product types:: 14PT1345/58, 14PT2665/00, 14PT2665/01, 14PT2665/05, 14PT2665/58, 21PT1354/48, 21PT1354/58C, 21PT1654/48, 21PT1654/58C, 21PT1664/05S, 21PT1664/58, 21PT1664/58C, 21PT1664/58S, 21PT1865/58, 21PT2264/20, 21PT2664/20, 21PT2665/01, 21PT2665/58, 21PT2665/58C, 21PT2684/21, 21PT2684/48, 21PT4255/00, 21PT4425/58, 21PT4425/58C, 21PT4475/48, 21PT4475/58, 21PT4475/58C, 21PT5305/58, 21PT5505/58, 21PT5505/58S, 25PT4455/20, 25PT4475/48, 25PT5025/58, 25PT5105/58, 25PT5305/58, 28PT4404/58, 28PT4455/20, 28PT5025/58, 28PT5105/58, 29PT5305/58, 72TA5215/00

CRP614/01

Highlights

Easy replacement of product parts

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality.

