

RM-WG-T11

VENDOR
WATCHGUARD

SUPPORTED MODELS
T185

COLOR
WATCHGURAD RED

DIMENSIONS
(HxWxD)
44 x 483 x 217 mm
1.75 x 19.00 x 8.54 inch



Please ensure proper ventilation according to the network appliance manufacturer's guidelines.



**CONSIDER THE ENVIRONMENT,
RECYCLE WHERE APPLICABLE**

QUESTIONS

Email support@rackmount.it or contact your reseller.

RACKMOUNT+

Install Guide - 14-01-2025

RM-WG-T11

VENDOR
WATCHGUARD

SUPPORTED MODELS
T185

COLOR
WATCHGURAD RED

DIMENSIONS
(HxWxD)
44 x 483 x 217 mm
1.75 x 19.00 x 8.54 inch




Mounting instructions

1. Take one slider, extend it fully, then push the black lever either up or down to separate it into two parts. See picture 1.
2. Attach the part with the lever to the rackmount. Use bolts on the inside and nuts on the outside. The pre-drilled holes can only align in one orientation. See picture 2.
3. Attach the other part to one of the brackets using bolts on the inside and nuts on the outside. Align the slider on the side with the ear; this is the only way the mounting holes will align correctly. See picture 3.
4. Repeat steps 1 to 3 for the other slider.
5. Place the appliance on the rackmount and secure it with four bolts. This can be done with the appliance oriented front-to-front or front-to-back.
6. Slide the sliders back into each other.
7. Secure the rackmount to the brackets with the thumbscrews.
8. Mount the rackmount in the server cabinet


Please ensure proper ventilation according to the network appliance manufacturer's guidelines.



PICTURE 1: BLACK LEVER



PICTURE 2: SMALL SLIDER ORIENTATION



PICTURE 3: LARGE SLIDER ORIENTATION

PACKAGE CONTENTS

- 1 Rackmount
- 4 Bolts M3
- 2 Brackets
- 2 Sliders
- 12 Bolts M4
- 12 Nuts M4
- 2 Thumbscrews

Appliance not included.



**CONSIDER THE ENVIRONMENT,
RECYCLE WHERE APPLICABLE**

QUESTIONS

Email support@rackmount.it or contact your reseller.

RACKMOUNT.IT

Install Guide - 14-01-2025